

CHASSIS SECTION

This service manual has been prepared to provide SUBARU service personnel with the necessary information and data for the correct maintenance and repair of SUBARU vehicles.

This manual includes the procedures for maintenance, disassembling, reassembling, inspection and adjustment of components and diagnostics for guidance of experienced mechanics.

Please peruse and utilize this manual fully to ensure complete repair work for satisfying our customers by keeping their vehicle in optimum condition. When replacement of parts during repair work is needed, be sure to use SUBARU genuine parts.

All information, illustration and specifications contained in this manual are based on the latest product information available at the time of publication approval.

FRONT SUSPENSION**FS****REAR SUSPENSION****RS****WHEEL AND TIRE SYSTEM****WT****DIFFERENTIALS****DI****TRANSFER CASE****TC****DRIVE SHAFT SYSTEM****DS****ABS****ABS****ABS (DIAGNOSTICS)****ABS****BRAKE****BR****PARKING BRAKE****PB****POWER ASSISTED SYSTEM
(POWER STEERING)****PS**

DRIVE SHAFT SYSTEM

DS

	Page
1. General Description	2
2. Propeller Shaft	16
3. Front Axle	19
4. Rear Axle	24
5. Front Drive Shaft	32
6. Rear Drive Shaft.....	37
7. General Diagnostic Table.....	41

GENERAL DESCRIPTION


DRIVE SHAFT SYSTEM

1. General Description

A: SPECIFICATIONS

1. PROPELLER SHAFT

Propeller shaft type		DOJ type	UJ type
Front propeller shaft Joint-to-joint length: L_1 mm (in)	AT	—	584 (22.99)
	MT	638 (25.12)	643 (25.32)
Rear propeller shaft Joint-to-joint length: L_2 mm (in)		713 (28.07)	708 (27.87)
Outside diameter of tube: mm (in)	D_1	63.5 (2.500)	
	D_2	57.0 (2.244)	




DR0008

(A) UJ type (Non-turbo model)

(B) DOJ type (Turbo model)

2. FRONT DRIVE SHAFT ASSEMBLY

Type of drive shaft assembly	SHAFT	
	Shaft diameter	
EBJ87+SFJ82	Non-turbo	26 mm (1.02 in)
	Turbo	28 mm (1.10 in)



B4M2218E

(A) EBJ87+SFJ82


(B) Measuring point

GENERAL DESCRIPTION

DRIVE SHAFT SYSTEM

3. REAR DRIVE SHAFT ASSEMBLY

	Size	Model	No. of identification protrusion on shaft	L1 (mm)	ϕD (mm)
A	EBJ82/DOJ82 Sedan RH	Sedan Turbo	2 (Two)	363	24
B	EBJ82/DOJ82 Sedan LH		1 (One)	353	24
C	BJ79/DOJ79 Sedan R160RH	Sedan 2.0L NA MT	2 (Two)	368	23
D	BJ79/DOJ79 Sedan R160LH		1 (One)	358	23
E	BJ79/DOJ79 Sedan R152R/L	Sedan 1.6L, 2.0L NA AT	3 (Three)	363	23
F	BJ79/DOJ79 Wagon R152R/L	Wagon 1.6L, 2.0L NA AT	None	355	23
G	EBJ82/DOJ82 Wagon RH	Wagon Turbo	2 (Two)	353	24
H	EBJ82/DOJ82 Wagon LH		1 (One)	343	24
I	BJ79/DOJ79 Wagon R160RH	Wagon 2.0L NA MT	2 (Two)	358	23
J	BJ79/DOJ79 Wagon R160LH		1 (One)	348	23



DR0009

GENERAL DESCRIPTION

DRIVE SHAFT SYSTEM


- | | | |
|-----------------------------|------------------------------|-------------------------------|
| (A) EBJ82/DOJ82 Sedan RH | (E) BJ79/DOJ79 Sedan R152R/L | (I) BJ79/DOJ79 Wagon R160RH |
| (B) EBJ82/DOJ82 Sedan LH | (F) BJ79/DOJ79 Wagon R152R/L | (J) BJ79/DOJ79 Wagon R160LH |
| (C) BJ79/DOJ79 Sedan R160RH | (G) EBJ82/DOJ82 Wagon RH | (K) Identification protrusion |
| (D) BJ79/DOJ79 Sedan R160LH | (H) EBJ82/DOJ82 Wagon LH | |

GENERAL DESCRIPTION

DRIVE SHAFT SYSTEM

B: COMPONENT

1. PROPELLER SHAFT



DR0010


- | | |
|---------------------------------------|--------------------------------|
| (1) Propeller shaft (Turbo model) | (4) Rear differential (T-type) |
| (2) Propeller shaft (Non-Turbo model) | (5) Bush |
| (3) Rear differential (VA-type) | |

Tightening torque: N·m (kgf·m, ft·lb)

T1: 31 (3.2, 23.1)

T2: 52 (5.3, 38.3)

2. FRONT AXLE



B4M2213A

- | | | |
|------------------------|----------------------------|---------------------|
| (1) Baffle plate (SFJ) | (9) Boot (SFJ) | (17) Housing |
| (2) Spring pin ★ | (10) Boot (EBJ) | (18) Oil seal (OUT) |
| (3) Outer race (SFJ) | (11) EBJ ASSY | (19) Hub bolt ★ |
| (4) Snap ring | (12) Tone wheel (With ABS) | (20) Hub |
| (5) Trunnion | (13) Baffle plate | (21) Axle nut ★ |
| (6) Free ring | (14) Oil seal (IN) ★ | |
| (7) Circlip | (15) Snap ring | |
| (8) Boot band ★ | (16) Bearing ★ | |

Tightening torque: N·m (kgf·m, ft·lb)


T1: 186 (19, 137)

GENERAL DESCRIPTION

DRIVE SHAFT SYSTEM

3. REAR AXLE

• AWD Model



- | | |
|------------------------|--|
| (1) Circlip | (12) Non-Turbo: BJ ASSY
Turbo: EBJ ASSY |
| (2) Baffle plate (DOJ) | (13) Baffle plate (*) |
| (3) Outer race (DOJ) | (14) Oil seal (IN. No. 2) |
| (4) Snap ring | (15) Oil seal (IN. No. 3) |
| (5) Inner race | (16) Housing |
| (6) Ball | (17) Bearing |
| (7) Cage | (18) Snap ring |
| (8) Circlip | (19) Oil seal (OUT) |
| (9) Boot band | (20) Tone wheel (With ABS) |
| (10) Boot (DOJ) | (21) Hub bolt |
| (11) Boot (*) | |

- | |
|---------------|
| (22) Hub |
| (23) Axle nut |

Tightening torque: N·m (kgf·m, ft·lb)


T1: 13 (1.3, 9.4)

T2: 186 (19, 137)

* Non-Turbo model: BJ
Turbo model: EBJ

GENERAL DESCRIPTION

• FWD Model



- (1) Hub cap
- (2) O-ring
- (3) Axle nut
- (4) Washer
- (5) Hub unit
- (6) Hub bolt
- (7) Tone wheel (With ABS)
- (8) Spindle





Tightening torque: N·m (kgf·m, ft·lb)
T1: 6 (0.6, 4.4)
T2: 186 (19, 137)

C: CAUTION

- Wear working clothing, including a cap, protective goggles, and protective shoes during operation.
- Remove contamination including dirt and corrosion before removal, installation or disassembly.
- Keep the disassembled parts in order and protect them from dust or dirt.
- Before removal, installation or disassembly, be sure to clarify the failure. Avoid unnecessary removal, installation, disassembly, and replacement.
- Be careful not to burn your hands, because each part on the vehicle is hot after running.
- Use SUBARU genuine grease etc. or the equivalent. Do not mix grease etc. with that of another grade or from other manufacturers.
- Be sure to tighten fasteners including bolts and nuts to the specified torque.
- Place shop jacks or safety stands at the specified points.
- Apply grease onto sliding or revolution surfaces before installation.
- Before installing O-rings or snap rings, apply sufficient amount of grease to avoid damage and deformation.
- Before securing a part on a vice, place cushioning material such as wood blocks, aluminum plate, or shop cloth between the part and the vice.





D: PREPARATION TOOL

1. SPECIAL TOOLS

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: right;">B4M2386</p>	922431000	AXLE SHAFT INSTALLER	<ul style="list-style-type: none"> • Used for installing axle shaft into housing. • Used with ADAPTER (927390000).
 <p style="text-align: right;">B4N2387A</p>	925091000	BAND TIGHTENING TOOL	<ul style="list-style-type: none"> • Used for tightening boot band. (A) Jig for band (B) Ratchet wrench
 <p style="text-align: right;">B4M2388</p>	926470000	AXLE SHAFT PULLER	Used for removing axle shaft.
 <p style="text-align: right;">B4M2389</p>	927060000	HUB REMOVER	<ul style="list-style-type: none"> • Used for removing front hub. • Used with HUB STAND (927080000).





GENERAL DESCRIPTION

DRIVE SHAFT SYSTEM

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">H5M0981</p>	927420000	HUB REMOVER	<ul style="list-style-type: none"> • Used for removing rear hub. • Used with HUB STAND (927080000).
 <p style="text-align: center;">B4M2390</p>	927080000	HUB STAND	Used for disassembling and assembling hub bolt in hub.
 <p style="text-align: center;">B4M2391</p>	927100000	BEARING PULLER	<ul style="list-style-type: none"> • Used for disassembling and assembling front housing bearing. • Used with HOUSING STAND (927400000).
 <p style="text-align: center;">B4M2392</p>	927140000	AXLE SHAFT PULLER PLATE	Same as plate 2 included in AXLE SHAFT PULLER (926470000).





GENERAL DESCRIPTION

DRIVE SHAFT SYSTEM

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">B4M2393</p>	927390000	ADAPTER	Used as an adapter for AXLE SHAFT INSTALLER (922431000).
 <p style="text-align: center;">B4M2394</p>	927400000	HOUSING STAND	<ul style="list-style-type: none"> • Used for disassembling and assembling front housing bearing. • Used with BEARING PULLER (927100000).
 <p style="text-align: center;">B4M2395</p>	927410000	OIL SEAL INSTALLER	<ul style="list-style-type: none"> • Used for installing oil seal into front housing. • Used with HOUSING STAND (927400000).
 <p style="text-align: center;">H5M0982</p>	927430000	HOUSING STAND	<ul style="list-style-type: none"> • Used for disassembling and assembling rear housing bearing. • Used with BEARING PULLER (927440000).




GENERAL DESCRIPTION

DRIVE SHAFT SYSTEM

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">B4M2399</p>	927120000	HUB INSTALLER	Used for installing hub.
 <p style="text-align: center;">H5M0983</p>	927440000	BEARING REMOVER	<ul style="list-style-type: none"> • Used for disassembling and assembling rear housing bearing. • Used with HOUSING STAND (927430000).
 <p style="text-align: center;">H5M0984</p>	927460000	OIL SEAL INSTALLER	<ul style="list-style-type: none"> • Used for installing outer bearing and sub bearing into housing. • Used with HOUSING STAND (927430000).
 <p style="text-align: center;">B4M2400</p>	927450000	HUB INSTALLER	<ul style="list-style-type: none"> • Used for installing hub unit into hub ASSY. • Used with BEARING SPACER (28499AE000) and HUB STAND (927080000).

GENERAL DESCRIPTION

DRIVE SHAFT SYSTEM

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 B4M2401	28099PA090	OIL SEAL PROTECTOR	<ul style="list-style-type: none"> • Used for installing rear drive shaft into rear differential. • For protecting oil seal.
 B4M2402	28099PA100	DRIVE SHAFT REMOVER	Used for removing rear drive shaft from rear differential.
 B4M2403	28099AC000	BOOT BAND PLIERS	Used for tightening front BJ boot band.

2. GENERAL PURPOSE TOOLS

TOOL NAME	REMERKS
Puller	Used for removing ball joint from knuckle arm.
Dial gauge	Used for inspecting propeller shaft run-out.
Snap ring pliers	Used for installing and removing snap ring.

PROPELLER SHAFT


DRIVE SHAFT SYSTEM

2. Propeller Shaft


A: REMOVAL

NOTE:

- Before removing propeller shaft, wrap metal parts with a cloth or rubber material.
- In case of DOJ type, before removing propeller shaft, wrap metal parts (installed at the rubber boot of center DOJ) with a cloth or rubber material, as shown in the figure. Rubber boot may be damaged due to interference with adjacent metal parts while bending the DOJ during removal.




- 1) Disconnect ground terminal from battery.
- 2) Move select lever or gear shift lever to "N".
- 3) Release the parking brake.
- 4) Jack-up vehicle and support it with sturdy racks.
- 5) Remove center exhaust pipes.
- 6) Remove rear exhaust pipe and muffler.
- 7) Remove differential mount front cover.



- 8) Remove the four bolts which hold propeller shaft to rear differential.


NOTE:

- Put matching mark on affected parts before removal.
- Remove all but one bolt.



(A) Matching mark

- 9) Remove the two bolts which hold center bearing to vehicle body.




- 10) Remove propeller shaft from transmission.

CAUTION:

- not to damage oil seals and frictional surface of sleeve yoke.
- Cover the center exhaust pipe with a cloth to keep off any ATF or oil spilled from transmission when removing propeller shaft.

NOTE:


- Be sure to use an empty oil can to catch oil flowing out when removing propeller shaft.
- Be sure to plug the opening in transmission after removal of propeller shaft.



11) Install the extension cap to transmission.

NOTE:

If extension cap is not available, place vinyl bag over opening and fasten with string to prevent gear oil or ATF from leaking.




(A) Extension cap

B: INSTALLATION

1) Insert sleeve yoke into transmission and attach center bearing to body.

Tightening torque:


52 N·m (5.3 kgf·m, 38.3 ft·lb)



2) Align matching marks and connect flange yoke and rear differential.

Tightening torque:

31 N·m (3.2 kgf·m, 23.1 ft·lb)




(A) Matching mark

3) Install differential mount front cover.

Tightening torque:

88 N·m (9.0 kgf·m, 65 ft·lb)



4) Install center exhaust pipes.

5) Install rear exhaust pipe and muffler.

C: INSPECTION

NOTE:

Do not disassemble propeller shaft. Check the following and replace if necessary.


- 1) Tube surfaces for dents or cracks
 - 2) Splines for deformation or abnormal wear
 - 3) Joints for non-smooth operation or abnormal noise
 - 4) Center bearing for free play, noise or non-smooth operation
 - 5) Oil seals for abnormal wear or damage
 - 6) Center bearing for breakage
- Check the following points with propeller shaft installed in vehicle.

1. JOINTS AND CONNECTIONS

- 1) Remove center exhaust pipes.
- 2) Remove heat shield cover.
- 3) Check for any looseness of yoke flange connecting bolts and center bearing retaining bolts.

2. SPLINES AND BEARING LOCATIONS

- 1) Remove center exhaust pipes.
- 2) Remove rear exhaust pipe and muffler.
- 3) Remove heat shield cover.
- 4) Turn propeller shaft by hand to see if abnormal free play exists at splines. Also move yokes to see if abnormal free play exists at spiders and bearings.



PROPELLER SHAFT

DRIVE SHAFT SYSTEM

3. RUNOUT OF PROPELLER SHAFT


- 1) Remove center exhaust pipes.
- 2) Remove rear exhaust pipe and muffler.
- 3) Remove heat shield cover.
- 4) Turn rear wheels by hand to check for “runout” of propeller shaft.

NOTE:

Measure runout with a dial gauge at the center of front and rear propeller shaft tubes.

Runout:


Limit 0.6 mm (0.024 in)



- (A) Propeller shaft
- (B) Dial gauge

4. CENTER BEARING FREE PLAY


- 1) Remove front and center exhaust pipes.
- 2) Remove rear exhaust pipe and muffler.
- 3) Remove heat shield cover.
- 4) While holding propeller shaft near center bearing with your hand, move it up and down, and left and right to check for any abnormal bearing free play.



3. Front Axle

A: REMOVAL

- 1) Disconnect ground cable from battery.
- 2) Jack-up vehicle, support it with safety stands, and remove front wheels.
- 3) Unlock axle nut.




- 4) Remove axle nut using a socket wrench.

CAUTION:

Be sure to loose and retighten axle nut after removing wheel from vehicle. Failure to follow this rule may damage wheel bearings.

- 5) Remove stabilizer link.




- 6) Remove disc brake caliper from housing, and suspend it from strut using a wire.

- 7) Remove front drive shaft assembly from hub. If it is hard to remove, use STs.

- | | | |
|-----|-----------|-------------------------|
| ST1 | 926470000 | AXLE SHAFT PULLER |
| ST2 | 927140000 | AXLE SHAFT PULLER PLATE |


CAUTION:

- Be careful not to damage oil seal lip when removing front drive shaft.
- When replacing front drive shaft, also replace inner oil seal.




- 8) Remove disc rotor from hub.

If disc rotor seizes up within hub, drive disc rotor out by installing an 8-mm bolt in screw hole on the rotor.



- 9) Remove cotter pin and castle nut which secure tie-rod end to housing knuckle arm.




- (A) Cotter pin
- (B) Castle nut
- (C) Tie-rod


FRONT AXLE

DRIVE SHAFT SYSTEM


10) Using a puller, remove tie-rod ball joint from knuckle arm.




11) On ABS equipped models, remove ABS sensor assembly and harness in advance.



12) Remove transverse link ball joint from housing.



13) After scribing an alignment mark on camber adjusting bolt head, remove bolts which connect housing and strut, and disconnect housing from strut.



B: INSTALLATION

1) Install transverse link ball joint to housing.

Tightening torque:

49 N·m (5.0 kgf·m, 36 ft-lb)

2) While aligning alignment mark on camber adjusting bolt head, connect housing and strut.

CAUTION:

Use a new self-locking nut.

Tightening torque:

152 N·m (15.5 kgf·m, 112 ft-lb)

3) Install ABS sensor on housing (only vehicle equipped with ABS).

Tightening torque:

32 N·m (3.3 kgf·m, 23.9 ft-lb)

4) Install disc rotor on hub.

5) Install disc brake caliper on housing.

Tightening torque:

78 N·m (8 kgf·m, 57.9 ft-lb)


6) Install front drive shaft. <Ref. to DS-32, INSTALLATION, Front Drive Shaft.>

7) Connect stabilizer link.

8) Connect tie-rod end ball joint and knuckle arm with a castle nut, and insert cotter pin into tie-rod end.

Tightening torque:

27.0 N·m (2.75 kgf·m, 19.9 ft-lb)



(A) Cotter pin

(B) Castle nut

(C) Tie-rod

9) While depressing brake pedal, tighten axle nut and lock it securely.


Tightening torque:

186 N·m (19 kgf·m, 137 ft-lb)

CAUTION:

- Use a new axle nut.
- Always tighten axle nut before installing wheel on vehicle. If wheel is installed and comes in contact with ground when axle nut is loose, wheel bearings may be damaged.
- Be sure to tighten axle nut to specified torque. Do not overtighten it as this may damage wheel bearing.

10) After tightening axle nut, lock it securely.



11) Install wheel and tighten wheel nuts to specified torque.


Tightening torque:

88 N·m (9 kgf-m, 65 ft-lb)

C: DISASSEMBLY

- 1) Using ST1, support housing and hub securely.
- 2) Attach ST2 to housing and drive hub out.


ST1 927060000 HUB REMOVER
ST2 927080000 HUB STAND




If inner bearing race remains in the hub, remove it with a suitable tool (commercially available).

CAUTION:

- Be careful not to scratch polished area of hub.
- Be sure to install inner race on the side of outer race from which it was removed.



3) Remove disc cover from housing.



FRONT AXLE

DRIVE SHAFT SYSTEM

4) Using a standard screwdriver, remove outer and inner oil seals.


CAUTION:

Do not use old oil seals.

5) Using flat bladed screwdriver, remove snap ring.

CAUTION:

Be careful not to damage housing at removal.



6) Using ST1, support housing securely.


7) Using ST2, press inner race to drive out outer bearing.

ST1 927400000 HOUSING STAND

ST2 927100000 BEARING PULLER

CAUTION:

- Do not remove outer race unless it is faulty.
- Discard outer race after removal.
- Do not replace inner or outer race separately; always replace as a unit.




8) Using ST and a hydraulic press, drive hub bolts out.

ST 927080000 HUB STAND

CAUTION:


Be careful not to hammer hub bolts. This may deform hub.



D: ASSEMBLY

1) Attach hub to ST securely.

ST 927080000 HUB STAND



2) Using a hydraulic press, press new hub bolts into place.

CAUTION:

Be sure to press hub bolts until their seating surfaces contact the hub.

NOTE:

Use 12 mm (0.47 in) dia. holes in HUB STAND to prevent bolts from tilting.

3) Clean dust or foreign particles from inside the housing.

4) Using ST1 and ST2, press a new bearing into place.

ST1 927400000 HOUSING STAND


ST2 927100000 BEARING PULLER

CAUTION:

- Always press outer race when installing bearing.
- Be careful not to remove plastic lock from inner race when installing bearing.
- Charge bearing with new grease when outer race is not removed.

Specified grease:


SHELL 6459N



5) Using pliers, install snap ring in its groove.

CAUTION:

Make sure to install it firmly to groove.




G4M0226

6) Using ST1 and ST2, press outer oil seal until it contacts the bottom of housing.

ST1 927410000 OIL SEAL INSTALLER

ST2 927400000 HOUSING STAND




G4M0233

7) Using ST1 and ST2, press inner oil seal until it contacts circlip.

ST1 927410000 OIL SEAL INSTALLER

ST2 927400000 HOUSING STAND



G4M0234

8) Invert ST and housing.

ST 927400000 HOUSING STAND

9) Apply sufficient grease to oil seal lip.

Specified grease

SHELL 6459N

CAUTION:

- If specified grease is not available, remove bearing grease and apply Auto Rex A instead.
- Do not mix different types of grease.

10) Install disc cover to housing the three bolts.

Tightening torque:

18 N·m (1.8 kgf·m, 13.0 ft·lb)


11) Attach hub to ST1 securely.

12) Clean dust or foreign particles from the polished surface of hub.

13) Using ST2, press bearing into hub by driving inner race.

ST1 927080000 HUB STAND

ST2 927120000 HUB INSTALLER




G4M0235

E: INSPECTION

Check the removed parts for wear and damage. If defective, replace with new ones.

CAUTION:

- If bearing is faulty, replace it as the bearing set.
- Be sure to replace oil seal at every overhaul.



H4M1002C

(A) Replace as a set.

4. Rear Axle

A: REMOVAL


1. DISC BRAKE

- 1) Disconnect ground cable from battery.
- 2) Jack-up vehicle, and remove rear wheel cap and wheels.


CAUTION:

Be sure to loosen and retighten axle nut after removing wheel from vehicle. Failure to follow this rule may damage wheel bearings.

- 3) Unlock axle nut.
- 4) Remove axle nut using a socket wrench.
- 5) Return parking brake lever and loosen adjusting nut.



- 6) Remove disc brake caliper from back plate, and suspend it from strut using a piece of wire.




- 7) Remove disc rotor from hub.

NOTE:

If disc rotor seizes up within hub, drive it out by installing an 8-mm bolt into bolt hole in disc rotor.


- 8) Disconnect parking brake cable end.



- 9) Disconnect rear stabilizer from rear lateral link.
- 10) Remove bolts which secure trailing link assembly to rear housing.

CAUTION:


Discard old self-locking nut. Replace with a new one.



- 11) Remove bolts which secure lateral assembly to rear housing.

CAUTION:

Discard old self-locking nut. Replace with a new one.




- 12) Disengage BJ from housing splines, and remove rear drive shaft assembly.

If it is hard to remove, use STs.


- | | | |
|-----|-----------|-------------------------|
| ST1 | 926470000 | AXLE SHAFT PULLER |
| ST2 | 927140000 | AXLE SHAFT PULLER PLATE |

CAUTION:


- Be careful not to damage oil seal lip when removing rear drive shaft.
- When rear drive shaft is to be replaced, also replace inner oil seal with a new one.



- 13) Remove rear ABS sensor from back plate (only vehicle equipped with ABS).



- 14) Remove bolts which secure rear housing to strut, and separate the two.




2. DRUM BRAKE

- 1) Disconnect ground cable from battery.
- 2) Jack-up vehicle, and remove rear wheel cap and wheels.

CAUTION:


Be sure to loosen and retighten axle nut after removing wheel from vehicle. Failure to follow this rule may damage wheel bearings.

- 3) Unlock axle nut.
- 4) Remove axle nut using a socket wrench.
- 5) Return parking brake lever and loosen adjusting nut.




- 6) Remove brake drum from hub.

- 7) If it is difficult to remove brake drum, remove adjusting hole cover from back plate, and then turn adjusting screw using a slot-type screwdriver until brake shoe separates from the drum.



NOTE:


If brake drum is difficult to remove, drive it out by installing an 8-mm bolt into bolt hole in brake drum.




- 8) Using a flare-net wrench, disconnect brake pipe from wheel cylinder.

CAUTION:

Cover open end of wheel cylinder to prevent entry of foreign particles.



- 9) Disconnect parking brake cable end.




REAR AXLE

DRIVE SHAFT SYSTEM


- 10) Disconnect rear stabilizer from rear lateral link.
- 11) Remove bolts which secure trailing link assembly to rear housing.

CAUTION:
Discard old self-locking nut. Replace with a new one.



- 12) Remove bolts which secure lateral link assembly to rear housing.

CAUTION:
Discard old self-locking nut. Replace with a new one.




- 13) Disengage BJ from housing splines, and remove rear drive shaft assembly.

If it is hard to remove, use STs.


- ST1 926470000 AXLE SHAFT PULLER
- ST2 927140000 AXLE SHAFT PULLER PLATE

CAUTION:


- Be careful not to damage oil seal lip when removing rear drive shaft.
- When rear drive shaft is to be replaced, also replace inner oil seal with a new one.



- 14) Remove rear ABS sensor from back plate (only vehicle equipped with ABS).



- 15) Remove bolts which secure rear housing to strut, and separate the two.



B: INSTALLATION

1. DISC BRAKE

1) Connect rear housing assembly and strut assembly.

CAUTION:

Use a new self-locking nut.

Tightening torque:

196 N·m (20 kgf·m, 145 ft·lb)

2) Fit BJ (bell joint) to rear housing splines.

CAUTION:

Be careful not to damage inner oil seal lip.


3) Connect rear housing assembly to lateral link assembly.

CAUTION:

Use a new self-locking nut.

Tightening torque:

137 N·m (14 kgf·m, 101 ft·lb)




4) Connect rear housing assembly to trailing link assembly.

CAUTION:

Use a new self-locking nut.

Tightening torque:

113 N·m (11.5 kgf·m, 83 ft·lb)



5) Connect rear stabilizer to rear lateral link.

CAUTION:

Use a new self-locking nut.

Tightening torque:

44 N·m (4.5 kgf·m, 32.5 ft·lb)


6) Connect parking brake cable to parking brake.

7) Install disc rotor on rear housing assembly.


8) Install disc brake caliper on back plate.

Tightening torque:

52 N·m (5.3 kgf·m, 38.3 ft·lb)



9) Install rear ABS sensor and brake cable bracket)only vehicle equipped with ABS).



10) Bleed air from brake system. <Ref. to BR-62, REPLACEMENT, Brake Fluid.>

11) Adjust parking brake lever stroke by turning adjuster.

12) Move brake lever back to apply brakes. While depressing brake pedal, tighten axle nut using a socket wrench. Lock axle nut after tightening.

Tightening torque:

186 N·m (19 kgf·m, 137 ft·lb)

CAUTION:

- Use a new axle nut.
- Always tighten axle nut before installing wheel on vehicle. If wheel is installed and comes in contact with ground when axle nut is loose, wheel bearings may be damaged.
- Be sure to tighten axle nut to specified torque. Do not overtighten it as this may damage wheel bearing.

13) Install wheel and tighten wheel nuts to specified torque.

Tightening torque:

88 N·m (9 kgf·m, 65 ft·lb)

REAR AXLE

DRIVE SHAFT SYSTEM

2. DRUM BRAKE

1) Connect rear housing assembly and strut assembly.

CAUTION:

Use a new self-locking nut.

Tightening torque:

196 N-m (20 kgf-m, 145 ft-lb)

2) Fit BJ (bell joint) to rear housing splines.

CAUTION:

Be careful not to damage inner oil seal lip.


3) Connect rear housing assembly to lateral link assembly.

CAUTION:

Use a new self-locking nut.

Tightening torque:

137 N-m (14 kgf-m, 101 ft-lb)




4) Connect rear housing assembly to trailing link assembly.

CAUTION:

Use a new self-locking nut.

Tightening torque:

113 N-m (11.5 kgf-m, 83 ft-lb)



5) Connect rear stabilizer to rear lateral link.

CAUTION:

Use a new self-locking nut.


Tightening torque:

44 N-m (4.5 kgf-m, 32.5 ft-lb)

6) Connect parking brake cable to parking brake.

7) Clean brake pipe connection. Using a flare-nut wrench, connect brake pipe to wheel cylinder.

8) Connect rear ABS sensor to back plate (only vehicle equipped with ABS).



9) Connect parking brake cable to lever.

10) Install brake drum on rear housing assembly.

11) Bleed air from brake system. <Ref. to BR-62, REPLACEMENT, Brake Fluid.>

12) Adjust parking brake lever stroke by turning adjuster.

13) Move brake lever back to apply brakes. While depressing brake pedal, tighten axle nut using a socket wrench. Lock axle nut after tightening.

Tightening torque:

186 N-m (19 kgf-m, 137 ft-lb)

CAUTION:

- Use a new axle nut.
- Always tighten axle nut before installing wheel on vehicle. If wheel is installed and comes in contact with ground when axle nut is loose, wheel bearings may be damaged.
- Be sure to tighten axle nut to specified torque. Do not overtighten it as this may damage wheel bearing.

14) Install wheel and tighten wheel nuts to specified torque.


Tightening torque:

88 N-m (9 kgf-m, 65 ft-lb)

C: DISASSEMBLY

1) Using ST1 and ST2, remove hub from rear housing.

ST 927080000 HUB STAND
ST 927420000 HUB REMOVER




2) Remove back plate from rear housing
3) Using a standard screwdriver, remove outer and inner oil seals.

CAUTION:
Use new oil seals.

4) Using flat bladed screwdriver, remove snap ring.

CAUTION:
Be careful not to damage housing at removal.




5) Using ST1 and ST2, remove bearing by pressing inner race.

ST1 927430000 HOUSING STAND
ST2 927440000 BEARING REMOVER

CAUTION:


- Do not remove bearing unless damaged.
- Do not re-use bearing after removal.



6) Remove tone wheel bolts and remove tone wheel from hub (only vehicle equipped with ABS).

7) Using ST, press hub bolt out.
ST 927080000 HUB STAND

CAUTION:
Be careful not to hammer hub bolts. This may deform hub.



REAR AXLE

DRIVE SHAFT SYSTEM


D: ASSEMBLY

1) Using ST, press new hub bolt into place.

CAUTION:

- Ensure hub bolt closely contacts hub.
- Use a 12 mm (0.47 in) hole in the ST to prevent hub bolt from tilting during installation.


ST 927080000 HUB STAND



2) Remove foreign particles (dust, rust, etc.) from mating surfaces of hub tone wheel, and install tone wheel to hub (only vehicle equipped with ABS).

CAUTION:

- Ensure tone wheel closely contacts hub.
- Be careful not to damage tone wheel teeth.




3) Clean housing interior completely. Using ST1 and ST2, press bearing into housing.

ST1 927430000 HOUSING STAND
ST2 927440000 BEARING REMOVER

CAUTION:


- Always press iouter race when installing bearing.
- Be careful not to remove plastic lock from inner race when installing bearing.
- Charge bearing with new grease when outer race is not removed.



4) Using plier, install snap ring.


CAUTION:

Ensure snap ring fits in groove properly.



5) Using ST1 and ST2, press outer oil seal unit it comes in contact with snap ring.


ST1 927430000 HOUSING STAND
ST2 927460000 OIL SEAL INSTALLER



6) Invert both ST1 and housing.


7) Using ST2, press inner oil seal into housing until it touches bottom.

ST1 927430000 HOUSING STAND
ST2 927460000 OIL SEAL INSTALLER



8) Using ST1 and ST2, press sub seal into place.

ST1 927430000 HOUSING STAND
ST2 927460000 OIL SEAL INSTALLER



9) Apply sufficient grease to oil seal lip.

Specified grease:
SHELL 6459N

CAUTION:


- If specification grease is not available, remove bearing grease and apply Auto Rex A instead.
- Do not mix different types of grease.

10) Install back plate to rear housing.

Tightening torque:
52 N·m (5.3 kgf-m, 38 ft-lb)

11) Using ST1 and ST2, press bearing into hub.

ST1 927080000 HUB STAND
ST2 927450000 HUB INSTALLER



E: INSPECTION

Check the removed parts for wear and damage. If defective, replace with a new one.

CAUTION:

- If a bearing is faulty, replace it as the bearing set.
- Be sure to replace oil seal at every overhaul.

FRONT DRIVE SHAFT

DRIVE SHAFT SYSTEM

5. Front Drive Shaft

A: REMOVAL

- 1) Disconnect ground cable from battery.
- 2) Jack-up vehicle, support it with safety stands (rigid racks), and remove front wheel cap and wheels.
- 3) Unlock axle nut.
- 4) Depress brake pedal and remove axle nut using a socket wrench.


CAUTION:

Be sure to loosen and retighten axle nut after removing wheel from vehicle. Failure to follow this rule may damage wheel bearings.

- 5) Remove stabilizer link from transverse link.
- 6) Disconnect transverse link from housing.
- 7) Remove spring pin which secures transmission spindle to SFJ.

CAUTION:

Use a new spring pin.




- 8) Remove front drive shaft assembly. If it is hard to remove, use ST1 and ST2.

ST1 926470000 AXLE SHAFT PULLER
ST2 927140000 AXLE SHAFT PULLER PLATE

CAUTION:

- Be careful not to damage oil seal lip and tone wheel when removing front drive shaft.
- When front drive shaft is to be replaced, also replace inner oil seal.



B: INSTALLATION

- 1) Insert BJ into hub splines.

CAUTION:


Be careful not to damage inner oil seal lip and tone wheel.

- 2) Using ST1 and ST2, pull drive shaft into place.

ST1 922431000 AXLE SHAFT INSTALLER
ST2 927390000 ADAPTER

CAUTION:


Do not hammer drive shaft when installing it.



- 3) Tighten axle nut temporarily.
- 4) Install SFJ on transmission spindle and drive spring pin into place.

CAUTION:

Always use a new spring pin.



- 5) Connect transverse link to housing.

Tightening torque (self-locking nut):

49 N·m (5.0 kgf-m, 36 ft-lb)

CAUTION:

Use a new self-locking nut.

- 6) Install stabilizer bracket.
- 7) While depressing brake pedal, tighten axle nut to the specified torque.

Tightening torque:

186 N·m (19 kgf-m, 137 ft-lb)

CAUTION:


- Use a new axle nut.
- Always tighten axle nut before installing wheel on vehicle. If wheel is installed and comes in contact with ground when axle nut is loose, wheel bearings may be damaged.

- Be sure to tighten axle nut to specified torque. Do not overtighten it as this may damage wheel bearing.

8) After tightening axle nut, lock it securely.

C: DISASSEMBLY


1) Place alignment marks on shaft and outer race.




2) Remove SFJ boot band and boot.

CAUTION:

Be careful not to damage boot.



3) Remove circlip from SFJ outer race using screwdriver.




4) Remove SFJ outer race from shaft assembly.

5) Wipe off grease.

CAUTION:

The grease is a special grease. Do not confuse with other greases.

6) Place alignment mark on free ring and trunnion.




7) Remove free ring from trunnion.


CAUTION:

Be careful with the free ring position.

8) Place alignment mark on trunnion and shaft.



9) Remove snap ring and trunnion.



CAUTION:

Be sure to wrap shaft splines with vinyl tape to prevent boot from scratches.

10) Remove SFJ boot.

11) Place drive shaft in a vise between wooden blocks.


FRONT DRIVE SHAFT

DRIVE SHAFT SYSTEM

CAUTION:

Do not place drive shaft directly in the vise; use wooden block.

12) Raise boot band claws by means of screwdriver and hammer.




(A) Boot band claws

13) Cut and remove the boot.

CAUTION:

The boot must be replaced with a new one whenever it is removed.



14) Thus, disassembly of axle is completed, but BJ cannot be disassembled.

D: ASSEMBLY

CAUTION:

Use specified grease.

BJ side:

NTG2218 (Part No. 28093AA000)

SFJ side:

SSG6003 (Part No. 28093TA000)

1) Place BJ boot and small boot band on BJ side of shaft.

CAUTION:

Be sure to wrap shaft splines with vinyl tape to prevent boot from scratches.

2) Place drive shaft in a vise.

CAUTION:

Do not place drive shaft directly in the vise; use wooden blocks.


3) Apply a coat of specified grease [60 to 70 g (2.12 to 2.47 oz)] to BJ.

4) Apply an even coat of specified grease [20 to 30 g (0.71 to 1.06 oz)] to the entire inner surface of boot. Also apply grease to shaft.

NOTE:

The inside of the larger end of BJ boot and the boot groove shall be cleaned so as to be free from grease and other substances.

5) Install boot projecting portion to BJ groove.




(A) BJ

(B) Large boot band

(C) Boot

6) Set large boot band in place.

7) Install boot projecting portion to shaft groove.




(A) Boot

(B) Small boot band

(C) Shaft

8) Tighten boot bands using ST, torque wrench and socket flex handle.

ST 28099AC000 BOOT BAND PLIER



- (A) Large boot band
- (B) Boot
- (C) Torque wrench
- (D) Socket flex handle
- (E) BJ

Tightening torque:

Large boot band


157 N·m (16.0 kgf·m, 116 ft·lb) or more

Small boot band

133 N·m (13.6 kgf·m, 98 ft·lb) or more

9) Place SFJ boot at the center of shaft.

10) Align alignment marks and install trunnion on shaft.



11) Install snap ring to shaft.

CAUTION:

Confirm that the snap ring is completely fitted in the shaft groove.


12) Fill 100 to 110 g (3.53 to 3.88 oz) of specified grease into the interior of SFJ outer race.

13) Apply a coat of specified grease to free ring and trunnion.


14) Align alignment marks on free ring and trunnion and install free ring.

CAUTION:

Be careful with the free ring position.



15) Align alignment marks on shaft and outer race, and install outer race.



16) Install circlip in the groove on SFJ outer race.

CAUTION:

Pull the shaft lightly and assure that the circlip is completely fitted in the groove.

17) Apply an even coat of the specified grease 30 to 40 g (1.06 to 1.41 oz) to the entire inner surface of boot.

18) Install SFJ boot taking care not to twist it.

CAUTION:

- The inside of the larger end of SFJ boot and the boot groove shall be cleaned so as to be free from grease and other substances.

- When installing SFJ boot, position outer race of SFJ at center of its travel.

19) Put a band through the clip and wind twice in alignment with band groove of boot.

CAUTION:

Use a new band.

FRONT DRIVE SHAFT

DRIVE SHAFT SYSTEM

20) Pinch the end of band with pliers. Hold the clip and tighten securely.

NOTE:


When tightening boot, exercise care so that the air within the boot is appropriate.

21) Tighten band by using ST.

ST 925091000 BAND TIGHTENING TOOL

NOTE:

Tighten band until it cannot be moved by hand.




22) Tap on the clip with the punch provided at the end of ST.

ST 925091000 BAND TIGHTENING TOOL

CAUTION:

Tap to an extent that the boot underneath is not damaged.



23) Cut off band with an allowance of about 10 mm (0.39 in) left from the clip and bend this allowance over the clip.

CAUTION:

Be careful so that the end of the band is in close contact with clip.

24) Fix up boot on BJ in the same manner.

NOTE:

Extend and retract SFJ to provide equal grease coating.

E: INSPECTION

Check the removed parts for damage, wear, corrosion etc. If faulty, repair or replace.

1) DOJ (Double Offset Joint)

Check seizure, corrosion, damage, wear and excessive play.

2) SFJ (Shudder-less Freering tripod Joint)

Check seizure, corrosion, damage and excessive play.

3) Shaft

Check excessive bending, twisting, damage and wear.

4) BJ (Bell Joint)

Check seizure, corrosion, damage and excessive play.

5) Boot

Check for wear, warping, breakage or scratches.

6) Grease

Check for discoloration or fluidity.

6. Rear Drive Shaft

A: REMOVAL

- 1) Disconnect ground cable from battery.
- 2) Lift-up vehicle, and remove rear wheel cap and wheels.

CAUTION:

Be sure to loosen and retighten axle nut after removing wheel from vehicle. Failure to follow this rule may damage wheel bearings.


- 3) Unlock axle nut.
- 4) Remove axle nut using a socket wrench.
- 5) Remove rear differential assembly.
with T-type
<Ref. to DI-25, REMOVAL, Rear Differential for T-type.>
with VA-type
<Ref. to DI-40, REMOVAL, Rear Differential for VA-type.>

- 6) Remove axle nut and drive shaft. If it is hard to remove, use ST1 and ST2.

- | | | |
|-----|-----------|-------------------------|
| ST1 | 926470000 | AXLE SHAFT PULLER |
| ST2 | 927140000 | AXLE SHAFT PULLER PLATE |

CAUTION:

Be careful not to damage tone wheel when removing rear drive shaft.



B: INSTALLATION

- 1) Insert BJ into rear hub splines.


CAUTION:

Be careful not to damage tone wheel.

- 2) Using ST1 and ST2, pull drive shaft into place.
ST1 922431000 AXLE SHAFT INSTALLER
ST2 927390000 ADAPTER

CAUTION:

Do not hammer drive shaft when installing it.



- 3) Tighten axle nut temporarily.
- 4) Install rear differential.
with T-type
<Ref. to DI-27, INSTALLATION, Rear Differential for T-type.>
with VA-type
<Ref. to DI-42, INSTALLATION, Rear Differential for VA-type.>
- 5) While depressing brake pedal, tighten axle nut using a socket wrench.

Tightening torque:

235 N·m (24 kgf·m, 174 ft·lb)

CAUTION:

- Use a new axle nut for rear use only.
- Always tighten axle nut before installing wheel on vehicle. If wheel is installed and comes in contact with ground when axle nut is loose, wheel bearings may be damaged.
- Be sure to tighten axle nut to specified torque. Do not overtighten it as this may damage wheel bearing.


- 6) After tightening axle nut, lock it securely.

REAR DRIVE SHAFT


DRIVE SHAFT SYSTEM

C: DISASSEMBLY

- 1) Straighten bent claw of larger end of DOJ boot.
- 2) Loosen band by means of screwdriver or pliers with care of not damaging boot.



- 3) Remove boot band on the small end of DOJ boot in the same manner.
- 4) Remove the larger end of DOJ boot from DOJ outer race.
- 5) Pry and remove round circlip located at the neck of DOJ outer race with a screwdriver.




- 6) Take out DOJ outer race from shaft assembly.
- 7) Wipe off grease and take out balls.

CAUTION:

The grease is a special grease (grease for constant velocity joint). Do not confuse with other greases.

NOTE:

Disassemble exercising care not to lose balls (6 pcs).



- (A) Outer race
- (B) Grease

- 8) To remove the cage from the inner race, turn the cage by a half pitch to the track groove of the inner race and shift the cage.
- 9) Remove snap ring, which fixes inner race to shaft, by using pliers.
- 10) Take out DOJ inner race.
- 11) Take off DOJ cage from shaft and remove DOJ boot.

CAUTION:

Be sure to wrap shaft splines with vinyl tape to prevent boot from scratches.

- 12) Remove BJ boot in the same procedure as DOJ boot.
- 13) Thus, disassembly of axle is completed, but BJ is unable to be disassembled.

D: ASSEMBLY

CAUTION:

Use specified grease.

BJ side:

Molylex No. 2 (Part No. 723223010)

DOJ side:

VU-3A702 (Yellow) (Part No. 23223GA050)

- 1) Install BJ boot in specified position, and fill it with 60 to 70 g (2.12 to 2.47 oz) of specified grease.
- 2) Place DOJ cage at the center of shaft.


CAUTION:

Be sure to wrap shaft splines with vinyl tape to prevent boot from scratches.

- 3) Insert DOJ cage onto shaft.

NOTE:

Insert the cage with the cut-out portion facing the shaft end, since the cage has an orientation.




- (A) Cage
- (B) Cut-out portion

- 4) Install DOJ inner race on shaft and fit snap ring with pliers.

NOTE:


Confirm that the snap ring is completely fitted in the shaft groove.



- 5) Install cage, which was previously fitted, to inner race fixed upon shaft.


NOTE:

Fit the cage with the protruded part aligned with the track on the inner race and then turn by a half pitch.



- (A) Inner race
- (B) Cage

- 6) Fill 80 to 90 g (2.82 to 3.17 oz) of specified grease into the interior of DOJ outer race.
- 7) Apply a coat of specified grease to the cage pocket and six balls.
- 8) Insert six balls into the cage pocket.
- 9) Align the outer race track and ball positions and place in the part where shaft, inner race, cage and balls are previously installed, and then fit outer race.



- (A) Outer race
- (B) Grease


REAR DRIVE SHAFT

DRIVE SHAFT SYSTEM

10) Install circlip in the groove on DOJ outer race.

NOTE:

- Assure that the balls, cage and inner race are completely fitted in the outer race of DOJ.
- Exercise care not to place the matched position of circlip in the ball groove of outer race.
- Pull the shaft lightly and assure that the circlip is completely fitted in the groove.



11) Apply an even coat of the specified grease [20 to 30 g (0.71 to 1.06 oz)] to the entire inner surface of boot. Also apply grease to shaft.

12) Install DOJ boot taking care not to twist it.

NOTE:

- The inside of the larger end of DOJ boot and the boot groove shall be cleaned so as to be free from grease and other substances.
- When installing DOJ boot, position outer race of DOJ at center of its travel.

13) Put a band through the clip and wind twice in alignment with band groove of boot.

CAUTION:

Use a new band.

14) Pinch the end of band with pliers. Hold the clip and tighten securely.

NOTE:


When tightening boot, exercise care so that the air within the boot is appropriate.

15) Tighten band by using ST.

ST 925091000 BAND TIGHTENING TOOL

NOTE:

Tighten band until it cannot be moved by hand.




16) Tap on the clip with the punch provided at the end of ST.

ST 925091000 BAND TIGHTENING TOOL

CAUTION:

Tap to an extent that the boot underneath is not damaged.



17) Cut off band with an allowance of about 10 mm (0.39 in) left from the clip and bend this allowance over the clip.

CAUTION:

Be careful so that the end of the band is in close contact with clip.

18) Fix up boot on BJ in the same manner.

NOTE:

Extend and retract DOJ to provide equal grease coating.

E: INSPECTION

Check the removed parts for damage, wear, corrosion etc. If faulty, repair or replace.

1) DOJ (Double Offset Joint)

Check seizure, corrosion, damage, wear and excessive play.

2) SFJ (Shudder-less Freering tripod Joint)

Check seizure, corrosion, damage and excessive play.

3) Shaft

Check excessive bending, twisting, damage and wear.

4) BJ (Bell Joint)

Check seizure, corrosion, damage and excessive play.

5) Boot

Check for wear, warping, breakage or scratches.

6) Grease

Check for discoloration or fluidity.

7. General Diagnostic Table

A:INSPECTION

NOTE:

Vibration while cruising may be caused by an unbalanced tire, improper tire inflation pressure, improper wheel alignment, etc.

Symptom	Possible cause	Remedy
1. Vibration of propeller shaft NOTE: Vibration is caused by propeller shaft during operation and is transferred to vehicle body. Generally vibration increase in proportion to vehicle speed.	(1) Worn or damaged universal joint.	Replace.
	(2) Unbalanced propeller shaft due to bend or dent.	Replace.
	(3) Loose installation of propeller shaft.	Retighten.
	(4) Worn or damaged center bearing and damaged center mounting rubber.	Replace.
2. Tapping when starting and noise while cruising, caused by propeller shaft.	(1) Worn or damaged universal joint.	Replace.
	(2) Worn spline of sleeve yoke.	Replace.
	(3) Loose installation of propeller shaft.	Retighten.
	(4) Loose installation of joint.	Replace.
	(5) Worn or damaged center bearing and damaged center mounting rubber.	Replace.

