

**ENGINE 2 SECTION**

This service manual has been prepared to provide SUBARU service personnel with the necessary information and data for the correct maintenance and repair of SUBARU vehicles.

This manual includes the procedures for maintenance, disassembling, reassembling, inspection and adjustment of components and diagnostics for guidance of experienced mechanics.

Please peruse and utilize this manual fully to ensure complete repair work for satisfying our customers by keeping their vehicle in optimum condition. When replacement of parts during repair work is needed, be sure to use SUBARU genuine parts.

All information, illustration and specifications contained in this manual are based on the latest product information available at the time of publication approval.

**FUEL INJECTION (FUEL SYSTEMS) FU(SOHCw/oOBD)**

**EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES) EC(SOHCw/oOBD)**

**EXHAUST EX(SOHCw/oOBD)**

**IGNITION IG(SOHCw/oOBD)**

**ENGINE(DIAGNOSTICS) EN(SOHCw/oOBD)**

**FUEL INJECTION (FUEL SYSTEMS) FU(DOHC TURBO)**

**EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES) EC(DOHC TURBO)**

**INTAKE (INDUCTION) IN(DOHC TURBO)**

**MECHANICAL ME(DOHC TURBO)**

**EXHAUST EX(DOHC TURBO)**

**IGNITION IG(DOHC TURBO)**

**ENGINE (DIAGNOSTICS) EN(DOHC TURBO)**

## 17. Diagnostic Procedure with Diagnostic Trouble Code (DTC)


### A: DTC P0031 — FRONT OXYGEN (A/F) SENSOR HEATER CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**



EN0966

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Go to step 2.	Go to step 5.
2	<p><b>CHECK POWER SUPPLY TO FRONT OXYGEN (A/F) SENSOR.</b></p> <p>1) Turn ignition switch to OFF.                      2) Disconnect connector from front oxygen (A/F) sensor.                      3) Turn ignition switch to ON.                      4) Measure voltage between front oxygen (A/F) sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B18) No. 2 (+) — Engine ground (-):</b></p>	Go to step 3.	Repair power supply line. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between main relay and front oxygen (A/F) sensor connector</li> <li>• Poor contact in front oxygen (A/F) sensor connector</li> <li>• Poor contact in main relay connector</li> </ul>
3	<p><b>CHECK GROUND CIRCUIT OF ECM.</b></p> <p>Measure resistance of harness between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B137) No. 8 — Chassis ground:</b>  <b>(B137) No. 9 — Chassis ground:</b></p>	Go to step 4.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and engine ground terminal</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>
4	<p><b>CHECK CURRENT DATA.</b></p> <p>1) Start engine                      2) Read data of front oxygen (A/F) sensor heater current using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:                      • Subaru Select Monitor                      For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt;                      • OBD-II scan tool                      For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	Go to step 5.	Repair poor contact in connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Poor contact in front oxygen (A/F) sensor connector</li> <li>• Poor contact in ECM connector</li> </ul>
5	<p><b>CHECK OUTPUT SIGNAL FROM ECM.</b></p> <p>1) Start and idle the engine.                      2) Measure voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B137) No. 4 (+) — Chassis ground (-):</b></p>	Go to step 7.	Go to step 6.
6	<p><b>CHECK OUTPUT SIGNAL FROM ECM.</b></p> <p>Measure voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B137) No. 4 (+) — Chassis ground (-):</b></p>	Go to step 7.	Go to step 7.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>7</b> <b>CHECK OUTPUT SIGNAL FROM ECM.</b> Measure voltage between ECM connector and chassis ground. <i><b>Connector &amp; terminal</b></i> <i><b>(B137) No. 5 (+) — Chassis ground (-):</b></i>	Is the voltage less than 1.0 V?	Go to step <b>9</b> .	Go to step <b>8</b> .
<b>8</b> <b>CHECK OUTPUT SIGNAL FROM ECM.</b> Measure voltage between ECM connector and chassis ground. <i><b>Connector &amp; terminal</b></i> <i><b>(B137) No. 5 (+) — Chassis ground (-):</b></i>	Does the voltage change less than 1.0 V by shaking harness and connector of ECM while monitoring the value with voltage meter?	Repair poor contact in ECM connector.	Go to step <b>9</b> .
<b>9</b> <b>CHECK FRONT OXYGEN (A/F) SENSOR.</b> 1) Turn ignition switch to OFF. 2) Measure resistance between front oxygen (A/F) sensor connector terminals. <i><b>Terminals</b></i> <i><b>No. 2 — No. 1:</b></i>	Is the resistance less than 10 $\Omega$ ?	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open or ground short circuit in harness between front oxygen (A/F) sensor and ECM connector</li> <li>• Poor contact in front oxygen (A/F) sensor connector</li> <li>• Poor contact in ECM connector</li> </ul>	Replace front oxygen (A/F) sensor. <Ref. to FU(DOHC TURBO)-41, Front Oxygen (A/F) Sensor.>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## B: DTC P0032 — FRONT OXYGEN (A/F) SENSOR HEATER CIRCUIT HIGH INPUT —

- DTC DETECTING CONDITION:
  - Immediately at fault recognition

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

### • WIRING DIAGRAM:



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1</b> <b>CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Turn ignition switch to ON. 2) Measure voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <i>(B137) No. 4 (+) — Chassis ground (-):</i> <i>(B137) No. 5 (+) — Chassis ground (-):</i>	Is the voltage more than 8 V?	Go to step 3.	Go to step 2.
<b>2</b> <b>CHECK FRONT OXYGEN (A/F) SENSOR HEATER CURRENT.</b> 1) Turn ignition switch to OFF. 2) Repair battery short circuit in harness between ECM and front oxygen (A/F) sensor connector. 3) Turn ignition switch to ON. 4) Read data of front oxygen (A/F) sensor heater current using Subaru Select Monitor or the OBD-II general scan tool. <b>NOTE:</b> •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.> •OBD-II general scan tool For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.	Is the value more than 2.3 A?	Replace ECM. <Ref. to FU(DOHC TURBO)-45, Engine Control Module.>	END
<b>3</b> <b>CHECK OUTPUT SIGNAL FROM ECM.</b> Measure voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <i>(B137) No. 4 (+) — Chassis ground (-):</i> <i>(B137) No. 5 (+) — Chassis ground (-):</i>	Does the voltage change more than 8 V by shaking harness and connector of ECM while monitoring the value with voltage meter?	Repair battery short circuit in harness between ECM and front oxygen (A/F) sensor connector.	END

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## C: DTC P0037 — REAR OXYGEN SENSOR HEATER CIRCUIT MALFUNCTION

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**



EN0967



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK GROUND CIRCUIT OF ECM.</b>                      1) Turn ignition switch to OFF.                      2) Disconnect connector from ECM.                      3) Measure resistance of harness between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B137) No. 8 — Chassis ground:</b>  <b>(B137) No. 9 — Chassis ground:</b></p>	<p>Is the resistance less than 5 <math>\Omega</math>?</p>	<p>Go to step 2.</p>	<p>Repair harness and connector.</p> <p>NOTE:                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and engine ground terminal</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>2</b></p> <p><b>CHECK CURRENT DATA.</b>                      1) Start engine.                      2) Read data of rear oxygen sensor heater current using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:                      • Subaru Select Monitor                      For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt;                      • OBD-II scan tool                      For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value more than 0.2 A?</p>	<p>Repair connector.</p> <p>NOTE:                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Poor contact in rear oxygen sensor connector</li> <li>• Poor contact in rear oxygen sensor connecting harness connector</li> <li>• Poor contact in ECM connector</li> </ul>	<p>Go to step 3.</p>
<p><b>3</b></p> <p><b>CHECK OUTPUT SIGNAL FROM ECM.</b>                      1) Start and idle the engine.                      2) Measure voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B136) No. 13 (+) — Chassis ground (-):</b></p>	<p>Is the voltage less than 1.0 V?</p>	<p>Go to step 6.</p>	<p>Go to step 4.</p>
<p><b>4</b></p> <p><b>CHECK OUTPUT SIGNAL FROM ECM.</b>                      Measure voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B136) No. 13 (+) — Chassis ground (-):</b></p>	<p>Does the voltage change less than 1.0 V by shaking harness and connector of ECM while monitoring the value with voltage meter?</p>	<p>Repair poor contact in ECM connector.</p>	<p>Go to step 5.</p>
<p><b>5</b></p> <p><b>CHECK OUTPUT SIGNAL FROM ECM.</b>                      1) Disconnect connector from rear oxygen sensor.                      2) Measure voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B136) No. 13 (+) — Chassis ground (-):</b></p>	<p>Is the voltage less than 1.0 V?</p>	<p>Replace ECM.                      &lt;Ref. to FU(DOHC TURBO)-45, Engine Control Module.&gt;</p>	<p>Repair battery short circuit in harness between ECM and rear oxygen sensor connector. After repair, replace ECM. &lt;Ref. to FU(DOHC TURBO)-45, Engine Control Module.&gt;</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
6	<p><b>CHECK POWER SUPPLY TO REAR OXYGEN SENSOR.</b></p> <p>1) Turn ignition switch to OFF.                      2) Disconnect connector from rear oxygen sensor.                      3) Turn ignition switch to ON.                      4) Measure voltage between rear oxygen sensor connector and engine ground or chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B19) No. 2 (+) — Chassis ground (-):</b></p>	Is the voltage more than 10 V?	Go to step 7.	<p>Repair power supply line.</p> <p><b>NOTE:</b>                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between main relay and rear oxygen sensor connector</li> <li>• Poor contact in rear oxygen sensor connector</li> <li>• Poor contact in coupling connector</li> </ul>
7	<p><b>CHECK REAR OXYGEN SENSOR.</b></p> <p>1) Turn ignition switch to OFF.                      2) Measure resistance between rear oxygen sensor connector terminals.</p> <p><b>Terminals</b>  <b>No. 1 — No. 2:</b></p>	Is the resistance less than 30 $\Omega$ ?	<p>Repair harness and connector.</p> <p><b>NOTE:</b>                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between rear oxygen sensor and ECM connector</li> <li>• Poor contact in rear oxygen sensor connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>	<p>Replace rear oxygen sensor. &lt;Ref. to FU(DOHC TURBO)-43, Rear Oxygen Sensor.&gt;</p>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### D: DTC P0038 — REAR OXYGEN SENSOR HEATER CIRCUIT HIGH INPUT —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN0967

Step	Check	Yes	No
<b>1</b> <b>CHECK INPUT SIGNAL FOR ECM.</b> Measure voltage between ECM connector and chassis ground. <i>Connector &amp; terminal</i> <i>(B136) No. 13 (+) — Chassis ground (-):</i>	Is the voltage more than 8 V?	Go to step 2.	Go to step 3.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
2	<p><b>CHECK CURRENT DATA.</b></p> <p>1) Turn ignition switch to OFF. 2) Repair battery short circuit in harness between ECM and rear oxygen sensor connector. 3) Turn ignition switch to ON. 4) Read data of rear oxygen sensor heater current using Subaru Select Monitor or the OBD-II general scan tool.</p> <p>NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt; • OBD-II general scan tool For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</p>	Is the value more than 7 A?	Replace ECM. <Ref. to FU(DOHC TURBO)-45, Engine Control Module.>	END
3	<p><b>CHECK POOR CONTACT.</b></p> <p>Check poor contact in ECM connector.</p>	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	END

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
 ENGINE (DIAGNOSTICS)


**E: DTC P0101 — MASS AIR FLOW SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (HIGH INPUT) —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN0970

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


Step	Check	Yes	No
1 <b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0102 or P0113?	Inspect DTC P0102 or P0103 using "10. Diagnostics Chart with Trouble Code".  NOTE: In this case, it is not necessary to inspect DTC P0101.	Replace mass air flow and intake air temperature sensor. <Ref. to FU(DOHC TURBO)-32, Mass Air Flow and Intake Air Temperature Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### F: DTC P0102 — MASS AIR FLOW SENSOR CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance
- **WIRING DIAGRAM:**



EN0970



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1 CONNECT SUBARU SELECT MONITOR OR THE OBD-II GENERAL SCAN TOOL, AND READ DATA.</b>                      1) Turn ignition switch to OFF.                      2) Connect Subaru Select Monitor or the OBD-II general scan tool to data link connector.                      3) Turn ignition switch to ON and Subaru Select Monitor or the OBD-II general scan tool switch to ON.                      4) Start engine.                      5) Read data of mass air flow sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p><b>NOTE:</b>                      • Subaru Select Monitor                      For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt;                      • OBD-II general scan tool                      For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value equal to or more than 1.3 g/sec (0.172 lb/min) or 0.3 V and equal to or less than 240 g/sec (32 lb/min) or 4.58 V?</p>	<p>Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in the mass air flow sensor.</p> <p><b>NOTE:</b>                      In this case, repair the following:                      • Open or ground short circuit in harness between mass air flow sensor and ECM connector                      • Poor contact in mass air flow sensor or ECM connector</p>	<p>Go to step 2.</p>
<p><b>2 CHECK INPUT SIGNAL FOR ECM.</b>                      Measure voltage between ECM connector and chassis ground while engine is idling.  <b>Connector &amp; terminal</b>  <b>(B84) No. 13 (+) — Chassis ground (-):</b></p>	<p>Is the voltage less than 0.2 V?</p>	<p>Go to step 4.</p>	<p>Go to step 3.</p>
<p><b>3 CHECK INPUT SIGNAL FOR ECM (USING SUBARU SELECT MONITOR).</b>                      Measure voltage between ECM connector and chassis ground while engine is idling.</p>	<p>Does the voltage change more than 0.2 V by shaking harness and connector of ECM while monitoring the value with Subaru select monitor?</p>	<p>Repair poor contact in ECM connector.</p>	<p>Contact with your Subaru distributor service.</p> <p><b>NOTE:</b>                      Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p>
<p><b>4 CHECK POWER SUPPLY TO MASS AIR FLOW SENSOR.</b>                      1) Turn ignition switch to OFF.                      2) Disconnect connector from mass air flow sensor.                      3) Turn ignition switch to ON.                      4) Measure voltage between mass air flow sensor connector and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B3) No. 1 (+) — Chassis ground (-):</b></p>	<p>Is the voltage more than 10V?</p>	<p>Go to step 5.</p>	<p>Repair open circuit between mass air flow sensor and main relay</p>
<p><b>5 CHECK HARNESS BETWEEN ECM AND MASS AIR FLOW SENSOR CONNECTOR.</b>                      1) Turn ignition switch to OFF.                      2) Disconnect connector from ECM.                      3) Measure resistance of harness between ECM and mass air flow sensor connector.  <b>Connector &amp; terminal</b>  <b>(B84) No. 13 — (B3) No. 3:</b>  <b>(B135) No. 27 — (B3) No. 4:</b>  <b>(B135) No. 19 — (B3) No. 5:</b></p>	<p>Is the resistance less than 1Ω?</p>	<p>Go to step 6.</p>	<p>Repair open circuit between ECM and mass air flow sensor connector.</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>6</b>	<b>CHECK HARNESS BETWEEN ECM AND MASS AIR FLOW SENSOR CONNECTOR</b> Measure resistance of harness between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B84) No. 13 — Chassis ground:</b> <b>(B135) No. 27 — Chassis ground:</b> <b>(B135) No. 19 — Chassis ground:</b>	Is the resistance more than 1MΩ?	Go to step 7.  Repair ground short circuit between ECM and mass air flow sensor connector.
<b>7</b>	<b>CHECK POOR CONTACT</b> Check poor contact in mass air flow sensor connector.	Is there poor contact in mass air flow sensor connector?	Repair poor contact in mass air flow sensor connector.  Replace mass air flow and intake air temperature sensor. <Ref. to FU(DOHC TURBO)-32, Mass Air Flow and Intake Air Temperature Sensor.>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### G: DTC P0103 — MASS AIR FLOW SENSOR CIRCUIT HIGH INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN0970

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1 CONNECT SUBARU SELECT MONITOR OR THE OBD-II GENERAL SCAN TOOL, AND READ DATA.</b></p> <p>1) Turn ignition switch to OFF.                      2) Connect Subaru Select Monitor or the OBD-II general scan tool to data link connector.                      3) Turn ignition switch to ON and Subaru Select Monitor or the OBD-II general scan tool switch to ON.                      4) Start engine.                      5) Read data of mass air flow sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:                      •Subaru Select Monitor                      For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt;                      •OBD-II general scan tool                      For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value equal to or more than 1.3 g/sec (0.172 lb/min) or 0.3 V and equal to or less than 240 g/sec (32 lb/min) or 4.58 V?</p>	<p>Even if MIL lights up, the circuit has returned to a normal condition at this time.</p>	<p>Go to step 2.</p>
<p><b>2 CHECK HARNESS BETWEEN ECM AND MASS AIR FLOW SENSOR CONNECTOR.</b></p> <p>1) Turn ignition switch to OFF and Subaru Select Monitor or the OBD-II general scan tool switch to OFF.                      2) Disconnect connector from mass air flow sensor.                      3) Turn ignition switch to ON and Subaru Select Monitor or the OBD-II general scan tool switch to ON.                      4) Read data of mass air flow sensor signal using Subaru select monitor or OBD-II general scan tool.</p> <p>NOTE:                      •Subaru Select Monitor                      For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt;                      •OBD-II general scan tool                      For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value more than 240 g/sec (32 lb/min) or 4.58 V in function mode F06?</p>	<p>Repair battery short circuit in harness between mass air flow sensor and ECM connector. After repair, replace ECM.</p>	<p>Replace mass air flow sensor.</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## H: DTC P0106 — PRESSURE SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (LOW INPUT) —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Failure of engine to start

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

• **LHD MODEL:**







EN0969

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

- RHD MODEL:



EN0968

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<p><b>CHECK IDLE SWITCH SIGNAL.</b></p> <p>1) Turn ignition switch to ON. 2) Operate the LED operation mode for engine using Subaru Select Monitor.</p> <p>NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "LED OPERATION MODE FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt;</p>	Does the LED of {Idle Switch Signal} come on?	Go to step 2.	<p>Check throttle position sensor circuit. &lt;Ref. to EN(DOHC TURBO)-120, DTC P0121 — THROTTLE POSITION SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (HIGH INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</p> <p>NOTE: In this case, it is not necessary to inspect DTC P0106.</p>
2	<p><b>CHECK ANY OTHER DTC ON DISPLAY.</b></p>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0107 or P0108?	Inspect DTC P0107 or P0108 using "17. List of Diagnostic Trouble Code (DTC) for MT Vehicles". <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).>	Go to step 3.
3	<p><b>CHECK CONDITION OF INTAKE MANIFOLD PRESSURE SENSOR.</b></p>	Is the pressure sensor installation bolt tightened securely?	Go to step 4.	Tighten pressure sensor installation bolt securely.
4	<p><b>CHECK CONDITION OF THROTTLE BODY.</b></p>	Is the throttle body installation bolt tightened securely?	Replace pressure sensor. <Ref. to FU(DOHC TURBO)-33, Pressure Sensor.>	Tighten throttle body installation bolt securely.





# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## I: DTC P0107 — PRESSURE SENSOR CIRCUIT LOW INPUT —

- DTC DETECTING CONDITION:
  - Immediately at fault recognition

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- WIRING DIAGRAM:
- LHD MODEL







EN0969

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

• RHD MODEL



EN0968

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK CURRENT DATA.</b></p> <p>1) Start engine.</p> <p>2) Read the data of intake manifold absolute pressure signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor</li> </ul> <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>• OBD-II general scan tool</li> </ul> <p>For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value less than <math>-7.2</math> kPa (<math>-54</math> mmHg, <math>-2.1</math> inHg)?</p>	<p>Go to step 3.</p>	<p>Go to step 2.</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
2	<b>CHECK POOR CONTACT.</b> Check poor contact in ECM and pressure sensor connector.	Is there poor contact in ECM or pressure sensor connector?	Repair poor contact in ECM or pressure sensor connector.	Even if MIL lights up, the circuit has returned to a normal condition at this time.
3	<b>CHECK INPUT SIGNAL FOR ECM.</b> Measure voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B135) No. 9 (+) — Chassis ground (-):</b>	Is the voltage more than 4.5 V?	Go to step 5.	Go to step 4.
4	<b>CHECK INPUT SIGNAL FOR ECM.</b> Measure voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B135) No. 9 (+) — Chassis ground (-):</b>	Does the voltage change more than 4.5 V by shaking harness and connector of ECM while monitoring the value with voltage meter?	Repair poor contact in ECM connector.	Contact with your Subaru distributor service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.
5	<b>CHECK INPUT SIGNAL FOR ECM.</b> Measure voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B135) No. 8 (+) — Chassis ground (-):</b>	Is the voltage less than 0.7 V?	Go to step 6.	Contact with your Subaru distributor service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.
6	<b>CHECK HARNESS BETWEEN ECM AND PRESSURE SENSOR CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from pressure sensor. 3) Turn ignition switch to ON. 4) Measure voltage between pressure sensor connector and engine ground. <b>Connector &amp; terminal</b> <b>(E21) No. 3 (+) — Engine ground (-):</b>	Is the voltage more than 4.5 V?	Go to step 7.	Repair open circuit in harness between ECM and intake manifold pressure sensor connector.
7	<b>CHECK HARNESS BETWEEN ECM AND PRESSURE SENSOR CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from ECM. 3) Measure resistance of harness between ECM and intake manifold pressure sensor connector. <b>Connector &amp; terminal</b> <b>(B135) No. 19 — (E21) No. 2:</b>	Is the resistance less than 1 $\Omega$ ?	Go to step 8.	Repair open circuit in harness between ECM and intake manifold pressure sensor connector.
8	<b>CHECK HARNESS BETWEEN ECM AND PRESSURE SENSOR CONNECTOR.</b> Measure resistance of harness between intake manifold pressure sensor connector and engine ground. <b>Connector &amp; terminal</b> <b>(E21) No. 1 — Engine ground:</b>	Is the resistance more than 1 M $\Omega$ ?	Go to step 9.	Repair ground short circuit in harness between ECM and intake manifold pressure sensor connector.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
9	<b>CHECK POOR CONTACT.</b> Check poor contact in pressure sensor connector.	Is there poor contact in pressure sensor connector?	Repair poor contact in pressure sensor connector.	Replace pressure sensor. <Ref. to FU(DOHC TURBO)-33, Pressure Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)





### J: DTC P0108 — PRESSURE SENSOR CIRCUIT HIGH INPUT —

- DTC DETECTING CONDITION:
  - Immediately at fault recognition

#### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- WIRING DIAGRAM:
- LHD MODEL



EN0969



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>2 CHECK INPUT SIGNAL FOR ECM.</b> Measure voltage between ECM connector and chassis ground. <i>Connector &amp; terminal</i> <i>(B135) No. 9 (+) — Chassis ground (-):</i>	Is the voltage more than 4.5 V?	Go to step 4.	Go to step 3.
<b>3 CHECK INPUT SIGNAL FOR ECM.</b> Measure voltage between ECM connector and chassis ground. <i>Connector &amp; terminal</i> <i>(B135) No. 9 (+) — Chassis ground (-):</i>	Does the voltage change more than 4.5 V by shaking harness and connector of ECM while monitoring the value with voltage meter?	Repair poor contact in ECM connector.	Contact with your Subaru distributor service.  NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.
<b>4 CHECK INPUT SIGNAL FOR ECM.</b> Measure voltage between ECM connector and chassis ground. <i>Connector &amp; terminal</i> <i>(B135) No. 8 (+) — Chassis ground (-):</i>	Is the voltage less than 0.7 V?	Go to step 5.	Contact with your Subaru distributor service.  NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.
<b>5 CHECK HARNESS BETWEEN ECM AND PRESSURE SENSOR CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from pressure sensor. 3) Turn ignition switch to ON. 4) Measure voltage between pressure sensor connector and engine ground. <i>Connector &amp; terminal</i> <i>(E21) No. 3 (+) — Engine ground (-):</i>	Is the voltage more than 4.5 V?	Go to step 6.	Repair open circuit in harness between ECM and pressure sensor connector.
<b>6 CHECK HARNESS BETWEEN ECM AND PRESSURE SENSOR CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from ECM. 3) Measure resistance of harness between ECM and pressure sensor connector. <i>Connector &amp; terminal</i> <i>(B135) No. 8 — (E21) No. 1:</i>	Is the resistance less than 1 $\Omega$ ?	Go to step 7.	Repair open circuit in harness between ECM and pressure sensor connector.
<b>7 CHECK HARNESS BETWEEN ECM AND INTAKE MANIFOLD PRESSURE SENSOR CONNECTOR.</b> Measure resistance of harness between ECM and pressure sensor connector. <i>Connector &amp; terminal</i> <i>(B135) No. 19 — (E21) No. 2:</i>	Is the resistance less than 1 $\Omega$ ?	Go to step 8.	Repair open circuit in harness between ECM and pressure sensor connector.
<b>8 CHECK POOR CONTACT.</b> Check poor contact in pressure sensor connector.	Is there poor contact in pressure sensor connector?	Repair poor contact in pressure sensor connector.	Replace intake manifold pressure sensor. <Ref. to FU(DOHC TURBO)-33, Pressure Sensor.>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>9</b>     <b>CHECK HARNESS BETWEEN ECM AND PRESSURE SENSOR CONNECTOR.</b> 1) Turn ignition switch to OFF and Subaru Select Monitor or the OBD-II general scan tool switch to OFF. 2) Disconnect connector from pressure sensor. 3) Turn ignition switch to ON and Subaru Select Monitor or the OBD-II general scan tool switch to ON. 4) Read data of intake manifold absolute pressure signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt; • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value more than 282 kPa (2121 mmHg, 83.50 inHg)?</p>	<p>Repair battery short circuit in harness between ECM and pressure sensor connector.</p>	<p>Replace pressure sensor. &lt;Ref. to FU(DOHC TURBO)-33, Pressure Sensor.&gt;</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### K: DTC P0111 — INTAKE AIR TEMPERATURE SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Poor driving performance

#### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

#### • WIRING DIAGRAM:



EN0970

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0112, P0113, P0117, P0118 or P0125?	Inspect DTC P0112, P0113, P0117, P0118 or P0125 using "17. List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).>  NOTE: In this case, it is not necessary to inspect DTC P0111.
2	<b>CHECK ENGINE COOLANT TEMPERATURE.</b> 1)Start the engine and warm it up completely. 2)Measure engine coolant temperature using Subaru Select Monitor or OBD-II general scan tool.  NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.> •OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.	Is the engine coolant temperature between 75°C (167°F) and 95°C (203°F)?	Replace mass air flow and intake air temperature sensor. <Ref. to FU(DOHC TURBO)-32, Mass Air Flow and Intake Air Temperature Sensor.>  Inspect DTC P0125 using "17. List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### L: DTC P0112 — INTAKE AIR TEMPERATURE SENSOR CIRCUIT LOW INPUT

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN0970

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK CURRENT DATA.</b>                      1)Start engine.                      2)Read data of intake air temperature sensor signal using Subaru Select Monitor or the OBD-II general scan tool.</p> <p>NOTE:                      •Subaru Select Monitor                      For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt;                      •OBD-II general scan tool                      For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value greater than 55°C (131°F)?</p>	<p>Go to step 2.</p>	<p>Repair poor contact.</p> <p>NOTE:                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Poor contact mass air flow and intake air temperature sensor</li> <li>• Poor contact in ECM</li> <li>• Poor contact in joint connector</li> </ul>
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR AND ECM CONNECTOR.</b>                      1)Turn ignition switch to OFF.                      2)Disconnect connector from mass air flow and intake air temperature sensor.                      3)Turn ignition switch to ON.                      4)Read data of intake air temperature sensor signal using Subaru Select Monitor or the OBD-II general scan tool.</p> <p>NOTE:                      •Subaru Select Monitor                      For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt;                      •OBD-II general scan tool                      For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value less than -36°C (-97°F)?</p>	<p>Replace mass air flow and intake air temperature sensor. &lt;Ref. to FU(DOHC TURBO)-32, Mass Air Flow and Intake Air Temperature Sensor.&gt;</p>	<p>Repair ground short circuit in harness between mass air flow and intake air temperature sensor and ECM connector.</p>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
 ENGINE (DIAGNOSTICS)


**M: DTC P0113 — INTAKE AIR TEMPERATURE SENSOR CIRCUIT HIGH INPUT**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN0970

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1 CHECK CURRENT DATA.</b></p> <p>1) Start engine.</p> <p>2) Read data of intake air temperature sensor signal using Subaru Select Monitor or the OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor</li> </ul> <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>• OBD-II general scan tool</li> </ul> <p>For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value less than <math>-36^{\circ}\text{C}</math> (<math>-97^{\circ}\text{F}</math>)?</p>	<p>Go to step 2.</p>	<p>Repair poor contact.</p> <p>NOTE:</p> <p>In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Poor contact in mass air flow and intake air temperature sensor</li> <li>• Poor contact in ECM</li> <li>• Poor contact in joint connector</li> </ul>
<p><b>2 CHECK HARNESS BETWEEN MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn ignition switch to OFF.</p> <p>2) Disconnect connector from mass air flow and intake air temperature sensor.</p> <p>3) Measure voltage between mass air flow and intake air temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(B3) No. 2 (+) — Engine ground (-):</b></p>	<p>Is the voltage more than 10 V?</p>	<p>Repair battery short circuit in harness between mass air flow and intake air temperature sensor and ECM connector.</p>	<p>Go to step 3.</p>
<p><b>3 CHECK HARNESS BETWEEN INTAKE AIR TEMPERATURE AND PRESSURE SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn ignition switch to ON.</p> <p>2) Measure voltage between mass air flow and intake air temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(B3) No. 2 (+) — Engine ground (-):</b></p>	<p>Is the voltage more than 10 V?</p>	<p>Repair battery short circuit in harness between mass air flow and intake air temperature sensor and ECM connector.</p>	<p>Go to step 4.</p>
<p><b>4 CHECK HARNESS BETWEEN MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>Measure voltage between mass air flow and intake air temperature sensor and pressure sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(B3) No. 2 (+) — Engine ground (-):</b></p>	<p>Is the voltage more than 3 V?</p>	<p>Go to step 5.</p>	<p>Repair harness and connector.</p> <p>NOTE:</p> <p>In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between mass air flow and intake air temperature sensor and ECM connector</li> <li>• Poor contact in mass air flow and intake air temperature sensor</li> <li>• Poor contact in ECM</li> <li>• Poor contact in joint connector</li> </ul>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>5</b></p> <p><b>CHECK HARNESS BETWEEN MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn ignition switch to OFF.</p> <p>2) Measure resistance of harness between mass air flow and intake air temperature sensor and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(B3) No. 5 — Engine ground:</b></p>	<p>Is the resistance less than 5 <math>\Omega</math>?</p>	<p>Replace mass air flow and intake air temperature sensor. &lt;Ref. to FU(DOHC TURBO)-32, Mass Air Flow and Intake Air Temperature Sensor.&gt;</p>	<p>Repair harness and connector.</p> <p><b>NOTE:</b> In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between mass air flow and intake air temperature sensor and ECM connector</li> <li>• Poor contact in mass air flow and intake air temperature sensor</li> <li>• Poor contact in ECM</li> <li>• Poor contact in joint connector</li> </ul>





# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### N: DTC P0117 — ENGINE COOLANT TEMPERATURE SENSOR CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Hard to start
  - Erroneous idling
  - Poor driving performance

#### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

#### • WIRING DIAGRAM:



EN0971

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK CURRENT DATA.</b>                      1)Start engine.                      2)Read data of engine coolant temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:                      •Subaru Select Monitor                      For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt;                      •OBD-II general scan tool                      For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value greater than 150°C (302°F)?</p>	<p>Go to step 2.</p>	<p>Repair poor contact.</p> <p>NOTE:                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Poor contact in engine coolant temperature sensor</li> <li>• Poor contact in ECM</li> <li>• Poor contact in coupling connector</li> <li>• Poor contact in joint connector</li> </ul>
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</b>                      1)Turn ignition switch to OFF.                      2)Disconnect connector from engine coolant temperature sensor.                      3)Turn ignition switch to ON.                      4)Read data of engine coolant temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:                      •Subaru Select Monitor                      For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt;                      •OBD-II general scan tool                      For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value less than -40°C (-40°F)?</p>	<p>Replace engine coolant temperature sensor. &lt;Ref. to FU(DOHC TURBO)-27, Engine Coolant Temperature Sensor.&gt;</p>	<p>Repair ground short circuit in harness between engine coolant temperature sensor and ECM connector.</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## O: DTC P0118 — ENGINE COOLANT TEMPERATURE SENSOR CIRCUIT HIGH INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Hard to start
  - Erroneous idling
  - Poor driving performance

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

### • WIRING DIAGRAM:



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1 CHECK CURRENT DATA.</b>                      1) Start engine.                      2) Read data of engine coolant temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:                      • Subaru Select Monitor                      For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt;                      • OBD-II general scan tool                      For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value less than <math>-40^{\circ}\text{C}</math> (<math>-40^{\circ}\text{F}</math>)?</p>	<p>Go to step 2.</p>	<p>Repair poor contact.</p> <p>NOTE:                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Poor contact in engine coolant temperature sensor</li> <li>• Poor contact in ECM</li> <li>• Poor contact in coupling connector</li> <li>• Poor contact in joint connector</li> </ul>
<p><b>2 CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</b>                      1) Turn ignition switch to OFF.                      2) Disconnect connector from engine coolant temperature sensor.                      3) Measure voltage between engine coolant temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E8) No. 2 (+) — Engine ground (-):</b></p>	<p>Is the voltage more than 10 V?</p>	<p>Repair battery short circuit in harness between ECM and engine coolant temperature sensor connector.</p>	<p>Go to step 3.</p>
<p><b>3 CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</b>                      1) Turn ignition switch to ON.                      2) Measure voltage between engine coolant temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E8) No. 2 (+) — Engine ground (-):</b></p>	<p>Is the voltage more than 10 V?</p>	<p>Repair battery short circuit in harness between ECM and engine coolant temperature sensor connector.</p>	<p>Go to step 4.</p>
<p><b>4 CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</b>                      Measure voltage between engine coolant temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E8) No. 2 (+) — Engine ground (-):</b></p>	<p>Is the voltage more than 4 V?</p>	<p>Go to step 5.</p>	<p>Repair harness and connector.</p> <p>NOTE:                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and engine coolant temperature sensor connector</li> <li>• Poor contact in engine coolant temperature sensor connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> <li>• Poor contact in joint connector</li> </ul>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>5</b></p> <p><b>CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn ignition switch to OFF.</p> <p>2) Measure resistance of harness between engine coolant temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(E8) No. 1 — Engine ground:</b></p>	<p>Is the resistance less than 5 <math>\Omega</math>?</p>	<p>Replace engine coolant temperature sensor. &lt;Ref. to FU(DOHC TURBO)-27, Engine Coolant Temperature Sensor.&gt;</p>	<p>Repair harness and connector.</p> <p><b>NOTE:</b> In this case, repair the following:</p> <ul style="list-style-type: none"><li>• Open circuit in harness between ECM and engine coolant temperature sensor connector</li><li>• Poor contact in engine coolant temperature sensor connector</li><li>• Poor contact in ECM connector</li><li>• Poor contact in coupling connector</li><li>• Poor contact in joint connector</li></ul>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## P: DTC P0121 — THROTTLE POSITION SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (HIGH INPUT) —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance
  - Fuel is cut.

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**
- **LHD MODEL**




EN0973



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

• RHD MODEL



EN0972

Step	Check	Yes	No	
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0122, P0123 or P1507?	Inspect DTC P0122, P0123 or P1507 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0121.	Replace throttle position sensor. <Ref. to FU(DOHC TURBO)-31, Throttle Position Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### Q: DTC P0122 — THROTTLE POSITION SENSOR CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .


- **WIRING DIAGRAM:**
- **LHD MODEL**



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

• RHD MODEL



EN0972

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<p><b>CHECK CURRENT DATA.</b></p> <p>1)Start engine. 2)Read data of throttle position sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt; •OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	Is the value less than 0.1 V?	Go to step 2.	Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause. NOTE: In this case, repair the following: • Poor contact in throttle position sensor connector • Poor contact in ECM connector • Poor contact in coupling connector
2	<p><b>CHECK INPUT SIGNAL FOR ECM.</b></p> <p>Measure voltage between ECM connector and chassis ground while throttle valve is fully closed.</p> <p><b>Connector &amp; terminal</b> <b>(B135) No. 9 (+) — Chassis ground (-):</b></p>	Is the voltage more than 4.5 V?	Go to step 4.	Go to step 3.
3	<p><b>CHECK INPUT SIGNAL FOR ECM.</b></p> <p>Measure voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b> <b>(B135) No. 9 (+) — Chassis ground (-):</b></p>	Does the voltage change more than 4.5 V by shaking harness and connector of ECM while monitoring the value with voltage meter?	Repair poor contact in ECM connector.	Contact with your Subaru distributor service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.
4	<p><b>CHECK INPUT SIGNAL FOR ECM.</b></p> <p>Measure voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b> <b>(B135) No. 7 (+) — Chassis ground (-):</b></p>	Is the voltage less than 0.1 V?	Go to step 6.	Go to step 5.
5	<p><b>CHECK INPUT SIGNAL FOR ECM. (USING SUBARU SELECT MONITOR.)</b></p> <p>Measure voltage between ECM connector and chassis ground.</p>	Does the voltage change more than 0.1 V by shaking harness and connector of ECM while monitoring the value with Subaru Select Monitor?	Repair poor contact in ECM connector.	Go to step 6.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>6</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND THROTTLE POSITION SENSOR CONNECTOR.</b></p> <p>1) Turn ignition switch to OFF.                      2) Disconnect connectors from throttle position sensor.                      3) Turn ignition switch to ON.                      4) Measure voltage between throttle position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E13) No. 1 (+) — Engine ground (-):</b></p>	<p>Is the voltage more than 4.5 V?</p>	<p>Go to step 7.</p>	<p>Repair harness and connector.</p> <p>NOTE:                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between throttle position sensor and ECM connector</li> <li>• Poor contact in throttle position sensor connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> <li>• Poor contact in joint connector</li> </ul>
<p><b>7</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND THROTTLE POSITION SENSOR CONNECTOR.</b></p> <p>1) Turn ignition switch to OFF.                      2) Measure resistance of harness between ECM connector and throttle position sensor connector.</p> <p><b>Connector &amp; terminal</b>  <b>(B135) No. 7 — (E13) No. 3:</b></p>	<p>Is the resistance less than 1 <math>\Omega</math>?</p>	<p>Go to step 8.</p>	<p>Repair harness and connector.</p> <p>NOTE:                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between throttle position sensor and ECM connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in throttle position sensor connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>8</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND THROTTLE POSITION SENSOR CONNECTOR.</b></p> <p>Measure resistance of harness between throttle position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E13) No. 3 — Engine ground:</b></p>	<p>Is the resistance less than 10 <math>\Omega</math>?</p>	<p>Repair ground short circuit in harness between throttle position sensor and ECM connector.</p>	<p>Go to step 9.</p>
<p><b>9</b></p> <p><b>CHECK POOR CONTACT.</b></p> <p>Check poor contact in throttle position sensor connector.</p>	<p>Is there poor contact in throttle position sensor connector?</p>	<p>Repair poor contact in throttle position sensor connector.</p>	<p>Replace throttle position sensor.                      &lt;Ref. to FU(DOHC TURBO)-31, Throttle Position Sensor.&gt;</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### R: DTC P0123 — THROTTLE POSITION SENSOR CIRCUIT HIGH INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**
- **LHD MODEL**




EN0973

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

• RHD MODEL



EN0972

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK CURRENT DATA.</b></p> <p>1)Start engine. 2)Read data of throttle position sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt; •OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value more than 4.9 V?</p>	<p>Go to step 2.</p>	<p>Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause.</p> <p>NOTE: In this case, repair the following: • Poor contact in throttle position sensor connector • Poor contact in ECM connector • Poor contact in coupling connector</p>
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN THROTTLE POSITION SENSOR AND ECM CONNECTOR.</b></p> <p>1)Turn ignition switch to OFF. 2)Disconnect connector from throttle position sensor. 3)Measure resistance of harness between throttle position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(E13) No. 2 — Engine ground:</b></p>	<p>Is the resistance less than 5 Ω?</p>	<p>Go to step 3.</p>	<p>Repair harness and connector.</p> <p>NOTE: In this case, repair the following: • Open circuit in harness between throttle position sensor and ECM connector • Poor contact in coupling connector • Poor contact in joint connector</p>
<p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN THROTTLE POSITION SENSOR AND ECM CONNECTOR.</b></p> <p>1)Turn ignition switch to ON. 2)Measure voltage between throttle position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(E13) No. 3 (+) — Engine ground (-):</b></p>	<p>Is the voltage more than 4.9 V?</p>	<p>Repair battery short circuit in harness between throttle position sensor and ECM connector. After repair, replace ECM. &lt;Ref. to FU(DOHC TURBO)-45, Engine Control Module.&gt;</p>	<p>Replace throttle position sensor. &lt;Ref. to FU(DOHC TURBO)-31, Throttle Position Sensor.&gt;</p>





# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## S: DTC P0125 — INSUFFICIENT COOLANT TEMPERATURE FOR CLOSED LOOP FUEL CONTROL —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Engine would not return to idling.

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN0971

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0117 or P0118?	Inspect DTC P0117 or P0118 using "17. List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0125.
2	<b>CHECK ENGINE COOLING SYSTEM.</b> NOTE: Check the following items. <ul style="list-style-type: none"><li>•Thermostat open stuck</li><li>•Coolant level</li><li>•Coolant freeze</li><li>•Tire diameter</li></ul>	Is there a fault in engine cooling system?	Replace thermostat. <Ref. to CO-35, Thermostat.>  Replace engine coolant temperature sensor. <Ref. to FU(DOHC TURBO)-27, Engine Coolant Temperature Sensor.>

## **DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**

ENGINE (DIAGNOSTICS)

---

### **T: DTC P0131 — FRONT OXYGEN (A/F) SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (LOW INPUT) —**

**NOTE:**

For the diagnostic procedure, refer to DTC P0132. <Ref. to EN(DOHC TURBO)-134, DTC P0132 — FRONT OXYGEN (A/F) SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (HIGH INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## U: DTC P0132 — FRONT OXYGEN (A/F) SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (HIGH INPUT) —


### • DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

### • WIRING DIAGRAM:



EN0966

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1</b> <b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0031, P0032, P1131, P1134 or P1139?	Inspect DTC P0031, P0032, P1131, P1134 or P1139 using "17. List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
<b>2</b> <b>CHECK FRONT (A/F) OXYGEN SENSOR DATA.</b> 1) Start engine. 2) While observing the Subaru Select Monitor or OBD-II general scan tool screen, warm-up the engine until coolant temperature is above 70°C (158°F). If the engine is already warmed-up, operate at idle speed for at least 1 minute. 3) Read data of front oxygen (A/F) sensor signal using Subaru Select Monitor or OBD-II general scan tool. NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.	Is the value equal to or more than 0.85 and equal to less than 1.15 in idling?	Go to step 3.	Go to step 4.
<b>3</b> <b>CHECK REAR OXYGEN SENSOR SIGNAL.</b> 1) Race engine at speeds from idling to 5,000 rpm for a total of 5 cycles. NOTE: To increase engine speed to 5,000 rpm, slowly depress accelerator pedal, taking approximately 5 seconds, and quickly release accelerator pedal to decrease engine speed. 2) Operate the LED operation mode for engine. NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "LED OPERATION MODE FOR ENGINE". <Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.>	Does the LED of {Rear O2 Rich Signal} blink?	Repair poor contact in front oxygen (A/F) sensor and rear oxygen sensor connector.	Check rear oxygen sensor circuit. <Ref. to FU(DOHC TURBO)-43, Rear Oxygen Sensor.>
<b>4</b> <b>CHECK EXHAUST SYSTEM.</b> Check exhaust system parts. NOTE: Check the following items. • Loose installation of portions • Damage (crack, hole etc.) of parts • Looseness of front oxygen (A/F) sensor • Looseness and ill fitting of parts between front oxygen (A/F) sensor and rear oxygen sensor	Is there a fault in exhaust system?	Repair or replace faulty parts.	Replace front oxygen (A/F) sensor. <Ref. to FU(DOHC TURBO)-41, Front Oxygen (A/F) Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### V: DTC P0133 — FRONT OXYGEN (A/F) SENSOR CIRCUIT SLOW RESPONSE

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**



EN0966



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0031, P0032, P0131, P0132, P1130, P1131, P1134 or P1139?	Inspect DTC P0031, P0032, P0131, P0132, P1130, P1131, P1134 or P1139 using "17. List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).>  NOTE: In this case, it is not necessary to inspect DTC P0133.	Go to step 2.
2	<b>CHECK EXHAUST SYSTEM.</b> NOTE: Check the following items. <ul style="list-style-type: none"><li>•Loose installation of front portion of exhaust pipe onto cylinder heads</li><li>•Loose connection between front exhaust pipe and front catalytic converter</li><li>•Damage of exhaust pipe resulting in a hole</li></ul>	Is there a fault in exhaust system?	Repair exhaust system.	Replace front oxygen (A/F) sensor. <Ref. to FU(DOHC TURBO)-41, Front Oxygen (A/F) Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### W: DTC P0136 — REAR OXYGEN SENSOR CIRCUIT MALFUNCTION —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**



	Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0131 or P0132?	Go to step 2.	Go to step 3.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>2 CHECK FAILURE CAUSE OF P0131 or P0132.</b> Inspect DTC P0131 or P0132 using "17. List of Diagnostic Trouble Code (DTC)". &lt;Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).&gt;</p>	Is the failure cause of P0131 or P0132 in the fuel system?	Check fuel system.  NOTE: In this case, it is not necessary to inspect DTC P0136.	Go to step 3.
<p><b>3 CHECK REAR OXYGEN SENSOR DATA.</b> 1) Warm-up the engine until engine coolant temperature is above 70°C (158°F), and keep the engine speed at 2,000 rpm to 3,000 rpm for two minutes. 2) Read data of rear oxygen sensor signal using Subaru Select Monitor or OBD-II general scan tool.  NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt; • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	Does the value fluctuate?	Go to step 7.	Go to step 4.
<p><b>4 CHECK REAR OXYGEN SENSOR DATA.</b> Read data of rear oxygen sensor signal using Subaru Select Monitor or OBD-II General Scan Tool.</p>	Is the value fixed between 0.2 and 0.4 V?	Go to step 5.	Replace rear oxygen sensor. <Ref. to FU(DOHC TURBO)-43, Rear Oxygen Sensor.>
<p><b>5 CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connectors from ECM and rear oxygen sensor. 3) Measure resistance of harness between ECM and rear oxygen sensor connector. <b>Connector &amp; terminal</b> <b>(B135) No. 26 — (B19) No. 4:</b></p>	Is the resistance more than 3 Ω?	Repair open circuit in harness between ECM and rear oxygen sensor connector.	Go to step 6.
<p><b>6 CHECK HARNESS BETWEEN REAR OXYGEN SENSOR AND ECM CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from rear oxygen sensor. 3) Turn ignition switch to ON. 4) Measure voltage between rear oxygen sensor harness connector and engine ground or chassis ground. <b>Connector &amp; terminal</b> <b>(B19) No. 3 (+) — Engine ground (-):</b></p>	Is the voltage more than 0.2 V?	Replace rear oxygen sensor. <Ref. to FU(DOHC TURBO)-43, Rear Oxygen Sensor.>	Repair harness and connector.  NOTE: In this case, repair the following: • Open circuit in harness between rear oxygen sensor and ECM connector • Poor contact in rear oxygen sensor connector • Poor contact in ECM connector
<p><b>7 CHECK EXHAUST SYSTEM.</b> Check exhaust system parts.  NOTE: Check the following items. • Loose installation of portions • Damage (crack, hole etc.) of parts • Looseness and ill fitting of parts between front oxygen (A/F) sensor and rear oxygen sensor</p>	Is there a fault in exhaust system?	Repair or replace faulty parts.	Replace rear oxygen sensor. <Ref. to FU(DOHC TURBO)-43, Rear Oxygen Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### X: DTC P0139 — REAR OXYGEN SENSOR CIRCUIT SLOW RESPONSE —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**



EN0967

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0136?	Inspect DTC P0136 using "17. List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).>  NOTE: In this case, it is not necessary to inspect DTC P0139.	Replace rear oxygen sensor. <Ref. to FU(DOHC TURBO)-43, Rear Oxygen Sensor.>

## **DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**

ENGINE (DIAGNOSTICS)

---

### **Y: DTC P0171 — FUEL TRIM MALFUNCTION (A/F TOO LEAN) —**

**NOTE:**

For the diagnostic procedure, refer to DTC P0172. <Ref. to EN(DOHC TURBO)-143, DTC P0172 — FUEL TRIM MALFUNCTION (A/F TOO RICH) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

**Z: DTC P0172 — FUEL TRIM MALFUNCTION (A/F TOO RICH) —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

**After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .**

Step	Check	Yes	No	
1	<b>CHECK EXHAUST SYSTEM.</b>	Are there holes or loose bolts on exhaust system?	Repair exhaust system. Go to step 2.	
2	<b>CHECK AIR INTAKE SYSTEM.</b>	Are there holes, loose bolts or disconnection of hose on air intake system?	Repair air intake system. Go to step 3.	
3	<p><b>CHECK FUEL PRESSURE.</b></p> <p><b>Warning:</b></p> <ul style="list-style-type: none"> <li>•Place “NO FIRE” signs near the working area.</li> <li>•Be careful not to spill fuel on the floor.</li> </ul> <p>1)Release fuel pressure.                      (1) Disconnect connector from fuel pump relay.                      (2) Start the engine and run it until it stalls.                      (3) After the engine stalls, crank it for five more seconds.                      (4) Turn ignition switch to OFF.</p> <p>2)Connect connector to fuel pump relay.                      3)Disconnect fuel delivery hose from fuel filter, and connect fuel pressure gauge.                      4)Install fuel filler cap.                      5)Start the engine and idle while gear position is neutral.                      6)Measure fuel pressure while disconnecting pressure regulator vacuum hose from intake manifold.</p> <p><b>Warning:</b>  <b>Before removing fuel pressure gauge, release fuel pressure.</b></p> <p><b>NOTE:</b>                      If fuel pressure does not increase, squeeze fuel return hose 2 to 3 times, then measure fuel pressure again.</p>	Is fuel pressure between 284 and 314 kPa (2.9 — 3.2 kg/cm <sup>2</sup> , 41 — 46 psi)?	Go to step 4.	Repair the following items. <b>Fuel pressure too high</b> <ul style="list-style-type: none"> <li>• Clogged fuel return line or bent hose</li> </ul> <b>Fuel pressure too low</b> <ul style="list-style-type: none"> <li>• Improper fuel pump discharge</li> <li>• Clogged fuel supply line</li> </ul>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
4	<p><b>CHECK FUEL PRESSURE.</b> After connecting pressure regulator vacuum hose, measure fuel pressure.</p> <p><b>Warning:</b> <b>Before removing fuel pressure gauge, release fuel pressure.</b></p> <p>NOTE: •If fuel pressure does not increase, squeeze fuel return hose 2 to 3 times, then measure fuel pressure again. •If out of specification as measured at this step, check or replace pressure regulator and pressure regulator vacuum hose.</p>	Is fuel pressure between 206 and 235 kPa (2.1 — 2.4 kg/cm <sup>2</sup> , 30 — 34 psi)?	Go to step 5.	<p>Repair the following items.</p> <p><b>Fuel pressure too high</b></p> <ul style="list-style-type: none"> <li>• Faulty pressure regulator</li> <li>• Clogged fuel return line or bent hose</li> </ul> <p><b>Fuel pressure too low</b></p> <ul style="list-style-type: none"> <li>• Faulty pressure regulator</li> <li>• Improper fuel pump discharge</li> <li>• Clogged fuel supply line</li> </ul>
5	<p><b>CHECK ENGINE COOLANT TEMPERATURE SENSOR.</b> 1)Start the engine and warm-up completely. 2)Read data of engine coolant temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt; •OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	Is temperature greater than 60°C (140°F)?	Go to step 6.	Replace engine coolant temperature sensor. <Ref. to FU(DOHC TURBO)-27, Engine Coolant Temperature Sensor.>
6	<p><b>CHECK INTAKE MANIFOLD PRESSURE SENSOR.</b> 1)Start the engine and warm-up engine until coolant temperature is greater than 60°C (140°F). 2)Place the shift lever in neutral position. 3)Turn A/C switch to OFF. 4)Turn all accessory switches to OFF. 5)Read data of intake manifold pressure sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt; •OBD-II general scan tool For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</p> <p>Specification: •Intake manifold absolute pressure</p> <p><b>Ignition ON</b> <b>73.3 — 106.6 kPa (550 — 800 mmHg, 21.65 — 31.50 inHg)</b></p> <p><b>Idling</b> <b>24.0 — 41.3 kPa (180 — 310 mmHg, 7.09 — 12.20 inHg)</b></p>	Is the value within the specifications?	Go to step 7.	Replace mass air flow and intake manifold pressure sensor. <Ref. to FU(DOHC TURBO)-32, Mass Air Flow and Intake Air Temperature Sensor.>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>7</b></p> <p><b>CHECK INTAKE AIR TEMPERATURE SENSOR.</b></p> <p>1)Start the engine and warm-up engine until coolant temperature is greater than 60°C (140°F).</p> <p>2)Place the shift lever in neutral position.</p> <p>3)Turn A/C switch to OFF.</p> <p>4)Turn all accessory switches to OFF.</p> <p>5)Open front hood.</p> <p>6)Measure ambient temperature.</p> <p>7)Read data of intake manifold pressure sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>•Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt;</li> <li>•OBD-II general scan tool For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</li> </ul>	<p>Is value obtained when ambient temperature is subtracted from intake air temperature greater than -10°C (14°F) and less than 50°C (122°F)?</p>	<p>Contact with your Subaru distributor service.</p> <p>NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p>	<p>Check mass air flow and intake air temperature sensor. &lt;Ref. to FU(DOHC TURBO)-32, Mass Air Flow and Intake Air Temperature Sensor.&gt;</p>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
 ENGINE (DIAGNOSTICS)


**AA:DTC P0244 — WASTEGATE CONTROL SOLENOID VALVE MALFUNCTION (HIGH INPUT) —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN0974

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0245 or P0246?	Inspect DTC P0245 or P0246 using "17. List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).>  NOTE: In this case, it is not necessary to inspect DTC P0121.	Replace wastegate control solenoid valve. <Ref. to FU(DOHC TURBO)-40, Wastegate Control Solenoid Valve.>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
 ENGINE (DIAGNOSTICS)


**AB:DTC P0245 — WASTEGATE CONTROL SOLENOID VALVE CIRCUIT LOW INPUT —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN0974

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK OUTPUT SIGNAL FROM ECM.</b>                      1) Turn ignition switch to ON.                      2) Measure voltage between ECM and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B137) No. 24 (+) — Chassis ground (-):</b></p>	<p>Is the voltage more than 10 V?</p>	<p>Even if MIL lights up, the circuit has returned to a normal condition at this time. Contact with your Subaru distributor.                       NOTE:                      Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p>	<p>Go to step 2.</p>
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN WASTEGATE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b>                      1) Turn ignition switch to OFF.                      2) Disconnect connectors from wastegate control solenoid valve and ECM.                      3) Measure resistance of harness between wastegate control solenoid valve connector and engine ground.  <b>Connector &amp; terminal</b>  <b>(B127) No. 1 — Engine ground:</b></p>	<p>Is the resistance less than 10 <math>\Omega</math>?</p>	<p>Repair ground short circuit in harness between ECM and wastegate control solenoid valve connector.</p>	<p>Go to step 3.</p>
<p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN WASTEGATE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b>                      Measure resistance of harness between ECM and wastegate control solenoid valve of harness connector.  <b>Connector &amp; terminal</b>  <b>(B137) No. 24 — (B127) No. 1:</b></p>	<p>Is the resistance less than 1 <math>\Omega</math>?</p>	<p>Go to step 4.</p>	<p>Repair open circuit in harness between ECM and wastegate control solenoid valve connector.                       NOTE:                      In this case, repair the following:                      • Open circuit in harness between ECM and wastegate control solenoid valve connector</p>
<p><b>4</b></p> <p><b>CHECK WASTEGATE CONTROL SOLENOID VALVE.</b>                      1) Remove purge control solenoid valve.                      2) Measure resistance between purge control solenoid valve terminals.  <b>Terminals</b>  <b>No. 1 — No. 2:</b></p>	<p>Is the resistance between 30 and 34 <math>\Omega</math>?</p>	<p>Go to step 5.</p>	<p>Replace wastegate control solenoid valve. &lt;Ref. to FU(DOHC TURBO)-40, Wastegate Control Solenoid Valve.&gt;</p>
<p><b>5</b></p> <p><b>CHECK POWER SUPPLY TO WASTEGATE CONTROL SOLENOID VALVE.</b>                      1) Turn ignition switch to ON.                      2) Measure voltage between wastegate control solenoid valve and engine ground.  <b>Connector &amp; terminal</b>  <b>(B127) No. 2 (+) — Engine ground (-):</b></p>	<p>Is the voltage more than 10 V?</p>	<p>Go to step 6.</p>	<p>Repair open circuit in harness between main relay and wastegate control solenoid valve connector.</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
6	<b>CHECK POOR CONTACT.</b> Check poor contact in wastegate control solenoid valve connector.	Is there poor contact in wastegate control solenoid valve connector?	Repair poor contact in wastegate control solenoid valve connector.	Contact with your Subaru distributor. <b>NOTE:</b> Inspection by DTM is required, because probable cause is deterioration of multiple parts.



**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
 ENGINE (DIAGNOSTICS)


**AC:DTC P0246 — WASTEGATE CONTROL SOLENOID VALVE CIRCUIT HIGH INPUT —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**



EN0974



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1</b> <b>CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Turn ignition switch to ON. 2) Measure voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B137) No. 24 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V?	Go to step 3.	Go to step 2.
<b>2</b> <b>CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Replace ECM. <Ref. to FU(DOHC TURBO)-45, Engine Control Module.>
<b>3</b> <b>CHECK HARNESS BETWEEN WASTEGATE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from wastegate control solenoid valve. 3) Turn ignition switch to ON. 4) Measure voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B137) No. 24 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V?	Repair battery short circuit in harness between ECM and wastegate control solenoid valve connector. After repair, replace ECM. <Ref. to FU(DOHC TURBO)-45, Engine Control Module.>	Go to step 4.
<b>4</b> <b>CHECK WASTEGATE CONTROL SOLENOID VALVE.</b> 1) Turn ignition switch to OFF. 2) Measure resistance between wastegate control solenoid valve terminals. <b>Terminals</b> <b>No. 1 — No. 2:</b>	Is the resistance less than 1 $\Omega$ ?	Replace wastegate control solenoid valve <Ref. to FU(DOHC TURBO)-40, Wastegate Control Solenoid Valve.> and ECM <Ref. to FU(DOHC TURBO)-45, Engine Control Module.>	Go to step 5.
<b>5</b> <b>CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Replace ECM. <Ref. to FU(DOHC TURBO)-45, Engine Control Module.>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**AD:DTC P0301 — CYLINDER 1 MISFIRE DETECTED —**

NOTE:

For the diagnostic procedure, refer to DTC P0304. <Ref. to EN(DOHC TURBO)-156, DTC P0304 — CYLINDER 4 MISFIRE DETECTED —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

**AE:DTC P0302 — CYLINDER 2 MISFIRE DETECTED —**

NOTE:

For the diagnostic procedure, refer to DTC P0304. <Ref. to EN(DOHC TURBO)-156, DTC P0304 — CYLINDER 4 MISFIRE DETECTED —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

**AF:DTC P0303 — CYLINDER 3 MISFIRE DETECTED —**

NOTE:

For the diagnostic procedure, refer to DTC P0304. <Ref. to EN(DOHC TURBO)-156, DTC P0304 — CYLINDER 4 MISFIRE DETECTED —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>



## DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

---

### AG:DTC P0304 — CYLINDER 4 MISFIRE DETECTED —

- **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault
- Immediately at fault recognition (A misfire which could damage catalyst occurs.)

- **TROUBLE SYMPTOM:**

- Engine stalls.
- Erroneous idling
- Rough driving







**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)

• LHD MODEL




EN0964

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### • RHD MODEL



EN0965

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No	
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0106, P0107, P0108, P0117, P0118 or P0125?	Inspect DTC P0106, P0107, P0108, P0117, P0118 or P0125 using "17. List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).>  NOTE: In this case, it is not necessary to inspect DTC P0301, P0302, P0303 and P0304.	Go to step 2.
2	<b>CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Turn ignition switch to ON. 2) Measure voltage between ECM connector and chassis ground on faulty cylinders. <b>Connector &amp; terminal</b> #1 (B137) No. 1 (+) — Chassis ground (-): #2 (B136) No. 6 (+) — Chassis ground (-): #3 (B136) No. 5 (+) — Chassis ground (-): #4 (B136) No. 4 (+) — Chassis ground (-):	Is the voltage more than 10 V?	Go to step 7.	Go to step 3.
3	<b>CHECK HARNESS BETWEEN FUEL INJECTOR AND ECM CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from fuel injector on faulty cylinders. 3) Disconnect connector from ECM. 4) Measure voltage between ECM connector and engine ground on faulty cylinders. <b>Connector &amp; terminal</b> #1 (E5) No. 1 — Engine ground: #2 (E16) No. 1 — Engine ground: #3 (E6) No. 1 — Engine ground: #4 (E17) No. 1 — Engine ground:	Is the resistance less than 10 Ω?	Repair ground short circuit in harness between fuel injector and ECM connector.	Go to step 4.
4	<b>CHECK HARNESS BETWEEN FUEL INJECTOR AND ECM CONNECTOR.</b> Measure resistance of harness connector between ECM connector and fuel injector on faulty cylinders. <b>Connector &amp; terminal</b> #1 (B137) No. 1 — (E5) No. 1: #2 (B136) No. 6 — (E16) No. 1: #3 (B136) No. 5 — (E6) No. 1: #4 (B136) No. 4 — (E17) No. 1:	Is the resistance less than 1 Ω?	Go to step 5.	Repair harness and connector.  NOTE: In this case, repair the following: • Open circuit in harness between ECM and fuel injector connector • Poor contact in coupling connector
5	<b>CHECK FUEL INJECTOR.</b> Measure resistance between fuel injector terminals on faulty cylinder. <b>Terminals</b> No. 1 — No. 2:	Is the resistance between 5 and 20 Ω?	Go to step 6.	Replace faulty fuel injector. <Ref. to FU(DOHC TURBO)-35, Fuel Injector.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>6</b></p> <p><b>CHECK POWER SUPPLY LINE.</b>                      1) Turn ignition switch to ON.                      2) Measure voltage between fuel injector and engine ground on faulty cylinders.</p> <p><b>Connector &amp; terminal</b>  <b>#1 (E5) No. 2 (+) — Engine ground (-):</b>  <b>#2 (E16) No. 2 (+) — Engine ground (-):</b>  <b>#3 (E6) No. 2 (+) — Engine ground (-):</b>  <b>#4 (E17) No. 2 (+) — Engine ground (-):</b></p>	Is the voltage more than 10 V?	Repair poor contact in all connectors in fuel injector circuit.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between main relay and fuel injector connector on faulty cylinders</li> <li>• Poor contact in coupling connector</li> <li>• Poor contact in main relay connector</li> <li>• Poor contact in fuel injector connector on faulty cylinders</li> </ul>
<p><b>7</b></p> <p><b>CHECK HARNESS BETWEEN FUEL INJECTOR AND ECM CONNECTOR.</b>                      1) Turn ignition switch to OFF.                      2) Disconnect connector from fuel injector on faulty cylinder.                      3) Turn ignition switch to ON.                      4) Measure voltage between ECM connector and chassis ground on faulty cylinders.</p> <p><b>Connector &amp; terminal</b>  <b>#1 (B137) No. 1 (+) — Chassis ground (-):</b>  <b>#2 (B136) No. 6 (+) — Chassis ground (-):</b>  <b>#3 (B136) No. 5 (+) — Chassis ground (-):</b>  <b>#4 (B136) No. 4 (+) — Chassis ground (-):</b></p>	Is the voltage more than 10 V?	Repair battery short circuit in harness between ECM and fuel injector. After repair, replace ECM. <Ref. to FU(DOHC TURBO)-45, Engine Control Module.>	Go to step <b>8</b> .
<p><b>8</b></p> <p><b>CHECK FUEL INJECTOR.</b>                      1) Turn ignition switch to OFF.                      2) Measure resistance between fuel injector terminals on faulty cylinder.</p> <p><b>Terminals</b>  <b>No. 1 — No. 2:</b></p>	Is the resistance less than 1 Ω?	Replace faulty fuel injector <Ref. to FU(DOHC TURBO)-35, Fuel Injector.> and ECM <Ref. to FU(DOHC TURBO)-45, Engine Control Module.>	Go to step <b>9</b> .
<p><b>9</b></p> <p><b>CHECK INSTALLATION OF CAMSHAFT POSITION SENSOR/CRANKSHAFT POSITION SENSOR.</b></p>	Is camshaft position sensor or crankshaft position sensor loosely installed?	Tighten camshaft position sensor or crankshaft position sensor.	Go to step <b>10</b> .
<p><b>10</b></p> <p><b>CHECK CRANKSHAFT SPROCKET.</b>                      Remove timing belt cover.</p>	Is crankshaft sprocket rusted or does it have broken teeth?	Replace crankshaft sprocket. <Ref. to ME(DOHC TURBO)-57, Crankshaft Sprocket.>	Go to step <b>11</b> .



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>11 CHECK INSTALLATION CONDITION OF TIMING BELT.</b> Turn crankshaft using ST, and align alignment mark on crankshaft sprocket with alignment mark on cylinder block. ST 499987500CRANKSHAFT SOCKET	Is timing belt dislocated from its proper position?	Repair installation condition of timing belt. <Ref. to ME(DOHC TURBO)-47, Timing Belt Assembly.>	Go to step <b>12</b> .
<b>12 CHECK FUEL LEVEL.</b>	Is the fuel meter indication higher than the "Lower" level?	Go to step <b>13</b> .	Replenish fuel so fuel meter indication is higher than the "Lower" level. After replenishing fuel, Go to step <b>13</b> .
<b>13 CHECK STATUS OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL).</b> 1)Clear memory using Subaru Select Monitor. <Ref. to EN(DOHC TURBO)-38, Clear Memory Mode.> 2)Start engine, and drive the vehicle more than 10 minutes.	Is the MIL coming on or blinking?	Go to step <b>15</b> .	Go to step <b>14</b> .
<b>14 CHECK CAUSE OF MISFIRE DIAGNOSED.</b>	Was the cause of misfire diagnosed when the engine is running?	Finish diagnostics operation, if the engine has no abnormality.  NOTE: Ex. Remove spark plug cord, etc.	Repair poor contact.  NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Poor contact in ignitor connector</li> <li>• Poor contact in ignition coil connector</li> <li>• Poor contact in fuel injector connector on faulty cylinders</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>
<b>15 CHECK AIR INTAKE SYSTEM.</b>	Is there a fault in air intake system?	Repair air intake system.  NOTE: Check the following items: <ul style="list-style-type: none"> <li>• Are there air leaks or air suction caused by loose or dislocated nuts and bolts?</li> <li>• Are there cracks or any disconnection of hoses?</li> </ul>	Go to step <b>16</b> .

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>16 CHECK MISFIRE SYMPTOM.</b> 1) Turn ignition switch to ON. 2) Read diagnostic trouble code (DTC). • Subaru Select Monitor <Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Operation Manual. NOTE: Perform diagnosis according to the items listed below.	Does the Subaru Select Monitor or OBD-II general scan tool indicate only one DTC?	Go to step 21.	Go to step 17.
<b>17 CHECK DIAGNOSTIC TROUBLE CODE (DTC) ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0301 and P0302?	Go to step 22.	Go to step 18.
<b>18 CHECK DIAGNOSTIC TROUBLE CODE (DTC) ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0303 and P0304?	Go to step 23.	Go to step 19.
<b>19 CHECK DIAGNOSTIC TROUBLE CODE (DTC) ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0301 and P0303?	Go to step 24.	Go to step 20.
<b>20 CHECK DIAGNOSTIC TROUBLE CODE (DTC) ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0302 and P0304?	Go to step 25.	Go to step 26.
<b>21 ONLY ONE CYLINDER</b>	Is there a fault in that cylinder?	Repair or replace faulty parts. NOTE: Check the following items. • Spark plug • Spark plug cord • Fuel injector • Compression ratio	Go to DTC P0171 and P0172. <Ref. to EN(DOHC TURBO)-142, DTC P0171 — FUEL TRIM MALFUNCTION (A/F TOO LEAN) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
<b>22 GROUP OF #1 AND #2 CYLINDERS</b>	Are there faults in #1 and #2 cylinders?	Repair or replace faulty parts. NOTE: • Check the following items. • Spark plugs • Fuel injectors • Ignition coil • Compression ratio • If no abnormal is discovered, check for "IGNITION CONTROL SYSTEM" of #1 and #2 cylinders side. <Ref. to EN(DOHC TURBO)-60, Ignition Control System.>	Go to DTC P0171 and P0172. <Ref. to EN(DOHC TURBO)-142, DTC P0171 — FUEL TRIM MALFUNCTION (A/F TOO LEAN) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No	
23	<b>GROUP OF #3 AND #4 CYLINDERS</b>	Are there faults in #3 and #4 cylinders?	<p>Repair or replace faulty parts.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Check the following items.                             <ul style="list-style-type: none"> <li>• Spark plugs</li> <li>• Fuel injectors</li> <li>• Ignition coil</li> </ul> </li> <li>• If no abnormal is discovered, check for "16. D: IGNITION CONTROL SYSTEM" of #3 and #4 cylinders side. &lt;Ref. to EN(DOHC TURBO)-60, Ignition Control System.&gt;</li> </ul>	<p>Go to DTC P0171 and P0172. &lt;Ref. to EN(DOHC TURBO)-142, DTC P0171 — FUEL TRIM MALFUNCTION (A/F TOO LEAN) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</p>
24	<b>GROUP OF #1 AND #3 CYLINDERS</b>	Are there faults in #1 and #3 cylinders?	<p>Repair or replace faulty parts.</p> <p>NOTE:</p> <p>Check the following items.</p> <ul style="list-style-type: none"> <li>• Spark plugs</li> <li>• Fuel injectors</li> <li>• Skipping timing belt teeth</li> </ul>	<p>Go to DTC P0171 and P0172. &lt;Ref. to EN(DOHC TURBO)-142, DTC P0171 — FUEL TRIM MALFUNCTION (A/F TOO LEAN) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</p>
25	<b>GROUP OF #2 AND #4 CYLINDERS</b>	Are there faults in #2 and #4 cylinders?	<p>Repair or replace faulty parts.</p> <p>NOTE:</p> <p>Check the following items.</p> <ul style="list-style-type: none"> <li>• Spark plugs</li> <li>• Fuel injectors</li> <li>• Compression ratio</li> <li>• Skipping timing belt teeth</li> </ul>	<p>Go to DTC P0171 and P0172. &lt;Ref. to EN(DOHC TURBO)-142, DTC P0171 — FUEL TRIM MALFUNCTION (A/F TOO LEAN) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</p>
26	<b>CYLINDER AT RANDOM</b>	Is the engine idle rough?	<p>Go to DTC P0171 and P0172. &lt;Ref. to EN(DOHC TURBO)-142, DTC P0171 — FUEL TRIM MALFUNCTION (A/F TOO LEAN) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</p>	<p>Repair or replace faulty parts.</p> <p>NOTE:</p> <p>Check the following items.</p> <ul style="list-style-type: none"> <li>• Spark plugs</li> <li>• Fuel injectors</li> <li>• Compression ratio</li> </ul>


**AH:DTC P0327 — KNOCK SENSOR CIRCUIT LOW INPUT —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Poor driving performance
  - Knocking occurs.

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**



EN0975

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1</b> <b>CHECK HARNESS BETWEEN KNOCK SENSOR AND ECM CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from ECM. 3) Measure resistance between ECM harness connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B135) No. 4 — Chassis ground:</b>	Is the resistance more than 700 kΩ?	Go to step 2.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between knock sensor and ECM connector</li> <li>• Poor contact in knock sensor connector</li> <li>• Poor contact in coupling connector</li> </ul>
<b>2</b> <b>CHECK KNOCK SENSOR.</b> 1) Disconnect connector from knock sensor. 2) Measure resistance between knock sensor connector terminal and engine ground. <b>Terminal</b> <b>No. 2 — Engine ground:</b>	Is the resistance more than 700 kΩ?	Go to step 3.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between knock sensor and ECM connector</li> <li>• Poor contact in knock sensor connector</li> <li>• Poor contact in coupling connector</li> </ul>
<b>3</b> <b>CHECK CONDITION OF KNOCK SENSOR INSTALLATION.</b>	Is the knock sensor installation bolt tightened securely?	Replace knock sensor. <Ref. to FU(DOHC TURBO)-30, Knock Sensor.>	Tighten knock sensor installation bolt securely.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### AI: DTC P0328 — KNOCK SENSOR CIRCUIT HIGH INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Poor driving performance
  - Knocking occurs.

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**



EN0975

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1</b> <b>CHECK HARNESS BETWEEN KNOCK SENSOR AND ECM CONNECTOR.</b> Measure resistance of harness between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B135) No. 4 — Chassis ground:</b>	Is the resistance less than 400 k $\Omega$ ?	Go to step 2.	Go to step 3.
<b>2</b> <b>CHECK KNOCK SENSOR.</b> 1)Disconnect connector from knock sensor. 2)Measure resistance between knock sensor connector terminal and engine ground. <b>Terminal</b> <b>No. 2 — Engine ground:</b>	Is the resistance less than 400 k $\Omega$ ?	Replace knock sensor. <Ref. to FU(DOHC TURBO)-30, Knock Sensor.>	Repair ground short circuit in harness between knock sensor connector and ECM connector.  NOTE: The harness between both connectors is shielded. Repair short circuit of harness together with shield.
<b>3</b> <b>CHECK INPUT SIGNAL FOR ECM.</b> 1)Connect connectors to ECM and knock sensor. 2)Turn ignition switch to ON. 3)Measure voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B135) No. 4 (+) — Chassis ground (-):</b>	Is the voltage more than 2 V?	Even if MIL lights up, the circuit has returned to a normal condition at this time. (However, the possibility of poor contact still remains.)  NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Poor contact in knock sensor connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>	Repair poor contact in ECM connector.

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
 ENGINE (DIAGNOSTICS)


**AJ:DTC P0335 — CRANKSHAFT POSITION SENSOR CIRCUIT MALFUNCTION**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Engine stalls.
  - Failure of engine to start

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**



EN0976



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK HARNESS BETWEEN CRANKSHAFT POSITION SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn ignition switch to OFF. 2) Disconnect connector from crankshaft position sensor. 3) Measure resistance of harness between crankshaft position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(E10) No. 1 — Engine ground:</b></p>	<p>Is the resistance more than 100 k<math>\Omega</math>?</p>	<p>Repair harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between crankshaft position sensor and ECM connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>	<p>Go to step 2.</p>
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN CRANKSHAFT POSITION SENSOR AND ECM CONNECTOR.</b></p> <p>Measure resistance of harness between crankshaft position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(E10) No. 1 — Engine ground:</b></p>	<p>Is the resistance less than 10 <math>\Omega</math>?</p>	<p>Repair ground short circuit in harness between crankshaft position sensor and ECM connector.</p> <p>NOTE: The harness between both connectors are shielded. Repair ground short circuit in harness together with shield.</p>	<p>Go to step 3.</p>
<p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN CRANKSHAFT POSITION SENSOR AND ECM CONNECTOR.</b></p> <p>Measure resistance of harness between crankshaft position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(E10) No. 2 — Engine ground:</b></p>	<p>Is the resistance less than 5 <math>\Omega</math>?</p>	<p>Go to step 4.</p>	<p>Repair harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between crankshaft position sensor and ECM connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>4</b></p> <p><b>CHECK CONDITION OF CRANKSHAFT POSITION SENSOR.</b></p>	<p>Is the crankshaft position sensor installation bolt tightened securely?</p>	<p>Go to step 5.</p>	<p>Tighten crankshaft position sensor installation bolt securely.</p>
<p><b>5</b></p> <p><b>CHECK CRANKSHAFT POSITION SENSOR.</b></p> <p>1) Remove crankshaft position sensor. 2) Measure resistance between connector terminals of crankshaft position sensor.</p> <p><b>Terminals</b> <b>No. 1 — No. 2:</b></p>	<p>Is the resistance between 1 and 4 k<math>\Omega</math>?</p>	<p>Repair poor contact in crankshaft position sensor connector.</p>	<p>Replace crankshaft position sensor. &lt;Ref. to FU(DOHC TURBO)-28, Crankshaft Position Sensor.&gt;</p>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
 ENGINE (DIAGNOSTICS)


**AK:DTC P0336 — CRANKSHAFT POSITION SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Engine stalls.
  - Failure of engine to start

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**



EN0976

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No	
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0335?	Inspect DTC P0335 using "17. List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
2	<b>CHECK CONDITION OF CRANKSHAFT POSITION SENSOR.</b> Turn ignition switch to OFF.	Is the crankshaft position sensor installation bolt tightened securely?	Go to step 3.	Tighten crankshaft position sensor installation bolt securely.
3	<b>CHECK CRANKSHAFT SPROCKET.</b> Remove front belt cover.	Are crankshaft sprocket teeth cracked or damaged?	Replace crankshaft sprocket. <Ref. to FU(DOHC TURBO)-28, Crankshaft Position Sensor.>	Go to step 4.
4	<b>CHECK INSTALLATION CONDITION OF TIMING BELT.</b> Turn crankshaft using ST, and align alignment mark on crankshaft sprocket with alignment mark on cylinder block. ST 499987500CRANKSHAFT SOCKET	Is timing belt dislocated from its proper position?	Repair installation condition of timing belt. <Ref. to ME(DOHC TURBO)-47, Timing Belt Assembly.>	Replace crankshaft position sensor. <Ref. to FU(DOHC TURBO)-28, Crankshaft Position Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## AL:DTC P0340 — CAMSHAFT POSITION SENSOR CIRCUIT MALFUNCTION —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Engine stalls.
  - Failure of engine to start

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**



EN0977

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from camshaft position sensor. 3) Measure resistance of harness between camshaft position sensor connector and engine ground. <b>Connector &amp; terminal</b> <b>(E15) No. 1 — Engine ground:</b>	Is the resistance more than 100 k $\Omega$ ?	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between camshaft position sensor and ECM connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>	Go to step 2.
<b>2 CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.</b> Measure resistance of harness between camshaft position sensor connector and engine ground. <b>Connector &amp; terminal</b> <b>(E15) No. 1 — Engine ground:</b>	Is the resistance less than 10 $\Omega$ ?	Repair ground short circuit in harness between camshaft position sensor and ECM connector. NOTE: The harness between both connectors are shielded. Repair ground short circuit in harness together with shield.	Go to step 3.
<b>3 CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.</b> Measure resistance of harness between camshaft position sensor connector and engine ground. <b>Connector &amp; terminal</b> <b>(E15) No. 2 — Engine ground:</b>	Is the resistance less than 5 $\Omega$ ?	Go to step 4.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between camshaft position sensor and ECM connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>
<b>4 CHECK CONDITION OF CAMSHAFT POSITION SENSOR.</b>	Is the camshaft position sensor installation bolt tightened securely?	Go to step 5.	Tighten camshaft position sensor installation bolt securely.
<b>5 CHECK CAMSHAFT POSITION SENSOR.</b> 1) Remove camshaft position sensor. 2) Measure resistance between connector terminals of camshaft position sensor. <b>Terminals</b> <b>No. 1 — No. 2:</b>	Is the resistance between 1 and 4 k $\Omega$ ?	Repair poor contact in camshaft position sensor connector.	Replace camshaft position sensor. <Ref. to FU(DOHC TURBO)-29, Camshaft Position Sensor.>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
 ENGINE (DIAGNOSTICS)


**AM:DTC P0341 — CAMSHAFT POSITION SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Engine stalls.
  - Failure of engine to start

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No	
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0340?	Inspect DTC P0340 using "17. List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
2	<b>CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from camshaft position sensor. 3) Measure resistance of harness between camshaft position sensor connector and engine ground. <b>Connector &amp; terminal</b> <b>(E15) No. 1 — Engine ground:</b>	Is the resistance more than 100 k $\Omega$ ?	Repair harness and connector. <b>NOTE:</b> In this case, repair the following: • Open circuit in harness between camshaft position sensor and ECM connector • Poor contact in ECM connector • Poor contact in coupling connector	Go to step 3.
3	<b>CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.</b> Measure resistance of harness between camshaft position sensor connector and engine ground. <b>Connector &amp; terminal</b> <b>(E15) No. 1 — Engine ground:</b>	Is the resistance less than 10 $\Omega$ ?	Repair ground short circuit in harness between camshaft position sensor and ECM connector. <b>NOTE:</b> The harness between both connectors are shielded. Repair ground short circuit in harness together with shield.	Go to step 4.
4	<b>CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.</b> Measure resistance of harness between camshaft position sensor connector and engine ground. <b>Connector &amp; terminal</b> <b>(E15) No. 2 — Engine ground:</b>	Is the resistance less than 5 $\Omega$ ?	Go to step 5.	Repair harness and connector. <b>NOTE:</b> In this case, repair the following: • Open circuit in harness between camshaft position sensor and ECM connector • Poor contact in ECM connector • Poor contact in coupling connector
5	<b>CHECK CONDITION OF CAMSHAFT POSITION SENSOR.</b>	Is the camshaft position sensor installation bolt tightened securely?	Go to step 6.	Tighten camshaft position sensor installation bolt securely.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>6</b> <b>CHECK CAMSHAFT POSITION SENSOR.</b> 1)Remove camshaft position sensor. 2)Measure resistance between connector terminals of camshaft position sensor. <b>Terminals</b> <b>No. 1 — No. 2:</b>	Is the resistance between 1 and 4 kΩ?	Go to step 7.	Replace camshaft position sensor. <Ref. to FU(DOHC TURBO)-29, Camshaft Position Sensor.>
<b>7</b> <b>CHECK CONDITION OF CAMSHAFT POSITION SENSOR.</b> Turn ignition switch to OFF.	Is the camshaft position sensor installation bolt tightened securely?	Go to step 8.	Tighten camshaft position sensor installation bolt securely.
<b>8</b> <b>CHECK CAMSHAFT SPROCKET.</b> Remove front belt cover. <Ref. to ME(SOHC)-45, Belt Cover.>	Are camshaft sprocket teeth cracked or damaged?	Replace camshaft sprocket. <Ref. to ME(DOHC TURBO)-56, Camshaft Sprocket.>	Go to step 9.
<b>9</b> <b>CHECK INSTALLATION CONDITION OF TIMING BELT.</b> Turn camshaft using ST, and align alignment mark on camshaft sprocket with alignment mark on timing belt cover LH. ST 499207100CAMSHAFT SPROCKET WRENCH	Is timing belt dislocated from its proper position?	Repair installation condition of timing belt. <Ref. to ME(DOHC TURBO)-47, Timing Belt Assembly.>	Replace camshaft position sensor. <Ref. to FU(DOHC TURBO)-29, Camshaft Position Sensor.>





# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### AN:DTC P0420 — CATALYST SYSTEM EFFICIENCY BELOW THRESHOLD —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Engine stalls.
  - Idle mixture is out of specifications.

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN0978

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1</b> <b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0031, P0032, P0131, P0132, P0133, P1130, P1131, P1134, P1139, P0037, P0038, P0136 and P0139?	Inspect the relevant DTC using "17. List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0420.	Go to step 2.
<b>2</b> <b>CHECK EXHAUST SYSTEM.</b> Check for gas leaks or air suction caused by loose or dislocated nuts and bolts, and open hole at exhaust pipes. NOTE: Check the following positions. <ul style="list-style-type: none"> <li>•Between cylinder head and front exhaust pipe</li> <li>•Between front exhaust pipe and front catalytic converter</li> <li>•Between front catalytic converter and rear catalytic converter</li> </ul>	Is there a fault in exhaust system?	Repair or replace exhaust system. <Ref. to EX(DOHC TURBO)-2, General Description.>	Go to step 3.
<b>3</b> <b>CHECK REAR CATALYTIC CONVERTER.</b> Separate rear catalytic converter from rear exhaust pipe.	Is there damage at rear face of rear catalyst?	Replace front catalytic converter <Ref. to EC(DOHC TURBO)-3, Front Catalytic Converter.> and rear catalytic converter <Ref. to EC(DOHC TURBO)-4, Rear Catalytic Converter.>	Go to step 4.
<b>4</b> <b>CHECK FRONT CATALYTIC CONVERTER.</b> Remove front catalytic converter.	Is there damage at rear face or front face of front catalyst?	Replace front catalytic converter. <Ref. to EC(DOHC TURBO)-3, Front Catalytic Converter.>	Contact with your Subaru distributor. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## AO:DTC P0444 — EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN0979

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK OUTPUT SIGNAL FROM ECM.</b>                      1) Turn ignition switch to ON.                      2) Measure voltage between ECM and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B137) No. 16 (+) — Chassis ground (-):</b></p>	<p>Is the voltage more than 10 V?</p>	<p>Even if MIL lights up, the circuit has returned to a normal condition at this time. Contact with your Subaru distributor.</p> <p>NOTE:                      Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p>	<p>Go to step 2.</p>
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN PURGE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b>                      1) Turn ignition switch to OFF.                      2) Disconnect connectors from purge control solenoid valve and ECM.                      3) Measure resistance of harness between purge control solenoid valve connector and engine ground.  <b>Connector &amp; terminal</b>  <b>(E4) No. 2 — Engine ground:</b></p>	<p>Is the resistance less than 10 <math>\Omega</math>?</p>	<p>Repair ground short circuit in harness between ECM and purge control solenoid valve connector.</p>	<p>Go to step 3.</p>
<p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN PURGE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b>                      Measure resistance of harness between ECM and purge control solenoid valve of harness connector.  <b>Connector &amp; terminal</b>  <b>(B137) No. 16 — (E4) No. 2:</b></p>	<p>Is the resistance less than 1 <math>\Omega</math>?</p>	<p>Go to step 4.</p>	<p>Repair open circuit in harness between ECM and purge control solenoid valve connector.</p> <p>NOTE:                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and purge control solenoid valve connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>4</b></p> <p><b>CHECK PURGE CONTROL SOLENOID VALVE.</b>                      1) Remove purge control solenoid valve.                      2) Measure resistance between purge control solenoid valve terminals.  <b>Terminals</b>  <b>No. 1 — No. 2:</b></p>	<p>Is the resistance between 10 and 100 <math>\Omega</math>?</p>	<p>Go to step 5.</p>	<p>Replace purge control solenoid valve. &lt;Ref. to EC(DOHC TURBO)-7, Purge Control Solenoid Valve.&gt;</p>
<p><b>5</b></p> <p><b>CHECK POWER SUPPLY TO PURGE CONTROL SOLENOID VALVE.</b>                      1) Turn ignition switch to ON.                      2) Measure voltage between purge control solenoid valve and engine ground.  <b>Connector &amp; terminal</b>  <b>(E4) No. 1 (+) — Engine ground (-):</b></p>	<p>Is the voltage more than 10 V?</p>	<p>Go to step 6.</p>	<p>Repair open circuit in harness between main relay and purge control solenoid valve connector.</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
6	<b>CHECK POOR CONTACT.</b> Check poor contact in purge control solenoid valve connector.	Is there poor contact in purge control solenoid valve connector?	Repair poor contact in purge control solenoid valve connector.	Contact with your Subaru distributor. <b>NOTE:</b> Inspection by DTM is required, because probable cause is deterioration of multiple parts.



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## AP:DTC P0445 — EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT HIGH INPUT —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN0979



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK OUTPUT SIGNAL FROM ECM.</b>                      1) Turn ignition switch to OFF.                      2) Connect test mode connector at the lower portion of instrument panel (on the driver's side), to the side of the center console box.                      3) Turn ignition switch to ON.                      4) While operating purge control solenoid valve, measure voltage between ECM and chassis ground.</p> <p>NOTE:                      Purge control solenoid valve operation can be executed using Subaru Select Monitor. For procedure, refer to "Compulsory Valve Operation Check Mode". &lt;Ref. to EN(DOHC TURBO)-39, Compulsory Valve Operation Check Mode.&gt;</p> <p><b>Connector &amp; terminal</b>  <b>(B137) No. 16 (+) — Chassis ground (-):</b></p>	<p>Does voltage change between 0 and 10 V?</p>	<p>Go to step 2.</p>	<p>Even if MIL light up, the circuit has returned to a normal condition at this time. In this case, repair poor contact in ECM connector.</p>
<p><b>2</b></p> <p><b>CHECK OUTPUT SIGNAL FROM ECM.</b>                      1) Turn ignition switch to ON.                      2) Measure voltage between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B137) No. 16 (+) — Chassis ground (-):</b></p>	<p>Is the voltage more than 10 V?</p>	<p>Go to step 4.</p>	<p>Go to step 3.</p>
<p><b>3</b></p> <p><b>CHECK POOR CONTACT.</b>                      Check poor contact in ECM connector.</p>	<p>Is there poor contact in ECM connector?</p>	<p>Repair poor contact in ECM connector.</p>	<p>Replace ECM. &lt;Ref. to FU(DOHC TURBO)-45, Engine Control Module.&gt;</p>
<p><b>4</b></p> <p><b>CHECK HARNESS BETWEEN PURGE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b>                      1) Turn ignition switch to OFF.                      2) Disconnect connector from purge control solenoid valve.                      3) Turn ignition switch to ON.                      4) Measure voltage between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B137) No. 16 (+) — Chassis ground (-):</b></p>	<p>Is the voltage more than 10 V?</p>	<p>Repair battery short circuit in harness between ECM and purge control solenoid valve connector. After repair, replace ECM. &lt;Ref. to FU(DOHC TURBO)-45, Engine Control Module.&gt;</p>	<p>Go to step 5.</p>
<p><b>5</b></p> <p><b>CHECK PURGE CONTROL SOLENOID VALVE.</b>                      1) Turn ignition switch to OFF.                      2) Measure resistance between purge control solenoid valve terminals.</p> <p><b>Terminals</b>  <b>No. 1 — No. 2:</b></p>	<p>Is the resistance less than 1 <math>\Omega</math>?</p>	<p>Replace purge control solenoid valve &lt;Ref. to EC(DOHC TURBO)-7, Purge Control Solenoid Valve.&gt; and ECM &lt;Ref. to FU(DOHC TURBO)-45, Engine Control Module.&gt;</p>	<p>Go to step 6.</p>
<p><b>6</b></p> <p><b>CHECK POOR CONTACT.</b>                      Check poor contact in ECM connector.</p>	<p>Is there poor contact in ECM connector?</p>	<p>Repair poor contact in ECM connector.</p>	<p>Replace ECM. &lt;Ref. to FU(DOHC TURBO)-45, Engine Control Module.&gt;</p>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**AQ:DTC P0461 — FUEL LEVEL SENSOR CIRCUIT RANGE/PERFORMANCE  
PROBLEM —**

• **DTC DETECTING CONDITION:**



- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)

## • WIRING DIAGRAM:



EN0980

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 <b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0462 or P0463?	Inspect DTC P0462 or P0463 using "17. List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).> <b>NOTE:</b> In this case, it is not necessary to inspect this trouble.	Replace fuel level sensor <Ref. to FU(DOHC TURBO)-58, Fuel Level Sensor.> and fuel sub level sensor <Ref. to FU(DOHC TURBO)-59, Fuel Sub Level Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)



### AR:DTC P0462 — FUEL LEVEL SENSOR CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No	
1	<p><b>CHECK SPEEDOMETER AND TACHOMETER OPERATION IN COMBINATION METER.</b></p>	Does speedometer and tachometer operate normally?	Go to step 2.	Repair or replace combination meter. <Ref. to IDI-4, Combination Meter System.>
2	<p><b>CHECK INPUT SIGNAL FOR ECM.</b>                      1) Turn ignition switch to ON. (Engine OFF)                      2) Measure voltage between ECM connector and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B135) No. 25 (+) — Chassis ground (-):</b></p>	Is the voltage less than 0.12 V?	Go to step 6.	Go to step 3.
3	<p><b>CHECK INPUT SIGNAL FOR ECM. (USING SUBARU SELECT MONITOR.)</b>                      Read data of fuel level sensor signal using Subaru Select Monitor.                      NOTE:                      • Subaru Select Monitor                      For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt;</p>	Does the value change less than 0.12 V by shaking harness and connector of ECM while monitoring the value with Subaru Select Monitor?	Repair poor contact in ECM connector.	Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause. NOTE: In this case, repair the following: • Poor contact in combination meter connector • Poor contact in ECM connector • Poor contact in coupling connectors
4	<p><b>CHECK INPUT VOLTAGE OF ECM.</b>                      1) Turn ignition switch to OFF.                      2) Separate fuel tank cord connector (R57) and rear wiring harness connector (R15).                      3) Turn ignition switch to ON.                      4) Measure voltage of harness between ECM connector and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B135) No. 25 (+) — Chassis ground (-):</b></p>	Is the voltage more than 0.12 V?	Go to step 4.	Go to step 7.
5	<p><b>CHECK HARNESS BETWEEN ECM AND COMBINATION METER.</b>                      1) Turn ignition switch to OFF.                      2) Disconnect connector from connector (i10), (i12) and ECM connector.                      3) Measure resistance between ECM and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B135) No. 25 — Chassis ground:</b></p>	Is the resistance more than 1 MΩ?	Go to step 6.	Repair ground short circuit in harness between ECM and combination meter connector.
6	<p><b>CHECK HARNESS BETWEEN ECM AND COMBINATION METER.</b>                      Measure resistance between ECM and combination meter connector.  <b>Connector &amp; terminal</b>  <b>(B135) No. 25 — (i12) No. 2:</b></p>	Is the resistance less than 10 Ω?	Repair or replace combination meter. <Ref. to IDI-4, Combination Meter System.>	Repair open circuit between ECM and combination meter connector. NOTE: In this case, repair the following: Poor contact in coupling connector

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
7	<b>CHECK FUEL TANK CORD.</b> 1)Turn ignition switch to OFF. 2)Disconnect connector from fuel sub level sensor. 3)Measure resistance between fuel sub level sensor and chassis ground. <b>Connector &amp; terminal</b> <b>(R59) No. 1 — Chassis ground:</b>	Is the resistance more than 1 M $\Omega$ ?	Go to step 8.	Repair ground short circuit in fuel tank cord.
8	<b>CHECK FUEL TANK CORD.</b> 1)Disconnect connector from fuel pump assembly. 2)Measure resistance between fuel pump assembly and chassis ground. <b>Connector &amp; terminal</b> <b>(R59) No. 2 — Chassis ground:</b>	Is the resistance more than 1 M $\Omega$ ?	Go to step 9.	Repair ground short circuit in fuel tank cord.
9	<b>CHECK FUEL LEVEL SENSOR.</b> 1)Remove fuel pump assembly. <Ref. to FU(DOHC TURBO)-56, Fuel Pump.> 2)Measure resistance between fuel level sensor and terminals with its float set to the full position. <b>Terminals</b> <b>No. 3 — No. 5:</b>	Is the resistance between 0.5 and 2.5 $\Omega$ ?	Go to step 10.	Replace fuel level sensor.
10	<b>CHECK FUEL SUB LEVEL SENSOR.</b> 1)Remove fuel sub level sensor. <Ref. to FU(DOHC TURBO)-59, Fuel Sub Level Sensor.> 2)Measure resistance between fuel sub level sensor and terminals with its float set to the full position. <b>Terminals</b> <b>No. 1 — No. 2:</b>	Is the resistance between 0.5 and 2.5 $\Omega$ ?	Repair poor contact in harness between ECM and combination meter connector.	Replace fuel sub level sensor.





# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)











### AS:DTC P0463 — FUEL LEVEL SENSOR CIRCUIT HIGH INPUT —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**



EN0980

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1	<b>CHECK SPEEDOMETER AND TACHOMETER OPERATION IN COMBINATION METER.</b>	Go to step 2.	Repair or replace combination meter. <Ref. to IDI-4, Combination Meter System.>
2	<b>CHECK INPUT SIGNAL FOR ECM.</b> 1) Turn ignition switch to ON. (Engine OFF) 2) Measure voltage between ECM connector and chassis ground. <i>Connector &amp; terminal</i> <i>(B135) No. 25 (+) — Chassis ground (-):</i>	Go to step 3.	Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause.  NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Poor contact in fuel pump connector</li> <li>• Poor contact in coupling connector</li> </ul>
3	<b>CHECK INPUT VOLTAGE OF ECM.</b> 1) Turn ignition switch to OFF. 2) Disconnect combination meter connector (i10) and ECM connector. 3) Turn ignition switch to ON. 4) Measure voltage of harness between ECM and chassis ground. <i>Connector &amp; terminal</i> <i>(B135) No. 25 (+) — Chassis ground (-):</i>	Go to step 4.	Repair battery short circuit between ECM and combination meter connector.
4	<b>CHECK HARNESS BETWEEN ECM AND FUEL TANK CORD.</b> 1) Turn ignition switch to OFF. 2) Separate fuel tank cord connector (R57) and rear wiring harness connector (R15). 3) Measure resistance between ECM and fuel tank cord. <i>Connector &amp; terminal</i> <i>(B135) No. 25 — (R15) No. 2:</i>	Go to step 5.	Repair open circuit between ECM and fuel tank cord.
5	<b>CHECK HARNESS BETWEEN FUEL TANK CORD AND CHASSIS GROUND.</b> Measure resistance between fuel tank cord and chassis ground. <i>Connector &amp; terminal</i> <i>(R15) No. 6 — Chassis ground:</i>	Go to step 6.	Repair open circuit between fuel tank cord and chassis ground.  NOTE: In this case, repair the following: Poor contact in coupling connectors
6	<b>CHECK FUEL TANK CORD.</b> 1) Disconnect connector from fuel level sensor. 2) Measure resistance between fuel level sensor and coupling connector. <i>Connector &amp; terminal</i> <i>(R57) No. 6 — (R58) No. 5:</i>	Go to step 7.	Repair open circuit between coupling connector and fuel level sensor.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
7	<p><b>CHECK FUEL TANK CORD.</b>                      1)Disconnect connector from fuel sub level sensor.                      2)Measure resistance between fuel level sensor and fuel sub level sensor.  <b>Connector &amp; terminal</b>  <b>(R58) No. 3 — (R59) No. 2:</b></p>	Is the resistance less than 10 Ω?	Go to step 8.	Repair open circuit between fuel level sensor and fuel sub level sensor.
8	<p><b>CHECK FUEL TANK CORD.</b>                      Measure resistance between fuel sub level sensor and coupling connector.  <b>Connector &amp; terminal</b>  <b>(R57) No. 2 — (R59) No. 1:</b></p>	Is the resistance less than 10 Ω?	Go to step 9.	Repair open circuit between coupling connector and fuel sub level sensor.
9	<p><b>CHECK FUEL LEVEL SENSOR.</b>                      1)Remove fuel pump assembly. &lt;Ref. to FU(DOHC TURBO)-56, Fuel Pump.&gt;                      2)While moving fuel level sensor float up and down, measure resistance between fuel level sensor terminals.  <b>Terminals</b>  <b>No. 3 — No. 5:</b></p>	Is the resistance more than 53 Ω?	Replace fuel level sensor. <Ref. to FU(DOHC TURBO)-58, Fuel Level Sensor.>	Go to step 10.
10	<p><b>CHECK FUEL SUB LEVEL SENSOR.</b>                      1)Remove fuel sub level sensor. &lt;Ref. to FU(DOHC TURBO)-59, Fuel Sub Level Sensor.&gt;                      2)While moving fuel sub level sensor float up and down, measure resistance between fuel sub level sensor terminals.  <b>Terminals</b>  <b>No. 1 — No. 2:</b></p>	Is the resistance more than 45 Ω?	Replace fuel sub level sensor. <Ref. to FU(DOHC TURBO)-59, Fuel Sub Level Sensor.>	Replace combination meter. <Ref. to IDI-19, Combination Meter Assembly.>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### AT:DTC P0464 — FUEL LEVEL SENSOR INTERMITTENT INPUT—



**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

**WIRING DIAGRAM:**



EN0980

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 <b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0462 or P0463?	Inspect DTC P0462 or P0463 using "17. List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
2 <b>CHECK FUEL LEVEL SENSOR.</b> 1)Remove fuel pump assembly. <Ref. to FU(DOHC TURBO)-56, Fuel Pump.> 2)While moving fuel level sensor float up and down, make sure that the resistance between fuel level sensro terminals changes smoothly. <b>Terminals</b> <b>No. 3 — No. 5:</b>	Does the resistance change smoothly between approx. 0.5 Ω and approx. 52 Ω?	Go to step 3.	Replace fuel level sensor. <Ref. to FU(DOHC TURBO)-58, Fuel Level Sensor.>
3 <b>CHECK FUEL SUB LEVEL SENSOR.</b> <b>Warning:</b> <b>During work procedures, if fuel tank is more than 3/4 full, be careful because fuel may spill.</b> 1)Remove fuel sub level sensor. <Ref. to FU(DOHC TURBO)-59, Fuel Sub Level Sensor.> 2)While moving fuel sub level sensor float up and down, make sure that the resistance between fuel level sensro terminals changes smoothly. <b>Terminals</b> <b>No. 1 — No. 2:</b>	Does the resistance change smoothly between approx. 0.5 Ω and approx. 44 Ω?	Repair poor contact in ECM, combination meter and coupling connectors.	Replace fuel sub level sensor. <Ref. to FU(DOHC TURBO)-59, Fuel Sub Level Sensor.>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---



**AU:DTC P0480 — COOLING FAN RELAY 1 CIRCUIT LOW INPUT —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Radiator fan does not operate properly.
  - Overheating



**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### • WIRING DIAGRAM:



EN0981

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1 CHECK OUTPUT SIGNAL FROM ECM.</b>                      1) Turn ignition switch to OFF.                      2) Connect test mode connector at the lower portion of instrument panel (on the driver's side), to the side of the center console box.                      3) Turn ignition switch to ON.                      4) While operating radiator fan relay, measure voltage between ECM terminal and ground.</p> <p>NOTE:                      Radiator fan relay operation can be executed using Subaru Select Monitor. For procedure, refer to "Compulsory Valve Operation Check Mode". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt;</p> <p><b>Connector &amp; terminal</b>                      (B137) No. 17 (+) — Chassis ground (-):                      (B137) No. 28 (+) — Chassis ground (-):</p>	Does voltage change between 0 and 10 V?	Repair poor contact in ECM connector.	Go to step 2.
<p><b>2 CHECK GROUND SHORT CIRCUIT IN RADIATOR MAIN FAN RELAY CONTROL CIRCUIT.</b>                      1) Turn ignition switch to OFF.                      2) Disconnect connectors from ECM.                      3) Measure resistance of harness between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>                      (B137) No. 17 — Chassis ground:                      (B137) No. 28 — Chassis ground:</p>	Is the resistance less than 10 $\Omega$ ?	Repair ground short circuit in radiator main fan relay control circuit.	Go to step 3.
<p><b>3 CHECK POWER SUPPLY FOR RELAY.</b>                      1) Remove main fan relay 1 and 2 from A/C relay holder.                      2) Turn ignition switch to ON.                      3) Measure voltage between fuse and relay box (F/B) connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>                      (F66) No. 27 (+) — Chassis ground (-):                      (F30) No. 22 (+) — Chassis ground (-):</p>	Is the voltage more than 10 V?	Go to step 4.	Repair open circuit in harness between ignition switch and fuse and relay box (F/B) connector.
<p><b>4 CHECK MAIN FAN RELAY.</b>                      1) Turn ignition switch to OFF.                      2) Measure resistance between main fan relay terminals.</p> <p><b>Terminal</b>                      No. 27 — No. 28:(Main fan relay 1)                      No. 22 — No. 21:(Main fan relay 2)</p>	Is the resistance between 87 and 107 $\Omega$ ?	Go to step 5.	Replace main fan relay.
<p><b>5 CHECK OPEN CIRCUIT IN MAIN FAN RELAY CONTROL CIRCUIT.</b>                      Measure resistance of harness between ECM and main fan relay connector.</p> <p><b>Connector &amp; terminal</b>                      (B137) No. 17 — (F66) No. 28:                      (B137) No. 28 — (F30) No. 21:</p>	Is the resistance less than 1 $\Omega$ ?	Go to step 6.	Repair harness and connector.  NOTE: In this case, repair the following: • Open circuit in harness between ECM and main fan relay connector • Poor contact in coupling connector
<p><b>6 CHECK POOR CONTACT.</b>                      Check poor contact in ECM or main fan relay connector.</p>	Is there poor contact in ECM or main fan relay connector?	Repair poor contact in ECM or main fan relay connector.	Contact with your Subaru distributor service.

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**AV:DTC P0483 — COOLING FAN FUNCTION PROBLEM —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Occurrence of noise
  - Overheating

**CAUTION:**

**After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .**



**NOTE:**

If the vehicle, with the engine idling, is placed very close to a wall or another vehicle, preventing normal cooling function, the OBD system may detect malfunction.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### • WIRING DIAGRAM:



EN0981

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Is there any other DTC on display?	Inspect the relevant DTC using "17. List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).>	Check radiator fan, fan motor and thermostat. <Ref. to CO-9, Radiator Main Fan System.> and <Ref. to CO-17, Radiator Sub Fan System.> If thermostat is stuck, replace thermostat.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## AW:DTC P0500 — VEHICLE SPEED SENSOR MALFUNCTION —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**



EN0982

Step	Check	Yes	No
1	<b>CHECK SPEEDOMETER OPERATION IN COMBINATION METER.</b>	Does speedometer operate normally?	Go to step 2.
			Check speedometer and vehicle speed sensor. <Ref. to IDI-21, Speedometer.>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
2	<p><b>CHECK HARNESS BETWEEN ECM AND COMBINATION METER CONNECTOR.</b></p> <p>1) Turn ignition switch to OFF. 2) Disconnect connector from combination meter. 3) Measure resistance between ECM and combination meter.</p> <p><b>Connector &amp; terminal</b> <b>(B134) No. 1 — (i10) No. 2:</b></p>	Is the resistance less than 10 $\Omega$ ?	Repair poor contact in ECM connector.	Repair harness and connector. <b>NOTE:</b> In this case, repair the following: <ul style="list-style-type: none"><li>• Open circuit in harness between ECM and combination meter connector</li><li>• Poor contact in ECM connector</li><li>• Poor contact in combination meter connector</li><li>• Poor contact in coupling connector</li></ul>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## AX:DTC P0506 — IDLE CONTROL SYSTEM RPM LOWER THAN EXPECTED —

**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault


**TROUBLE SYMPTOM:**

- Engine is difficult to start.
- Engine does not start.
- Erroneous idling
- Engine stalls.

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

**WIRING DIAGRAM:**



EN0983

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1</b> <b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0508 or P509?	Inspect DTC P0505 or P1505 using "17. List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0506.	Go to step 2.
<b>2</b> <b>CHECK IDLE AIR CONTROL SOLENOID VALVE.</b> 1) Turn ignition switch to OFF. 2) Remove idle air control solenoid valve from throttle body. <Ref. to FU(DOHC TURBO)-34, REMOVAL, Idle Air Control Solenoid Valve.> 3) Using an air gun, force air into idle air control solenoid valve by-pass air inlet. Confirm that forced air subsequently escapes from both main air passage and assist air passage.	Does air flow out?	Go to step 4.	Replace idle air control solenoid valve. <Ref. to FU(DOHC TURBO)-34, Idle Air Control Solenoid Valve.> After replace, Go to step 3.
<b>3</b> <b>CHECK IDLE AIR CONTROL SOLENOID VALVE DUTY RATIO.</b> 1) Turn ignition switch to ON. 2) Start engine, and warm-up the engine. 3) Turn all accessory switches to OFF. 4) Read data of idle air control solenoid valve duty ratio using Subaru Select Monitor or OBD-II general scan tool. NOTE: • Subaru Select Monitor For detailed operation procedures, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.	Is the value more than 60%?	Go to step 4.	END.
<b>4</b> <b>CHECK BY-PASS AIR LINE.</b> 1) Turn ignition switch to OFF. 2) Remove idle air control solenoid valve from throttle body. <Ref. to FU(DOHC TURBO)-34, REMOVAL, Idle Air Control Solenoid Valve.> 3) Remove throttle body to intake manifold. <Ref. to FU(DOHC TURBO)-14, REMOVAL, Throttle Body.> 4) Using an air gun, force air into solenoid valve installation area and throttle valve interior. Confirm that forced air subsequently escapes from both these areas.	Does air flow out?	Replace idle air control solenoid valve. <Ref. to FU(DOHC TURBO)-34, Idle Air Control Solenoid Valve.>	Replace throttle body. <Ref. to FU(DOHC TURBO)-14, Throttle Body.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## AY:DTC P0507 — IDLE CONTROL SYSTEM RPM HIGHER THAN EXPECTED —

**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault


**TROUBLE SYMPTOM:**

- Engine keeps running at higher revolution than specified idling revolution.

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

**WIRING DIAGRAM:**



EN0983

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No	
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0508 or P509?	Inspect DTC P0505 or P1505 using "17. List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0507.	Go to step 2.
2	<b>CHECK THROTTLE CABLE.</b>	Does throttle cable have play for adjustment?	Go to step 3.	Adjust throttle cable. <Ref. to SP-9, INSTALLATION, Accelerator Control Cable.>
3	<b>CHECK AIR INTAKE SYSTEM.</b> 1) Turn ignition switch to ON. 2) Start engine, and idle it. 3) Check the following items. • Loose installation of intake manifold, idle air control solenoid valve and throttle body • Cracks of intake manifold gasket, idle air control solenoid valve gasket and throttle body gasket • Disconnections of vacuum hoses	Is there a fault in air intake system?	Repair air suction and leaks.	Replace idle air control solenoid valve. <Ref. to FU(DOHC TURBO)-34, Idle Air Control Solenoid Valve.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## AZ:DTC P0508 — IDLE CONTROL SYSTEM CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Engine breathing

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN0983

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Turn ignition switch to ON. 2) Measure voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 10 (+) — Chassis ground (-):</b>	Is the voltage more than 3 V?	Repair poor contact in ECM connector.	Go to step 2.
<b>2 CHECK POWER SUPPLY TO IDLE AIR CONTROL SOLENOID VALVE.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from idle air control solenoid valve. 3) Turn ignition switch to ON. 4) Measure voltage between idle air control solenoid valve and engine ground. <b>Connector &amp; terminal</b> <b>(E7) No. 2 (+) — Engine ground (-):</b>	Is the voltage more than 10 V?	Go to step 3.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between idle air control solenoid valve and main relay connector</li> <li>• Poor contact in coupling connector</li> </ul>
<b>3 CHECK HARNESS BETWEEN ECM AND IDLE AIR CONTROL SOLENOID VALVE CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from ECM. 3) Measure resistance of harness between ECM and idle air control solenoid valve connector. <b>Connector &amp; terminal</b> <b>(B136) No. 10 — (E7) No. 1:</b>	Is the resistance less than 1 $\Omega$ ?	Go to step 4.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and idle air control solenoid valve connector</li> <li>• Poor contact in coupling connector</li> </ul>
<b>4 CHECK HARNESS BETWEEN ECM AND IDLE AIR CONTROL SOLENOID VALVE CONNECTOR.</b> Measure resistance of harness between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 10 — Chassis ground:</b>	Is the resistance less than 10 $\Omega$ ?	Repair ground short circuit in harness between ECM and idle air control solenoid valve connector.	Go to step 5.
<b>5 CHECK GROUND CIRCUIT OF IDLE AIR CONTROL SOLENOID VALVE.</b> Measure resistance of harness between idle air control solenoid valve connector and engine ground. <b>Connector &amp; terminal</b> <b>(E7) No. 3 — Engine ground:</b>	Is the resistance less than 5 $\Omega$ ?	Go to step 6.	Repair open circuit in harness between idle air control solenoid valve connector and engine ground terminal.
<b>6 CHECK POOR CONTACT.</b> Check poor contact in ECM and idle air control solenoid valve connectors.	Is there poor contact in ECM and idle air control solenoid valve connectors?	Repair poor contact in ECM and idle air control solenoid valve connectors.	Replace idle air control solenoid valve. <Ref. to FU(DOHC TURBO)-34, Idle Air Control Solenoid Valve.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## BA:DTC P0509 — IDLE CONTROL SYSTEM CIRCUIT HIGH INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Engine breathing

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN0983



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1</b> <b>CHECK THROTTLE CABLE.</b>	Does throttle cable have play for adjustment?	Go to step 2.	Adjust throttle cable. <Ref. to SP-9, INSTALLATION, Accelerator Control Cable.>
<b>2</b> <b>CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Turn ignition switch to ON. 2) Measure voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 10 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V?	Go to step 3.	Go to step 4.
<b>3</b> <b>CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from idle air control solenoid valve. 3) Turn ignition switch to ON. 4) Measure voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 10 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V?	Repair battery short circuit in harness between ECM and idle air control solenoid valve connector. After repair, replace ECM. <Ref. to FU(DOHC TURBO)-45, Engine Control Module.>	Replace idle air control solenoid valve <Ref. to FU(DOHC TURBO)-34, Idle Air Control Solenoid Valve.> and ECM <Ref. to FU(DOHC TURBO)-45, Engine Control Module.>.
<b>4</b> <b>CHECK OUTPUT SIGNAL FROM ECM.</b> Measure voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 10 (+) — Chassis ground (-):</b>	Does the voltage change more than 10 V by shaking harness and connector of ECM while monitoring the value with voltage meter?	Repair battery short circuit in harness between ECM and idle air control solenoid valve connector. After repair, replace ECM. <Ref. to FU(DOHC TURBO)-45, Engine Control Module.>	Contact with your Subaru distributor service.  NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## BB:DTC P0512 — STARTER SWITCH CIRCUIT HIGH INPUT —

### • DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault


### • TROUBLE SYMPTOM:

- Failure of engine to start

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

### • WIRING DIAGRAM:



EN0958

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<b>CHECK OPERATION OF STARTER MOTOR.</b> NOTE: Place the inhibitor switch in each position.	Does starter motor operate when ignition switch to "ON"?	Repair battery short circuit in starter motor circuit. After repair, replace ECM. <Ref. to FU(DOHC TURBO)-45, Engine Control Module.>	Check starter motor circuit. <Ref. to EN(DOHC TURBO)-54, STARTER MOTOR CIRCUIT, Diagnostics for Engine Starting Failure.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### BC:DTC P0545 — EXHAUST GAS TEMPERATURE SENSOR CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Hard to start
  - Erroneous idling
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN0984

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK CURRENT DATA.</b></p> <p>1) Start engine.</p> <p>2) Read data of exhaust gas temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor</li> </ul> <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>• OBD-II general scan tool</li> </ul> <p>For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value greater than 1200°C (2192°F)?</p>	<p>Go to step 2.</p>	<p>Repair poor contact.</p> <p>NOTE:</p> <p>In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Poor contact in exhaust gas temperature sensor</li> <li>• Poor contact in ECM</li> <li>• Poor contact in joint connector</li> </ul>
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN EXHAUST GAS TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn ignition switch to OFF.</p> <p>2) Disconnect connector from exhaust gas temperature sensor.</p> <p>3) Turn ignition switch to ON.</p> <p>4) Read data of exhaust gas temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor</li> </ul> <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>• OBD-II general scan tool</li> </ul> <p>For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value less than 372°C (702°F)?</p>	<p>Replace exhaust gas temperature sensor. &lt;Ref. to FU(DOHC TURBO)-44, Exhaust Temperature Sensor.&gt;</p>	<p>Repair ground short circuit in harness between exhaust gas temperature sensor and ECM connector.</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## BD:DTC P0546 — EXHAUST GAS TEMPERATURE SENSOR CIRCUIT HIGH INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Hard to start
  - Erroneous idling
  - Poor driving performance

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**



EN0984

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1 CHECK CURRENT DATA.</b>                      1) Start engine.                      2) Read data of exhaust gas temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:                      • Subaru Select Monitor                      For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt;                      • OBD-II general scan tool                      For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value less than 372°C (702°F)?</p>	<p>Go to step 2.</p>	<p>Repair poor contact.</p> <p>NOTE:                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Poor contact in exhaust gas temperature sensor</li> <li>• Poor contact in ECM</li> <li>• Poor contact in joint connector</li> </ul>
<p><b>2 CHECK HARNESS BETWEEN EXHAUST GAS TEMPERATURE SENSOR AND ECM CONNECTOR.</b>                      1) Turn ignition switch to OFF.                      2) Disconnect connector from exhaust gas temperature sensor.                      3) Measure voltage between exhaust gas temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <i>(B279) No. 1 (+) — Engine ground (-):</i></p>	<p>Is the voltage more than 10 V?</p>	<p>Repair battery short circuit in harness between ECM and exhaust gas temperature sensor connector.</p>	<p>Go to step 3.</p>
<p><b>3 CHECK HARNESS BETWEEN EXHAUST GAS TEMPERATURE SENSOR AND ECM CONNECTOR.</b>                      1) Turn ignition switch to ON.                      2) Measure voltage between exhaust gas temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <i>(B279) No. 1 (+) — Engine ground (-):</i></p>	<p>Is the voltage more than 10 V?</p>	<p>Repair battery short circuit in harness between ECM and exhaust gas temperature sensor connector.</p>	<p>Go to step 4.</p>
<p><b>4 CHECK HARNESS BETWEEN EXHAUST GAS TEMPERATURE SENSOR AND ECM CONNECTOR.</b>                      Measure voltage between exhaust gas temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <i>(B279) No. 1 (+) — Engine ground (-):</i></p>	<p>Is the voltage more than 4 V?</p>	<p>Go to step 5.</p>	<p>Repair harness and connector.</p> <p>NOTE:                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and exhaust gas temperature sensor connector</li> <li>• Poor contact in exhaust gas temperature sensor connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in joint connector</li> </ul>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
5	<p><b>CHECK HARNESS BETWEEN EXHAUST GAS TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn ignition switch to OFF. 2) Measure resistance of harness between exhaust gas temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(B279) No. 2 — Engine ground:</b></p>	Is the resistance less than 5 $\Omega$ ?	Replace exhaust gas temperature sensor. <Ref. to FU(DOHC TURBO)-44, Exhaust Temperature Sensor.>	Repair harness and connector. <b>NOTE:</b> In this case, repair the following: <ul style="list-style-type: none"><li>• Open circuit in harness between ECM and exhaust gas temperature sensor connector</li><li>• Poor contact in exhaust gas temperature sensor connector</li><li>• Poor contact in ECM connector</li><li>• Poor contact in joint connector</li></ul>





## DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

---

### BE:DTC P0604 — INTERNAL CONTROL MODULE MEMORY CHECK SUM ERROR —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Engine does not start.
  - Engine stalls.


#### **CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


• LHD MODEL



EN0959

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)

## • RHD MODEL



EN0960

Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b> Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0604?	Replace ECM. <Ref. to FU(DOHC TURBO)-45, Engine Control Module.>	It is not necessary to inspect DTC P0604.



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## BF: DTC P1086 — TUMBLE GENERATOR VALVE #2 (LH) POSITION SENSOR CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**
- **LHD MODEL**




EN0985

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

• RHD MODEL



EN0986

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<p><b>CHECK CURRENT DATA.</b>                      1) Start engine.                      2) Read data of throttle position sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:                      • Subaru Select Monitor                      For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt;                      • OBD-II general scan tool                      For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	Is the value less than 0.1 V?	Go to step 2.	Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause. NOTE: In this case, repair the following: • Poor contact in throttle position sensor connector • Poor contact in ECM connector • Poor contact in coupling connector
2	<p><b>CHECK INPUT SIGNAL FOR ECM.</b>                      Measure voltage between ECM connector and chassis ground while tumble generator valve is fully closed.  <b>Connector &amp; terminal</b>  <b>(B135) No. 9 (+) — Chassis ground (-):</b></p>	Is the voltage more than 4.5 V?	Go to step 4.	Go to step 3.
3	<p><b>CHECK INPUT SIGNAL FOR ECM.</b>                      Measure voltage between ECM connector and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B135) No. 9 (+) — Chassis ground (-):</b></p>	Does the voltage change more than 4.5 V by shaking harness and connector of ECM while monitoring the value with voltage meter?	Repair poor contact in ECM connector.	Contact with your Subaru distributor service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.
4	<p><b>CHECK INPUT SIGNAL FOR ECM.</b>                      Measure voltage between ECM connector and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B135) No. 13 (+) — Chassis ground (-):</b></p>	Is the voltage less than 0.1 V?	Go to step 6.	Go to step 5.
5	<p><b>CHECK INPUT SIGNAL FOR ECM. (USING SUBARU SELECT MONITOR.)</b>                      Measure voltage between ECM connector and chassis ground.</p>	Does the voltage change more than 0.1 V by shaking harness and connector of ECM while monitoring the value with Subaru Select Monitor?	Repair poor contact in ECM connector.	Go to step 6.



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>6</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE POSITION SENSOR CONNECTOR.</b>                      1) Turn ignition switch to OFF.                      2) Disconnect connectors from tumble generator valve position sensor.                      3) Turn ignition switch to ON.                      4) Measure voltage between tumble generator valve position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E50) No. 1 (+) — Engine ground (-):</b></p>	<p>Is the voltage more than 4.5 V?</p>	<p>Go to step 7.</p>	<p>Repair harness and connector.</p> <p>NOTE:                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between tumble generator valve position sensor and ECM connector</li> <li>• Poor contact in tumble generator valve position sensor connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> <li>• Poor contact in joint connector</li> </ul>
<p><b>7</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE POSITION SENSOR CONNECTOR.</b>                      1) Turn ignition switch to OFF.                      2) Measure resistance of harness between ECM connector and tumble generator valve position sensor connector.</p> <p><b>Connector &amp; terminal</b>  <b>(B135) No. 13 — (E50) No. 3:</b></p>	<p>Is the resistance less than 1 <math>\Omega</math>?</p>	<p>Go to step 8.</p>	<p>Repair harness and connector.</p> <p>NOTE:                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between tumble generator valve position sensor and ECM connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in tumble generator valve position sensor connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>8</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE POSITION SENSOR CONNECTOR.</b>                      Measure resistance of harness between tumble generator valve position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E50) No. 3 — Engine ground:</b></p>	<p>Is the resistance less than 10 <math>\Omega</math>?</p>	<p>Repair ground short circuit in harness between tumble generator valve position sensor and ECM connector.</p>	<p>Go to step 9.</p>
<p><b>9</b></p> <p><b>CHECK POOR CONTACT.</b>                      Check poor contact in tumble generator valve position sensor connector.</p>	<p>Is there poor contact in tumble generator valve position sensor connector?</p>	<p>Repair poor contact in tumble generator valve position sensor connector.</p>	<p>Replace tumble generator valve assembly. &lt;Ref. to FU(DOHC TURBO)-38, Tumble Generator Valve Assembly.&gt;</p>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
 ENGINE (DIAGNOSTICS)


**BG:DTC P1087 — TUMBLE GENERATOR VALVE #2 (LH) POSITION SENSOR  
 CIRCUIT HIGH INPUT —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .





• **WIRING DIAGRAM:**



EN0985

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)

TUMBLE GENERATOR VALVE  
POSITION SENSOR



EN0986

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<p><b>CHECK CURRENT DATA.</b></p> <p>1)Start engine. 2)Read data of throttle position sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt; •OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	Is the value more than 4.9 V?	Go to step 2.	<p>Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause.</p> <p>NOTE: In this case, repair the following: • Poor contact in tumble generator valve position sensor connector • Poor contact in ECM connector • Poor contact in coupling connector</p>
2	<p><b>CHECK HARNESS BETWEEN TUMBLE GENERATOR VALVE POSITION SENSOR AND ECM CONNECTOR.</b></p> <p>1)Turn ignition switch to OFF. 2)Disconnect connector from throttle position sensor. 3)Measure resistance of harness between throttle position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(E50) No. 2 — Engine ground:</b></p>	Is the resistance less than 5 $\Omega$ ?	Go to step 3.	<p>Repair harness and connector.</p> <p>NOTE: In this case, repair the following: • Open circuit in harness between tumble generator valve position sensor and ECM connector • Poor contact in coupling connector • Poor contact in joint connector</p>
3	<p><b>CHECK HARNESS BETWEEN THROTTLE POSITION SENSOR AND ECM CONNECTOR.</b></p> <p>1)Turn ignition switch to ON. 2)Measure voltage between throttle position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(E50) No. 3 (+) — Engine ground (-):</b></p>	Is the voltage more than 4.9 V?	Repair battery short circuit in harness between tumble generator valve position sensor and ECM connector. After repair, replace ECM. <Ref. to FU(DOHC TURBO)-45, Engine Control Module.>	Replace tumble generator valve assembly. <Ref. to FU(DOHC TURBO)-38, Tumble Generator Valve Assembly.>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### BH: DTC P1088 — TUMBLE GENERATOR VALVE #1 (RH) POSITION SENSOR CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**
- **LHD MODEL**




EN0987

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

• RHD MODEL



EN0988

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<p><b>CHECK CURRENT DATA.</b></p> <p>1) Start engine. 2) Read data of tumble generator valve position sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt; • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	Is the value less than 0.1 V?	Go to step 2.	Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause. NOTE: In this case, repair the following: • Poor contact in tumble generator valve position sensor connector • Poor contact in ECM connector • Poor contact in coupling connector
2	<p><b>CHECK INPUT SIGNAL FOR ECM.</b></p> <p>Measure voltage between ECM connector and chassis ground while throttle valve is fully closed.</p> <p><b>Connector &amp; terminal</b> <b>(B135) No. 9 (+) — Chassis ground (-):</b></p>	Is the voltage more than 4.5 V?	Go to step 4.	Go to step 3.
3	<p><b>CHECK INPUT SIGNAL FOR ECM.</b></p> <p>Measure voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b> <b>(B135) No. 9 (+) — Chassis ground (-):</b></p>	Does the voltage change more than 4.5 V by shaking harness and connector of ECM while monitoring the value with voltage meter?	Repair poor contact in ECM connector.	Contact with your Subaru distributor service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.
4	<p><b>CHECK INPUT SIGNAL FOR ECM.</b></p> <p>Measure voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b> <b>(B135) No. 23 (+) — Chassis ground (-):</b></p>	Is the voltage less than 0.1 V?	Go to step 6.	Go to step 5.
5	<p><b>CHECK INPUT SIGNAL FOR ECM. (USING SUBARU SELECT MONITOR.)</b></p> <p>Measure voltage between ECM connector and chassis ground.</p>	Does the voltage change more than 0.1 V by shaking harness and connector of ECM while monitoring the value with Subaru Select Monitor?	Repair poor contact in ECM connector.	Go to step 6.



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>6</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE POSITION SENSOR CONNECTOR.</b></p> <p>1) Turn ignition switch to OFF.                      2) Disconnect connectors from throttle position sensor.                      3) Turn ignition switch to ON.                      4) Measure voltage between throttle position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E54) No. 1 (+) — Engine ground (-):</b></p>	<p>Is the voltage more than 4.5 V?</p>	<p>Go to step 7.</p>	<p>Repair harness and connector.</p> <p>NOTE:                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between tumble generator valve position sensor and ECM connector</li> <li>• Poor contact in throttle position sensor connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> <li>• Poor contact in joint connector</li> </ul>
<p><b>7</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE POSITION SENSOR CONNECTOR.</b></p> <p>1) Turn ignition switch to OFF.                      2) Measure resistance of harness between ECM connector and throttle position sensor connector.</p> <p><b>Connector &amp; terminal</b>  <b>(B135) No. 23 — (E54) No. 3:</b></p>	<p>Is the resistance less than 1 <math>\Omega</math>?</p>	<p>Go to step 8.</p>	<p>Repair harness and connector.</p> <p>NOTE:                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between tumble generator valve position sensor and ECM connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in tumble generator valve position sensor connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>8</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND THROTTLE POSITION SENSOR CONNECTOR.</b></p> <p>Measure resistance of harness between tumble generator valve position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E54) No. 3 — Engine ground:</b></p>	<p>Is the resistance less than 10 <math>\Omega</math>?</p>	<p>Repair ground short circuit in harness between tumble generator valve position sensor and ECM connector.</p>	<p>Go to step 9.</p>
<p><b>9</b></p> <p><b>CHECK POOR CONTACT.</b></p> <p>Check poor contact in tumble generator valve position sensor connector.</p>	<p>Is there poor contact in tumble generator valve position sensor connector?</p>	<p>Repair poor contact in tumble generator valve position sensor connector.</p>	<p>Replace tumble generator valve assembly. &lt;Ref. to FU(DOHC TURBO)-38, Tumble Generator Valve Assembly.&gt;</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### BI: DTC P1089 — TUMBLE GENERATOR VALVE #1 (RH) POSITION SENSOR CIRCUIT HIGH INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**
- **LHD MODEL**




EN0987

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

• RHD MODEL



EN0988

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK CURRENT DATA.</b></p> <p>1)Start engine. 2)Read data of tumble generator valve position sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt; •OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value more than 4.9 V?</p>	<p>Go to step 2.</p>	<p>Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause.</p> <p>NOTE: In this case, repair the following: • Poor contact in tumble generator valve position sensor connector • Poor contact in ECM connector • Poor contact in coupling connector</p>
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN TUMBLE GENERATOR VALVE POSITION SENSOR AND ECM CONNECTOR.</b></p> <p>1)Turn ignition switch to OFF. 2)Disconnect connector from throttle position sensor. 3)Measure resistance of harness between tumble generator valve position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(E54) No. 2 — Engine ground:</b></p>	<p>Is the resistance less than 5 <math>\Omega</math>?</p>	<p>Go to step 3.</p>	<p>Repair harness and connector.</p> <p>NOTE: In this case, repair the following: • Open circuit in harness between tumble generator valve position sensor and ECM connector • Poor contact in coupling connector • Poor contact in joint connector</p>
<p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN TUMBLE GENERATOR VALVE POSITION SENSOR AND ECM CONNECTOR.</b></p> <p>1)Turn ignition switch to ON. 2)Measure voltage between throttle position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(E54) No. 3 (+) — Engine ground (-):</b></p>	<p>Is the voltage more than 4.9 V?</p>	<p>Repair battery short circuit in harness between tumble generator valve position sensor and ECM connector. After repair, replace ECM. &lt;Ref. to FU(DOHC TURBO)-45, Engine Control Module.&gt;</p>	<p>Replace tumble generator valve assembly. &lt;Ref. to FU(DOHC TURBO)-38, Tumble Generator Valve Assembly.&gt;</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## BJ:DTC P1090 — TUMBLE GENERATOR VALVE SYSTEM #1 (RH) MALFUNCTION (STUCK OPEN) —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

### CAUTION:

After repair or replacement of faulty parts, conduct **Clear Memory Mode** <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and **Inspection Mode** <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

	Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate P1088, P1089, P1094 or P1095?	Inspect DTC P1088, P1089, P1094 or P1095 using List of Diagnostic Trouble Code (DTC) <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
2	<b>CHECK TUMBLE GENERATOR VALVE RH</b> 1)Remove tumble generator valve assembly. 2)Check tumble generator valve body.	Does tumble generator valve move smoothly? (No dirt or foreign materials clogged)	Replace tumble generator valve assembly. <Ref. to FU(DOHC TURBO)-38, Tumble Generator Valve Assembly.>	Clean tumble generator valve.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## BK:DTC P1091 — TUMBLE GENERATOR VALVE SYSTEM #1 (RH) MALFUNCTION (STUCK CLOSE) —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

	Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate P1088, P1089, P1094 or P1095?	Inspect DTC P1088, P1089, P1094 or P1095 using List of Diagnostic Trouble Code (DTC) <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
2	<b>CHECK TUMBLE GENERATOR VALVE RH</b> 1)Remove tumble generator valve assembly. 2)Check tumble generator valve body.	Does tumble generator valve move smoothly? (No dirt or foreign materials clogged)	Replace tumble generator valve assembly. <Ref. to FU(DOHC TURBO)-38, Tumble Generator Valve Assembly.>	Clean tumble generator valve.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## BL:DTC P1092 — TUMBLE GENERATOR VALVE SYSTEM #2 (LH) MALFUNCTION (STUCK OPEN) —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

### CAUTION:

After repair or replacement of faulty parts, conduct **Clear Memory Mode** <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and **Inspection Mode** <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

	Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate P1086, P1087, P1096 or P1097?	Inspect DTC P1086, P1087, P1096 or P1097 using List of Diagnostic Trouble Code (DTC) <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
2	<b>CHECK TUMBLE GENERATOR VALVE RH</b> 1)Remove tumble generator valve assembly. 2)Check tumble generator valve body.	Does tumble generator valve move smoothly? (No dirt or foreign materials clogged)	Replace tumble generator valve assembly. <Ref. to FU(DOHC TURBO)-38, Tumble Generator Valve Assembly.>	Clean tumble generator valve.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## BM:DTC P1093 — TUMBLE GENERATOR VALVE SYSTEM #2 (LH) MALFUNCTION (STUCK CLOSE) —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

	Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate P1086, P1087, P1096 or P1097?	Inspect DTC P1086, P1087, P1096 or P1097 using List of Diagnostic Trouble Code (DTC) <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
2	<b>CHECK TUMBLE GENERATOR VALVE RH</b> 1)Remove tumble generator valve assembly. 2)Check tumble generator valve body.	Does tumble generator valve move smoothly? (No dirt or foreign materials clogged)	Replace tumble generator valve assembly. <Ref. to FU(DOHC TURBO)-38, Tumble Generator Valve Assembly.>	Clean tumble generator valve.





# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## BN:DTC P1094 — TUMBLE GENERATOR VALVE CIRCUIT #1 (OPEN CIRCUIT)

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**



EN0989

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE ACTUATOR CONNECTOR.</b></p> <p>1) Turn ignition switch to OFF.                      2) Disconnect connector from tumble generator valve and ECM connector.                      3) Measure resistance between tumble generator valve actuator and ECM connector.</p> <p><b>Connector &amp; terminal</b>                      (E55) No. 1 — (B84) No.4:                      (E55) No. 2 — (B84) No.5:</p>	<p>Is the resistance less than 1Ω?</p>	<p>Go to step 2.</p>	<p>Repair open circuit between ECM and tumble generator valve connector.</p> <p>NOTE:                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and tumble generator valve actuator connector.</li> <li>• Poor contact in coupling connector.</li> </ul>
<p><b>2</b></p> <p><b>CHECK POOR CONTACT.</b></p> <p>Check poor contact in tumble generator valve actuator connector.</p>	<p>Is there poor contact in tumble generator valve actuator connector.</p>	<p>Repair poor contact in tumble generator valve actuator connector.</p>	<p>Replace tumble generator valve assembly. &lt;Ref. to FU(DOHC TURBO)-38, Tumble Generator Valve Assembly.&gt;</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## BO:DTC P1095 — TUMBLE GENERATOR VALVE CIRCUIT #1 (OVERCURRENT)

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<p><b>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE ACTUATOR CONNECTOR.</b></p> <p>1) Turn ignition switch to OFF. 2) Disconnect connector from tumble generator valve connector. 3) Measure voltage between tumble generator valve actuator and chassis ground.</p> <p><b>Connector &amp; terminal</b> <b>(E55) No. 1 (+) — Chassis ground (-):</b> <b>(E55) No. 2 (+) — Chassis ground (-):</b></p>	Is the voltage less than 5V?	Replace tumble generator valve assembly. <Ref. to FU(DOHC TURBO)-38, Tumble Generator Valve Assembly.>	Repair battery short circuit between ECM and tumble generator valve actuator.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## BP:DTC P1096 — TUMBLE GENERATOR VALVE CIRCUIT #2 (OPEN CIRCUIT)

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE ACTUATOR CONNECTOR.</b></p> <p>1) Turn ignition switch to OFF.                      2) Disconnect connector from tumble generator valve and ECM connector.                      3) Measure resistance between tumble generator valve actuator and ECM connector.</p> <p><b>Connector &amp; terminal</b>                      (E51) No. 1 — (B84) No. 10:                      (E51) No. 2 — (B84) No. 11:</p>	<p>Is the resistance less than 1Ω?</p>	<p>Go to step 2.</p>	<p>Repair open circuit between ECM and tumble generator valve connector.</p> <p>NOTE:                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and tumble generator valve actuator connector.</li> <li>• Poor contact in coupling connector.</li> </ul>
<p><b>2</b></p> <p><b>CHECK POOR CONTACT.</b></p> <p>Check poor contact in tumble generator valve actuator connector.</p>	<p>Is there poor contact in tumble generator valve actuator connector.</p>	<p>Repair poor contact in tumble generator valve actuator connector.</p>	<p>Replace tumble generator valve assembly. &lt;Ref. to FU(DOHC TURBO)-38, Tumble Generator Valve Assembly.&gt;</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### BQ:DTC P1097 — TUMBLE GENERATOR VALVE CIRCUIT #2 (OVERCURRENT)

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**





# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No	
1	<b>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE ACTUATOR CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from tumble generator valve connector. 3) Measure voltage between tumble generator valve actuator and chassis ground. <b>Connector &amp; terminal</b> (E51) No. 1 (+) — Chassis ground (-): (E51) No. 2 (+) — Chassis ground (-):	Is the voltage less than 5V?	Replace tumble generator valve assembly. <Ref. to FU(DOHC TURBO)-38, Tumble Generator Valve Assembly.>	Repair battery short circuit between ECM and tumble generator valve actuator.

## BR:DTC P1110 — ATMOSPHERIC PRESSURE SENSOR CIRCUIT LOW INPUT

• **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct **Clear Memory Mode** <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and **Inspection Mode** <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

Step	Check	Yes	No	
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P1110?	Replace ECM. <Ref. to FU(DOHC TURBO)-45, Engine Control Module.> NOTE: Atmospheric pressure sensor is built into ECM.	It is not necessary to inspect DTC P1110.

## BS:DTC P1111 — ATMOSPHERIC PRESSURE SENSOR CIRCUIT HIGH INPUT

• **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct **Clear Memory Mode** <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and **Inspection Mode** <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

Step	Check	Yes	No	
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P1111?	Replace ECM. <Ref. to FU(DOHC TURBO)-45, Engine Control Module.> NOTE: Atmospheric pressure sensor is built into ECM.	It is not necessary to inspect DTC P1111.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## BT:DTC P1112 — ATMOSPHERIC PRESSURE SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

	Step	Check	Yes	No
1	CHECK ANY OTHER DTC ON DISPLAY.	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0106, P0107, P0108, P1110 or P1111?	Inspect DTC P0106, P0107, P0108, P1110 or P1111 using "17. List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).>	Replace ECM. <Ref. to FU(DOHC TURBO)-45, Engine Control Module.> NOTE: Atmospheric pressure sensor is built into ECM.



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## BU: DTC P1130 — FRONT OXYGEN (A/F) SENSOR CIRCUIT MALFUNCTION (OPEN CIRCUIT) —

- DTC DETECTING CONDITION:
  - Immediately at fault recognition

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- WIRING DIAGRAM:



EN0966

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b></p> <p>1) Turn ignition switch to OFF.                      2) Disconnect connectors from ECM and front oxygen (A/F) sensor connector.                      3) Measure resistance of harness between ECM and front oxygen (A/F) sensor connector.</p> <p><b>Connector &amp; terminal</b>                      (B137) No. 29 — (B18) No. 3:                      (B137) No. 19 — (B18) No. 4:</p>	<p>Is the resistance less than 1 <math>\Omega</math>?</p>	<p>Go to step 2.</p>	<p>Repair harness and connector.</p> <p>NOTE:                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and front oxygen (A/F) sensor connector</li> <li>• Poor contact in front oxygen (A/F) sensor connector</li> <li>• Poor contact in ECM connector</li> </ul>
<p><b>2</b></p> <p><b>CHECK POOR CONTACT.</b></p> <p>Check poor contact in front oxygen (A/F) sensor connector.</p>	<p>Is there poor contact in front oxygen (A/F) sensor connector?</p>	<p>Repair poor contact in front oxygen (A/F) sensor connector.</p>	<p>Replace front oxygen (A/F) sensor.                      &lt;Ref. to FU(DOHC TURBO)-41, Front Oxygen (A/F) Sensor.&gt;</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## BV: DTC P1131 — FRONT OXYGEN (A/F) SENSOR CIRCUIT MALFUNCTION (SHORT CIRCUIT) —

- DTC DETECTING CONDITION:
  - Immediately at fault recognition

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

### • WIRING DIAGRAM:



EN0966

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from ECM. 3) Measure resistance of harness between ECM connector and chassis ground. <i>Connector &amp; terminal</i> <i>(B137) No. 19 — Chassis ground:</i>	Is the resistance more than 10 $\Omega$ ?	Go to step 2.	Repair ground short circuit in harness between ECM and front oxygen (A/F) sensor connector.
<b>2 CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b> Measure resistance of harness between ECM connector and chassis ground. <i>Connector &amp; terminal</i> <i>(B137) No. 29 — Chassis ground:</i>	Is the resistance more than 10 $\Omega$ ?	Go to step 3.	Repair ground short circuit in harness between ECM and front oxygen (A/F) sensor connector.
<b>3 CHECK OUTPUT SIGNAL FOR ECM.</b> 1) Connect connector to ECM. 2) Turn ignition switch to ON. 3) Measure voltage between ECM connector and chassis ground. <i>Connector &amp; terminal</i> <i>(B137) No. 19 (+) — Chassis ground (-):</i>	Is the voltage more than 4.5 V?	Go to step 4.	Go to step 5.
<b>4 CHECK OUTPUT SIGNAL FOR ECM.</b> Measure voltage between ECM connector and chassis ground. <i>Connector &amp; terminal</i> <i>(B137) No. 19 (+) — Chassis ground (-):</i>	Is the voltage more than 10 V?	Repair battery short circuit in harness between ECM and front oxygen (A/F) sensor connector. After repair, replace ECM. <Ref. to FU(DOHC TURBO)-45, Engine Control Module.>	Repair poor contact in ECM connector.
<b>5 CHECK OUTPUT SIGNAL FOR ECM.</b> Measure voltage between ECM connector and chassis ground. <i>Connector &amp; terminal</i> <i>(B137) No. 29 (+) — Chassis ground (-):</i>	Is the voltage more than 4.95 V?	Go to step 6.	Replace front oxygen (A/F) sensor. <Ref. to FU(DOHC TURBO)-41, Front Oxygen (A/F) Sensor.>
<b>6 CHECK OUTPUT SIGNAL FOR ECM.</b> Measure voltage between ECM connector and chassis ground. <i>Connector &amp; terminal</i> <i>(B137) No. 29 (+) — Chassis ground (-):</i>	Is the voltage more than 10 V?	Repair battery short circuit in harness between ECM and front oxygen (A/F) sensor connector. After repair, replace ECM. <Ref. to FU(DOHC TURBO)-45, Engine Control Module.>	Repair poor contact in ECM connector.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### BW:DTC P1134 — FRONT OXYGEN (A/F) SENSOR MICRO-COMPUTER PROBLEM —

- DTC DETECTING CONDITION:
  - Immediately at fault recognition

#### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

#### • WIRING DIAGRAM:



EN0966



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P1134?	Replace ECM. <Ref. to FU(DOHC TURBO)-45, Engine Control Module.>	It is not necessary to inspect DTC P1134.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## BX: DTC P1139 — FRONT OXYGEN (A/F) SENSOR #1 HEATER CIRCUIT RANGE/PERFORMANCE PROBLEM —

- DTC DETECTING CONDITION:
  - Two consecutive driving cycles with fault

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

### • WIRING DIAGRAM:



EN0966

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b>                      1)Start engine, and warm-up the engine.                      2)Turn ignition switch to OFF.                      3)Disconnect connectors from ECM and front oxygen (A/F) sensor.                      4)Measure resistance of harness between ECM and front oxygen (A/F) sensor connector.  <b>Connector &amp; terminal</b>  <i>(B137) No. 5 — (B18) No. 1:</i>  <i>(B137) No. 4 — (B18) No. 1:</i></p>	<p>Is the resistance less than 1 <math>\Omega</math>?</p>	<p>Go to step <b>2</b>.</p>	<p>Repair open circuit in harness between ECM and front oxygen (A/F) sensor connector.</p>
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b>                      Measure resistance of harness between ECM and front oxygen (A/F) sensor connector.  <b>Connector &amp; terminal</b>  <i>(B137) No. 19 — (B18) No. 4:</i>  <i>(B137) No. 29 — (B18) No. 3:</i></p>	<p>Is the resistance less than 1 <math>\Omega</math>?</p>	<p>Go to step <b>3</b>.</p>	<p>Repair open circuit in harness between ECM and front oxygen (A/F) sensor connector.</p>
<p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b>                      Measure resistance of harness between main relay and front oxygen (A/F) sensor connector.  <b>Connector &amp; terminal</b>  <i>(B47) No. 4 — (B18) No. 2:</i></p>	<p>Is the resistance less than 1 <math>\Omega</math>?</p>	<p>Go to step <b>4</b>.</p>	<p>Repair open circuit in harness between ECM and front oxygen (A/F) sensor connector.</p>
<p><b>4</b></p> <p><b>CHECK FRONT OXYGEN (A/F) SENSOR.</b>                      Measure resistance between front oxygen (A/F) sensor connector terminals.  <b>Terminals</b>  <i>No. 2 — No. 1:</i></p>	<p>Is the resistance less than 5 <math>\Omega</math>?</p>	<p>Go to step <b>5</b>.</p>	<p>Replace front oxygen (A/F) sensor.                      &lt;Ref. to FU(DOHC TURBO)-41, Front Oxygen (A/F) Sensor.&gt;</p>
<p><b>5</b></p> <p><b>CHECK POOR CONTACT.</b>                      Check poor contact in ECM and front oxygen (A/F) sensor connector.</p>	<p>Is there poor contact in ECM or front oxygen (A/F) sensor connector?</p>	<p>Repair poor contact in ECM or front oxygen (A/F) sensor connector.</p>	<p>Replace front oxygen (A/F) sensor.                      &lt;Ref. to FU(DOHC TURBO)-41, Front Oxygen (A/F) Sensor.&gt;</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## BY:DTC P1141 — MASS AIR FLOW SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (LOW INPUT) —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN0970

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 <b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does Subaru select monitor or OBD-II general scan tool indicate DTC P0102 or P0103?	Inspect DTC P0102 or P0103 using "10. Diagnostics Chart with Trouble Code"<Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).>  NOTE: In this case, it is not necessary to inspect DTC P1141.	Replace mass air flow and intake air temperature sensor.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## BZ:DTC P1142 — THROTTLE POSITION SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (LOW INPUT) —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**
- **LHD MODEL**




EN0973

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

• RHD MODEL



EN0972

Step	Check	Yes	No	
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0122 or P0123?	Inspect DTC P0122 or P0123 using "17. List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).>  NOTE: In this case, it is not necessary to inspect DTC P1142.	Replace throttle position sensor. <Ref. to FU(DOHC TURBO)-31, Throttle Position Sensor.>


# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)

## CA:DTC P1146 — PRESSURE SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (HIGH INPUT) —

- DTC DETECTING CONDITION:
  - Two consecutive driving cycles with fault

**CAUTION:**  
After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- WIRING DIAGRAM:
- LHD MODEL




EN0969



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

• RHD MODEL



	Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b> NOTE: In this case, it is not necessary to inspect DTC P0106.	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0107, P0108 or P1112?	Inspect DTC P0107, P0108 or P1112 using "17. List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
2	<b>CHECK AIR INTAKE SYSTEM.</b>	Are there holes, loose bolts or disconnection of hose on air intake system?	Repair air intake system.	Go to step 3.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
3	<p><b>CHECK PRESSURE SENSOR.</b></p> <p>1) Start the engine and warm-up engine until coolant temperature is greater than 60°C (140°F).</p> <p>2) Place the shift lever in the selector lever in "N" or "P" position.</p> <p>3) Turn A/C switch to OFF.</p> <p>4) Turn all accessory switches to OFF.</p> <p>5) Read data of intake manifold pressure sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt;</li> <li>• OBD-II general scan tool For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</li> </ul> <p>Specification:</p> <ul style="list-style-type: none"> <li>• Intake manifold absolute pressure</li> </ul> <p><b>Ignition ON</b> 73.3 — 106.6 kPa (550 — 800 mmHg, 21.65 — 31.50 inHg)</p> <p><b>Idling</b> 20.0 — 46.7 kPa (150 — 350 mmHg, 5.91 — 13.78 inHg)</p>	Is the value within the specifications?	Go to step 4.	Replace intake air temperature sensor and pressure sensor. <Ref. to FU(DOHC TURBO)-33, Pressure Sensor.>
4	<p><b>CHECK THROTTLE POSITION.</b></p> <p>Read data of throttle position signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt;</li> <li>• OBD-II general scan tool For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</li> </ul>	Is throttle positioning ratio equal to or less than 5% when throttle is fully closed?	Go to step 5.	Adjust or replace throttle position sensor. <Ref. to FU(DOHC TURBO)-31, Throttle Position Sensor.>
5	<p><b>CHECK THROTTLE POSITION.</b></p>	Is throttle positioning ratio equal to or more than 85% when throttle is fully open?	Replace intake air temperature and pressure sensor. <Ref. to FU(DOHC TURBO)-33, Pressure Sensor.>	Replace throttle position sensor. <Ref. to FU(DOHC TURBO)-31, Throttle Position Sensor.>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## CB:DTC P1230 — FUEL PUMP CONTROLLER MALFUNCTION —


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

**WIRING DIAGRAM:**



EN0991

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1 CHECK POWER SUPPLY CIRCUIT TO FUEL PUMP CONTROLLER.</b>                      1) Turn ignition switch to OFF.                      2) Disconnect connector from fuel pump controller.                      3) Turn ignition switch to ON.                      4) Measure voltage between fuel pump controller and chassis ground.  <b>Connector &amp; terminal</b>  <b>(R122) No. 10 (+) — Chassis ground (-):</b></p>	Is the voltage more than 10V?	Go to step 2.	Repair power supply circuit. NOTE: In this case repair the following: <ul style="list-style-type: none"> <li>• Open or ground short circuit in harness between fuel pump relay and fuel pump controller.</li> <li>• Poor contact in fuel pump controller connector.</li> <li>• Poor contact in fuel pump relay connector.</li> </ul>
<p><b>2 CHECK GROUND CIRCUIT OF FUEL PUMP CONTROLLER.</b>                      1) Turn ignition switch to OFF.                      2) Measure resistance of harness between fuel pump controller and chassis ground.  <b>Connector &amp; terminal</b>  <b>(R122) No. 5 — Chassis ground:</b></p>	Is the resistance less than 5 $\Omega$ ?	Go to step 3.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit between fuel pump controller and chassis ground.</li> <li>• Poor contact in fuel pump controller connector.</li> </ul>
<p><b>3 CHECK HARNESS BETWEEN FUEL PUMP CONTROLLER AND FUEL PUMP CONNECTOR.</b>                      1) Disconnect connector from fuel pump.                      2) Measure resistance of harness between fuel pump controller and fuel pump connector.  <b>Connector &amp; terminal</b>  <b>(R122) No. 7 — (R58) No. 2:</b>  <b>(R122) No. 6 — (R58) No. 1:</b></p>	Is the resistance less than 1 $\Omega$ ?	Go to step 4.	Repair open circuit between fuel pump controller and fuel pump.
<p><b>4 CHECK HARNESS BETWEEN FUEL PUMP CONTROLLER AND FUEL PUMP CONNECTOR.</b>                      Measure resistance of harness between fuel pump controller and chassis ground.  <b>Connector &amp; terminal</b>  <b>(R122) No. 7 — Chassis ground:</b>  <b>(R122) No. 6 — Chassis ground:</b></p>	Is the resistance more than 1M $\Omega$ ?	Go to step 5.	Repair ground short circuit between fuel pump controller and fuel pump.
<p><b>5 CHECK HARNESS BETWEEN FUEL PUMP CONTROLLER AND ECM CONNECTOR.</b>                      1) Turn ignition switch to OFF.                      2) Disconnect connector from ECM.                      3) Measure resistance of harness between fuel pump controller and ECM connector.  <b>Connector &amp; terminal</b>  <b>(R122) No. 9 — (B134) No. 13:</b>  <b>(R122) No. 8 — (B136) No. 16:</b></p>	Is the resistance less than 1 $\Omega$ ?	Go to step 6.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit between fuel pump controller and ECM.</li> <li>• Poor contact in fuel pump controller and ECM connector.</li> </ul>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>6</b> <b>CHECK HARNESS BETWEEN FUEL PUMP CONTROLLER AND ECM CONNECTOR.</b> Measure resistance of harness between fuel pump controller and chassis ground. <b>Connector &amp; terminal</b> <b>(R122) No. 9 — Chassis ground:</b> <b>(R122) No. 8 — Chassis ground:</b>	Is the resistance more than 1M $\Omega$ ?	Go to step 7.	Repair ground short circuit between fuel pump controller and ECM.
<b>7</b> <b>CHECK POOR CONTACT.</b> Check poor contact in ECM and fuel pump controller connector.	Is there poor contact in ECM and fuel pump controller connector.	Repair poor contact in ECM and fuel pump controller.	Replace fuel pump controller. <Ref. to FU(DOHC TURBO)-48, Fuel Pump Controller.>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## CC:DTC P1244 — WASTEGATE CONTROL SOLENOID VALVE RANGE/PERFORMANCE PROBLEM (LOW INPUT) —


### • DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

### • WIRING DIAGRAM:



EN0974



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0245 or P0246?	Inspect DTC P0245 or P0246 using "17. List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).>  NOTE: In this case, it is not necessary to inspect DTC P1142.	Replace wastegate control solenoid valve. <Ref. to FU(DOHC TURBO)-40, Wastegate Control Solenoid Valve.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## CD:DTC P1245 — WASTEGATE CONTROL SOLENOID VALVE MALFUNCTION (FAIL-SAFE) —

- DTC DETECTING CONDITION:
  - Immediately at fault recognition

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, Operation.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- WIRING DIAGRAM:



EN0974

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0244, P0245, P0246 or P1244?	Inspect DTC P0244, P0245, P0246 or P1244 using "17. List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).>  NOTE: In this case, it is not necessary to inspect DTC P0507.	Replace wastegate control solenoid valve. <Ref. to FU(DOHC TURBO)-40, Wastegate Control Solenoid Valve.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## CE:DTC P1301 — FIRE DUE TO INCREASED EXHAUST TEMPERATURE —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls
  - Poor driving performance

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**



EN0984

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC.</b> Conduct troubleshooting for all DTC P0301, P0302, P0303 and P0304. <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).>	Does failure for repair or replacement exist?	Repair or replace failure, then replace pre-catalytic converter.	Contact with your Subaru distributor service. <b>NOTE:</b> Inspection by DTM is required, because probable cause is deterioration of multiple parts.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## CF:DTC P1312 — EXHAUST GAS TEMPERATURE CIRCUIT MALFUNCTION —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**



EN0984

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No	
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0545 or P0546?	Inspect DTC P0545, P0546 or P1544 using "17. List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).>  NOTE: In this case, it is not necessary to inspect DTC P1312.	Replace exhaust gas temperature sensor. <Ref. to FU(DOHC TURBO)-44, Exhaust Temperature Sensor.>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---



**CG:DTC P1480 — COOLING FAN RELAY 1 CIRCUIT HIGH INPUT —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Radiator fan does not operate properly.
  - Overheating



**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, Operation.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### • WIRING DIAGRAM:



EN0981

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1 CHECK OUTPUT SIGNAL FROM ECM.</b>                      1) Turn ignition switch to OFF.                      2) Connect test mode connector at the lower portion of instrument panel (on the driver's side), to the side of the center console box.                      3) Turn ignition switch to ON.                      4) While operating radiator fan relay, measure voltage between ECM and chassis ground.</p> <p>NOTE:                      Radiator fan relay operation can be executed using Subaru Select Monitor. For procedure, refer to "Compulsory Valve Operation Check Mode". &lt;Ref. to EN(DOHC TURBO)-39, Compulsory Valve Operation Check Mode.&gt;</p> <p><b>Connector &amp; terminal</b>                      (B137) No. 17 (+) — Chassis ground (-):                      (B137) No. 28 (+) — Chassis ground (-):</p>	<p>Does voltage change between 0 and 10 V?</p>	<p>Even if MIL lights up, the circuit has returned to a normal condition at this time. In this case, repair poor contact in ECM connector.</p>	<p>Go to step 2.</p>
<p><b>2 CHECK SHORT CIRCUIT IN RADIATOR FAN RELAY CONTROL CIRCUIT.</b>                      1) Turn ignition switch to OFF.                      2) Remove main fan relay and sub fan relay. (with A/C models)                      3) Disconnect test mode connector.                      4) Turn ignition switch to ON.                      5) Measure voltage between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b>                      (B137) No. 17 (+) — Chassis ground (-):                      (B137) No. 28 (+) — Chassis ground (-):</p>	<p>Is the voltage more than 10 V?</p>	<p>Repair battery short circuit in radiator fan relay control circuit. After repair, replace ECM. &lt;Ref. to FU(DOHC TURBO)-45, Engine Control Module.&gt;</p>	<p>Go to step 3.</p>
<p><b>3 CHECK MAIN FAN RELAY.</b>                      1) Turn ignition switch to OFF.                      2) Remove main fan relay 1 and 2.                      3) Measure resistance between main fan relay terminals.</p> <p><b>Terminal</b>                      No. 25 — No. 26 (Main fan relay 1)                      No. 23 — No. 24 (Main fan relay 2)</p>	<p>Is the resistance less than 1 <math>\Omega</math>?</p>	<p>Replace main fan relay and ECM. &lt;Ref. to FU(DOHC TURBO)-45, Engine Control Module.&gt;</p>	<p>Go to step 4.</p>
<p><b>4 CHECK SUB FAN RELAY.</b>                      1) Remove sub fan relay.                      2) Measure resistance between sub fan relay terminals.</p> <p><b>Terminal</b>                      No. 7 — No. 8 (Sub fan relay 1)                      No. 17 — No. 18 (Sub fan relay 2)</p>	<p>Is the resistance less than 1 <math>\Omega</math>?</p>	<p>Replace sub fan relay and ECM. &lt;Ref. to FU(DOHC TURBO)-45, Engine Control Module.&gt;</p>	<p>Go to step 5.</p>
<p><b>5 CHECK POOR CONTACT.</b>                      Check poor contact in ECM connector.</p>	<p>Is there poor contact in ECM connector?</p>	<p>Repair poor contact in ECM connector.</p>	<p>Replace ECM. &lt;Ref. to FU(DOHC TURBO)-45, Engine Control Module.&gt;</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### CH:DTC P1507 — IDLE CONTROL SYSTEM MALFUNCTION (FAIL-SAFE) —

**DTC DETECTING CONDITION:**

- Immediately at fault recognition


**TROUBLE SYMPTOM:**

- Engine keeps running at higher revolution than specified idling revolution.
- Fuel is cut according to fail-safe function.

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

**WIRING DIAGRAM:**



EN0983

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0506, P0507, P0508, P0509 or P1142?	Inspect DTC P0506, P0507, P0508, P0509 or P1142 using "17. List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).>  NOTE: In this case, it is not necessary to inspect DTC P0507.	Go to step 2.
2	<b>CHECK AIR INTAKE SYSTEM.</b> 1) Turn ignition switch to ON. 2) Start engine, and idle it. 3) Check the following items. • Loose installation of intake manifold, idle air control solenoid valve and throttle body • Cracks of intake manifold gasket, idle air control solenoid valve gasket and throttle body gasket • Disconnections of vacuum hoses	Is there a fault in air intake system?	Repair air suction and leaks.	Go to step 3.
3	<b>CHECK THROTTLE CABLE.</b>	Does throttle cable have play for adjustment?	Go to step 4.	Adjust throttle cable. <Ref. to SP-9, INSTALLATION, Accelerator Control Cable.>
4	<b>CHECK AIR BY-PASS LINE.</b> 1) Turn ignition switch to OFF. 2) Remove idle air control solenoid valve from throttle body. <Ref. to FU(DOHC TURBO)-34, Idle Air Control Solenoid Valve.> 3) Confirm that there are no foreign particles in by-pass air line.	Are foreign particles in by-pass air line?	Remove foreign particles from by-pass air line.	Replace idle air control solenoid valve. <Ref. to FU(DOHC TURBO)-34, Idle Air Control Solenoid Valve.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## CI: DTC P1518 — STARTER SWITCH CIRCUIT LOW INPUT —

### • DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault


### • TROUBLE SYMPTOM:

- Failure of engine to start

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

### • WIRING DIAGRAM:



EN0958

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 <b>CHECK OPERATION OF STARTER MOTOR.</b>	Does starter motor operate when ignition switch to "ST"?	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"><li>• Open or ground short circuit in harness between ECM and starter motor connector.</li><li>• Poor contact in ECM connector.</li></ul>	Check starter motor circuit. <Ref. to EN(DOHC TURBO)-54, STARTER MOTOR CIRCUIT, Diagnostics for Engine Starting Failure.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## CJ:DTC P1544 — HIGH EXHAUST TEMPERATURE DETECTED —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Poor driving performance

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**



EN0984



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK ANY OTHER DTC ON DISPLAY.</b></p>	<p>Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0335, P0336, P0340, P0341, P0545, P0546, P1312, P0102, P0103, P0101, P1141, P0301, P0302, P0303, P0304, P1301, P0171, P0133, P1134, P0131, P0132, P1130, P1131, P1139, P0031, P0032, P0139, P0136, P0039 or P0037?</p>	<p>Inspect DTC P0335, P0336, P0340, P0341, P0545, P0546, P1312, P0102, P0103, P0101, P1141, P0301, P0302, P0303, P0304, P1301, P0171, P0133, P0304, P1301, P0171, P0133, P1134, P0131, P0132, P1130, P1131, P1139, P0031, P0032, P0139, P0136, P0039 or P0037 using List of Diagnostic Trouble Code (DTC). &lt;Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).&gt;</p> <p>NOTE: In this case, it is not necessary to inspect DTC P1544.</p>	<p>Go to step 2.</p>
<p><b>2</b></p> <p><b>CHECK EXHAUST SYSTEM.</b> Check exhaust system parts.</p> <p>NOTE: Check the following items.</p> <ul style="list-style-type: none"> <li>•Loose installation of exhaust manifold</li> <li>•Cracks or hole of exhaust manifold</li> <li>•Loose installation of front oxygen (A/F) sensor</li> </ul>	<p>Is there a fault in exhaust system?</p>	<p>Repair or replace failure, then replace pre-catalytic converter.</p>	<p>Contact with your Subaru distributor service.</p> <p>NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### CK:DTC P1560 — BACK-UP VOLTAGE CIRCUIT MALFUNCTION —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .


- **WIRING DIAGRAM:**
- **LHD MODEL**



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

• RHD MODEL



Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK INPUT SIGNAL FOR ECM.</b>                      1) Turn ignition switch to OFF.                      2) Measure voltage between ECM and chassis ground.  <i>Connector &amp; terminal</i>                      (B137) No. 10 (+) — Chassis ground (-):</p>	<p>Is the voltage more than 10 V?</p>	<p>Repair poor contact in ECM connector.</p>	<p>Go to step 2.</p>
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND MAIN FUSE BOX CONNECTOR.</b>                      1) Disconnect connector from ECM.                      2) Measure resistance of harness between ECM and chassis ground.  <i>Connector &amp; terminal</i>                      (B137) No. 10 — Chassis ground:</p>	<p>Is the resistance less than 10 Ω?</p>	<p>Repair ground short circuit in harness between ECM connector and battery terminal.</p>	<p>Go to step 3.</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
3 <b>CHECK FUSE SBF-5.</b>	Is fuse blown?	Replace fuse.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"><li>• Open circuit in harness between ECM and battery</li><li>• Poor contact in ECM connector</li><li>• Poor contact in battery terminal</li></ul>

## 18. General Diagnostic Table

### A: INSPECTION

#### 1. ENGINE

**NOTE:**

Malfunction of parts other than those listed is also possible. <Ref. to ME(DOHC TURBO)-89, Engine Trouble in General.>

Symptom	Problem parts
1. Engine stalls during idling.	1) Idle air control solenoid valve 2) Pressure sensor 3) Mass air flow and intake temperature sensor 4) Ignition parts (*1) 5) Engine coolant temperature sensor (*2) 6) Crankshaft position sensor (*3) 7) Camshaft position sensor (*3) 8) Fuel injection parts (*4)
2. Rough idling	1) Idle air control solenoid valve 2) Pressure sensor 3) Mass air flow and intake temperature sensor 4) Engine coolant temperature sensor (*2) 5) Ignition parts (*1) 6) Air intake system (*5) 7) Fuel injection parts (*4) 8) Throttle position sensor 9) Crankshaft position sensor (*3) 10) Camshaft position sensor (*3) 11) Oxygen sensor 12) Fuel pump and fuel pump relay
3. Engine does not return to idle.	1) Idle air control solenoid valve 2) Engine coolant temperature sensor 3) Accelerator cable (*6) 4) Throttle position sensor 5) Pressure sensor 6) Mass air flow sensor
4. Poor acceleration	1) Pressure sensor 2) Mass air flow and intake temperature sensor 3) Throttle position sensor 4) Fuel injection parts (*4) 5) Fuel pump and fuel pump relay 6) Engine coolant temperature sensor (*2) 7) Crankshaft position sensor (*3) 8) Camshaft position sensor (*3) 9) A/C switch and A/C cut relay 10) Engine torque control signal circuit 11) Ignition parts (*1)
5. Engine stalls or engine sags or hesitates at acceleration.	1) Pressure sensor 2) Mass air flow and intake temperature sensor 3) Engine coolant temperature sensor (*2) 4) Crankshaft position sensor (*3) 5) Camshaft position sensor (*3) 6) Purge control solenoid valve 7) Fuel injection parts (*4) 8) Throttle position sensor 9) Fuel pump and fuel pump relay

## GENERAL DIAGNOSTIC TABLE

### ENGINE (DIAGNOSTICS)

Symptom	Problem parts
6. Surge	1) Pressure sensor 2) Mass air flow and intake temperature sensor 3) Engine coolant temperature sensor (*2) 4) Crankshaft position sensor (*3) 5) Camshaft position sensor (*3) 6) Fuel injection parts (*4) 7) Throttle position sensor 8) Fuel pump and fuel pump relay
7. Spark knock	1) Pressure sensor 2) Mass air flow and intake temperature sensor 3) Engine coolant temperature sensor 4) Knock sensor 5) Fuel injection parts (*4) 6) Fuel pump and fuel pump relay
8. After burning in exhaust system	1) Pressure sensor 2) Mass air flow and intake temperature sensor 3) Engine coolant temperature sensor (*2) 4) Fuel injection parts (*4) 5) Fuel pump and fuel pump relay

\*1: Check ignition coil & ignitor assembly and spark plug.

\*2: Indicate the symptom occurring only in cold temperatures.

\*3: Ensure the secure installation.

\*4: Check fuel injector, fuel pressure regulator and fuel filter.

\*5: Inspect air leak in air intake system.

\*6: Adjust accelerator cable.