

CHASSIS SECTION

This service manual has been prepared to provide SUBARU service personnel with the necessary information and data for the correct maintenance and repair of SUBARU vehicles.

This manual includes the procedures for maintenance, disassembling, reassembling, inspection and adjustment of components and diagnostics for guidance of experienced mechanics.

Please peruse and utilize this manual fully to ensure complete repair work for satisfying our customers by keeping their vehicle in optimum condition. When replacement of parts during repair work is needed, be sure to use SUBARU genuine parts.

All information, illustration and specifications contained in this manual are based on the latest product information available at the time of publication approval.

FRONT SUSPENSION	FS
REAR SUSPENSION	RS
WHEEL AND TIRE SYSTEM	WT
DIFFERENTIALS	DI
TRANSFER CASE	TC
DRIVE SHAFT SYSTEM	DS
ABS	ABS
ABS (DIAGNOSTICS)	ABS(diag)
BRAKE	BR
PARKING BRAKE	PB
POWER ASSISTED SYSTEM (POWER STEERING)	PS

POWER ASSISTED SYSTEM (POWER STEERING)

PS

	Page
1. General Description	2
2. Steering Wheel.....	23
3. Universal Joint.....	24
4. Tilt Steering Column.....	26
5. Steering Gearbox [LHD MODEL]	29
6. Steering Gearbox [RHD MODEL]	47
7. Pipe Assembly [LHD MODEL]	64
8. Pipe Assembly [RHD MODEL].....	72
9. Oil Pump	80
10. Reservoir Tank.....	85
11. Power Steering Fluid.....	86
12. General Diagnostic Table.....	87

General Description

POWER ASSISTED SYSTEM (POWER STEERING)

1. General Description

A: SPECIFICATIONS

Model		1.6 L	2.0 L				2.5 L
			Except OUTBACK	OUT- BACK	DOHC TURBO		
		LHD			RHD	STi	
Whole system	Minimum turning radius m (ft)	5.2 (17.1)		5.5 (18.0)			
	Steering angle (Inside-Outside)	37.3° — 32.4°		34.5° — 30.3°			
	Steering wheel diameter mm (in)	385 (15.16)				375 (14.76)	385 (15.16)
	Overall gear ratio (Turns, lock to lock Gear box)	3.22		3.02		2.69	
Gearbox	Type	Rack and pinion, Integral					
	Backlash	0 (Automatically adjustable)					
	Valve (Power steering system)	Rotary valve					
Pump (Power steering system)	Type	Vane pump					
	Oil tank	Installed on body					
	Output cm ³ (cu in)/rev.	7.2 (0.439)	7.8 (0.476)		7.2 (0.439)		7.8 (0.476)
	Relief pressure kPa (kg/cm ² , psi)	6,174 — 6,860 (63 — 70, 896 — 994)	6,767 — 7,453 (69 — 76, 981 — 1,081)		7,350 — 8,036 (75 — 82, 1,067 — 1,165)		6,767 — 7,453 (69 — 76, 981 — 1,081)
	Hydraulic fluid control	Dropping in response to increased engine revolutions					
	Hydraulic fluid ℓ (US qt, Imp qt)/min	1,000 rpm: 6.7 (7.1, 5.9) 3,000 rpm: 6.2 (6.6, 5.4)	1,000 rpm: 7 (7.4, 6.2) 3,000 rpm: 5 (5.3, 4.4)		7.5 (7.9, 6.6) ^{*1} 7 (7.4, 6.2) ^{*2}		1,000 rpm: 7 (7.4, 6.2) 3,000 rpm: 5 (5.3, 4.4)
	Range of revolution rpm	700 — 9,000					
	Revolving direction	Clockwise					
Working fluid (Power steering system)	Name	ATF DEXRON III or equivalent					
	Capacity ℓ (US qt, Imp qt)	Oil tank	0.3 (0.3, 0.3)				
		Total	0.7 (0.7, 0.6)				

*1: With maximum load.

*2: With no load.

General Description

POWER ASSISTED SYSTEM (POWER STEERING)

Model		LHD	RHD	
Steering wheel	Free play	mm (in)	17 (0.67)	
Turning angle	Inner tire & wheel	TURBO, OUTBACK, RS	34.5°±1.5°	
		Except TURBO, OUTBACK, RS	37.3°±1.5°	
	Outer tire & wheel	TURBO, OUTBACK, RS	30.3°±1.5°	
		Except TURBO, OUTBACK, RS	32.4°±1.5°	
Steering shaft	Clearance between steering wheel and column cover	mm (in)	4.0 (0.16)	
Steering gear-box (Power steering system)	Sliding resistance		400 (41, 90) or less	
	Rack shaft play in radial direction	Right-turn steering	mm (in)	0.19 (0.0075) or less
		Left-turn steering	mm (in)	Horizontal movement: 0.15 (0.0059) or less Vertical movement: 0.3 (0.012) or less
	Input shaft play	In radial direction	mm (in)	0.18 (0.0071) or less
		In axial direction	mm (in)	0.5 (0.020) or less
	Turning resistance		N (kgf, lb)	Maximum allowable value: Less than 10.5 N (1.1 kgf, 2.4 lb) Difference between right and left sliding resistance: Less than 20%
Oil pump (Power steering system)	Pulley shaft	Radial play	mm (in)	0.4 (0.016) or less
		Axial play	mm (in)	0.9 (0.035) or less
	Pulley	Ditch deflection	mm (in)	1.0 (0.039) or less
		Resistance to rotation	N (kgf, lb)	9.22 (0.94, 2.07) or less
	Regular pressure (Unloaded)		kPa (kg/cm ² , psi)	981 (10, 142) or less
Steering wheel effort (Power steering system)	At standstill with engine idling on a concrete road	N (kgf, lb)	31.4 (3.2, 7.1) or less	
	At standstill with engine stalled on a concrete road	N (kgf, lb)	294.2 (30, 66.2) or less	

Recommended power steering fluid	Manufacturer
ATF DEXRON III or equivalent	B.P.
	CALTEX
	CASTROL
	MOBIL
	SHELL
	TEXACO

General Description


POWER ASSISTED SYSTEM (POWER STEERING)

CAUTION:

This table lists various clearances that must be correctly adjusted to ensure the normal vehicle driving without interfering noise, or any other faults.

Location	Minimum allowance
(1) Crossmember — Pipe	5 mm (0.20 in)
(2) DOJ — Shaft or joint	14 mm (0.55 in)
(3) DOJ — Valve housing	11 mm (0.43 in)
(4) Pipe — Pipe	2 mm (0.08 in)
(5) Stabilizer — Pipe	5 mm (0.20 in)
(6) Exhaust pipe — Pipe	11 mm (0.43 in)
(7) Exhaust pipe — Gearbox bolt	15 mm (0.59 in)
(8) Side frame — Hose A and B	10 mm (0.39 in)
(9) Cruise control pump — Hose A and B	15 mm (0.59 in)
(10) Pipe portion of hose A — Pipe portion of hose B	1.5 mm (0.059 in)

• LHD MODEL




PS-00193

General Description

POWER ASSISTED SYSTEM (POWER STEERING)

- RHD MODEL




PS-00428

General Description

POWER ASSISTED SYSTEM (POWER STEERING)

B: COMPONENT

1. STEERING WHEEL AND COLUMN



- | | |
|-----------------------------|--------------------------------|
| (1) Bushing | (5) Steering wheel |
| (2) Steering shaft | (6) Airbag module |
| (3) Steering roll connector | (7) Steering wheel lower cover |
| (4) Column cover | |

Tightening torque: N·m (kgf·m, ft·lb)

T1: 1.2 (0.12, 0.9)

T2: 25 (2.5, 18.1)



T3: 45 (4.6, 33.2)

General Description

POWER ASSISTED SYSTEM (POWER STEERING)

2. POWER ASSISTED SYSTEM

• LHD MODEL



PS-00429

General Description

POWER ASSISTED SYSTEM (POWER STEERING)

(A) NON-TURBO MODEL	(24) Oil seal	(50) Steering body
(B) TURBO MODEL	(25) Ball bearing	(51) Oil seal
	(26) Seal ring	(52) Piston ring
(1) Eye bolt	(27) Pinion and valve ASSY	(53) Rack
(2) Pipe C	(28) Oil seal	(54) Rack bushing
(3) Gasket	(29) Back-up washer	(55) Rack stopper
(4) Clip	(30) Ball bearing	(56) Circlip
(5) Pipe D	(31) Snap ring	(57) Suction hose
(6) Clamp E	(32) Lock nut	(58) Hose
(7) O-ring	(33) Adjusting screw	
(8) Cap	(34) Spring	
(9) Reservoir tank	(35) Sleeve	
(10) Reservoir tank bracket	(36) Adapter	
(11) Pulley	(37) Clamp	
(12) Oil pump	(38) Cotter pin	
(13) Bracket	(39) Castle nut	
(14) Belt tension nut	(40) Dust cover	
(15) Bush	(41) Clip	
(16) Belt cover	(42) Tie-rod end	
(17) Pipe E	(43) Clip	
(18) Pipe F	(44) Boot	
(19) Clamp plate	(45) Band	
(20) Universal joint	(46) Tie-rod	
(21) Dust seal	(47) Lock washer	
(22) Valve housing	(48) Pipe B	
(23) Gasket	(49) Pipe A	

Tightening torque: N·m (kgf-m, ft-lb)

T1: 6 (0.6, 4.3)

T2: 7.4 (0.75, 5.4)

T3: 8 (0.8, 5.8)

T4: 13 (1.3, 9.4)

T5: 15 (1.5, 10.8)

T6: 15.7 (1.6, 11.6)

T7: 22 (2.2, 15.9)

T8: 24 (2.4, 17.4)

T9: 25 (2.5, 18.1)

T10: 27 (2.75, 19.9)

T11: 37.3 (3.8, 27.5)

T12: 39 (4.0, 28.9)

T13: 60 (6.1, 44.1)



T14: 78 (8.0, 57.9)

T15: 83 (8.5, 61.5)

General Description

POWER ASSISTED SYSTEM (POWER STEERING)

• RHD MODEL



PS-00430

General Description

POWER ASSISTED SYSTEM (POWER STEERING)

(A) NON-TURBO MODEL	(23) Seal ring	(48) Adjusting screw
(B) TURBO MODEL	(24) Oil seal	(49) Spring
	(25) Adapter	(50) Sleeve
(1) Eye bolt	(26) Clamp	(51) Seat pad
(2) Pipe C	(27) Castle nut	(52) Suction hose
(3) Gasket	(28) Cotter pin	(53) Return hose
(4) Clip	(29) Dust seal	
(5) Pipe D	(30) Clip	
(6) Clamp E	(31) Tie-rod end	
(7) O-ring	(32) Clip	
(8) Cap	(33) Boot	
(9) Reservoir tank	(34) Wire	
(10) Reservoir tank bracket	(35) Tie-rod	
(11) Pulley	(36) Holder	
(12) Oil pump	(37) Bush	
(13) Bracket	(38) Oil seal	
(14) Belt tension nut	(39) Oil seal	
(15) Bush	(40) O-ring	
(16) Belt cover	(41) Rack	
(17) Universal joint	(42) Oil seal	
(18) Dust cover	(43) Back-up washer	
(19) Plug	(44) Steering body	
(20) O-ring	(45) Pipe A	
(21) Oil seal	(46) Pipe B	
(22) Pinion	(47) Lock nut	

Tightening torque: N-m (kgf-m, ft-lb)

T1: 7.4 (0.75, 5.4)

T2: 8 (0.8, 5.8)

T3: 13 (1.3, 9.4)

T4: 15 (1.5, 10.8)

T5: 15.7 (1.6, 11.6)

T6: 20 (2.0, 14.5)

T7: 22 (2.2, 15.9)

T8: 24 (2.4, 17.4)

T9: 25 (2.5, 18.1)

T10: 27 (2.75, 19.9)

T11: 37.3 (3.8, 27.5)

T12: 39 (4.0, 28.9)

T13: 60 (6.1, 44.1)

T14: 64 (6.5, 47.0)

T15: 90 (9.0, 65.1)


T16: 85 (8.6, 62.2)

General Description

POWER ASSISTED SYSTEM (POWER STEERING)

3. OIL PUMP

- EXCEPT DOHC TURBO MODEL




PS-00024

(1) Oil pump ASSY

General Description

POWER ASSISTED SYSTEM (POWER STEERING)

• DOHC TURBO MODEL



(1) Oil pump ASSY

PS-00005

C: CAUTION





- Wear working clothing, including a cap, protective goggles, and protective shoes during operation.
- Before removal, installation or disassembly, be sure to clarify the failure. Avoid unnecessary removal, installation, disassembly and replacement.
- Be careful not to burn your hands, because each part on the vehicle is hot after running.
- Use SUBARU genuine power steering fluid, grease etc. or the equivalent. Do not mix steering fluid, grease etc. with that of another grade or from other manufacturers.
- Be sure to tighten fasteners including bolts and nuts to the specified torque.
- Place shop jacks or rigid racks at the specified points.
- Before securing a part on a vise, place cushioning material such as wood blocks, aluminum plate, or shop cloth between the part and the vise.

General Description

POWER ASSISTED SYSTEM (POWER STEERING)





D: PREPARATION TOOL

1. SPECIAL TOOLS

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">ST-925700000</p>	925700000	WRENCH	<ul style="list-style-type: none"> • Used for removing and installing tie-rod. • Apply this tool to rack.
 <p style="text-align: center;">ST-925711000</p>	925711000	PRESSURE GAUGE	Used for measuring oil pump pressure.
 <p style="text-align: center;">ST-926200000</p>	926200000	STAND	Used when inspecting characteristic of gearbox assembly and disassembling it.
 <p style="text-align: center;">ST34099AC010</p>	34099AC010	ADAPTER HOSE A	Used with PRESSURE GAUGE (925711000).





General Description

POWER ASSISTED SYSTEM (POWER STEERING)

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">ST34099AC020</p>	34099AC020	ADAPTER HOSE B	Used with PRESSURE GAUGE (925711000).
 <p style="text-align: center;">ST-926230000</p>	926230000	SPANNER	For the lock nut when adjusting backlash of gear-box.
 <p style="text-align: center;">ST34099PA100</p>	34099PA100	SPANNER	Used for measuring the rotating resistance of gear-box assembly.
 <p style="text-align: center;">ST34199AE040</p>	34199AE040	OIL CHARGE GUIDE	Used for charging power steering fluid.





General Description

POWER ASSISTED SYSTEM (POWER STEERING)

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">ST-926420000</p>	926420000	PLUG	When oil leaks from pinion side of gearbox assembly, remove pipe B from valve housing, attach this tool and check oil leaking points.
 <p style="text-align: center;">ST-926370000</p>	926370000	INSTALLER A	<ul style="list-style-type: none"> • Used for installing valve assembly into valve housing assembly. • Used with STAND BASE (34099FA100). • For LHD model.
 <p style="text-align: center;">ST34099FA100</p>	34099FA100	STAND BASE	<ul style="list-style-type: none"> • Used for assembling power steering gearbox. • For LHD model.
 <p style="text-align: center;">ST-926390001</p>	926390001	COVER & REMOVER ASSY	<ul style="list-style-type: none"> • Used for assembling rack assembly. • For LHD model.





General Description

POWER ASSISTED SYSTEM (POWER STEERING)

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST-926400000	926400000	GUIDE	<ul style="list-style-type: none">• Right side of rack when installing rack bush.• Used with GUIDE (927660000).• For LHD model.
 ST-927660000	927660000	GUIDE	<ul style="list-style-type: none">• Right side of rack when installing rack bush.• Used with GUIDE (926400000).• For LHD model.
 ST-927620000	927620000	INSTALLER B	<ul style="list-style-type: none">• Used for installing oil seal of valve housing.• Used with INSTALLER A (926360000).• For LHD model.
 ST-926360000	926360000	INSTALLER A	<ul style="list-style-type: none">• Used as a guide to install oil seal.• Used with INSTALLER B (927620000).• For LHD model.





General Description

POWER ASSISTED SYSTEM (POWER STEERING)

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">ST34099FA110</p>	<p style="text-align: center;">34099FA110</p>	<p style="text-align: center;">INSTALLER</p>	<p>Used for installing oil seal.</p> <ul style="list-style-type: none"> • For LHD model.
 <p style="text-align: center;">ST34099FA120</p>	<p style="text-align: center;">34099FA120</p>	<p style="text-align: center;">INSTALLER AND REMOVER SEAL</p>	<ul style="list-style-type: none"> • Used for installing valve housing oil seal. • Used with INSTALLER SEAL. (34099FA130) • Used for installing valve housing ball bearing. • Used for removing oil seal and ball bearing from valve housing. • For LHD model.
 <p style="text-align: center;">ST34099FA130</p>	<p style="text-align: center;">34099FA130</p>	<p style="text-align: center;">INSTALLER SEAL</p>	<ul style="list-style-type: none"> • Used for installing valve housing oil seal. • Used with INSTALLER AND REMOVER SEAL (34099FA120). • For LHD model.
 <p style="text-align: center;">ST-926250000</p>	<p style="text-align: center;">926250000</p>	<p style="text-align: center;">GUIDE</p>	<ul style="list-style-type: none"> • Used for installing holder ASSY into rack housing. • For RHD model.





General Description

POWER ASSISTED SYSTEM (POWER STEERING)

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">ST-927490000</p>	<p style="text-align: center;">927490000</p>	<p>INSTALLER A, B, C</p>	<ul style="list-style-type: none"> • Used for installing oil seal into rack assembly. • For RHD model.
 <p style="text-align: center;">ST-927580000</p>	<p style="text-align: center;">927580000</p>	<p>REMOVER</p>	<ul style="list-style-type: none"> • Used for removing back-up ring and oil seal. • For RHD model.
 <p style="text-align: center;">ST34199AE000</p>	<p style="text-align: center;">34199AE000</p>	<p>GUIDE</p>	<ul style="list-style-type: none"> • Used for installing rack and seal into housing assembly. • For RHD model.
 <p style="text-align: center;">ST34099FA030</p>	<p style="text-align: center;">34099FA030</p>	<p>INSTALLER & REMOVER</p>	<ul style="list-style-type: none"> • Used for removing and installing rack oil seal (outer & inner). • For RHD model.





General Description

POWER ASSISTED SYSTEM (POWER STEERING)

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">ST34199AE010</p>	34199AE010	INSTALLER	<ul style="list-style-type: none"> • Used for installing rack oil seal (outer). • For RHD model.
 <p style="text-align: center;">ST34099FA060</p>	34099FA060	PUNCH HOLDER	<ul style="list-style-type: none"> • Used for caulking. • For RHD model.
 <p style="text-align: center;">ST34099FA070</p>	34099FA070	BASE	<ul style="list-style-type: none"> • Used for supporting housing assembly. • For RHD model.
 <p style="text-align: center;">ST34099FA080</p>	34099FA080	PUNCH	<ul style="list-style-type: none"> • Used for removing caulking. • For RHD model.


General Description

POWER ASSISTED SYSTEM (POWER STEERING)

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST34199AE090	34199AE090	PLUG WRENCH	<ul style="list-style-type: none">• Used for removing plug.• For RHD model.
 ST34199AE100	34199AE100	PLUG OIL SEAL REMOVER	<ul style="list-style-type: none">• Used for removing plug oil seal.• For RHD model.
 ST34199AE110	34199AE110	PLUG OIL SEAL INSTALLER	<ul style="list-style-type: none">• Used for installing plug oil seal.• For RHD model.
 ST34199AE120	34199AE120	GEARBOX OIL SEAL REMOVER	<ul style="list-style-type: none">• Used for removing gearbox oil seal.• For RHD model.

General Description

POWER ASSISTED SYSTEM (POWER STEERING)

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p data-bbox="326 548 467 569">ST34199AE130</p>	34199AE130	GEARBOX OIL SEAL INSTALLER	<ul style="list-style-type: none">• Used for installing gearbox oil seal.• For RHD model.

Steering Wheel

POWER ASSISTED SYSTEM (POWER STEERING)

2. Steering Wheel


A: REMOVAL

- 1) Disconnect the ground cable from battery.
- 2) Set the tires to straight-ahead position.
- 3) Remove the airbag module. <Ref. to AB-12, REMOVAL, Driver's Airbag Module.>

WARNING:

Always refer to "Airbag System" before performing airbag module service. <Ref. to AB-3, CAUTION, General Description.>

- 4) Make matching marks on the steering wheel and steering shaft.



(1) Matching mark

- 5) Remove the steering wheel nut, and then draw out the steering wheel from shaft using steering puller.

B: INSTALLATION

WARNING:

Always refer to "Airbag System" before performing airbag module service. <Ref. to AB-3, CAUTION, General Description.>

- 1) Align the center of roll connector. <Ref. to AB-18, ADJUSTMENT, Roll Connector.>
- 2) Install in the reverse order of removal.

NOTE:

Align matching marks on the steering wheel and steering shaft.

Tightening torque:

45 N·m (4.6 kgf·m, 33.2 ft·lb)

Column cover-to-steering wheel clearance:

2 — 4 mm (0.08 — 0.16 in)

CAUTION:

Insert the roll connector guide pin into guide hole on lower end of surface of steering wheel to prevent damage.

C: INSPECTION

- 1) Check the steering wheel for deformation. If the deformation is excessive, replace steering wheel.
- 2) Check the splines on steering wheel for damage. If the damage is excessive, replace steering wheel.


Universal Joint

POWER ASSISTED SYSTEM (POWER STEERING)

3. Universal Joint


A: REMOVAL

- 1) Remove the steering wheel. <Ref. to PS-23, REMOVAL, Steering Wheel.>
- 2) Make matching mark on the universal joint.
- 3) Remove the universal joint bolts, and then remove the universal joint.



B: INSTALLATION

- 1) Align the cutout at serrated section of the column shaft and yoke, and then insert the universal joint into column shaft.



- (1) Cutout
- (2) Yoke
- (3) Column shaft
- (4) Column shaft side
- (5) Gearbox side

- 2) Align the matching marks, and then insert the universal joint to serrated section of gear box assembly.

- 3) Tighten the bolt.

Tightening torque:

24 N·m (2.4 kgf·m, 17.4 ft·lb)

CAUTION:

Excessively large tightening torque of the universal joint bolts may lead to heavy steering wheel operation.

Standard clearance between gearbox to DOJ:
Over 14 mm (0.55 in)

- 4) Align the center of roll connector. <Ref. to AB-18, ADJUSTMENT, Roll Connector.>
- 5) Install the steering wheel and airbag module. <Ref. to PS-23, INSTALLATION, Steering Wheel.>

WARNING:

Always refer to "Airbag System" before performing airbag module service. <Ref. to AB-3, CAUTION, General Description.>


C: INSPECTION

Check for wear, damage, or any other faults. If necessary, replace.

Service limit:

Universal joint play; 0 mm (0 in)

Maximum swing torque; 0.3 N (0.03 kgf, 0.07 lb)



- (1) Swing torque
- (2) Play


Measurement of folding torque of universal joint is as shown in the figures.

Universal Joint

POWER ASSISTED SYSTEM (POWER STEERING)

Service limit:


Maximum load; 3.8 N (0.39 kgf, 0.86 lb) or less



(1) Yoke (gearbox side)

Service limit:


Maximum load; 7.3 N (0.74 kgf, 1.64 lb) or less



(1) Yoke (Steering column side)

Service limit:


Maximum load; 3.8 N (0.39 kgf, 0.86 lb) or less



(1) Yoke (gearbox side)

Service limit:

Maximum load; 7.3 N (0.74 kgf, 1.64 lb) or less




(1) Yoke (Steering column side)

Tilt Steering Column

POWER ASSISTED SYSTEM (POWER STEERING)

4. Tilt Steering Column

A: REMOVAL



PS-00038

(1) Tilt steering column

(2) Universal joint

Tightening torque: N·m (kgf·m, ft·lb)

T1: 24 (2.4, 17.4)

T2: 25 (2.5, 18.1)

Tilt Steering Column


POWER ASSISTED SYSTEM (POWER STEERING)

- 1) Set the vehicle on a lift.
- 2) Disconnect the ground cable from battery.
- 3) Remove the airbag module. <Ref. to AB-12, REMOVAL, Driver's Airbag Module.>

WARNING:

Always refer to "Airbag System" before performing airbag module service. <Ref. to AB-3, CAUTION, General Description.>

- 4) Remove the steering wheel. <Ref. to PS-23, REMOVAL, Steering Wheel.>
- 5) Remove the universal joint. <Ref. to PS-24, REMOVAL, Universal Joint.>
- 6) Remove the trim panel under instrument panel.
- 7) Remove the steering column lower cover.
- 8) Remove all connectors from steering column.
- 9) Remove the two bolts under instrument panel securing steering column.




- 10) Pull out the steering shaft assembly from hole on toe board.

CAUTION:

- Be sure to remove the universal joint before removing the steering shaft assembly installing bolts when removing the steering shaft assembly or when lowering it for servicing of other parts.
- Do not loosen the tilt lever when the steering column is not secured to the vehicle.

B: INSTALLATION

- 1) Set the grommet to toe board.



- 2) Insert the end of steering shaft into toe board grommet.
- 3) With the tilt lever secured, tighten the steering shaft mounting bolts under instrument panel.

Tightening torque:

25 N·m (2.5 kgf·m, 18.1 ft·lb)

- 4) Connect all connectors under instrument panel.
- 5) Connect the airbag system connector at harness spool.

NOTE:

Make sure to apply double lock.

- 6) Install the lower column cover with tilt lever held in the lowered position.
- 7) Install the universal joint. <Ref. to PS-24, INSTALLATION, Universal Joint.>
- 8) Align center of roll connector. <Ref. to AB-18, ADJUSTMENT, Roll Connector.>
- 9) Install the steering wheel. <Ref. to PS-23, INSTALLATION, Steering Wheel.>

CAUTION:

Insert the roll connector guide pin into guide hole on lower end of surface of steering wheel to prevent damage.

- 10) Install the airbag module to steering wheel.

WARNING:

Always refer to "Airbag System" before performing the service operation. <Ref. to AB-3, CAUTION, General Description.>

C: DISASSEMBLY

Remove the two screws securing upper steering column covers, and two screws securing combination switch, and then remove the related parts.

Tilt Steering Column

POWER ASSISTED SYSTEM (POWER STEERING)

D: ASSEMBLY

Insert the combination switch to upper column shaft, and then install the upper column cover. Then route the ignition key harness and combination switch harness between column cover mounting bosses.

Tightening torque:

1.2 N·m (0.12 kgf-m, 0.9 ft-lb)

CAUTION:

Do not overtorque the screw.

E: INSPECTION

1. BASIC INSPECTION

Measure overall length of the steering column. If not as specified, replace.

Standard value:


Overall length L

Except STi model

825.7±1.5 mm (32.51±0.059 in)

STi model

818.7±1.5 mm (32.23±0.059 in)



2. AIRBAG MODEL INSPECTION

WARNING:

For airbag inspection procedures, refer to “Airbag System”. <Ref. to AB-3, CAUTION, General Description.>

Steering Gearbox [LHD MODEL]

POWER ASSISTED SYSTEM (POWER STEERING)

5. Steering Gearbox [LHD MODEL]


A: REMOVAL

- 1) Set the vehicle on a lift.
- 2) Disconnect the ground cable from battery.
- 3) Loosen the front wheel nut.
- 4) Lift-up the vehicle, and then remove the front wheels.
- 5) Remove the under cover.
- 6) Remove the sub frame. <Ref. to FS-25, REMOVAL, Sub Frame.>
- 7) Remove the front exhaust pipe assembly. (Non-turbo model)
<Ref. to EX(H4SO)-6, REMOVAL, Front Exhaust Pipe.>

WARNING:


Be careful, the exhaust pipe is hot.

- 8) Using a puller, remove the tie-rod end from knuckle arm after pulling off cotter pin and removing castle nut.




- (1) Castle nut
- (2) Tie-rod end
- (3) Knuckle arm

- 9) Remove the jack-up plate and front stabilizer.




- (1) Jack-up plate

- 10) Remove the one pipe joint at center of gearbox, and connect vinyl hose to pipe and joint. Discharge fluid by turning the steering wheel fully clockwise and counterclockwise. Discharge fluid similarly from the other pipe.




- (1) Pipe A
- (2) Pipe B

- 11) Remove the universal joint. <Ref. to PS-24, REMOVAL, Universal Joint.>
- 12) Disconnect the lower pipe C from gear box first, and upper pipe D second.



- (1) Pipe C
- (2) Pipe D

- 13) Remove the clamp bolts securing the gearbox to crossmember, and then remove the gearbox.



- (1) Clamp

Steering Gearbox [LHD MODEL]


POWER ASSISTED SYSTEM (POWER STEERING)

B: INSTALLATION

- 1) Insert the gearbox into crossmember, being careful not to damage the gearbox boot.
- 2) Tighten the gearbox to crossmember bracket via clamp with bolts to specified torque.

Tightening torque:

60 N·m (6.1 kgf·m, 44.1 ft·lb)




(1) Clamp

- 3) Connect the pipe D first to gear box, and pipe C second.

Tightening torque:

15 N·m (1.5 kgf·m, 10.8 ft·lb)



(1) Pipe C

(2) Pipe D

- 4) Install the universal joint. <Ref. to PS-24, INSTALLATION, Universal Joint.>
- 5) Connect the tie-rod end and knuckle arm, and tighten with castle nut.


Castle nut tightening torque:

27 N·m (2.75 kgf·m, 19.9 ft·lb)

CAUTION:

When connecting, do not hit the cap at bottom of tie-rod end with hammer.

- 6) After tightening the castle nut to specified torque, tighten it further within 60° until cotter pin hole is aligned with the slot in nut, and then bend the cotter pin to lock.



(A) Cotter pin

(B) Castle nut

(C) Tie-rod end

- 7) Install the front stabilizer to vehicle. <Ref. to FS-23, INSTALLATION, Front Stabilizer.>
- 8) Install the front exhaust pipe assembly.
- 9) Install the sub frame. <Ref. to FS-25, INSTALLATION, Sub Frame.>
- 10) Install the under cover. <Ref. to EI-21, INSTALLATION, Front Under Cover.>
- 11) Align the center of roll connector. <Ref. to AB-18, ADJUSTMENT, Roll Connector.>
- 12) Install the steering wheel. <Ref. to PS-23, INSTALLATION, Steering Wheel.>
- 13) Install the front wheels.
- 14) Tighten the wheel nuts to specified torque.

Tightening torque:

90 N·m (9.1 kgf·m, 65.8 ft·lb)

- 15) Connect the battery ground cable to battery.
- 16) Pour fluid into the oil tank, and bleed air. <Ref. to PS-86, Power Steering Fluid.>
- 17) Check for fluid leaks.
- 18) Install the jack-up plate.
- 19) Lower the vehicle.
- 20) Check the fluid level in oil tank.

Steering Gearbox [LHD MODEL]

POWER ASSISTED SYSTEM (POWER STEERING)


21) After adjusting the toe-in and steering angle, tighten the lock nut on tie-rod end.

Tightening torque:

83 N-m (8.5 kgf-m, 61.5 ft-lb)

NOTE:

When adjusting the toe-in, hold boot as shown to prevent it from being rotated or twisted. If twisted, straighten it.



C: DISASSEMBLY

1. RACK HOUSING ASSEMBLY

1) Disconnect the four pipes from gearbox.

NOTE:


Remove the pipes E and F as a single unit being fixed at clamp plate.

2) Secure the gearbox removed from vehicle in vice using ST.

ST 926200000 STAND


CAUTION:

Secure the gearbox in a vise using ST as shown. Do not attempt to secure it without this ST.




3) Remove the tie-rod end and lock nut from gearbox.

4) Remove the small clip from boot using pliers, and then move the boot to tie-rod end side.



(1) Clip

5) Using a flat tip screwdriver, remove the band from boot.




(1) Band

6) Extend the rack approx. 40 mm (1.57 in) out. Unlock the lock washer on both side of tie-rod end using a flat tip screwdriver.

CAUTION:

Be careful not to scratch the rack surface as oil leaks may result.




(1) Lock washer

(2) Approx. 40 mm (1.57 in)


Steering Gearbox [LHD MODEL]

POWER ASSISTED SYSTEM (POWER STEERING)


7) Using the ST, loosen the lock nut.
ST 926230000 SPANNER



8) Tighten the adjusting screw until it no longer tightens.




9) Using a wrench [32 mm (1.26 in) width across flats] or adjustable wrench, remove the tie-rod.




10) Loosen the adjusting screw, and then remove the spring and sleeve.


11) Remove the two bolts securing valve assembly.



12) Carefully draw out the input shaft, and then remove the valve assembly.



13) Using a sharp pointed pliers, rotate the rack stopper in direction of the arrow until end of the circlip comes out of stopper. Rotate the circlip in opposite direction and pull it out.




(1) Rack stopper

14) Pull the rack assembly from cylinder side, and draw out the rack bushing and rack stopper together with the rack assembly.

CAUTION:

Be careful not to contact the rack to inner wall of cylinder when drawing out. Any scratch on the cylinder inner wall will cause oil leakage.



(1) Rack bushing

(2) Rack assembly


(3) Rack stopper

15) Remove the rack bushing and rack stopper from rack assembly.

Steering Gearbox [LHD MODEL]

POWER ASSISTED SYSTEM (POWER STEERING)

- 16) Remove the oil seal from rack.
 - 17) Insert the ST from pinion housing side, and then remove the oil seal using a press.
- ST 34099FA110 INSTALLER



- (1) Press
- (2) Oil seal

2. CONTROL VALVE

- 1) Disconnect the four pipes from gearbox.

NOTE:


Remove the pipes E and F as a single unit being fixed at clamp plate.

- 2) Secure the gearbox removed from the vehicle in vise using ST.


ST 926200000 STAND

CAUTION:


Secure the gearbox in a vise using ST as shown. Do not attempt to secure it without this ST.



- 3) Using the ST, loosen the lock nut.
- ST 926230000 SPANNER




- 4) Tighten the adjusting screw until it no longer tightens.




- 5) Loosen the adjusting screw, and then remove the spring and sleeve.

- 6) Remove the two bolts securing valve assembly.




- 7) Carefully draw out the input shaft, and then remove the valve assembly.



Steering Gearbox [LHD MODEL]


POWER ASSISTED SYSTEM (POWER STEERING)

8) Slide the dust cover out.



(1) Dust cover

9) Using a press remove the pinion and valve assembly from valve housing.




(1) Valve assembly
(2) Valve housing
(3) Cloth

10) Using the ST and press, remove the dust seal, oil seal and special bearing from valve housing.
ST 34099FA120 INSTALLER & REMOVER SEAL

CAUTION:

- Do not apply force to the end surface of valve housing.
- Do not reuse the oil seal after removal.




(1) Oil seal
(2) Special bearing


11) Remove the snap ring using snap ring pliers.

CAUTION:

Be careful not to scratch the pinion and valve assembly.



12) Press out the bearing together with the back up washer using pipe of I.D. 38.5 to 39.5 mm (1.516 to 1.555 in) and press.



(1) Bearing
(2) Backing washer
(3) Oil seal
(4) Pipe

13) Remove the oil seal.

Steering Gearbox [LHD MODEL]

POWER ASSISTED SYSTEM (POWER STEERING)

D: ASSEMBLY

1. RACK HOUSING ASSEMBLY

CAUTION:

Use only SUBARU genuine grease for the gearbox.

Specified grease for gearbox:

VALIANT GREASE M2 (Part No. 003608001)


1) Apply power steering fluid to a new oil seal.

2) Install the oil seal in correct position as shown in the figure. Push the oil seal using a press until portion A of ST contacts face of B.

ST 34099FA110 INSTALLER

CAUTION:

Be careful not to damage or scratch the cylinder inner wall.



(1) Press

(2) Oil seal

3) Fix the rack housing in vise using ST.


ST 926200000 STAND

NOTE:

- When fixing the rack housing in vise, be sure to use this special tool. Do not fix rack housing in vise using pad such as aluminum plates, etc.
- When using the old rack housing, be sure to clean and remove rust before assembling. Check pinion housing bushing carefully.

4) Fit the ST over toothed portion of rack assembly, and check for binding or unsmooth insertion. If any deformation is noted on flats at the end of rack, shape by using file, and wash with cleaning fluid.

ST 926390001 COVER & REMOVER



(1) Rack assembly

5) Apply genuine grease to the teeth of thoroughly washed rack assembly, and then fit the ST over the toothed portion.

CAUTION:

- Be careful not to block the air passage with grease. Remove excessive grease.
- After fitting cover, check the air passage hole for clogging. If clogged, open by removing grease from the hole.

6) Before inserting the rack assembly, apply a coat of specified power steering fluid to the surfaces of ST and rack piston.

7) Insert the rack assembly into rack housing from cylinder side, and then remove the ST after it has passed completely through oil seal.

8) Fit the ST1 and ST2 over the end of rack, and then install a new rack bushing.

ST1 926400000 GUIDE


ST2 927660000 GUIDE

Steering Gearbox [LHD MODEL]

POWER ASSISTED SYSTEM (POWER STEERING)

CAUTION:

- If burrs or nicks are found on this guide and rack shaft portion, remove by filing.
- Dip the rack bushing in specified power steering fluid before installing, and pay attention not to damage O-ring and oil seal.



(1) Rack bushing assembly

9) Insert the rack stopper into the cylinder tube until internal groove (on cylinder side) is aligned with external groove (on rack stopper). Turn the rack stopper with ST so that the rack stopper hole is seen through cylinder slits.


10) Insert the rack stopper into the rack housing, and then wrap a new circlip using a sharp pointed pliers to secure the rack stopper in position.

CAUTION:


Be careful not to scratch the rack while winding circlip.

NOTE:

Rotate the wrench another 90 to 180° after end of circlip has been wrapped in.




11) Apply genuine grease to dust cover, and then install the dust cover to valve assembly.




(1) Dust cover

12) Apply genuine grease to the pinion gear and bearing of valve assembly.



13) Install a new gasket on valve assembly. Insert the valve assembly into place while facing rack teeth toward pinion.



14) Tighten the bolts alternately to secure valve assembly.

Tightening torque:

25 N·m (2.5 kgf·m, 18.1 ft·lb)

CAUTION:

Be sure to alternately tighten the bolts.

Steering Gearbox [LHD MODEL]

POWER ASSISTED SYSTEM (POWER STEERING)


15) Temporarily install the rack, and then operate it from lock to lock two or three times to make it fit in. Remove the grease blocking air vent hole.

CAUTION:

If operating the rack from lock to lock without installing tie-rod, it may damage the oil seal. Always install the tie-rods LH and RH.

16) Apply a coat of grease to the sliding surface of sleeve and seating surface of spring, and then insert sleeve into steering body.

Charge the adjusting screw with grease, and then insert the spring into adjusting screw and install on steering body.



- (1) Sleeve
- (2) Spring
- (3) Adjusting screw

17) Tighten the adjusting screw to specified torque.

Tightening torque:

7.4 N-m (0.75 kgf-m, 5.4 ft-lb)

18) After tightening to the specified tightening torque, loosen it by 25°.


19) Remove the tie-rod.

20) Verify that play is within specified value. <Ref. to PS-44, SERVICE LIMIT, INSPECTION, Steering Gearbox [LHD MODEL].>

21) Loosen the adjusting screw, and then apply liquid gasket to at least 1/3 of the entire perimeter of adjusting screw thread.

Liquid gasket:

THREE BOND 1141



- (1) Apply liquid gasket to at least 1/3 of entire perimeter.

22) Tighten the adjusting screw to specified torque.

Tightening torque:

7.4 N-m (0.75 kgf-m, 5.4 ft-lb)

23) After tightening to the specified tightening torque, loosen it by 25°.

24) Install the lock nut. While holding the adjusting screw with a wrench, tighten lock nut using ST. ST 926230000 SPANNER

Tightening torque (Lock nut):

39 N-m (4.0 kgf-m, 28.9 ft-lb)

NOTE:


Hold the adjusting screw with a wrench to prevent it from turning while tightening lock nut.

25) Extend the rack approx. 40 mm (1.57 in) beyond side of steering body.

26) Install the tie-rod and a new lock washer into rack.

Tightening torque:

78 N-m (8.0 kgf-m, 57.9 ft-lb)



- (1) Lock washer
- (2) Approx. 40 mm (1.57 in)


Steering Gearbox [LHD MODEL]

POWER ASSISTED SYSTEM (POWER STEERING)

27) Bend the lock washer.

CAUTION:

Be careful not to scratch the rack when bending lock washer.




(1) Lock washer


28) Apply a coat of grease to the tie-rod groove, and then install the boot to housing.

NOTE:

Make sure that the boot is installed without unusual inflation or deflation.




29) Install a new boot band. Using band clamp pliers, caulk the boot band until caulking part clearance is 2 mm (0.079 in) or less.



(1) Boot band
(2) 2 mm (0.079 in) or less

30) Fix the boot end with clip (small).



(1) Clip

31) After installing, check the boot end is positioned into groove on tie-rod.

Steering Gearbox [LHD MODEL]

POWER ASSISTED SYSTEM (POWER STEERING)

32) If the tie-rod end was removed, screw in the lock nut and tie-rod end to screwed portion of tie-rod, and then tighten the lock nut temporarily in a position as shown in the figure.


Installed tie-rod length: L

Sedan:


25 mm (0.98 in)

Wagon:

15 mm (0.59 in)



33) Inspect the gearbox as follows:
"A" Holding the tie-rod end, repeat lock to lock two or three times as quickly as possible.
"B" Holding the tie-rod end, turn it slowly at a radius one or two times as large as possible.
After all, make sure that the boot is installed in specified position without deflation.



34) Remove the gearbox from ST.

ST 926200000 STAND

35) Install the four pipes on gearbox.

(1) Connect the pipe A and B to four pipe joints of gearbox.

Tightening torque:

13 N·m (1.3 kgf·m, 9.4 ft·lb)

(2) Connect the pipe E and F to gearbox.

Tightening torque:

Pipe E: 15 N·m (1.5 kgf·m, 10.8 ft·lb)


Pipe F: 25 N·m (2.5 kgf·m, 18.1 ft·lb)

2. CONTROL VALVE ASSEMBLY

Specified steering grease:

VALIANT GREASE M2 (Part No. 003608001)

- 1) Clean all parts and tools before reassembling.
- 2) Apply a coat of specified power steering fluid to the inner wall of valve housing.



(1) Apply fluid.

3) Attach the ST2 to ST1.

ST1 34099FA120 INSTALLER & REMOVER SEAL


ST2 34099FA130 INSTALLER SEAL

4) To avoid scratching the oil seal, apply a coat of grease to the contact surface of installer and oil seal.

5) Verify the oil seal direction.

Attach the oil seal to installer and position in valve housing before pressing into place.

6) Press the oil seal into place using a press.




Steering Gearbox [LHD MODEL]

POWER ASSISTED SYSTEM (POWER STEERING)

7) Attach the bearing to ST, and then position in value housing. Using the ST and press, install the special bearing in valve housing.

ST 34099FA120 INSTALLER & REMOVER SEAL



- (1) Special bearing
- (2) Oil seal

8) Put vinyl tape around the pinion shaft splines to protect oil seal from damage.

9) Fit the pinion and valve assembly into valve housing.

10) Secure the valve assembly to ST1 and ST2.

ST1 926370000 INSTALLER A


ST2 34099FA100 STAND BASE

11) Apply specified power steering fluid to oil seal and ST3.

12) Install the ST3 to pinion, and then insert the oil seal. Press the oil seal using a press until ST4 contacts face end of valve housing.

ST3 926360000 INSTALLER A

ST4 927620000 INSTALLER B



- (1) Oil seal


13) Remove the ST3, and then fit the back-up washer.

14) Force-fit the ball bearing using ST3.

ST1 926370000 INSTALLER A

ST2 34099FA100 STAND BASE

ST3 927640000 INSTALLER B



- (1) Ball bearing
- (2) Back-up washer

NOTE:

Be careful not to tilt the ball bearing during installation.

Steering Gearbox [LHD MODEL]

POWER ASSISTED SYSTEM (POWER STEERING)


15) Install the snap ring using snap ring pliers.

NOTE:

Rotate the snap ring to check for proper installation.


16) Apply the specified grease to dust cover.

17) Install the dust cover on valve assembly.




(1) Dust cover

18) Apply genuine grease to the pinion gear and bearing of valve assembly.



19) Install a new gasket on valve assembly. Insert the valve assembly into place while facing rack teeth toward pinion.



20) Tighten the bolts alternately to secure valve assembly.

Tightening torque:


25 N-m (2.5 kgf-m, 18.1 ft-lb)

CAUTION:

Be sure to alternately tighten the bolts.

21) Apply a coat of grease to the sliding surface of sleeve and seating surface of spring, and then insert sleeve into steering body.

Charge the adjusting screw with grease, and then insert the spring into adjusting screw and install on steering body.



(1) Sleeve

(2) Spring

(3) Adjusting screw

22) Tighten the adjusting screw to specified torque.

Tightening torque:

7.4 N-m (0.75 kgf-m, 5.4 ft-lb)


23) After tightening to the specified tightening torque, loosen it by 25°.

24) Verify that play is within specified value. <Ref. to PS-44, SERVICE LIMIT, INSPECTION, Steering Gearbox [LHD MODEL].>

25) Loosen the adjusting screw, and then apply liquid gasket to at least 1/3 of the entire perimeter of adjusting screw thread.

Liquid gasket:

THREE BOND 1141



(1) Apply liquid gasket to at least 1/3 of entire perimeter.

26) Tighten the adjusting screw to specified torque.

Tightening torque:

7.4 N-m (0.75 kgf-m, 5.4 ft-lb)

27) After tightening to the specified tightening torque, loosen it by 25°.

Steering Gearbox [LHD MODEL]

POWER ASSISTED SYSTEM (POWER STEERING)

28) Install the lock nut. While holding the adjusting screw with a wrench, tighten lock nut using ST.

ST 926230000 SPANNER

Tightening torque (Lock nut):

39 N·m (4.0 kgf-m, 28.9 ft-lb)

NOTE:

Hold the adjusting screw with a wrench to prevent it from turning while tightening lock nut.

29) Remove the gearbox from ST.

30) Install the four pipes on gearbox.

(1) Connect the pipe A and B to the gearbox.

Tightening torque:

13 N·m (1.3 kgf-m, 9.4 ft-lb)

(2) Connect the pipe E and F to gearbox.

Tightening torque:

Pipe E: 15 N·m (1.5 kgf-m, 10.8 ft-lb)

Pipe F: 25 N·m (2.5 kgf-m, 18.1 ft-lb)

Steering Gearbox [LHD MODEL]

POWER ASSISTED SYSTEM (POWER STEERING)

E: INSPECTION

1. BASIC INSPECTION

1) Clean all disassembled parts, and check for wear, damage, or any other faults, then repair or replace as necessary.

2) When disassembling, check the inside of gearbox for water. If any water is found, carefully check the boot for damage, input shaft dust seal, adjusting screw and boot clips for poor sealing. If faulty, replace with new parts.

No.	Parts	Inspection	Corrective action
1	Input shaft	(1) Bend of input shaft (2) Damage on serration	If the bend or damage is excessive, replace the entire gearbox.
2	Dust seal	(1) Crack or damage (2) Wear	If the outer wall slips, the lip is worn out or damage is found, replace it with a new one.
3	Rack and pinion	Poor mating of rack with pinion	(1) Adjust the backlash properly. By measuring the turning torque of gearbox and sliding resistance of rack, check if rack and pinion engage uniformly and smoothly with each other. (Refer to "Service limit".) (2) Keeping the rack pulled out all the way so that all teeth emerge, check teeth for damage. Even if abnormality is found in either (1) or (2), replace the entire gearbox.
4	Gearbox unit	(1) Bend of rack shaft (2) Bend of cylinder portion (3) Crack or damage on cast iron portion	Replace the gearbox with a new one.
		(4) Wear or damage on rack bush	If the free play of rack shaft in radial direction is out of the specified range, replace the gearbox with a new one. (Refer to "Service limit".)
		(5) Wear on input shaft bearing	If the free plays of input shaft in radial and axial directions are out of the specified ranges, replace the gearbox with a new one. (Refer to "Service limit".)
5	Boot	Crack, damage or deterioration	Replace.
6	Tie-rod	(1) Looseness of ball joint (2) Bend of tie-rod	Replace.
7	Tie-rod end	Damage or deterioration on dust seal	Replace.
8	Adjusting screw spring	Deterioration	Replace.
9	Boot clip	Deterioration	Replace.
10	Sleeve	Damage	Replace.
11	Pipes	(1) Damage to flared surface (2) Damage to flare nut (3) Damage to pipe	Replace.

Steering Gearbox [LHD MODEL]

POWER ASSISTED SYSTEM (POWER STEERING)

2. SERVICE LIMIT

Make a measurement as follows. If it exceeds the specified service limit, adjust or replace.

NOTE:


When making a measurement, vise the gearbox by using ST. Never vise the gearbox by inserting aluminum plates, etc. between vise and gearbox.

ST 926200000 STAND


Sliding resistance of rack shaft:

Service limit

400 N (41 kgf, 90 lb) or less



PS-00099



PS-00100

3. RACK SHAFT PLAY IN RADIAL DIRECTION

Right-turn steering:


Service limit

0.19 mm (0.0075 in) or less

On condition

L: 5 mm (0.20 in)

P: 122.6 N (12.5 kgf, 27.6 lb)



PS-00101

Left-turn steering:


Service limit

Direction $\leftarrow \rightarrow$

0.3 mm (0.012 in) or less

Direction $\leftarrow \rightarrow$

0.15 mm (0.0059 in) or less



PS-00102

4. INPUT SHAFT PLAY


In radial direction:

Service limit

0.18 mm (0.0071 in) or less

On condition

P: 98 N (10 kgf, 22 lb)



PS-00103


In axial direction:

Service limit

0.5 mm (0.020 in) or less

On condition

P: 20 — 49 N (2 — 5 kgf, 4 — 11 lb)



PS-00104

Steering Gearbox [LHD MODEL]

POWER ASSISTED SYSTEM (POWER STEERING)

5. TURNING RESISTANCE OF GEARBOX

Using the ST, measure the gearbox turning resistance.


ST 34099PA100 SPANNER

Service limit


Maximum allowable resistance

10.5 N (1.1 kgf, 2.4 lb) or less

Difference between right and left turning resistance: Less than 20%



6. OIL LEAKING



- (1) Power cylinder
- (2) Cylinder

- (3) Rack piston
- (4) Rack axle

- (5) Input shaft
- (6) Valve housing

Steering Gearbox [LHD MODEL]

POWER ASSISTED SYSTEM (POWER STEERING)

- 1) Lift up the vehicle.
- 2) Even if the location of the leak can be easily found by observing the leaking condition, it is necessary to thoroughly remove the fluid from the suspected portion and turn the steering wheel from lock to lock about thirty to forty times with engine running, then make comparison of the suspected portion between immediately after and several hours after this operation.
- 3) Inspect leakage from "a".
The oil seal is damaged. Replace the valve assembly with a new one.
- 4) Inspect leakage from "b".
The torsion bar O-ring is damaged. Replace the valve assembly with a new one.
- 5) Inspect leakage from "c".
The oil seal is damaged. Replace the valve assembly or oil seal with a new one.
- 6) Inspect leakage from "d".
The pipe is damaged. Replace the faulty pipe or O-ring.
- 7) Inspect leakage from "g".
The hose is damaged. Replace the hose with a new one.
- 8) If leak is other than a, b, c, d, or g, and if oil is leaking from the gearbox, move the right and left boots toward tie-rod end side, respectively, with the gearbox mounted to the vehicle, and remove fluid from the surrounding portions. Then, turn the steering wheel from lock to lock thirty to forty times with the engine running, then make comparison of the leaked portion immediately after and several hours after this operation.

(1) Leakage from "e"

The cylinder seal is damaged. Replace the rack bush with a new one.

(2) Leakage from "f"

There are two possible causes. Take the following step first. Remove the pipe assembly B from the valve housing, and close the circuit with ST.

ST 926420000 PLUG

Turn the steering wheel from lock to lock thirty to forty times with the engine running, then make comparison of the leaked portion between immediately after and several hours after this operation.

- If leakage from "f" is noted again:

The oil seal of pinion and valve assembly is damaged. Replace the pinion and valve assembly with a new one. Or replace the oil seal and parts that are damaged during disassembly with new ones.

- If oil stops leaking from "f":


The oil seal of rack housing is damaged. Replace the oil seal and the parts that are damaged during disassembly with new ones.

F: ADJUSTMENT

- 1) Adjust the front toe. <Ref. to FS-10, FRONT WHEEL TOE-IN, INSPECTION, Wheel Alignment.>

Standard of front toe:

IN 3 — OUT 3 mm (IN 0.12 — OUT 0.12 in)




(1) Lock nut

- 2) Adjust the steering angle of wheels.

Standard of steering angle:

Model	TURBO, 2.5 L and OUTBACK	Others
Inner wheel	34.5°±1.5°	37.3°±1.5°
Outer wheel	30.3°±1.5°	32.4°±1.5°

- 3) If the steering wheel spokes are not horizontal when wheels are set in the straight ahead position, and error is more than 5° on the periphery of steering wheel, correctly re-install the steering wheel.



(1) Within 5°

- 4) If the steering wheel spokes are not horizontal with vehicle set in the straight ahead position after this adjustment, correct it by turning the right and left tie-rods in opposite direction by same angle.

Steering Gearbox [RHD MODEL]

POWER ASSISTED SYSTEM (POWER STEERING)

6. Steering Gearbox [RHD MODEL]


A: REMOVAL

- 1) Set the vehicle on a lift.
- 2) Disconnect the ground cable from battery.
- 3) Loosen the front wheel nut.
- 4) Lift-up the vehicle, and then remove the front wheels.
- 5) Remove the under cover.
- 6) Remove the sub frame.
- 7) Remove the front exhaust pipe assembly. (Non-turbo model)
<Ref. to EX(H4SO)-6, REMOVAL, Front Exhaust Pipe.>

WARNING:


Be careful, the exhaust pipe is hot.

- 8) Using a puller, remove the tie-rod end from knuckle arm after pulling off cotter pin and removing castle nut.




- (1) Castle nut
- (2) Tie-rod end
- (3) Knuckle arm

- 9) Remove the jack-up plate and front stabilizer.



- (1) Jack-up plate


- 10) Remove the one pipe joint at center of gearbox, and connect vinyl hose to pipe and joint. Discharge fluid by turning the steering wheel fully clockwise and counterclockwise. Discharge fluid similarly from the other pipe.



- (1) Pipe A
- (2) Pipe B


- 11) Remove the universal joint. <Ref. to PS-24, REMOVAL, Universal Joint.>

- 12) Disconnect the lower pipe C from gear box first, and upper pipe D second.



- (1) Pipe C
- (2) Pipe D

- 13) Remove the clamp bolts securing the gearbox to crossmember, and then remove the gearbox.



- (1) Clamp