
## 9. Lateral G Sensor

# A: REMOVAL


1) Disconnect the ground cable from battery.



- 2) Remove the console cover.
- <Ref. to EI-43, REMOVAL, Console Box.>
- 3) Disconnect the connector from lateral G sensor.
- 4) Remove the lateral G sensor from vehicle.

#### **CAUTION:**

Do not drop or bump the lateral G sensor.



### **B: INSTALLATION**

Install in the reverse order of removal.

#### **CAUTION:**

Do not drop or bump the lateral G sensor.

### Tightening torque:

18 N⋅m (1.8 kgf-m, 13.0 ft-lb)

# **C: INSPECTION**

|   | Step   | Check  | Yes                         | No                               |
|---|--|--|-----------------------------|----------------------------------|
| 1 | CHECK SUBARU SELECT MONITOR.   | Do you have a SUBARU<br>SELECT MONITOR?  | Go to step 5.               | Go to step 2.                    |
| 2 | CHECK LATERAL G SENSOR.  1) Turn the ignition switch to OFF.  2) Remove the lateral G sensor from vehicle.  3) Connect the connector to lateral G sensor.  4) Turn the ignition switch to ON.  5) Measure the voltage between lateral G sensor connector terminals.  Connector & terminal  (B257) No. 2 (+) — No. 3 (-): | Is the voltage 2.5±0.2 V when lateral G sensor is horizontal?                          | Go to step 3.               | Replace the lateral G sensor.    |
| 3 | CHECK LATERAL G SENSOR.  Measure the voltage between lateral G sensor connector terminals.  Connector & terminal  (B257) No. 2 (+) — No. 3 (-):  | Is the voltage 3.5±0.2 V when lateral G sensor is inclined forwards to 90°?            | Go to step 4.               | Replace the lateral G sensor.    |
| 4 | CHECK LATERAL G SENSOR.  Measure the voltage between lateral G sensor connector terminals.  Connector & terminal  (B257) No. 2 (+) — No. 3 (-):  | Is the voltage 1.5±0.2 V when lateral G sensor is inclined backwards to 90°?           | Lateral G sensor is normal. | Replace the lateral<br>G sensor. |
| 5 | CHECK LATERAL G SENSOR.  1)Turn the ignition switch to OFF.  2)Connect the Subaru Select Monitor to data link connector.  3)Turn the Subaru Select Monitor into {BRAKE CONTROL} mode.  4)Set the display in the {Current Data Display & Save} mode.  5)Read the lateral G sensor output voltage.                         | Is the indicated reading 2.5±0.2 V when the vehicle is in horizontal position?         | Go to step 6.               | Replace the lateral G sensor.    |
| 6 | CHECK LATERAL G SENSOR.  1)Remove the console box.  2)Remove the lateral G sensor from vehicle. (Do not disconnect the connector.)  3)Read the Subaru Select Monitor display.  | Is the indicated reading 3.5±0.2 V when lateral G sensor is inclined forwards to 90°?  | Go to step 7.               | Replace the lateral G sensor.    |
| 7 | CHECK LATERAL G SENSOR. Read the Subaru Select Monitor display.  | Is the indicated reading 1.5±0.2 V when lateral G sensor is inclined backwards to 90°? | Lateral G sensor is normal. | Replace the lateral G sensor.    |