

**ENGINE2 SECTION**

This service manual has been prepared to provide SUBARU service personnel with the necessary information and data for the correct maintenance and repair of SUBARU vehicles.

This manual includes the procedures for maintenance, disassembling, reassembling, inspection and adjustment of components and diagnostics for guidance of experienced mechanics.

Please peruse and utilize this manual fully to ensure complete repair work for satisfying our customers by keeping their vehicle in optimum condition. When replacement of parts during repair work is needed, be sure to use SUBARU genuine parts.

All information, illustration and specifications contained in this manual are based on the latest product information available at the time of publication approval.

**FUEL INJECTION (FUEL SYSTEMS)**

**FU(DOHC TURBO)**

**EMISSION CONTROL  
(AUX. EMISSION CONTROL DEVICES)**

**EC(DOHC TURBO)**

**INTAKE (INDUCTION)**

**IN(DOHC TURBO)**

**MECHANICAL**

**ME(DOHC TURBO)**

**EXHAUST**

**EX(DOHC TURBO)**

**IGNITION**

**IG(DOHC TURBO)**

**ENGINE (DIAGNOSTICS)**

**EN(DOHC TURBO)**



# FUEL INJECTION (FUEL SYSTEMS)

# *FU(DOHC TURBO)*

---

	<b>Page</b>
1. General Description .....	2
2. Throttle Body .....	14
3. Intake Manifold .....	15
4. Engine Coolant Temperature Sensor.....	29
5. Crankshaft Position Sensor.....	30
6. Camshaft Position Sensor.....	31
7. Knock Sensor .....	32
8. Throttle Position Sensor.....	33
9. Mass Air Flow and Intake Air Temperature Sensor .....	34
10. Pressure Sensor .....	35
11. Idle Air Control Solenoid Valve .....	36
12. Fuel Injector .....	37
13. Tumble Generator Valve Assembly .....	40
14. Wastegate Control Solenoid Valve .....	41
15. Front Oxygen (A/F) Sensor.....	42
16. Rear Oxygen Sensor.....	44
17. Exhaust Temperature Sensor .....	46
18. Engine Control Module.....	47
19. Main Relay .....	48
20. Fuel Pump Relay.....	49
21. Fuel Pump Controller .....	50
22. Fuel .....	51
23. Fuel Tank .....	52
24. Fuel Filler Pipe .....	55
25. Fuel Pump.....	60
26. Fuel Level Sensor .....	62
27. Fuel Sub Level Sensor.....	63
28. Fuel Filter .....	65
29. Fuel Cut Valve.....	66
30. Fuel Damper Valve .....	67
31. Fuel Delivery, Return and Evaporation Lines.....	68
32. Fuel System Trouble in General .....	71

# GENERAL DESCRIPTION

## FUEL INJECTION (FUEL SYSTEMS)

### 1. General Description

#### A: SPECIFICATIONS

Fuel tank	Capacity	60 ℓ (15.9 US gal, 13.2 Imp gal)
	Location	Under rear seat
Fuel pump	Type	Impeller
	Shutoff discharge pressure	450 — 677 kPa (4.59 — 6.9 kg/cm <sup>2</sup> , 65.27 — 98.2 psi)
	Discharge flow	More than 130 ℓ (34.3 US gal, 28.6 Imp gal)/h [12 V at 300 kPa (3.06 kg/cm <sup>2</sup> , 43.5 psi)]
Fuel filter		Cartridge type

# GENERAL DESCRIPTION

FUEL INJECTION (FUEL SYSTEMS)

---


**FU(DOHC TURBO)-3**

# GENERAL DESCRIPTION

## FUEL INJECTION (FUEL SYSTEMS)

### B: COMPONENT

#### 1. INTAKE MANIFOLD



EN1135

FU(DOHC TURBO)-4

# GENERAL DESCRIPTION

## FUEL INJECTION (FUEL SYSTEMS)

---

(1) Fuel pipe ASSY	(13) Accelerator cable bracket	(25) Fuel pipe protector LH
(2) Fuel hose	(14) Fuel injector	(26) Nipple
(3) Clip	(15) Insulator	
(4) Purge control solenoid valve	(16) Fuel injector pipe	
(5) Vacuum hose	(17) Pressure regulator	
(6) Vacuum control hose	(18) Pressure regulator hose	
(7) Purge valve	(19) Fuel pipe protector RH	
(8) Purge hose	(20) Blow-by hose stay	
(9) Intake manifold gasket	(21) Intake manifold	
(10) Guide pin	(22) Solenoid valve cover	
(11) Tumble generator valve ASSY	(23) Solenoid valve cover stay	
(12) Tumble generator valve gasket	(24) Wastegate control solenoid valve ASSY	

---


**Tightening torque: N·m (kgf-m, ft-lb)****T1: 4.9 (0.5, 3.6)****T2: 6.4 (0.65, 4.7)****T3: 8.25 (0.84, 6.1)****T4: 16 (1.6, 11.8)****T5: 17 (1.73, 12.5)****T6: 19 (1.94, 13.7)****T7: 25 (2.5, 18.1)**

---

# GENERAL DESCRIPTION

## FUEL INJECTION (FUEL SYSTEMS)

### 2. AIR INTAKE SYSTEM



EN113

- |                                     |                     |
|-------------------------------------|---------------------|
| (1) Gasket                          | (5) Pressure sensor |
| (2) Throttle position sensor        | (6) Gasket          |
| (3) Idle air control solenoid valve | (7) O-ring          |
| (4) Throttle body                   |                     |

**Tightening torque: N-m (kgf-m, ft-lb)**

**T1: 1.6 (0.16, 1.2)**

**T2: 2.8 (0.29, 2.1)**


**T3: 22 (2.2, 15.9)**

**FU(DOHC TURBO)-6**

# GENERAL DESCRIPTION

FUEL INJECTION (FUEL SYSTEMS)

## 3. CRANKSHAFT POSITION, CAMSHAFT POSITION AND KNOCK SENSORS



- (1) Crankshaft position sensor
- (2) Knock sensor

- (3) Camshaft position sensor

**Tightening torque: N·m (kgf-m, ft-lb)**

**T1: 6.4 (0.65, 4.7)**

**T2: 24 (2.4, 17.4)**



# GENERAL DESCRIPTION

## FUEL INJECTION (FUEL SYSTEMS)

---

(1) Heat shield cover	(15) Evaporation hose C	(29) Fuel sub level sensor gasket
(2) Fuel tank band	(16) Evaporation hose B	(30) Jet pump filter
(3) Protector LH	(17) Evaporation hose D	(31) Fuel sub level sensor
(4) Protector RH	(18) Evaporation hose E	(32) Protector cover
(5) Fuel tank	(19) Evaporation pipe ASSY	(33) Vent valve hose
(6) Canister hose A	(20) Retainer	(34) Vent valve
(7) Clamp	(21) Quick connector	(35) Fuel tank pressure sensor
(8) Fuel pump gasket	(22) Jet pump hose A	(36) Fuel tank pressure sensor hose
(9) Fuel pump ASSY	(23) Fuel return hose A	(37) Vent valve gasket
(10) Fuel cut valve gasket	(24) Fuel pipe ASSY	
(11) Fuel cut valve	(25) Jet pump hose B	
(12) Evaporation hose A	(26) Fuel return hose B	
(13) Clip	(27) Evaporation hose F	
(14) Joint pipe	(28) Evaporation hose G	

---

**Tightening torque: N·m (kgf-m, ft-lb)**

**T1: 4.4 (0.45, 3.3)**

**T2: 7.4 (0.75, 5.4)**


**T3: 33 (3.4, 25)**

---

# GENERAL DESCRIPTION

## FUEL INJECTION (FUEL SYSTEMS)

### 5. FUEL LINE



EN1120

# GENERAL DESCRIPTION

## FUEL INJECTION (FUEL SYSTEMS)


---

(1) Clamp	(13) Evaporation hose J	(25) Canister holder
(2) Fuel delivery hose A	(14) Evaporation hose K	(26) Evaporation hose L
(3) Fuel filter bracket	(15) Joint pipe	(27) Pressure control solenoid valve
(4) Fuel filter holder	(16) Canister hose A	(28) Canister hose B
(5) Fuel filter cup	(17) Air filter hose A	(29) Canister
(6) Fuel filter	(18) Drain valve hose	(30) Fuel pipe ASSY
(7) Evaporation hose	(19) Air filter hose B	
(8) Clip	(20) Drain filter	<hr/> <b>Tightening torque: N-m (kgf-m, ft-lb)</b>
(9) Fuel delivery hose B	(21) Drain valve	<b>T1: 25 (2.5, 18.1)</b>
(10) Fuel return hose A	(22) Canister upper bracket	<b>T2: 23 (2.3, 16.6)</b>
(11) Fuel return hose B	(23) Cushion rubber	<b>T3: 1.25 (0.13, 0.94)</b>
(12) Fuel damper	(24) Canister lower bracket	<hr/>

# GENERAL DESCRIPTION

## FUEL INJECTION (FUEL SYSTEMS)

### 6. FUEL FILLER PIPE



- |                             |                         |
|-----------------------------|-------------------------|
| (1) Fuel filter pipe ASSY   | (8) Filler pipe packing |
| (2) Evaporation hose holder | (9) Filler ring         |
| (3) Clamp                   | (10) Filler cap         |
| (4) Clamp                   | (11) Shut valve         |
| (5) Evaporation hose A      | (12) Evaporation hose B |
| (6) Evaporation pipe        | (13) Evaporation hose C |
| (7) Evaporation pipe holder | (14) Joint pipe         |

- (15) Fuel filler pipe protector

**Tightening torque: N·m (kgf-m, ft-lb)**

**T1: 4.4 (0.45, 3.3)**

**T2: 7.5 (0.76, 5.5)**

# GENERAL DESCRIPTION


## FUEL INJECTION (FUEL SYSTEMS)

### C: CAUTION

- Wear working clothing, including a cap, protective goggles, and protective shoes during operation.
- Remove contamination including dirt and corrosion before removal, installation or disassembly.
- Keep the disassembled parts in order and protect them from dust or dirt.
- Before removal, installation or disassembly, be sure to clarify the failure. Avoid unnecessary removal, installation, disassembly, and replacement.

- Be careful not to burn your hands, because each part on the vehicle is hot after running.
- Be sure to tighten fasteners including bolts and nuts to the specified torque.
- Place shop jacks or safety stands at the specified points.
- Before disconnecting electrical connectors of sensors or units, be sure to disconnect negative terminal from battery.
- Place "NO FIRE" signs near the working area.
- Be careful not to spill fuel on the floor.

### D: PREPARATION TOOL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p>B2M3876</p>	24082AA150 (Newly adopted tool)	CARTRIDGE	Troubleshooting for electrical system.
 <p>B2M3877</p>	22771AA030	SELECT MONITOR KIT	Troubleshooting for electrical systems. <ul style="list-style-type: none"> <li>• English: 22771AA030 (Without printer)</li> <li>• German: 22771AA070 (Without printer)</li> <li>• French: 22771AA080 (Without printer)</li> <li>• Spanish: 22771AA090 (Without printer)</li> </ul>


# THROTTLE BODY

FUEL INJECTION (FUEL SYSTEMS)

## 2. Throttle Body


### A: REMOVAL

1) Disconnect the battery ground cable.




2) Remove the intercooler. <Ref. to IN(DOHC TURBO)-10, REMOVAL, Intercooler.>


3) Disconnect the connector from the throttle position sensor (A) and idle air control solenoid valve (B) and pressure sensor (C).



4) Disconnect the accelerator cable.



5) Disconnect the engine coolant hoses from the throttle body.



6) Remove the bolts which secure the throttle body to intake manifold.

### B: INSTALLATION


Install in the reverse order of removal.

NOTE:

Always use a new gasket.

**Tightening torque:**


**22 N·m (2.2 kgf-m, 15.9 ft-lb)**




## 3. Intake Manifold

### A: REMOVAL


- 1) Release the fuel pressure. <Ref. to FU(DOHC TURBO)-51, RELEASING OF FUEL PRESSURE, OPERATION, Fuel.>
- 2) Disconnect the battery ground cable.



- 3) Lift up the vehicle.
- 4) Remove the under cover.
- 5) Drain the coolant about 3.0 ℓ (3.2 US qt, 2.6 Imp qt).




- 6) Remove the air cleaner upper cover and air intake boot. <Ref. to IN(DOHC TURBO)-7, REMOVAL, Air Cleaner.>
- 7) Remove the air cleaner element.
- 8) Remove the intercooler. <Ref. to IN(DOHC TURBO)-10, REMOVAL, Intercooler.>
- 9) Disconnect the accelerator cable.




- 10) Remove the coolant filler tank. <Ref. to CO-51, REMOVAL, Coolant Filler Tank.>

- 11) Remove the power steering pump.
  - (1) Remove the front side V-belt. <Ref. to ME(DOHC TURBO)-44, REMOVAL, V-belt.>
  - (2) Disconnect the power steering switch connector.




- (3) Remove the bolts which secure the power steering pipe brackets to the intake manifold.

**NOTE:**  
Do not disconnect the power steering hose.




- (4) Remove the bolts which secure the power steering pump bracket.




# INTAKE MANIFOLD

## FUEL INJECTION (FUEL SYSTEMS)


(5) Remove the power steering tank from the bracket by pulling it upward.




(6) Place the power steering pump on the right side wheel apron.




(12) Disconnect the emission hose from the PCV valve.




(13) Disconnect the engine coolant hoses from the throttle body.





(14) Disconnect the brake booster hose.



(15) Disconnect the pressure hose from the intake duct.




(16) Disconnect the engine harness connectors from the bulkhead harness connectors.




# INTAKE MANIFOLD

FUEL INJECTION (FUEL SYSTEMS)


17) Disconnect the connectors from the engine coolant temperature sensor (A), oil pressure switch (B) and crankshaft position sensor (C).




18) Disconnect the knock sensor connector.




19) Disconnect the connector from the camshaft position sensor.



20) Disconnect the connector from the ignition coil.




21) Disconnect the engine harness fixed by clip (A) from the bracket.




22) Disconnect the fuel delivery hose, return hose and evaporation hose.

**WARNING:**  
Catch the fuel from hoses in a container.



23) Remove the bolts which secure the intake manifold to the cylinder heads.



24) Remove the intake manifold.

# INTAKE MANIFOLD

## FUEL INJECTION (FUEL SYSTEMS)

### B: INSTALLATION


1) Install the intake manifold onto cylinder heads.

#### NOTE:


Always use new gaskets.

#### Tightening torque:


25 N·m (2.5 kgf-m, 18.1 ft-lb)




2) Connect the fuel delivery hose, return hose, and evaporation hose.




3) Connect the connector to the oil pressure switch (B), crankshaft position sensor (C) and engine coolant temperature sensor (A).




4) Connect the connector to the knock sensor.




5) Connect the connector to the camshaft position sensor.



6) Connect the connector to the ignition coil.





7) Connect the engine harness with clip (A) to the bracket.




# INTAKE MANIFOLD

## FUEL INJECTION (FUEL SYSTEMS)


8) Connect the engine harness connector to the bulkhead harness connectors.




9) Connect the brake booster vacuum hose.




10) Connect the engine coolant hoses to the throttle body.



11) Connect the emission hose to the PCV valve.




12) Connect the pressure hose to the intake duct.




13) Install the power steering pump.

(1) Install the power steering tank on the bracket.



(2) Connect the connector to the power steering pump switch.




# INTAKE MANIFOLD

## FUEL INJECTION (FUEL SYSTEMS)


(3) Install the power steering pump, and tighten the bolts.

### Tightening torque:

**22 N·m (2.2 kgf-m, 15.9 ft-lb)**




(4) Install the power steering pipe brackets on the right side intake manifold.



(5) Install the front side V-belt.  
<Ref. to ME(DOHC TURBO)-44, REMOVAL, V-belt.>

14) Install the cooler filler tank. <Ref. to CO-51, INSTALLATION, Cooler Filler Tank.>

15) Connect the accelerator cable.




16) Install the intercooler. <Ref. to IN(DOHC TURBO)-11, INSTALLATION, Intercooler.>

17) Install the air cleaner element.

18) Install the air cleaner upper cover and air intake duct as a unit. <Ref. to IN(DOHC TURBO)-7, INSTALLATION, Air Cleaner.>

19) Connect the connector to the fuel pump relay.



20) Connect the battery ground cable.

21) Lift up the vehicle.

22) Install the under cover.


23) Fill the coolant. <Ref. to CO-25, FILLING OF ENGINE COOLANT, Engine Coolant.>

# INTAKE MANIFOLD


FUEL INJECTION (FUEL SYSTEMS)

## C: DISASSEMBLY



1) Remove the fuel pipe protector LH.



2) Remove the fuel pipe protector RH.




3) Remove the engine ground terminal from the intake manifold.




4) Disconnect the connector from the throttle position sensor (A), idle air control solenoid valve (B) and pressure sensor (C).


5) Disconnect the engine harness fixed by clip (D) from the intake manifold.




6) Remove the throttle body from the intake manifold.



7) Disconnect the connector from the fuel injector.




8) Disconnect the connector from the tumble generator valve actuator.




# INTAKE MANIFOLD

## FUEL INJECTION (FUEL SYSTEMS)


9) Disconnect the connector from the tumble generator valve sensor.




13) Disconnect the evaporation hoses from the purge valve.




10) Disconnect the connector from the purge control solenoid valve.




14) Remove the two bolts which hold the fuel pipes on the left side of intake manifold.



11) Remove the purge control solenoid valve.



12) Disconnect the evaporation hose from the intake manifold.





# INTAKE MANIFOLD



## FUEL INJECTION (FUEL SYSTEMS)

15) Remove the bolt which hold the fuel injector pipe onto intake manifold.


• LH SIDE




• RH SIDE



16) Remove the fuel injector.




17) Remove the harness bracket which hold the engine harness onto intake manifold.




18) Remove the engine harness from the intake manifold.

19) Loosen the clamp which holds the front left side fuel hose to injector pipe and remove the pipe from clamp.



20) Remove the fuel injector pipe LH.


21) Remove the bolts which installs the fuel pipe on intake manifold.




# INTAKE MANIFOLD

## FUEL INJECTION (FUEL SYSTEMS)

- 22) Remove the fuel pipe assembly and pressure regulator, from the intake manifold.
- 23) Remove the intake duct from the intake manifold.



- 24) Remove the tumble generator valve assembly from the intake manifold.



## D: ASSEMBLY


### NOTE:

Replace the gasket with a new one.

- 1) Install the tumble generator valve assembly to the intake manifold.

### Tightening torque:


**8.25 N·m (0.84 kgf-m, 6.08 ft-lb)**



- 2) Install the air intake duct to the intake manifold.

### Tightening torque:


**19 N·m (1.94 kgf-m, 13.7 ft-lb)**



- 3) Install the fuel pipe assembly and pressure regulator, to the intake manifold.


### Tightening torque:

**4.9 N·m (0.5 kgf-m, 3.6 ft-lb)**



- 4) Install the fuel injector pipe LH.

- 5) Connect the left side fuel hose to injector pipe, and tighten the clamp screw.



- 6) Install the engine harness to the intake manifold.


# INTAKE MANIFOLD

FUEL INJECTION (FUEL SYSTEMS)


7) Install the harness bracket which hold the engine harness onto intake manifold.

**Tightening torque:**

**19 N·m (1.94 kgf-m, 13.7 ft-lb)**



8) Install the fuel injector.





9) Tighten the bolt which install the fuel injector pipe onto intake manifold.



**Tightening torque:**

**19 N·m (1.94 kgf-m, 13.7 ft-lb)**

• LH SIDE



• RH SIDE




# INTAKE MANIFOLD

## FUEL INJECTION (FUEL SYSTEMS)

10) Tighten the two bolts which install the fuel pipes on the left side of intake manifold.

**Tightening torque:**


**4.9 N·m (0.5 kgf-m, 3.6 ft-lb)**



11) Connect the evaporation hoses to the purge valve.


**CAUTION:**

**Carefully connect the evaporation hoses.**



- (A) To fuel pipe ASSY
- (B) To intake duct
- (C) To purge control solenoid valve
- (D) To intake manifold


12) Connect the evaporation hose to the intake manifold.



13) Install the purge control solenoid valve.

**Tightening torque:**


**16 N·m (1.6 kgf-m, 11.8 ft-lb)**



14) Connect the hoses to the purge control solenoid valve.

**CAUTION:**

**Carefully connect the evaporation hoses.**




- (A) To intake manifold
- (B) To purge valve


# INTAKE MANIFOLD

## FUEL INJECTION (FUEL SYSTEMS)


15) Connect the connector to the purge control solenoid valve.




16) Connect the connector to the tumble generator valve sensor.



17) Connect the connector to the tumble generator valve actuator.



18) Connect the connector to the fuel injector.




19) Install the throttle body to the intake manifold.

NOTE:

Replace gasket with a new one.


**Tightening torque:**

**22 N·m (2.2 kgf-m, 15.9 ft-lb)**



20) Connect the connector to the throttle position sensor (A), idle air control solenoid valve (B) and pressure sensor (C).

21) Connect the engine harness with clip (D) to the intake manifold.





# INTAKE MANIFOLD

## FUEL INJECTION (FUEL SYSTEMS)

22) Install the engine ground terminal to the intake manifold.

**Tightening torque:**


**19 N·m (1.94 kgf·m, 13.7 ft·lb)**



23) Install the fuel pipe protector RH.

**Tightening torque:**


**19 N·m (1.94 kgf·m, 13.7 ft·lb)**



24) Install the fuel pipe protector LH.

**Tightening torque:**

**19 N·m (1.94 kgf·m, 13.7 ft·lb)**



## E: INSPECTION

Make sure the fuel pipe and fuel hoses are not cracked and that connections are tight.


# ENGINE COOLANT TEMPERATURE SENSOR

FUEL INJECTION (FUEL SYSTEMS)

## 4. Engine Coolant Temperature Sensor


### A: REMOVAL

1) Disconnect the battery ground cable.



2) Remove the generator <Ref. to SC-13, REMOVAL, Generator.>

3) Disconnect the connector from the engine coolant temperature sensor.



4) Remove the engine coolant temperature sensor.

### B: INSTALLATION

Install in the reverse order of removal.

*Tightening torque:*

**18 N·m (1.8 kgf-m, 13.3 ft-lb)**


# CRANKSHAFT POSITION SENSOR

FUEL INJECTION (FUEL SYSTEMS)


## 5. Crankshaft Position Sensor

### A: REMOVAL


- 1) Disconnect the battery ground cable.



- 2) Remove the bolt which install the crankshaft position sensor to cylinder block.



- 3) Remove the crankshaft position sensor, and disconnect the connector from it.




### B: INSTALLATION

Install in the reverse order of removal.

**Tightening torque:**

**T: 6.4 N·m (0.65 kgf-m, 4.7 ft-lb)**




# CAMSHAFT POSITION SENSOR

FUEL INJECTION (FUEL SYSTEMS)


## 6. Camshaft Position Sensor

### A: REMOVAL


- 1) Disconnect the battery ground cable.



- 2) Disconnect the connector from the camshaft position sensor.



- 3) Remove the camshaft position sensor from the camshaft support LH.




### B: INSTALLATION

Install in the reverse order of removal.

**Tightening torque:**

**T: 6.4 N·m (0.65 kgf·m, 4.7 ft·lb)**




# KNOCK SENSOR

FUEL INJECTION (FUEL SYSTEMS)


## 7. Knock Sensor

### A: REMOVAL


- 1) Disconnect the battery ground cable.



- 2) Remove the intercooler. <Ref. to IN(DOHC TURBO)-10, REMOVAL, Intercooler.>
- 3) Disconnect the knock sensor connector.



- 4) Remove the knock sensor from the cylinder block.



### B: INSTALLATION


- 1) Install the knock sensor to the cylinder block.

**Tightening torque:**

**24 N·m (2.4 kgf-m, 17.4 ft-lb)**


**NOTE:**

The extraction area of the knock sensor cord must be positioned at a 60° angle relative to the engine rear.




(A) Front side

- 2) Connect the knock sensor connector.




- 3) Install the intercooler. <Ref. to IN(DOHC TURBO)-11, INSTALLATION, Intercooler.>
- 4) Connect the battery ground cable.




## 8. Throttle Position Sensor

### A: REMOVAL


- 1) Disconnect the battery ground cable.



- 2) Remove the intercooler. <Ref. to IN(DOHC TURBO)-10, REMOVAL, Intercooler.>
- 3) Disconnect the connector from the throttle position sensor.



- 4) Remove the throttle position sensor holding screws, and remove it.




### B: INSTALLATION

Install in the reverse order of removal.

**Tightening torque:**

**1.6 N·m (0.16 kgf-m, 1.2 ft-lb)**




# MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR

FUEL INJECTION (FUEL SYSTEMS)

## 9. Mass Air Flow and Intake Air Temperature Sensor


### A: REMOVAL

1) Disconnect the battery ground cable.



2) Disconnect the connector mass air flow and intake air temperature sensor.

3) Remove the mass air flow and intake air temperature sensor.



### B: INSTALLATION

Install in the reverse order of removal.


*Tightening torque:*

*7.5 N·m (0.76 kgf-m, 5.5 ft-lb)*


## 10. Pressure Sensor

### A: REMOVAL

- 1) Disconnect the battery ground cable.



- 2) Remove the idle air control solenoid valve. <Ref. to FU(DOHC TURBO)-36, REMOVAL, Idle Air Control Solenoid Valve.>
- 3) Disconnect the connectors from pressure sensor.



- 4) Remove the pressure sensor from the throttle body.

### B: INSTALLATION

Install in the reverse order of removal.

#### NOTE:

Replace the O-ring for the pressure sensor with new ones.

#### *Tightening torque:*

**1.6 N·m (0.16 kgf-m, 1.2 ft-lb)**


# IDLE AIR CONTROL SOLENOID VALVE

## FUEL INJECTION (FUEL SYSTEMS)


### 11. Idle Air Control Solenoid Valve

#### A: REMOVAL


1) Disconnect the battery ground cable.




2) Disconnect the connector from the idle air control solenoid valve.



3) Remove the idle air control solenoid valve from the throttle body.



4) Remove the gasket from throttle body.



#### B: INSTALLATION


Install in the reverse order of removal.

NOTE:

Always use a new gasket.

**Tightening torque:**

**2.8 N·m (0.29 kgf·m, 2.1 ft·lb)**




### 12. Fuel Injector


#### A: REMOVAL

##### 1. RH SIDE



- 1) Remove the intake manifold. <Ref. to FU(DOHC TURBO)-15, REMOVAL, Intake Manifold.>
- 2) Remove the fuel pipe protector RH.




- 3) Disconnect the connector from the fuel injector.



- 4) Remove the bolts which hold the injector pipe to intake manifold.




- 5) Remove the fuel injector while lifting up the fuel injector pipe.




##### 2. LH SIDE

- 1) Remove the intake manifold. <Ref. to FU(DOHC TURBO)-15, REMOVAL, Intake Manifold.>
- 2) Remove the fuel pipe protector LH.






- 3) Disconnect the connector from the fuel injector.




# FUEL INJECTOR

## FUEL INJECTION (FUEL SYSTEMS)

4) Remove the bolts which hold the injector pipe to intake manifold.



5) Remove the fuel injector while lifting up the fuel injector pipe.




## B: INSTALLATION

### 1. RH SIDE

Install in the reverse order of removal.

#### NOTE:


Replace the O-ring and insulators with new ones.



- (A) O-ring
- (B) Fuel injector
- (C) Insulator


#### Tightening torque:

**19 N·m (1.94 kgf-m, 13.7 ft-lb)**




#### Tightening torque:


**19 N·m (1.94 kgf-m, 13.7 ft-lb)**



**Tightening torque:**  
**19 N·m (1.94 kgf-m, 13.7 ft-lb)**




**Tightening torque:**  
**19 N·m (1.94 kgf-m, 13.7 ft-lb)**



## 2. LH SIDE


Install in the reverse order of removal.

**NOTE:**  
 Replace the O-ring and insulators with new ones.




- (A) O-ring
- (B) Fuel injector
- (C) Insulator


**Tightening torque:**  
**19 N·m (1.94 kgf-m, 13.7 ft-lb)**



**Tightening torque:**  
**19 N·m (1.94 kgf-m, 13.7 ft-lb)**



**Tightening torque:**  
**4.9 N·m (0.5 kgf-m, 3.6 ft-lb)**




# TUMBLE GENERATOR VALVE ASSEMBLY

FUEL INJECTION (FUEL SYSTEMS)

## 13. Tumble Generator Valve Assembly


### A: REMOVAL

1) Disconnect the battery ground cable.




2) Remove the intake manifold. <Ref. to FU(DOHC TURBO)-15, REMOVAL, Intake Manifold.>

3) Disconnect the connector from the tumble generator valve sensor.




4) Disconnect the connector from the tumble generator valve actuator.



5) Remove the fuel injector. <Ref. to FU(DOHC TURBO)-37, REMOVAL, Fuel Injector.>

6) Remove the tumble generator valve body from the intake manifold.



### B: INSTALLATION


Install in the reverse order of removal.

NOTE:

Always use new gaskets.

**Tightening torque:**

**8.25 N·m (0.84 kgf-m, 6.1 ft-lb)**




# WASTEGATE CONTROL SOLENOID VALVE

FUEL INJECTION (FUEL SYSTEMS)


## 14. Wastegate Control Solenoid Valve

### A: REMOVAL


- 1) Disconnect the battery ground cable.




- 2) Remove the solenoid valve cover.



- 3) Disconnect the connector (A) from the wastegate control solenoid valve.
- 4) Disconnect the pressure hoses (B) from the wastegate control solenoid valve.



- 5) Remove the wastegate control solenoid valve from the bracket




### B: INSTALLATION

Install in the reverse order of removal.

**Tightening torque:**

**6.4 N·m (0.65 kgf·m, 4.7 ft·lb)**




# FRONT OXYGEN (A/F) SENSOR

FUEL INJECTION (FUEL SYSTEMS)


## 15. Front Oxygen (A/F) Sensor

### A: REMOVAL


1) Disconnect the battery ground cable.




2) Remove the solenoid valve cover.



3) Disconnect the connector from the front oxygen (A/F) sensor.




4) Disconnect the engine harness fixed by clip (A) from the bracket (B).



5) Remove the front right side wheel.

6) Lift-up the vehicle.

7) Remove the service hole cover.




8) Apply SUBARU CRC or its equivalent to the threaded portion of front oxygen (A/F) sensor, and leave it for one minute or more.

**SUBARU CRC (Part No. 004301003)**

9) Remove the front oxygen (A/F) sensor.

### CAUTION:

**When removing the oxygen (A/F) sensor, wait until exhaust pipe cools, otherwise it will damage exhaust pipe.**



# FRONT OXYGEN (A/F) SENSOR

FUEL INJECTION (FUEL SYSTEMS)

## B: INSTALLATION


1) Before installing front oxygen (A/F) sensor, apply the anti-seize compound only to the threaded portion of front oxygen (A/F) sensor to make the next removal easier.

**Anti-seize compound:**  
**SS-30 by JET LUBE**


**CAUTION:**  
**Never apply anti-seize compound to protector of front oxygen (A/F) sensor.**

2) Install the front oxygen (A/F) sensor.

**Tightening torque:**  
**21N·m (2.1 kgf-m, 15.2 ft-lb)**




3) Install the service hole cover.




4) Lower the vehicle.

5) Install the front right side wheel.


6) Connect the engine harness with clip (A) to the bracket (B).




7) Connect the connector of front oxygen (A/F) sensor.



8) Install the solenoid valve cover.



9) Connect the battery ground cable.




# REAR OXYGEN SENSOR

FUEL INJECTION (FUEL SYSTEMS)


## 16. Rear Oxygen Sensor

### A: REMOVAL


- 1) Disconnect the battery ground cable.



- 2) Lift-up the vehicle.
- 3) Disconnect the connector from the rear oxygen sensor.



- 4) Remove the clip by pulling out from the upper side of crossmember.




- 5) Apply SUBARU CRC or its equivalent to the threaded portion of rear oxygen sensor, and leave it for one minute or more.

**SUBARU CRC (Part No. 004301003)**

- 6) Remove the rear oxygen sensor.

### CAUTION:

**When removing the oxygen sensor, wait until exhaust pipe cools, otherwise it will damage exhaust pipe.**



### B: INSTALLATION

- 1) Before installing rear oxygen sensor, apply the anti-seize compound only to the threaded portion of rear oxygen sensor to make the next removal easier.

### CAUTION:


**Never apply anti-seize compound to protector of rear oxygen sensor.**

**Anti-seize compound:  
SS-30 by JET LUBE**


- 2) Install the rear oxygen sensor.

### Tightening torque:


**21 N·m (2.1 kgf-m, 15.2 ft-lb)**



- 3) Connect the connector to the rear oxygen sensor.




4) Connect the clip to the crossmember.



5) Lower the vehicle.

6) Connect the battery ground cable.




# EXHAUST TEMPERATURE SENSOR

FUEL INJECTION (FUEL SYSTEMS)

## 17. Exhaust Temperature Sensor

### A: REMOVAL

- 1) Disconnect the battery ground cable.



- 2) Remove the joint pipe. <Ref. to EX(DOHC TURBO)-12, REMOVAL, Joint Pipe.>


- 3) Apply SUBARU CRC or its equivalent to the threaded portion of exhaust temperature sensor, and leave it for one minute or more.

**SUBARU CRC (Part No. 004301003)**

- 4) Remove the exhaust temperature sensor.

### CAUTION:

When removing the oxygen sensor, wait until exhaust pipe cools, otherwise it will damage exhaust pipe.



### B: INSTALLATION

- 1) Before installing exhaust temperature sensor, apply the anti-seize compound only to the threaded portion of rear oxygen sensor to make the next removal easier.

### CAUTION:

Never apply anti-seize compound to protector of exhaust temperature sensor.

**Anti-seize compound:**

**SS-30 by JET LUBE**


- 2) Install the exhaust temperature sensor.

### NOTE:

Align the marking (A) of exhaust temperature sensor to the marking (B) of joint pipe, and tighten the screws.


**Tightening torque:**

**21 N·m (2.1 kgf-m, 15.2 ft-lb)**



- 3) Install the joint pipe <Ref. to EX(DOHC TURBO)-12, INSTALLATION, Joint Pipe.>


- 4) Connect the battery ground cable.




### 18.Engine Control Module

#### A: REMOVAL


- 1) Disconnect the battery ground cable.



- 2) Remove the lower inner trim of the passenger side.  
<Ref. to EI-46, REMOVAL, Lower Inner Trim.>
- 3) Detach the floor mat of the front passenger seat.
- 4) Remove the protect cover.



- 5) Remove the nuts (A) which hold ECM to the bracket.
- 6) Remove the clip (B) from the bracket.



- 7) Disconnect the ECM connectors and take out the ECM.

#### B: INSTALLATION

Install in the reverse order of removal.

#### CAUTION:

When replacing ECM, be careful not to use the wrong spec. ECM to avoid any damage to the fuel injection system.

# MAIN RELAY


FUEL INJECTION (FUEL SYSTEMS)

---

## 19. Main Relay

### A: REMOVAL


1) Disconnect the battery ground cable.



2) Remove the passenger's side front side sill cover.

3) Remove the bolt which holds the main relay bracket on the body.

4) Disconnect the connectors from the main relay.




### B: INSTALLATION

Install in the reverse order of removal.


## 20. Fuel Pump Relay

### A: REMOVAL

- 1) Disconnect the battery ground cable.



- 2) Remove the passenger's side front side sill cover.
- 3) Remove the bolt which holds fuel pump relay bracket on the body.
- 4) Disconnect the connector from the fuel pump relay.



- 5) Remove the fuel pump relay from the mounting bracket.

### B: INSTALLATION

Install in the reverse order of removal.


# FUEL PUMP CONTROLLER

FUEL INJECTION (FUEL SYSTEMS)

## 21. Fuel Pump Controller


### A: REMOVAL

1) Disconnect the battery ground cable.




2) Remove the rear quarter trim. <Ref. to EI-47, REMOVAL, Rear Quarter Trim.>

3) Disconnect the connector from the fuel pump control unit.



4) Remove the fuel pump control unit.



### B: INSTALLATION

Install in the reverse order of removal.

## 22. Fuel


### A: OPERATION

#### 1. RELEASING OF FUEL PRESSURE

##### WARNING:

- Place "NO FIRE" signs near the working area.
- Be careful not to spill fuel on the floor.

1) Disconnect the connector from the fuel pump relay.




- 2) Start the engine and run it until it stalls.
- 3) After the engine stalls, crank it for five more seconds.
- 4) Turn the ignition switch to OFF.

#### 2. DRAINING FUEL

##### WARNING:

- Place "NO FIRE" signs near the working area.
- Be careful not to spill fuel on the floor.


- 1) Set the vehicle on the lift.
- 2) Disconnect the battery ground cable.



3) Lift-up the vehicle.

4) Drain the fuel from the fuel tank.


Set a container under the vehicle and remove drain plug from the fuel tank.



5) Tighten the fuel drain plug.

**Tightening torque:**

**26 N·m (2.65 kgf-m, 19.2 ft-lb)**



# FUEL TANK

## FUEL INJECTION (FUEL SYSTEMS)


### 23. Fuel Tank

#### A: REMOVAL


##### WARNING:

- Place "NO FIRE" signs near the working area.
- Be careful not to spill fuel on the floor.


- 1) Set the vehicle on the lift.
- 2) Release the fuel pressure. <Ref. to FU(DOHC TURBO)-51, RELEASING OF FUEL PRESSURE, OPERATION, Fuel.>
- 3) Drain the fuel from the fuel tank. <Ref. to FU(DOHC TURBO)-51, DRAINING FUEL, OPERATION, Fuel.>
- 4) Remove the rear seat.
- 5) Disconnect the connector (A) of fuel tank cord to the rear harness.
- 6) Push the grommet (B) which holds the fuel tank cord on floor panel into under the body.




- 7) Remove the rear crossmember. <Ref. to RS-19, REMOVAL, Rear Crossmember.>
- 8) Move the clamp, and disconnect the evaporation hose from canister.




- 9) Disconnect the connector from the pressure control solenoid valve.
- 10) Disconnect the connector from the drain valve.



- 11) Loosen the clamp and disconnect the fuel filler hose (A) and air vent hose (B) from fuel filler pipe and air vent pipe.




- 12) Move the clips, and disconnect the quick connector. <Ref. to FU(DOHC TURBO)-68, REMOVAL, Fuel Delivery, Return and Evaporation Lines.>
- 13) Disconnect the fuel hoses.



14) Support the fuel tank with transmission jack, remove the bolts from bands and dismount the fuel tank from vehicle.

**WARNING:**

**A helper is required to perform this work.**




**B: INSTALLATION**

1) Support the fuel tank with transmission jack and push the fuel tank harness into the access hole with grommet.


2) Set the fuel tank and temporarily tighten the bolts of fuel tank bands.

**WARNING:**


**A helper is required to perform this work.**




3) Connect the fuel filler hose and air vent hose.



4) Connect the fuel hoses, and hold them with clips and quick connector. <Ref. to FU(DOHC TURBO)-69, INSTALLATION, Fuel Delivery, Return and Evaporation Lines.>




5) Connect the connector to the drain valve.



6) Connect the connector to the pressure control solenoid valve.

7) Connect the evaporation hose to the canister, and hold them with clamp.




# FUEL TANK

## FUEL INJECTION (FUEL SYSTEMS)

8) Tighten the band mounting bolts.


**Tightening torque:**

**33 N·m (3.4 kgf-m, 25 ft-lb)**




9) Install the rear crossmember. <Ref. to RS-19, INSTALLATION, Rear Crossmember.>

10) Connect the connector (A) to the fuel tank cord and plug the service hole with grommet (B).



11) Set the rear seat and floor mat.

12) Connect the connector to the fuel pump relay.



## C: INSPECTION

1) Make sure there are no cracks, holes, or other damage on the fuel tank.

2) Make sure that the fuel hoses and fuel pipes are not cracked and that connections are tight.


### 24. Fuel Filler Pipe

#### A: REMOVAL


##### WARNING:

- Place "NO FIRE" signs near the working area.
- Be careful not to spill fuel on the floor.


- 1) Release the fuel pressure. <Ref. to FU(DOHC TURBO)-51, RELEASING OF FUEL PRESSURE, OPERATION, Fuel.>
- 2) Open the fuel filler flap lid and remove the filler cap.
- 3) Disconnect the battery ground cable.




- 4) Remove the screws holding packing in place.



- 5) Lift-up the vehicle.
- 6) Remove the rear right side wheel nuts.
- 7) Remove the rear right side wheel.




- 8) Drain the fuel from fuel tank. Set a container under the vehicle and remove the drain plug from fuel tank.




- 9) Tighten the fuel drain plug and then install the front right side tank cover.

##### Tightening torque:


**26 N·m (2.65 kgf-m, 19.2 ft-lb)**



- 10) Remove the fuel filler pipe protector.




- 11) Separate the evaporation hoses from the clip of fuel filler pipe.




# FUEL FILLER PIPE

## FUEL INJECTION (FUEL SYSTEMS)

12) Disconnect the evaporation hoses from the pipes.




13) Remove the bolts which hold fuel filler pipe bracket on the body.




14) Loosen the clamp and separate the fuel filler hose (A) from fuel filler pipe.

15) Move the clip and separate the evaporation hose (B).



16) Remove the fuel filler pipe to under side of the vehicle.


17) Remove the air vent pipe together with clip from the body.



## B: INSTALLATION

1) Hold the fuel filler flap open.


2) Set the fuel saucer (A) with rubber packing (C) and insert the fuel filler pipe into the hole from the inner side of apron.



3) Align the holes in fuel filler pipe neck and set the cup (B), and tighten the screws.

### NOTE:


If edges of rubber packing are folded toward the inside, straighten it with a screwdriver.




# FUEL FILLER PIPE

FUEL INJECTION (FUEL SYSTEMS)

4) Install the evaporation pipes.




5) Connect the evaporation hose to pipes.



6) Insert the fuel filler hose (A) approximately 35 to 40 mm (1.38 to 1.57 in) over the lower end of fuel filler pipe and tighten the clamp.


**CAUTION:**

**Do not allow clips to touch air vent hose (B) and rear suspension crossmember.**



7) Insert the air vent hose approximately 25 to 30 mm (0.98 to 1.18 in) into the lower end of air vent pipe and hold clip.

$L = 27.5 \pm 2.5 \text{ mm (1.083 \pm 0.098 in)}$




- (1) Hose
- (2) Clip
- (3) Pipe


8) Tighten the bolt which holds fuel filler pipe bracket on the body.

**Tightening torque:**

$7.4 \text{ N}\cdot\text{m (0.75 kgf}\cdot\text{m, 5.4 ft}\cdot\text{lb)}$




9) Tighten the bolts which hold evaporation hoses onto the clip of fuel filler pipe.




# FUEL FILLER PIPE

## FUEL INJECTION (FUEL SYSTEMS)

10) Install the fuel filler pipe protector.




11) Install the rear right wheel.




12) Lower the vehicle.

13) Tighten the wheel nuts.

14) Connect the connector to the fuel pump relay.




15) Connect the battery ground terminal.




## C: DISASSEMBLY


1) Move the clip, and disconnect the evaporation hose from joint pipe.



2) Remove the bolt which installs the joint pipe on fuel filler pipe.




3) Disconnect the evaporation hose from the fuel filler pipe.




4) Remove the shut valve from the fuel filler pipe.  
<Ref. to EC(DOHC TURBO)-16, REMOVAL, Shut Valve.>

### D: ASSEMBLY


- 1) Install the shut valve on the fuel filler pipe. <Ref. to EC(DOHC TURBO)-16, INSTALLATION, Shut Valve.>
- 2) Connect the evaporation hose to the fuel filler pipe.



- 3) Connect the evaporation hose to the evaporation pipe.



- 4) Install the evaporation pipe to the fuel filler pipe.



# FUEL PUMP

## FUEL INJECTION (FUEL SYSTEMS)

### 25. Fuel Pump

#### A: REMOVAL

##### WARNING:

- Place "NO FIRE" signs near the working area.
- Be careful not to spill fuel on the floor.


##### NOTE:

Fuel pump assembly consists of fuel pump and fuel level sensor.

1) Release the fuel pressure. <Ref. to FU(DOHC TURBO)-51, RELEASING OF FUEL PRESSURE, OPERATION, Fuel.>


2) Open the fuel filler flap lid and remove the fuel filler cap.

3) Disconnect the battery ground cable.



4) Lift-up the vehicle.


5) Drain the fuel from fuel tank. Set a container under the vehicle and remove the drain plug from fuel tank.



6) Tighten the fuel drain plug.


##### Tightening torque:

26 N·m (2.65 kgf-m, 19.2 ft-lb)




7) Raise the rear seat and turn the floor mat up.

8) Remove the access hole lid.




9) Disconnect the connector from the fuel pump.




10) Disconnect the quick connector and then disconnect the fuel delivery hose (A). <Ref. to FU(DOHC TURBO)-68, Fuel Delivery, Return and Evaporation Lines.>

11) Move the clips, and then disconnect the fuel return hose (B) and jet pump hose (C).



12) Remove the nuts which install the fuel pump assembly onto fuel tank.



13) Take off the fuel pump assembly from the fuel tank.


### B: INSTALLATION

Install in the reverse order of removal. Do the following:

- (1) Always use new gaskets.
- (2) Ensure the sealing portion is free from fuel or foreign particles before installation.
- (3) Tighten the nuts in alphabetical sequence shown in figure to specified torque.

#### Tightening torque:

**4.4 N-m (0.45 kgf-m, 3.3 ft-lb)**




### C: INSPECTION

Connect the lead harness to the connector terminal of fuel pump and apply battery power supply to check whether the pump operate.

#### WARNING:

- Wipe off the fuel completely.
- Keep battery as far apart from fuel pump as possible.
- Be sure to turn the battery supply ON and OFF on the battery side.
- Do not run fuel pump for a long time under non-load condition.



# FUEL LEVEL SENSOR

FUEL INJECTION (FUEL SYSTEMS)

---

## 26. Fuel Level Sensor

### A: REMOVAL


#### WARNING:

- Place "NO FIRE" signs near the working area.
- Be careful not to spill fuel on the floor.


#### NOTE:

Fuel level sensor is built in fuel pump assembly.

- 1) Remove the fuel pump assembly. <Ref. to FU(DOHC TURBO)-60, REMOVAL, Fuel Pump.>
- 2) Disconnect the connector from the fuel pump bracket.



- 3) Remove the bolt which installs the fuel level sensor on mounting bracket.



### B: INSTALLATION

Install in the reverse order of removal.


### 27. Fuel Sub Level Sensor

#### A: REMOVAL

##### WARNING:


- Place "NO FIRE" signs near the working area.
- Be careful not to spill fuel on the floor.

1) Disconnect the battery ground cable.



2) Lift-up the vehicle.


3) Drain the fuel from the fuel tank. Set a container under the vehicle and remove drain plug from fuel tank.



4) Tighten the fuel drain plug.


##### Tightening torque:

**26 N·m (2.65 kgf·m, 19.2 ft·lb)**




5) Remove the rear seat.

6) Remove the service hole cover.




7) Disconnect the connector from the fuel sub meter.


8) Disconnect the fuel jet pump hose.



9) Remove the bolts which install the fuel sub meter unit on fuel tank.



10) Remove the fuel sub meter unit.



# FUEL SUB LEVEL SENSOR

FUEL INJECTION (FUEL SYSTEMS)


---

## B: INSTALLATION

Install in the reverse order of removal.

**Tightening torque:**

**4.4 N·m (0.45 kgf-m, 3.3 ft-lb)**




## 28. Fuel Filter

### A: REMOVAL

#### WARNING:

- Place “NO FIRE” signs near the working area.
- Be careful not to spill fuel on the floor.

- 1) Release the fuel pressure. <Ref. to FU(DOHC TURBO)-51, RELEASING OF FUEL PRESSURE, OPERATION, Fuel.>
- 2) Disconnect the fuel delivery hoses from the fuel filter.



- 3) Remove the filter from the holder.

### B: INSTALLATION


#### CAUTION:

- If fuel hoses are damaged at the connecting portion, replace it with a new one.
- If clamps are badly damaged, replace with new ones.

- 1) Install in the reverse order of removal.
- 2) Tighten the hose clamp screws.

#### Tightening torque:

**1.25 N·m (0.13 kgf·m, 0.94 ft·lb)**



### C: INSPECTION

- 1) Check the inside of fuel filter for dirt and water sediment.
- 2) If it is clogged, or if replacement interval has been reached, replace it.
- 3) If water is found in it, shake and expel the water from the inlet port.


# FUEL CUT VALVE

FUEL INJECTION (FUEL SYSTEMS)


## 29. Fuel Cut Valve

### A: REMOVAL

- 1) Remove the fuel tank. <Ref. to FU(DOHC TURBO)-52, REMOVAL, Fuel Tank.>
- 2) Remove the protect cover.



- 3) Move the clip and disconnect the evaporation hose from fuel cut valve.




- 4) Remove the bolts which install the fuel cut valve.

### B: INSTALLATION

Install in the reverse order of removal.

**Tightening torque:**


**4.4 N·m (0.45 kgf-m, 3.3 ft-lb)**



### 30. Fuel Damper Valve

#### A: REMOVAL

- 1) Release the fuel pressure. <Ref. to FU(DOHC TURBO)-51, RELEASING OF FUEL PRESSURE, OPERATION, Fuel.>
- 2) Remove the fuel damper valve from the fuel return line.



#### B: INSTALLATION

Install in the reverse order of removal.

#### **Tightening torque:**

**1.25 N·m (0.13 kgf-m, 0.94 ft-lb)**

# FUEL DELIVERY, RETURN AND EVAPORATION LINES


## FUEL INJECTION (FUEL SYSTEMS)

### 31. Fuel Delivery, Return and Evaporation Lines


#### A: REMOVAL

- 1) Set the vehicle on the lift.
- 2) Release the fuel pressure. <Ref. to FU(DOHC TURBO)-51, RELEASING OF FUEL PRESSURE, OPERATION, Fuel.>

- 3) Open the fuel filler flap lid and remove the fuel filler cap.
- 4) Remove the floor mat. <Ref. to EI-55, REMOVAL, Floor Mat.>
- 5) Remove the fuel delivery pipes and hoses, fuel return pipes and hoses, evaporation pipes and hoses.



- 6) In engine compartment, detach the fuel delivery hoses, return hoses and evaporation hose.



- 7) Lift-up the vehicle.

# FUEL DELIVERY, RETURN AND EVAPORATION LINES


FUEL INJECTION (FUEL SYSTEMS)

8) Separate the quick connector on the fuel delivery and return line.

- (1) Clean the pipe and connector, if they are covered with dust.
- (2) Hold the connector (A) and push retainer (B) down.
- (3) Pull out the connector (A) from retainer (B).

## CAUTION:

Replace retainer with new ones.




- (A) Connector
- (B) Retainer
- (C) Pipe

## B: INSTALLATION

1) Connect the quick connector on the fuel delivery line.

## CAUTION:


- Always use a new retainer.
- Make sure that the connected portion is not damaged or has dust. If necessary, clean seal surface of pipe.



- (1) Set the new retainer (B) to connector (A).
- (2) Push the pipe into the connector completely.

## NOTE:


At this time, two clicking sounds are heard.



- (A) Connector
- (B) Retainer
- (C) Pipe

## CAUTION:

- Pull the connector to ensure it is connected securely.
- Ensure the two retainer pawls are engaged in their mating positions in the connector.
- Be sure to inspect hoses and their connections for any leakage of fuel.



- (A) Connector
- (B) Retainer
- (C) Pipe

# FUEL DELIVERY, RETURN AND EVAPORATION LINES

## FUEL INJECTION (FUEL SYSTEMS)


2) Connect the fuel delivery hose to the pipe with an overlap of 20 to 25 mm (0.79 to 0.98 in).

Type A: When the fitting length is specified.

Type B: When the fitting length is not specified.

$\varnothing : 2.5 \pm 1.5 \text{ mm } (0.098 \pm 0.059 \text{ in})$

$L : 22.5 \pm 2.5 \text{ mm } (0.886 \pm 0.098 \text{ in})$



- (1) Fitting
- (2) Clamp
- (3) Hose

3) Connect the return hose and evaporation hose to the pipe by approx. 15 mm (0.59 in) from the hose end.

**Fuel return hose:**


$L = 22.5 \pm 2.5 \text{ mm } (0.885 \pm 0.098 \text{ in})$

**Fuel evaporation hose:**

$L = 17.5 \pm 2.5 \text{ mm } (0.689 \pm 0.098 \text{ in})$

**CAUTION:**

**Be sure to inspect hoses and their connections for any leakage of fuel.**



- (1) Hose
- (2) Clip
- (3) Pipe

## 32. Fuel System Trouble in General

### A: INSPECTION

Trouble and possible cause		Corrective action
<b>1. Insufficient fuel supply to the injector</b>		
1)	Fuel pump will not operate.	
	○ Defective terminal contact.	Inspect connections, especially ground, and tighten securely.
	○ Trouble in electromagnetic or electronic circuit parts.	Replace fuel pump.
2)	Lowering of fuel pump function.	Replace fuel pump.
3)	Clogged dust or water in the fuel filter.	Replace fuel filter, clean or replace fuel tank.
4)	Clogged or bent fuel pipe or hose.	Clean, correct or replace fuel pipe or hose.
5)	Air is mixed in the fuel system.	Inspect or retighten each connection part.
6)	Clogged or bent breather tube or pipe.	Clean, correct or replace air breather tube or pipe.
7)	Damaged diaphragm of pressure regulator.	Replace.
<b>2. Leakage or blow out fuel</b>		
1)	Loosened joints of the fuel pipe.	Retightening.
2)	Cracked fuel pipe, hose and fuel tank.	Replace.
3)	Defective welding part on the fuel tank.	Replace.
4)	Defective drain packing of the fuel tank.	Replace.
5)	Clogged or bent air breather tube or air vent tube.	Clean, correct or replace air breather tube or air vent tube.
<b>3. Gasoline smell inside of compartment</b>		
1)	Loose joints at air breather tube, air vent tube and fuel filler pipe.	Retightening.
2)	Defective packing air tightness on the fuel saucer.	Correct or replace packing.
3)	Cracked fuel separator.	Replace separator.
4)	Inoperative fuel pump modulator or circuit.	Replace.
<b>4. Defective fuel meter indicator</b>		
1)	Defective operation of fuel level sensor.	Replace.
2)	Defective operation of fuel meter.	Replace.
<b>5. Noise</b>		
1)	Large operation noise or vibration of fuel pump.	Replace.

**NOTE:**

- When the vehicle is left unattended for an extended period of time, water may accumulate in the fuel tank.

To prevent water condensation.

(1) Top off the fuel tank or drain the fuel completely.

(2) Drain the water condensation from the fuel filter.

- Refilling the fuel tank.

Refill the fuel tank while there is still some fuel left in the tank.

- Protecting the fuel system against freezing and water condensation.

(3) Cold areas

In snow-covered areas, mountainous areas, skiing areas, etc. where ambient temperatures drop below 0°C (32°F) throughout the winter season, use an anti-freeze solution in the cool-

ing system. Refueling will also complement the effect of anti-freeze solution each time the fuel level drops to about one-half. After the winter season, drain the water which may have accumulated in the fuel filter and fuel tank in the manner same as that described under Affected areas below.

(4) Affected areas

When the water condensation is notched in the fuel filter, drain the water from both the fuel filter and fuel tank or use a water removing agent (or anti-freeze solution) in the fuel tank.

- Observe the instructions, notes, etc., indicated on the label affixed to the anti-freeze solution (water removing agent) container before use.

# **FUEL SYSTEM TROUBLE IN GENERAL**

FUEL INJECTION (FUEL SYSTEMS)

---

**FU(DOHC TURBO)-72**

# EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES) *EC(DOHC TURBO)*

---

	<b>Page</b>
1. General Description .....	2
2. Front Catalytic Converter .....	3
3. Rear Catalytic Converter .....	4
4. Precatalytic Converter .....	5
5. Canister .....	6
6. Purge Control Solenoid Valve .....	7
7. Main Fuel Level Sensor .....	8
8. Fuel Temperature Sensor .....	9
9. Fuel Sub Level Sensor .....	10
10. Fuel Tank Pressure Sensor .....	11
11. Pressure Control Solenoid Valve .....	12
12. Drain Filter .....	14
13. Vent Valve .....	15
14. Shut Valve .....	16
15. Drain Valve .....	17

# GENERAL DESCRIPTION

EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)

---

## 1. General Description

### A: CAUTION

- Wear working clothing, including a cap, protective goggles, and protective shoes during operation.
- Remove contamination including dirt and corrosion before removal, installation or disassembly.
- Keep the disassembled parts in order and protect them from dust or dirt.
- Before removal, installation or disassembly, be sure to clarify the failure. Avoid unnecessary removal, installation, disassembly, and replacement.
- Be careful not to burn your hands, because each part on the vehicle is hot after running.
- Be sure to tighten fasteners including bolts and nuts to the specified torque.
- Place shop jacks or safety stands at the specified points.
- Before disconnecting electrical connectors of sensors or units, be sure to disconnect the negative terminal from battery.


# FRONT CATALYTIC CONVERTER

EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)

## 2. Front Catalytic Converter

### A: REMOVAL

- 1) Remove the center exhaust pipe. <Ref. to EX(DOHC TURBO)-8, REMOVAL, Center Exhaust Pipe.>
- 2) Separate the front catalytic converter (A) from rear catalytic converter (B).



### B: INSTALLATION

#### NOTE:

Replace the gaskets with new ones.  
Install in the reverse order of removal.

### C: INSPECTION

- 1) Make sure there are no exhaust leaks from connections and welds.
- 2) Make sure there are no holes or rusting.

# REAR CATALYTIC CONVERTER


EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)

---

## 3. Rear Catalytic Converter

### A: REMOVAL

- 1) Remove the center exhaust pipe. <Ref. to EX(DOHC TURBO)-8, REMOVAL, Center Exhaust Pipe.>
- 2) Separate the rear catalytic converter (B) from front catalytic converter (A).



### B: INSTALLATION

NOTE:

Replace the gaskets with new ones.  
Install in the reverse order of removal.

### C: INSPECTION

- 1) Make sure there are no exhaust leaks from connections and welds.
- 2) Make sure there are no holes or rusting.


# PRECATALYTIC CONVERTER

EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)

## 4. Precatalytic Converter

### A: REMOVAL

Precatalytic converter (A) is built in the joint pipe. Refer to the removal of joint pipe for removal procedure. <Ref. to EX(DOHC TURBO)-12, REMOVAL, Joint Pipe.>



### B: INSTALLATION

Precatalytic converter is built in the joint pipe. Refer to the installation of joint pipe for installation procedure. <Ref. to EX(DOHC TURBO)-12, INSTALLATION, Joint Pipe.>

### C: INSPECTION

- 1) Make sure there are no exhaust leaks from connections and welds.
- 2) Make sure there are no holes or rusting.


# CANISTER

EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)


## 5. Canister

### A: REMOVAL

- 1) Lift-up the vehicle.
- 2) Loosen the two clamps which hold two canister hoses, and disconnect the evaporation three hoses from canister.



- 3) Remove the canister from body.




### B: INSTALLATION

- 1) Install in the reverse order of removal.

**Tightening torque:**

**23 N·m (2.3 kgf-m, 17 ft-lb)**



### C: INSPECTION

Make sure the canister and canister hoses are not cracked or loose.


# PURGE CONTROL SOLENOID VALVE

EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)


## 6. Purge Control Solenoid Valve

### A: REMOVAL

- 1) Disconnect the ground terminal from battery.



- 2) Disconnect the connector and hoses from purge control solenoid valve.
- 3) Remove the bolt which installs the purge control solenoid valve onto intake manifold.




### B: INSTALLATION

Install in the reverse order of removal.


**Tightening torque:**

**16 N·m (1.6 kgf-m, 11.6 ft-lb)**



### CAUTION:

**Carefully connect the evaporation hoses.**



(A) To intake manifold

(B) To purge value

### C: INSPECTION

Make sure the hoses are not cracked or loose.

# MAIN FUEL LEVEL SENSOR

EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)

---

## 7. Main Fuel Level Sensor

### A: REMOVAL

For work procedures, refer to "FU" section. <Ref. to FU(DOHC TURBO)-62, REMOVAL, Fuel Level Sensor.>

### B: INSTALLATION

For work procedures, refer to "FU" section. <Ref. to FU(DOHC TURBO)-62, INSTALLATION, Fuel Level Sensor.>


# FUEL TEMPERATURE SENSOR

EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)


## 8. Fuel Temperature Sensor

### A: REMOVAL

- 1) Remove the fuel pump assembly. <Ref. to FU(DOHC TURBO)-60, REMOVAL, Fuel Pump.>
- 2) Disconnect the connector from fuel pump bracket.



- 3) Remove the main fuel level sensor from fuel pump assembly. <Ref. to FU(DOHC TURBO)-62, REMOVAL, Fuel Level Sensor.>



### NOTE:

Fuel temperature sensor is a unit with the fuel pump. If replacing it, replace as a fuel pump.

### B: INSTALLATION

Install in the reverse order of removal.

### WARNING:

Spark may occur and ignite if fuel is nearby.

# FUEL SUB LEVEL SENSOR

EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)

---

## 9. Fuel Sub Level Sensor

### A: REMOVAL

For work procedures, refer to "FU(DOHC TURBO)" section. <Ref. to FU(DOHC TURBO)-63, REMOVAL, Fuel Sub Level Sensor.>

### B: INSTALLATION

For work procedures, refer to "FU(DOHC TURBO)" section. <Ref. to FU(DOHC TURBO)-64, INSTALLATION, Fuel Sub Level Sensor.>


# FUEL TANK PRESSURE SENSOR

EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)


## 10. Fuel Tank Pressure Sensor

### A: REMOVAL


- 1) Remove the fuel tank. <Ref. to FU(DOHC TURBO)-52, REMOVAL, Fuel Tank.>
- 2) Remove the protector cover.



- 3) Disconnect the connector from fuel pressure sensor, then remove the fixing nut.




- 4) Release the clips which hold fuel pipes onto fuel tank.



- 5) Remove the clip, and disconnect pressure hose from fuel tank.

- 6) Disconnect the pressure hose from fuel tank pressure sensor.




### B: INSTALLATION

Install in the reverse order of removal.

**Tightening torque:**

**7.4 N·m (0.75 kgf·m, 5.4 ft·lb)**



### C: INSPECTION

Make sure the hoses are not cracked or loose.


# PRESSURE CONTROL SOLENOID VALVE

EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)

## 11. Pressure Control Solenoid Valve


### A: REMOVAL

1) Disconnect the ground terminal from battery.




2) Remove the canister. <Ref. to EC(DOHC TURBO)-6, REMOVAL, Canister.>


3) Disconnect the evaporation hoses (A) from joint pipes.



4) Remove the bolt which installs pressure control solenoid valve holding bracket on body.




5) Disconnect the connector from pressure control solenoid valve.




6) Disconnect the two evaporation hoses from pressure control solenoid valve.


7) Remove the pressure control solenoid valve with bracket.



8) Remove the pressure control solenoid valve from bracket.



9) Disconnect the vacuum hose from pressure control solenoid valve.



# PRESSURE CONTROL SOLENOID VALVE


EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)

## B: INSTALLATION

Install in the reverse order of removal.

### *Tightening torque:*

**17.6 N·m (1.8 kgf-m, 13.0 ft-lb)**



## C: INSPECTION

Make sure the hoses are not cracked or loose.


# DRAIN FILTER

EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)

## 12. Drain Filter

### A: REMOVAL


1) Disconnect the ground terminal from battery.




2) Lift-up the vehicle.

3) Remove the canister. <Ref. to EC(DOHC TURBO)-6, REMOVAL, Canister.>


4) Disconnect the connector from drain valve.




5) Disconnect the evaporation hoses (A) from joint pipes.



6) Remove the bolt which installs the drain filter and drain valve brackets on body, and remove them as a unit.



7) Disconnect the evaporation hoses, and remove the drain filter.




### B: INSTALLATION

Install in the reverse order of removal.

**Tightening torque:**

**23 N·m (2.3 kgf-m, 17 ft-lb)**



### C: INSPECTION

- 1) Make sure all hoses are installed correctly.
- 2) Make sure the hoses are not cracked or loose.


# VENT VALVE

EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)


## 13. Vent Valve

### A: REMOVAL


- 1) Remove the fuel tank. <Ref. to FU(DOHC TURBO)-52, REMOVAL, Fuel Tank.>
- 2) Remove the protector cover.



- 3) Remove the clips, and disconnect the hoses from vent valve.



- 4) Remove the nuts which install the vent on fuel tank.



### B: INSTALLATION


Install in the reverse order of removal.

#### CAUTION:

Replace the rubber seat with a new one.

#### Tightening torque:

*T: 4.4 N·m (0.45 kgf·m, 3.3 ft·lb)*



### C: INSPECTION

Make sure the hoses are not cracked or loose.


# SHUT VALVE

EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)

## 14. Shut Valve

### A: REMOVAL


1) Disconnect the ground terminal from battery.




2) Drain fuel from the fuel tank. <Ref. to FU(DOHC TURBO)-52, REMOVAL, Fuel Tank.>

3) Remove the fuel filler pipe. <Ref. to FU(DOHC TURBO)-55, REMOVAL, Fuel Filler Pipe.>

4) Disconnect the evaporation hoses from shut valve.



5) Remove the shut valve from fuel filler pipe.




### B: INSTALLATION

Install in the reverse order of removal.

**Tightening torque:**

**4.5 N·m (0.46 kgf-m, 3.3 ft-lb)**



### C: INSPECTION

Make sure the hoses are not cracked or loose.


# DRAIN VALVE

EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)

## 15.Drain Valve

### A: REMOVAL


1) Disconnect the ground terminal from battery.




2) Lift-up the vehicle.

3) Remove the canister. <Ref. to EC(DOHC TURBO)-6, REMOVAL, Canister.>


4) Disconnect the connector from drain valve.




5) Disconnect the evaporation hoses from drain valve.



6) Remove the bolt which installs the drain filter and drain valve brackets on body, and remove them as a unit.



7) Remove the drain valve from bracket.




### B: INSTALLATION

Install in the reverse order of removal.

**Tightening torque:**

**23 N·m (2.3 kgf·m, 17 ft·lb)**



### C: INSPECTION

- 1) Make sure all hoses are installed correctly.
- 2) Make sure the hoses are not cracked or loose.

# **DRAIN VALVE**

EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES)

---

# INTAKE (INDUCTION)

# *IN(DOHC TURBO)*

---

	<b>Page</b>
1. General Description .....	2
2. Air Cleaner .....	7
3. Air Intake Duct.....	8
4. Intake Duct.....	9
5. Intercooler .....	10
6. Turbocharger.....	12
7. Air By-pass Valve.....	14


# GENERAL DESCRIPTION

INTAKE (INDUCTION)

## 1. General Description

### A: COMPONENT

#### 1. AIR CLEANER



EN1178

- |                             |                             |
|-----------------------------|-----------------------------|
| (1) Mass air flow sensor    | (8) Cushion rubber          |
| (2) Air cleaner upper cover | (9) Air intake duct         |
| (3) Air cleaner element     | (10) Resonator chamber ASSY |
| (4) Spacer                  | (11) Cushion rubber         |
| (5) Bush                    | (12) Clamp                  |
| (6) Clip                    | (13) Air intake boot        |
| (7) Air cleaner lower case  | (14) Cushion                |

**Tightening torque: N-m (kgf-m, ft-lb)**

**T1: 7.5 (0.76, 5.5)**


**T2: 33 (3.4, 25)**

**T3: 2.5 (0.25, 1.8)**

**T4: 1.7 (0.17, 1.2)**

**IN(DOHC TURBO)-2**

2. INTAKE DUCT




- |                        |                        |
|------------------------|------------------------|
| (1) Clamp              | (5) Air by-pass hose D |
| (2) PCV hose ASSY      | (6) Intake duct        |
| (3) Air by-pass hose B | (7) Clamp              |
| (4) Air by-pass hose C |                        |

**Tightening torque: N·m (kgf-m, ft-lb)**  
**T1: 16 (1.6, 11.7)**

# GENERAL DESCRIPTION

## INTAKE (INDUCTION)

### 3. INTERCOOLER



EN0904

- |                            |                         |
|----------------------------|-------------------------|
| (1) Intercooler            | (7) Gasket              |
| (2) Intercooler bracket RH | (8) Clamp               |
| (3) Intercooler bracket LH | (9) Air by-pass hose A  |
| (4) Clamp                  | (10) Intercooler duct A |
| (5) Air intake duct        | (11) Intercooler duct B |
| (6) Air by-pass valve      | (12) Intercooler duct C |

- (13) Clamp


**Tightening torque: N·m (kgf·m, ft·lb)**

**T1: 3 (0.22, 1.6)**

**T2: 16 (1.6, 11.7)**

**IN(DOHC TURBO)-4**

4. TURBOCHARGER



EN1116

- (1) Oil inlet pipe
- (2) Metal gasket
- (3) Turbocharger
- (4) Water pipe
- (5) Clamp
- (6) Engine coolant hose
- (7) Gasket

- (8) Oil outlet pipe
- (9) Clip
- (10) Oil outlet hose
- (11) Turbocharger bracket RH
- (12) Turbocharger bracket LH

**Tightening torque: N·m (kgf·m, ft·lb)**

- T1: 4.4 (0.45, 3.3)**
- T2: 4.9 (0.50, 3.6)**
- T3: 29 (3.0, 21.7)**
- T4: 30 (3.1, 22.4)**
- T5: 33 (3.4, 24.6)**
- T6: 16 (1.6, 11.7)**

## GENERAL DESCRIPTION

### INTAKE (INDUCTION)

---


#### **B: CAUTION**

- Wear working clothing, including a cap, protective goggles, and protective shoes during operation.
- Remove contamination including dirt and corrosion before removal, installation or disassembly.
- Keep the disassembled parts in order and protect them from dust or dirt.
- Before removal, installation or disassembly, be sure to clarify the failure. Avoid unnecessary removal, installation, disassembly, and replacement.
- Be careful not to burn your hands, because each part on the vehicle is hot after running.
- Be sure to tighten fasteners including bolts and nuts to the specified torque.
- Place shop jacks or safety stands at the specified points.
- Before disconnecting electrical connectors of sensor or units, be sure to disconnect negative terminal from battery.


## 2. Air Cleaner

### A: REMOVAL

1) Disconnect the ground terminal from battery.




2) Disconnect the connector from mass air flow sensor.



3) Loosen the clamp (A) which connects air intake boot to intake duct.


4) Remove the two clips (B) from air cleaner upper cover.



5) Remove the air cleaner upper cover.

6) Remove the air cleaner element.

7) Remove the air cleaner lower case.




### B: INSTALLATION

Install in the reverse order of removal.


**Tightening torque:**

**33 N·m (3.4 kgf-m, 25 ft-lb)**



### CAUTION:

**Before installing the air cleaner upper cover, align holes with protruding portions of air cleaner lower case, then secure the upper cover to lower case.**



### C: INSPECTION

Replace if excessively damaged or dirty.

# AIR INTAKE DUCT


INTAKE (INDUCTION)

---

## 3. Air Intake Duct

### A: REMOVAL

1) Remove the bolts which install air intake duct on the front side of body.



### B: INSTALLATION

Install in the reverse order of removal.


### C: INSPECTION

- 1) Inspect for cracks and loose connections.
- 2) Inspect that no foreign objects are mixed in the air intake duct.


## 4. Intake Duct

### A: REMOVAL

- 1) Disconnect the ground terminal from battery.



- 2) Remove the intake manifold. <Ref. to FU(DOHC TURBO)-15, REMOVAL, Intake Manifold.>
- 3) Remove the sensor, engine harness, and fuel pipe attached to the intake manifold. <Ref. to FU(DOHC TURBO)-21, DISASSEMBLY, Intake Manifold.>
- 4) Remove the intake duct from intake manifold.



### B: INSTALLATION

Install in the reverse order of removal.


# INTERCOOLER

INTAKE (INDUCTION)


## 5. Intercooler

### A: REMOVAL



1) Disconnect the air by-pass hoses from intercooler.



2) Separate the air by-pass valve from intercooler.




3) Remove the bolts which secure intercooler to bracket.



4) Separate the intercooler air duct from turbocharger.

5) Separate the intercooler from throttle body.






## B: INSTALLATION

Install in the reverse order of removal.


**Tightening torque:**

**16 N·m (1.6 kgf-m, 11.7 ft-lb)**




## C: DISASSEMBLY

1) Loosen the clamps, then remove intercooler duct.



2) Remove the intercooler ducts from intercooler.




## D: ASSEMBLY

Assemble in the reverse order of disassembly.

**Tightening torque:**

**16 N·m (1.6 kgf-m, 11.7 ft-lb)**




# TURBOCHARGER

INTAKE (INDUCTION)


## 6. Turbocharger

### A: REMOVAL


- 1) Set the vehicle on the lift.
- 2) Disconnect the ground terminal from battery.




- 3) Remove the center exhaust pipe. <Ref. to EX(DOHC TURBO)-8, REMOVAL, Center Exhaust Pipe.>
- 4) Lower the vehicle.
- 5) Separate the turbocharger joint pipe from turbocharger.




- 6) Disconnect the engine coolant hose which is connected to coolant filler tank.




- 7) Loosen the clamp which secures turbocharger to air inlet duct.




- 8) Remove the bolt which secures bracket of oil pipe to turbocharger.
- 9) Remove the oil pipe from turbocharger.



- 10) Remove the turbocharger bracket.




- 11) Disconnect the oil outlet hose from pipe.




- 12) Take out the turbocharger from engine compartment.

### B: INSTALLATION


1) Connect the oil outlet hose to outlet pipe.



2) Install the turbocharger to air intake duct.



3) Install the oil pipe to turbocharger.




4) Install the joint pipe to turbocharger.

NOTE:


Replace the gasket with a new one.

**Tightening torque:**


**30 N·m (3.1 kgf·m, 22.4 ft·lb)**



5) Install the turbocharger bracket.



6) Connect the engine coolant hose which is connected to coolant filler tank.




7) Lift-up the vehicle.

8) Install the center exhaust pipe. <Ref. to EX(DOHC TURBO)-9, INSTALLATION, Center Exhaust Pipe.>

## 7. Air By-pass Valve

### A: REMOVAL

- 1) Remove the air by-pass valve from intercooler.




- 2) Disconnect the air by-pass hoses from air by-pass valve.

### B: INSTALLATION

Install in the reverse order of removal.

**Tightening torque:**

**16 N·m (1.6 kgf-m, 11.7 ft-lb)**



# MECHANICAL

# ME(DOHC TURBO)

---

	Page
1. General Description .....	2
2. Compression .....	22
3. Idle Speed .....	23
4. Ignition Timing .....	24
5. Intake Manifold Vacuum .....	25
6. Engine Oil Pressure .....	26
7. Fuel Pressure .....	27
8. Valve Clearance .....	28
9. Engine Assembly .....	33
10. Engine Mounting .....	42
11. Preparation for Overhaul .....	43
12. V-belt .....	44
13. Crankshaft Pulley .....	46
14. Belt Cover .....	47
15. Timing Belt Assembly .....	48
16. Camshaft Sprocket .....	57
17. Crankshaft Sprocket .....	58
18. Camshaft .....	59
19. Cylinder Head Assembly .....	64
20. Cylinder Block .....	72
21. Engine Trouble in General .....	91
22. Engine Noise .....	96

# GENERAL DESCRIPTION

MECHANICAL

## 1. General Description

### A: SPECIFICATIONS

Engine	Type		Horizontally opposed, liquid cooled, 4-cylinder, 4-stroke gasoline engine		
	Valve arrangement		Belt driven, double overhead camshaft, 4-valve/cylinder		
	Bore x Stroke		mm (in)	92 x 75 (3.62 x 2.95)	
	Piston displacement		cm <sup>3</sup> (cu in)	1,994 (121.67)	
	Compression ratio		8.0		
	Compression pressure (at 200 — 300 rpm)		kPa (kgf/cm <sup>2</sup> , psi)	981 — 1,177 (10 — 12, 142 — 171)	
	Number of piston rings		Pressure ring: 2, Oil ring: 1		
	Intake valve timing	Opening	10° BTDC		
		Closing	50° ABDC		
	Exhaust valve timing	Opening	53° BBDC		
		Closing	7° ATDC		
	Valve clearance	Intake	mm (in)	0.20±0.02 (0.0079±0.0008)	
		Exhaust	mm (in)	0.25±0.02 (0.0098±0.0008)	
	Idling speed [At neutral position]		rpm	MT	750±100 (No load) 800±150 (A/C switch ON)
				AT	750±100 (No load) 825±150 (A/C switch ON)
Firing order		1 → 3 → 2 → 4			
Ignition timing		BTDC/rpm	12°±3°/750 rpm		

**ME(DOHC TURBO)-2**

# GENERAL DESCRIPTION

MECHANICAL

**NOTE:**

STD: Standard I.D.: Inner Diameter O.D.: Outer Diameter OS: Oversize US: Undersize

Belt tension adjuster	Protrusion of adjuster rod		5.2 — 6.2 mm (0.205 — 0.244 in)	
Belt tensioner	Spacer O.D.		17.955 — 17.975 mm (0.7069 — 0.7077 in)	
	Tensioner bush I.D.		18.0 — 18.08 mm (0.7087 — 0.7118 in)	
	Clearance between spacer and bush	STD	0.025 — 0.125 mm (0.0010 — 0.0049 in)	
		Limit	0.175 mm (0.0069 in)	
	Side clearance of spacer	STD	0.2 — 0.55 mm (0.0079 — 0.0217 in)	
Limit		0.81 mm (0.0319 in)		
Camshaft	Bend limit		0.020 mm (0.0079 in)	
	Thrust clearance	STD	0.015 — 0.070 mm (0.0006 — 0.0028 in)	
		Limit	0.10 mm (0.0039 in)	
	Cam lobe height	Intake	STD	46.25 — 46.35 mm (1.821 — 1.825 in)
			Limit	46.15 mm (1.817 in)
		Exhaust	STD	46.15 — 46.25 mm (1.817 — 1.821 in)
			Limit	46.05 mm (1.813 in)
	Journal O.D.	STD	Front	37.946 — 37.963 mm (1.4939 — 1.4946 in)
			Center rear	29.946 — 29.963 mm (1.1790 — 1.1796 in)
			Oil clearance	STD
		Limit	0.10 mm (0.0039 in)	
Cylinder head	Surface warpage limit		0.05 mm (0.0020 in)	
	Surface grinding limit		0.3 mm (0.012 in)	
	Standard height		127.5 mm (5.02 in)	
Valve seat	Refacing angle		90°	
	Contacting width	Intake	STD	1.0 mm (0.039 in)
			Limit	1.7 mm (0.067 in)
		Exhaust	STD	1.5 mm (0.059 in)
			Limit	2.2 mm (0.087 in)
Valve guide	Inner diameter		6.000 — 6.012 mm (0.2362 — 0.2367 in)	
	Protrusion above head		12.0 — 12.4 mm (0.472 — 0.488 in)	
Valve	Head edge thickness	Intake	STD	1.2 mm (0.047 in)
			Limit	0.8 mm (0.031 in)
		Exhaust	STD	1.5 mm (0.059 in)
			Limit	0.8 mm (0.031 in)
	Stem diameter	Intake	5.950 — 5.965 mm (0.2343 — 0.2348 in)	
		Exhaust	5.945 — 5.960 mm (0.2341 — 0.2346 in)	
	Stem oil clearance	STD	Intake	0.035 — 0.062 mm (0.0014 — 0.0024 in)
			Exhaust	0.040 — 0.067 mm (0.0016 — 0.0026 in)
		Limit	—	0.15 mm (0.0059 in)
	Overall length	Intake	104.4 mm (4.110 in)	
Exhaust		104.7 mm (4.122 in)		
Valve spring	Free length		44.67 mm (1.7587 in)	
	Squareness		2.5°, 2.0 mm (0.079 in)	
	Tension/spring height		220.7±15.7 N (22.5±1.6 kgf, 49.6±3.5 lb)/36.0 mm (1.417 in) 510.9±25.5 N (52.1±2.6 kgf, 114.9±5.7 lb)/26.6 mm (1.047 in)	

**ME(DOHC TURBO)-3**

# GENERAL DESCRIPTION

## MECHANICAL

Cylinder block	Surface warpage limit (mating with cylinder head)			0.05 mm (0.0020 in)
	Surface grinding limit			0.1 mm (0.004 in)
	Cylinder bore	STD	A	92.005 — 92.015 mm (3.6222 — 3.6226 in)
			B	91.995 — 92.005 mm (3.6218 — 3.6222 in)
	Taper	STD		0.015 mm (0.0006 in)
		Limit		0.050 mm (0.0020 in)
	Out-of-roundness	STD		0.010 mm (0.0004 in)
		Limit		0.050 mm (0.0020 in)
Piston clearance	STD		0.010 — 0.030 mm (0.0004 — 0.0012 in)	
	Limit		0.050 mm (0.0020 in)	
Enlarging (boring) limit			0.5 mm (0.020 in)	
Piston	Outer diameter	STD	A	91.985 — 91.995 mm (3.6214 — 3.6218 in)
			B	91.975 — 91.985 mm (3.6211 — 3.6214 in)
		0.25 mm (0.0098 in) OS		92.225 — 92.235 mm (3.6309 — 3.6313 in)
		0.50 mm (0.0197 in) OS		92.475 — 92.485 mm (3.6407 — 3.6411 in)
Piston pin	Standard clearance between piston pin and hole in piston		STD	0.004 — 0.008 mm (0.0002 — 0.0003 in)
			Limit	0.020 mm (0.0008 in)
	Degree of fit		Piston pin must be fitted into position with thumb at 20°C (68°F).	
Piston ring	Piston ring gap	Top ring	STD	0.20 — 0.35 mm (0.0079 — 0.0138 in)
			Limit	1.0 mm (0.039 in)
		Second ring	STD	0.35 — 0.50 mm (0.0138 — 0.0197 in)
			Limit	1.0 mm (0.039 in)
	Oil ring	STD	0.20 — 0.70 mm (0.0079 — 0.0276 in)	
		Limit	1.5 mm (0.059 in)	
	Clearance between piston ring and piston ring groove	Top ring	STD	0.040 — 0.080 mm (0.0016 — 0.0031 in)
			Limit	0.15 mm (0.0059 in)
Second ring		STD	0.030 — 0.070 mm (0.0012 — 0.0028 in)	
		Limit	0.15 mm (0.0059 in)	
Connecting rod	Bend twist per 100 mm (3.94 in) in length		Limit	0.10 mm (0.0039 in)
	Side clearance	STD	0.070 — 0.330 mm (0.0028 — 0.0130 in)	
		Limit	0.4 mm (0.016 in)	
Connecting rod bearing	Oil clearance		STD	0.020 — 0.046 mm (0.0008 — 0.0018 in)
			Limit	0.05 mm (0.0020 in)
	Thickness at center portion		STD	1.492 — 1.501 mm (0.0587 — 0.0591 in)
			0.03 mm (0.0012 in) US	1.510 — 1.513 mm (0.0594 — 0.0596 in)
			0.05 mm (0.0020 in) US	1.520 — 1.523 mm (0.0598 — 0.0600 in)
			0.25 mm (0.0098 in) US	1.620 — 1.623 mm (0.0638 — 0.0639 in)
Connecting rod bushing	Clearance between piston pin and bushing		STD	0 — 0.022 mm (0 — 0.0009 in)
			Limit	0.030 mm (0.0012 in)

# GENERAL DESCRIPTION


MECHANICAL

Crankshaft	Bend limit		0.035 mm (0.0014 in)			
	Crank pin and crank journal	Out-of-roundness		0.020 mm (0.0008 in) or less		
		Grinding limit		0.25 mm (0.0098 in)		
	Crank pin outer diameter		STD	47.984 — 48.000 mm (1.8891 — 1.8898)		
			0.03 mm (0.0012 in) US	47.954 — 47.970 mm (1.8879 — 1.8886)		
			0.05 mm (0.0020 in) US	47.934 — 47.950 mm (1.8872 — 1.8878)		
			0.25 mm (0.0098 in) US	47.734 — 47.750 mm (1.8793 — 1.8799)		
	Crank journal outer diameter		#1, #3, #5	STD	59.992 — 60.008 mm (2.3619 — 2.3625 in)	
				0.03 mm (0.0012 in) US	59.962 — 59.978 mm (2.3607 — 2.3613 in)	
				0.05 mm (0.0020 in) US	59.942 — 59.958 mm (2.3599 — 2.3605 in)	
				0.25 mm (0.0098 in) US	59.742 — 59.758 mm (2.3520 — 2.3527 in)	
			#2, #4	STD	59.992 — 60.008 mm (2.3619 — 2.3625 in)	
				0.03 mm (0.0012 in) US	59.962 — 59.978 mm (2.3607 — 2.3613 in)	
				0.05 mm (0.0020 in) US	59.942 — 59.958 mm (2.3599 — 2.3605 in)	
				0.25 mm (0.0098 in) US	59.742 — 59.758 mm (2.3520 — 2.3527 in)	
	Thrust clearance		STD	0.030 — 0.115 mm (0.0012 — 0.0045 in)		
Limit			0.25 mm (0.0098 in)			
Oil clearance		STD	0.010 — 0.030 mm (0.0004 — 0.0012 in)			
		Limit	0.040 mm (0.0016 in)			
Crankshaft bearing	Crankshaft bearing thickness		#1, #3	STD	1.998 — 2.011 mm (0.0787 — 0.0792 in)	
				0.03 mm (0.0012 in) US	2.017 — 2.020 mm (0.0794 — 0.0795 in)	
				0.05 mm (0.0020 in) US	2.027 — 2.030 mm (0.0798 — 0.0799 in)	
				0.25 mm (0.0098 in) US	2.127 — 2.130 mm (0.0837 — 0.0839 in)	
			#2, #4, #5	STD	2.000 — 2.013 mm (0.0787 — 0.0793 in)	
				0.03 mm (0.0012 in) US	2.019 — 2.022 mm (0.0795 — 0.0796 in)	
				0.05 mm (0.0020 in) US	2.029 — 2.032 mm (0.0799 — 0.0800 in)	
				0.25 mm (0.0098 in) US	2.129 — 2.132 mm (0.0838 — 0.0839 in)	

**ME(DOHC TURBO)-5**

### B: COMPONENT

#### 1. TIMING BELT



EN1136

- |  |  |                            |
|--|--|----------------------------|
| (1) Right-hand belt cover No. 2          | (9) Right-hand intake camshaft sprocket  | (17) Right-hand belt cover |
| (2) Timing belt guide (MT vehicles only) | (10) Left-hand intake camshaft sprocket  | (18) Crankshaft pulley     |
| (3) Crankshaft sprocket                  | (11) Left-hand exhaust camshaft sprocket |                            |
| (4) Left-hand belt cover No. 2           | (12) Timing belt                         |                            |
| (5) Tensioner bracket                    | (13) Belt idler No. 2                    |                            |
| (6) Automatic belt tension adjuster ASSY | (14) Belt idler                          |                            |
| (7) Belt idler                           | (15) Left-hand belt cover                |                            |
| (8) Right-hand exhaust camshaft sprocket | (16) Front belt cover                    |                            |

**Tightening torque: N·m (kgf·m, ft·lb)**


- T1: 5 (0.5, 3.6)**  
**T2: 10 (1.0, 7)**  
**T3: 25 (2.5, 18.1)**  
**T4: 39 (4.0, 28.9)**  
**T5: 98 (10, 72.4)**  
**T6: <Ref. to ME(DOHC TURBO)-46, INSTALLATION, Crankshaft Pulley.>**

**ME(DOHC TURBO)-7**

# GENERAL DESCRIPTION

MECHANICAL

## 2. CYLINDER HEAD AND CAMSHAFT



S2M1188A

ME(DOHC TURBO)-8

# GENERAL DESCRIPTION

MECHANICAL

- |                                       |                                       |                      |
|---------------------------------------|---------------------------------------|----------------------|
| (1) Rocker cover (RH)                 | (15) Cylinder head (RH)               | (29) Oil filler cap  |
| (2) Rocker cover gasket (RH)          | (16) Cylinder head gasket (RH)        | (30) Gasket          |
| (3) Oil separator cover               | (17) Cylinder head gasket (LH)        | (31) Oil filler duct |
| (4) Gasket                            | (18) Cylinder head (LH)               | (32) O-ring          |
| (5) Intake camshaft cap (Front RH)    | (19) Intake camshaft (LH)             | (33) Stud bolt       |
| (6) Intake camshaft cap (Center RH)   | (20) Exhaust camshaft (LH)            |                      |
| (7) Intake camshaft cap (Rear RH)     | (21) Intake camshaft cap (Front LH)   |                      |
| (8) Intake camshaft (RH)              | (22) Intake camshaft cap (Center LH)  |                      |
| (9) Exhaust camshaft cap (Front RH)   | (23) Intake camshaft cap (Rear LH)    |                      |
| (10) Exhaust camshaft cap (Center RH) | (24) Exhaust camshaft (Front LH)      |                      |
| (11) Exhaust camshaft cap (Rear RH)   | (25) Exhaust camshaft cap (Center LH) |                      |
| (12) Exhaust camshaft (RH)            | (26) Exhaust camshaft cap (Rear LH)   |                      |
| (13) Cylinder head bolt               | (27) Rocker cover gasket (LH)         |                      |
| (14) Oil seal                         | (28) Rocker cover (LH)                |                      |

---

**Tightening torque: N·m (kgf-m, ft-lb)**

**T1: <Ref. to ME(DOHC TURBO)-64, INSTALLATION, Cylinder Head Assembly.>**

**T2: 5 (0.5, 3.6)**

**T3: 10 (1.0, 7)**


**T4: 6.4 (0.65, 4.7)**

---

# GENERAL DESCRIPTION

## MECHANICAL


### 3. CYLINDER HEAD AND VALVE ASSEMBLY



S2M1197A

- |                           |                  |                             |
|---------------------------|------------------|-----------------------------|
| (1) Exhaust valve         | (6) Valve spring | (11) Exhaust valve oil seal |
| (2) Intake valve          | (7) Retainer     | (12) Intake valve guide     |
| (3) Cylinder head         | (8) Retainer key | (13) Exhaust valve guide    |
| (4) Valve spring seat     | (9) Valve lifter |                             |
| (5) Intake valve oil seal | (10) Shim        |                             |

## 4. CYLINDER BLOCK



EN0144

- |                          |                            |
|--------------------------|----------------------------|
| (1) Oil pressure switch  | (15) Oil cooler            |
| (2) Cylinder block (RH)  | (16) Waster by-pass pipe   |
| (3) Service hole plug    | (17) Connector             |
| (4) Gasket               | (18) Oil strainer          |
| (5) Oil separator cover  | (19) Gasket                |
| (6) Water by-pass pipe   | (20) Oil pan               |
| (7) Oil pump             | (21) Drain plug            |
| (8) Front oil seal       | (22) Metal gasket          |
| (9) Rear oil seal        | (23) Oil level gauge guide |
| (10) O-ring              | (24) Oil filter            |
| (11) Service hole cover  | (25) Gasket                |
| (12) Cylinder block (LH) | (26) Water pump hose       |
| (13) Water pump          | (27) Plug                  |
| (14) Baffle plate        |                            |


**Tightening torque: N-m (kgf-m, ft-lb)**

- T1: 5 (0.5, 3.6)**  
**T2: 6.4 (0.65, 4.7)**  
**T3: 10 (1.0, 7)**  
**T4: 25 (2.5, 18.1)**  
**T5: 47 (4.8, 34.7)**  
**T6: 69 (7.0, 50.6)**  
**T7: First 12 (1.2, 8.7)**  
**Second 12 (1.2, 8.7)**  
**T8: 16 (1.6, 11.6)**  
**T9: 44 (4.5, 33)**  
**T10: 25 (2.5, 18.1)**  
**T11: 55 (5.5, 40)**

# GENERAL DESCRIPTION

MECHANICAL

## 5. CRANKSHAFT AND PISTON



EN0415


- |                                      |                             |                                |
|--------------------------------------|-----------------------------|--------------------------------|
| (1) Flywheel (MT vehicles only)      | (9) Piston pin              | (17) Crankshaft bearing #1, #3 |
| (2) Ball bearing (MT vehicles only)  | (10) Circlip                | (18) Crankshaft bearing #2, #4 |
| (3) Reinforcement (AT vehicles only) | (11) Connecting rod bolt    | (19) Crankshaft bearing #5     |
| (4) Drive plate (AT vehicles only)   | (12) Connecting rod         |                                |
| (5) Top ring                         | (13) Connecting rod bearing |                                |
| (6) Second ring                      | (14) Connecting rod cap     |                                |
| (7) Oil ring                         | (15) Crankshaft             |                                |
| (8) Piston                           | (16) Woodruff key           |                                |

**Tightening torque: N·m (kgf·m, ft·lb)**

**T1: 44.6 (4.55, 32.9)**

**T2: 72 (7.3, 52.8)**

6. ENGINE MOUNTING



- (1) Hear shield cover
- (2) Front cushion rubber

- (3) Front engine mounting bracket

**Tightening torque: N-m (kgf-m, ft-lb)**

**T1: 35 (3.6, 25.8)**

**T2: 42 (4.3, 30.9)**

**T3: 85 (8.7, 62.7)**

# GENERAL DESCRIPTION

## MECHANICAL



### C: CAUTION

- Wear working clothing, including a cap, protective goggles, and protective shoes during operation.
- Remove contamination including dirt and corrosion before removal, installation or disassembly.
- Keep the disassembled parts in order and protect them from dust or dirt.
- Before removal, installation or disassembly, be sure to clarify the failure. Avoid unnecessary removal, installation, disassembly, and replacement.
- Be careful not to burn your hands, because each part in the vehicle is hot after running.
- Be sure to tighten fasteners including bolts and nuts to the specified torque.
- Place shop jacks or safety stands at the specified points.
- Before disconnecting electrical connectors of sensors or units, be sure to disconnect the negative terminal from battery.
- All parts should be thoroughly cleaned, paying special attention to the engine oil passages, pistons and bearings.

- Rotating parts and sliding parts such as piston, bearing and gear should be coated with oil prior to assembly.
- Be careful not to let oil, grease or coolant contact the timing belt, clutch disc and flywheel.
- All removed parts, if to be reused, should be re-installed in the original positions and directions.
- Bolts, nuts and washers should be replaced with new ones as required.
- Even if necessary inspections have been made in advance, proceed with assembly work while making rechecks.
- Remove or install the engine in an area where chain hoists, lifting devices, etc. are available for ready use.
- Be sure not to damage coated surfaces of body panels with tools or stain seats and windows with coolant or oil. Place a cover over fenders, as required, for protection.
- Prior to starting work, prepare the following:  
Service tools, clean cloth, containers to catch coolant and oil, wire ropes, chain hoist, transmission jacks, etc.
- Lift-up or lower the vehicle when necessary. Make sure to support the correct positions.





### D: PREPARATION TOOL

#### 1. SPECIAL TOOLS

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p>EN0147</p>	498267600	CYLINDER HEAD TABLE	<ul style="list-style-type: none"> <li>• Used for replacing valve guides.</li> <li>• Used for removing and installing valve springs.</li> </ul>
 <p>B2M3851</p>	498457000	ENGINE STAND ADAPTER RH	Used with ENGINE STAND (499817000).





# GENERAL DESCRIPTION

MECHANICAL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">B2M3852</p>	498457100	ENGINE STAND ADAPTER LH	Used with ENGINE STAND (499817000).
 <p style="text-align: center;">B2M3853</p>	498497100	CRANKSHAFT STOPPER	Used for stopping rotation of flywheel when loosening and tightening crankshaft pulley bolt, etc.
 <p style="text-align: center;">B2M3854</p>	398744300 (Newly adopted tool)	PISTON GUIDE	Used for installing piston in cylinder for 2000 cc engine.
 <p style="text-align: center;">B2M3855</p>	498857100	VALVE OIL SEAL GUIDE	Used for press-fitting of intake and exhaust valve guide oil seals.





# GENERAL DESCRIPTION

## MECHANICAL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: right;">B2M3856</p>	499017100	PISTON PIN GUIDE	Used for installing piston pin, piston and connecting rod.
 <p style="text-align: right;">B2M3857</p>	499037100	CONNECTING ROD BUSHING REMOVER & INSTALLER	Used for removing and installing connecting rod bushing.
 <p style="text-align: right;">B2M3858</p>	499097700	PISTON PIN REMOVER ASSY	Used for removing piston pin.
 <p style="text-align: right;">B2M4158</p>	499207400 (Newly adopted tool)	CAMSHAFT SPROCKET WRENCH	Used for removing and installing camshaft sprocket.





# GENERAL DESCRIPTION

MECHANICAL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: right;">B2M3860</p>	499587700 (Newly adopted tool)	CAMSHAFT OIL SEAL INSTALLER	Used for installing cylinder head plug for DOHC engine.
 <p style="text-align: right;">B2M3861</p>	499587200	CRANKSHAFT OIL SEAL INSTALLER	<ul style="list-style-type: none"> <li>• Used for installing crankshaft oil seal.</li> <li>• Used with CRANKSHAFT OIL SEAL GUIDE (499597100).</li> </ul>
 <p style="text-align: right;">B2M3863</p>	499597100	CRANKSHAFT OIL SEAL GUIDE	<ul style="list-style-type: none"> <li>• Used for installing crankshaft oil seal.</li> <li>• Used with CRANKSHAFT OIL SEAL INSTALLER (499587200).</li> </ul>
 <p style="text-align: right;">B2M3864</p>	499718000	VALVE SPRING REMOVER	Used for removing and installing valve spring.





# GENERAL DESCRIPTION

## MECHANICAL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: right;">B2M3865</p>	498267700	VALVE GUIDE ADJUSTER	Used for installing intake and exhaust valve guides.
 <p style="text-align: right;">B2M3867</p>	499767200	VALVE GUIDE REMOVER	Used for removing valve guides.
 <p style="text-align: right;">B2M3868</p>	499767400	VALVE GUIDE REAMER	Used for reaming valve guides.
 <p style="text-align: right;">B2M3869</p>	499817000	ENGINE STAND	<ul style="list-style-type: none"> <li>• Stand used for engine disassembly and assembly.</li> <li>• Used with ENGINE STAND ADAPTER RH (498457000) &amp; LH (498457100).</li> </ul>





# GENERAL DESCRIPTION

MECHANICAL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: right;">B2M4157</p>	499977300	CRANK PULLEY WRENCH	Used for stopping rotation of crankshaft pulley when loosening and tightening crankshaft pulley bolts.
 <p style="text-align: right;">B2M3871</p>	499987500	CRANKSHAFT SOCKET	Used for rotating crankshaft.
 <p style="text-align: right;">B2M3872</p>	498547000	OIL FILTER WRENCH	Used for removing and installing oil filter.
 <p style="text-align: right;">B2M3875</p>	499587100	OIL SEAL INSTALLER	Used for installing oil pump oil seal.


# GENERAL DESCRIPTION

## MECHANICAL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">S1H0136</p>	<p style="text-align: center;">499587600 (Newly adopted tool)</p>	<p style="text-align: center;">OIL SEAL GUIDE</p>	<p>Used for installing camshaft oil seal for DOHC engine.</p>
 <p style="text-align: center;">EN0168</p>	<p style="text-align: center;">499597200 (Newly adopted tool)</p>	<p style="text-align: center;">OIL SEAL GUIDE</p>	<p>Used for installing camshaft oil seal for DOHC engine. Used with OIL SEAL GUIDE (499587600).</p>
 <p style="text-align: center;">EN0168</p>	<p style="text-align: center;">498187200 (Newly adopted tool)</p>	<p style="text-align: center;">SHIM REPLACER</p>	<p>Used for correct valve clearance.</p>
 <p style="text-align: center;">H1H049</p>	<p style="text-align: center;">498277200</p>	<p style="text-align: center;">STOPPER SET</p>	<p>Used for installing automatic transmission assembly to engine.</p>

# GENERAL DESCRIPTION

MECHANICAL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 B2M3876	24082AA150	CARTRIDGE	Troubleshooting for electrical systems.
 B2M3877	22771AA030	SELECT MONI-TOR KIT	Troubleshooting for electrical systems. <ul style="list-style-type: none"> <li>• English: 22771AA030 (Without printer)</li> <li>• German: 22771AA070 (Without printer)</li> <li>• French: 22771AA080 (Without printer)</li> <li>• Spanish: 22771AA090 (Without printer)</li> </ul>

## 2. GENERAL PURPOSE TOOLS

TOOL NAME	REMARKS
Compression Gauge	Used for measuring compression.
Timing Light	Used for measuring ignition timing.

### E: PROCEDURE

It is possible to conduct the following service procedures with engine on the vehicle, however, the procedures described in this section are based on the condition that the engine is removed from the vehicle.

- V-belt
- Timing Belt
- Camshaft
- Cylinder Head

## 2. Compression

### A: INSPECTION

**CAUTION:**


**After warming-up, engine becomes very hot. Be careful not to burn yourself during measurement.**

- 1) After warming-up the engine, turn the ignition switch to OFF.
- 2) Make sure that the battery is fully charged.
- 3) Release fuel pressure. <Ref. to FU(DOHC TURBO)-51, RELEASING OF FUEL PRESSURE, OPERATION, Fuel.>
- 4) Remove all the spark plugs. <Ref. to IG(DOHC TURBO)-4, REMOVAL, Spark Plug.>
- 5) Fully open the throttle valve.
- 6) Check the starter motor for satisfactory performance and operation.
- 7) Hold the compression gauge tight against the spark plug hole.

**CAUTION:**

**When using a screw-in type compression gauge, the screw (put into cylinder head spark plug hole) should be less than 18 mm (0.71 in) long.**

- 8) Crank the engine by means of the starter motor, and read the maximum value on the gauge when the pointer is steady.



- 9) Perform at least two measurements per cylinder, and make sure that the values are correct.

**Compression (350 rpm and fully open throttle):**

**Standard;**

**951 — 1,147 kPa (9.7 — 11.7 kgf/cm<sup>2</sup>, 138 — 166 psi)**

**Limit;**

**834 kPa (8.5 kgf/cm<sup>2</sup>, 121 psi)**

**Difference between cylinders;**

**49 kPa (0.5 kgf/cm<sup>2</sup>, 7 psi)**

### 3. Idle Speed

#### A: INSPECTION

1) Before checking the idle speed, check the following:

(1) Ensure the air cleaner element is free from clogging, ignition timing is correct, spark plugs are in good condition, and that hoses are connected properly.

(2) Ensure the malfunction indicator light (CHECK ENGINE light) does not illuminate.

2) Warm-up the engine.

3) Stop the engine, and turn the ignition switch to OFF.

4) Insert the cartridge to the SUBARU SELECT MONITOR.

5) Connect the SUBARU SELECT MONITOR to the data link connector.

6) Turn the ignition switch to ON, and SUBARU SELECT MONITOR switch to ON.

7) Select {2. Each System Check} in Main Menu.

8) Select {Engine Control System} in Selection Menu.

9) Select {1. Current Data Display & Save} in Engine Control System Diagnosis.

10) Select {1.12 Data Display} in Data Display Menu.

11) Start the engine, and read engine idle speed.

12) Check the idle speed when unloaded. (With headlights, heater fan, rear defroster, radiator fan, air conditioning, etc. OFF)

***Idle speed (No load and gears in neutral:***

***750±100 rpm***

13) Check the idle speed when loaded. (Turn the air conditioning switch to "ON" and operate the compressor for at least one minute before measurement.)

***Idle speed [A/C "ON", no load and gears in neutral]:***

***800±150 rpm (MT model)***

***825±150 rpm (AT model)***

#### **CAUTION:**

**Never rotate the idle adjusting screw. If the idle speed is out of specifications, refer to General On-board Diagnosis Table under "Engine Control System". <Ref. to EN(DOHC TURBO)-2, Basic Diagnostic Procedure.>**

## 4. Ignition Timing

### A: INSPECTION

1) Before checking the ignition timing speed, check the following:

(1) Ensure the air cleaner element is free from clogging, spark plugs are in good condition, and that hoses are connected properly.

(2) Ensure the malfunction indicator light (CHECK ENGINE light) does not illuminate.

2) Warm-up the engine.

3) Stop the engine, and turn the ignition switch to OFF.

4) Insert the cartridge to the SUBARU SELECT MONITOR.

5) Connect the SUBARU SELECT MONITOR to the data link connector.

6) Turn the ignition switch to ON, and SUBARU SELECT MONITOR switch to ON.

7) Select {2. Each System Check} in Main Menu.

8) Select {Engine Control System} in Selection Menu.

9) Select {1. Current Data Display & Save} in Engine Control System Diagnosis.

10) Select {1.12 Data Display} in Data Display Menu.

11) Start the engine, at idle speed and check the ignition timing.

#### ***Ignition timing [BTDC/rpm]:***

***12°±3°/750***

If the timing is not correct, check the ignition control system. Refer to Engine Control System. <Ref. to EN(DOHC TURBO)-2, Basic Diagnostic Procedure.>


## 5. Intake Manifold Vacuum

### A: INSPECTION

- 1) Warm-up the engine.
- 2) Disconnect the brake vacuum hose and install the vacuum gauge to the hose fitting on the manifold.

3) Keep the engine at the idle speed and read the vacuum gauge indication.

By observing the gauge needle movement, the internal condition of the engine can be diagnosed as described below.




**Vacuum pressure (at idling, A/C "OFF"):**  
**Less than -60.0 kPa (-450 mmHg, -17.72 in-Hg)**

Diagnosis of engine condition by measurement of manifold vacuum	
Vacuum gauge indication	Possible engine condition
1. Needle is steady but lower than normal position. This tendency becomes more evident as engine temperature rises.	Leakage around intake manifold gasket or disconnection or damaged vacuum hose
2. When engine speed is reduced slowly from higher speed, needle stops temporarily when it is lowering or becomes steady above normal position.	Back pressure too high, or exhaust system clogged
3. Needle intermittently drops to position lower than normal position.	Leakage around cylinder
4. Needle drops suddenly and intermittently from normal position.	Sticky valves
5. When engine speed is gradually increased, needle begins to vibrate rapidly at certain speed, and then vibration increases as engine speed increases.	Weak or broken valve springs
6. Needle vibrates above and below normal position in narrow range.	Defective ignition system or throttle chamber idle adjustment


## 6. Engine Oil Pressure

### A: INSPECTION

- 1) Remove the oil pressure switch from engine cylinder block. <Ref. to LU-22, REMOVAL, Oil Pressure Switch.>
- 2) Connect the oil pressure gauge hose to cylinder block.
- 3) Connect the battery ground terminal to battery.



- 4) Start the engine, and measure oil pressure.



#### Oil pressure:

**98 kPa (1.0 kg/cm<sup>2</sup>, 14 psi) or more at 800 rpm**  
**294 kPa (3.0 kg/cm<sup>2</sup>, 43 psi) or more at 5,000 rpm**

#### CAUTION:

- If the oil pressure is out of specification, check oil pump, oil filter and lubrication line. <Ref. to LU-28, INSPECTION, Engine Lubrication System Trouble in General.>
- If the oil pressure warning light is turned ON and oil pressure is in specification, replace the oil pressure switch. <Ref. to LU-28, INSPECTION, Engine Lubrication System Trouble in General.>

#### NOTE:

The specified data is based on an engine oil temperature of 80°C (176°F).

- 5) After measuring the oil pressure, install the oil pressure switch. <Ref. to LU-23, INSTALLATION, Oil Pressure Switch.>

#### Tightening torque:

**25 N·m (2.5 kgf-m, 18.1 ft-lb)**

## 7. Fuel Pressure

### A: INSPECTION


**WARNING:**

Before removing the fuel pressure gauge, release the fuel pressure.


**NOTE:**

If out of specification, check or replace the pressure regulator and pressure regulator vacuum hose.


- 1) Release the fuel pressure. <Ref. to FU(DOHC TURBO)-51, RELEASING OF FUEL PRESSURE, OPERATION, Fuel.>
- 2) Open the fuel flap lid, and remove the fuel filler cap.



- 3) Disconnect the fuel delivery hoses from fuel filter, and connect the fuel pressure gauge.




- 4) Connect the connector of fuel pump relay.



- 5) Start the engine.
- 6) Measure fuel pressure while disconnecting the pressure regulator vacuum hose from intake manifold.

**Fuel pressure:**


**Standard; 284 — 314 kPa (2.9 — 3.2 kgf/cm<sup>2</sup>, 41 — 46 psi)**



- 7) After connecting the pressure regulator vacuum hose, measure fuel pressure.

**Fuel pressure:**

**Standard; 230 — 260 kPa (2.35 — 2.65 kgf/cm<sup>2</sup>, 33 — 38 psi)**



**NOTE:**

The fuel pressure gauge registers 10 to 20 kPa (0.1 to 0.2 kgf/cm<sup>2</sup>, 1 to 3 psi) higher than standard values during high-altitude operations.

# VALVE CLEARANCE

## MECHANICAL


### 8. Valve Clearance

#### A: INSPECTION


##### CAUTION:

Inspection and adjustment of valve clearance should be performed while engine is cold.

- 1) Set the vehicle onto the lift.
- 2) Disconnect the ground terminal from battery.




- 3) Remove the air intake duct. <Ref. to IN(DOHC TURBO)-8, REMOVAL, Air Intake Duct.>
- 4) Remove one bolt which secures the timing belt cover (RH).
- 5) Lift-up the vehicle.
- 6) Remove the under cover.
- 7) Loosen the remaining bolts which secure the timing belt cover (RH), then remove the belt cover.
- 8) Lower the vehicle.
- 9) When inspecting #1 and #3 cylinders:
  - (1) Pull out the engine harness connector with bracket from air cleaner upper cover.




- (2) Remove the air cleaner case. <Ref. to IN(DOHC TURBO)-7, REMOVAL, Air Cleaner.>
- (3) Disconnect the spark plug cords from spark plugs (#1 and #3 cylinders).
- (4) Place a suitable container under the vehicle.
- (5) Disconnect the PCV hose from rocker cover (RH).
- (6) Remove the bolts, then remove the rocker cover (RH).


- 10) When inspecting #2 and #4 cylinders:
  - (1) Disconnect the battery terminal, and then remove the battery and battery carrier.




- (2) Remove the bolt which secures the engine harness bracket onto body.




- (3) Disconnect the washer motor connectors.



- (4) Remove the washer tank mounting bolts.



(5) Move the washer tank upward.



(6) Disconnect the spark plug cords from spark plugs (#2 and #4 cylinders).

(7) Place a suitable container under the vehicle.

(8) Disconnect the PCV hose from rocker cover (LH).


(9) Remove the bolts, then remove the rocker cover (LH).

11) Turn the crankshaft pulley clockwise until arrow mark on the camshaft sprocket is set to position shown in the figure.

**NOTE:**

Turn the crankshaft using ST.

ST 499987500 CRANKSHAFT SOCKET



12) Measure #1 cylinder intake valve and #3 cylinder exhaust valve clearance by using thickness gauge (A).

**CAUTION:**

- Insert the thickness gauge in as horizontal a direction as possible with respect to the shim.
- Measure the exhaust valve clearances while lifting-up the vehicle.


**Valve clearance:**

**Intake:  $0.20 \pm 0.02$  mm ( $0.0079 \pm 0.0008$  in)**

**Exhaust:  $0.25 \pm 0.02$  mm ( $0.0098 \pm 0.0008$  in)**

**NOTE:**


If the measured value is not within specification, take notes of the value in order to adjust the valve clearance later on.




13) If necessary, adjust the valve clearance. <Ref. to ME(DOHC TURBO)-30, ADJUSTMENT, Valve Clearance.>

14) Further turn the crankshaft pulley clockwise. Using the same procedures described previously, then measure valve clearances again.

(1) Set the arrow mark on camshaft sprocket to position shown in the figure, and measure #2 cylinder exhaust valve and #3 cylinder intake valve clearances.




(2) Set the arrow mark on camshaft sprocket to position shown in the figure, and measure #2 cylinder intake valve and #4 cylinder exhaust valve clearances.



# VALVE CLEARANCE

## MECHANICAL


(3) Set the arrow mark on camshaft sprocket to position shown in the figure, and measure #1 cylinder exhaust valve and #4 cylinder intake valve clearances.



15) After inspection, install the related parts in the reverse order of removal.

### Tightening torque:

**32 N·m (3.3 kgf·m, 24 ft·lb)**



## B: ADJUSTMENT


### CAUTION:

**Adjustment of valve clearance should be performed while engine is cold.**

1) Measure all valve clearances. <Ref. to ME(DOHC TURBO)-28, INSPECTION, Valve Clearance.>

### NOTE:


Record each valve clearance after it has been measured.




2) Remove the shim from valve lifter.

(1) Prepare the ST.

ST 498187200 SHIM REPLACER




(2) Rotate the notch of the valve lifter outward by 45°.



# VALVE CLEARANCE

MECHANICAL

(3) Adjust the SHIM REPLACER notch to valve lifter and set it.




**NOTE:**


When setting, be careful the SHIM REPLACER edge does not touch shim.

(4) Tighten bolt (A) and install it to the cylinder head.

(5) Tighten bolt (B) and insert the valve lifter.




(6) Insert tweezers into the notch of the valve lifter, and take the shim out.




**NOTE:**

By using a magnet (A), the shim (B) can be taken out without dropping it.



3) Measure the thickness of shim with a micrometer.



4) Select a shim of suitable thickness using measured valve clearance and shim thickness, by referring to the following table.

5) Set the suitable shim selected in step 4) to valve lifter.

Unit: mm	
Intake valve:	$S = (V + T) - 0.20$
Exhaust valve:	$S = (V + T) - 0.25$
S: Shim thickness to be used	
V: Measured valve clearance	
T: Shim thickness required	

# VALVE CLEARANCE

## MECHANICAL

Part No.	Thickness mm (in)
13218 AK010	2.00 (0.0787)
13218 AK020	2.02 (0.0795)
13218 AK030	2.04 (0.0803)
13218 AK040	2.06 (0.0811)
13218 AK050	2.08 (0.0819)
13218 AK060	2.10 (0.0827)
13218 AK070	2.12 (0.0835)
13218 AK080	2.14 (0.0843)
13218 AK090	2.16 (0.0850)
13218 AK100	2.18 (0.0858)
13218 AK110	2.20 (0.0866)
13218 AE710	2.22 (0.0874)
13218 AE730	2.24 (0.0882)
13218 AE750	2.26 (0.0890)
13218 AE770	2.28 (0.0898)
13218 AE790	2.30 (0.0906)
13218 AE810	2.32 (0.0913)
13218 AE830	2.34 (0.0921)
13218 AE850	2.36 (0.0929)
13218 AE870	2.38 (0.0937)
13218 AE890	2.40 (0.0945)
13218 AE910	2.42 (0.0953)
13218 AE920	2.43 (0.0957)
13218 AE930	2.44 (0.0961)
13218 AE940	2.45 (0.0965)
13218 AE950	2.46 (0.0969)
13218 AE960	2.47 (0.0972)
13218 AE970	2.48 (0.0976)
13218 AE980	2.49 (0.0980)
13218 AE990	2.50 (0.0984)
13218 AF000	2.51 (0.0988)
13218 AF010	2.52 (0.0992)
13218 AF020	2.53 (0.0996)
13218 AF030	2.54 (0.1000)
13218 AF040	2.55 (0.1004)
13218 AF050	2.56 (0.1008)
13218 AF060	2.57 (0.1012)
13218 AF070	2.58 (0.1016)
13218 AF090	2.60 (0.1024)
13218 AF110	2.62 (0.1031)
13218 AF130	2.64 (0.1039)
13218 AF150	2.66 (0.1047)
13218 AF170	2.68 (0.1055)
13218 AF190	2.70 (0.1063)


6) Inspect all valves for clearance again at this stage. If the valve clearance is not correct, repeat the procedure over again from the first step.

7) After inspection, install the related parts in the reverse order of removal.


## 9. Engine Assembly

### A: REMOVAL

- 1) Set the vehicle on lift arms.
- 2) Open the front hood fully and support with stay.
- 3) Raise the rear seat, and turn the floor mat up.
- 4) Release the fuel pressure.
  - (1) Disconnect the fuel pump relay connector.




- (2) Start the engine, and run until stalls.
- (3) After the engine stalls, crank it for five seconds more.
- (4) Turn the ignition switch to "OFF".
- 5) Remove the filler cap.
- 6) Disconnect the ground terminal from battery.



- 7) Remove the radiator from vehicle. <Ref. to CO-37, REMOVAL, Radiator.>
- 8) Remove the coolant filler tank. <Ref. to CO-51, REMOVAL, Coolant Filler Tank.>

- 9) Collect refrigerant, and remove the pressure hoses.


- (1) Place and connect the attachment hose to the refrigerant recycle system.
- (2) Collect the refrigerant from A/C system.
- (3) Disconnect the A/C pressure hoses from A/C compressor.




- 10) Remove the intercooler. <Ref. to IN(DOHC TURBO)-10, REMOVAL, Intercooler.>

- 11) Disconnect the following connectors and cable.

- (1) Engine harness connector




- (2) Engine ground terminal




# ENGINE ASSEMBLY

## MECHANICAL

### (3) Engine harness connector




### (4) Generator connector, terminal and A/C compressor connectors




- (A) A/C compressor connector
- (B) Generator connector and terminal

### (5) Accelerator cable




### (6) Clutch release spring




### 12) Disconnect the following hoses.

#### (1) Brake booster vacuum hose




#### (2) Heater inlet outlet hose




### 13) Remove the power steering pump from bracket.

(1) Loosen lock bolt and slider bolt, and remove the front side V-belt. <Ref. to ME(DOHC TURBO)-44, FRONT SIDE BELT, REMOVAL, V-belt.>


(2) Disconnect the power steering switch connector.




(3) Remove the pipe with bracket from intake manifold.




(4) Remove the power steering pump from engine.



(5) Remove the power steering tank from the bracket by pulling it upward.




(6) Place the power steering pump on the right side wheel apron.




14) Remove the center exhaust pipe. <Ref. to EX(DOHC TURBO)-8, REMOVAL, Center Exhaust Pipe.>

15) Remove the nuts which hold lower side of transmission to engine.




16) Remove the nuts which install the front cushion rubber onto front crossmember.



17) Separate the clutch release fork from release bearing. (MT vehicles)


- (1) Remove the clutch operating cylinder from transmission.
- (2) Remove the plug using a 10 mm hexagon wrench.



# ENGINE ASSEMBLY

## MECHANICAL

- (3) Screw the 6 mm dia. bolt into release fork shaft, and remove it.



- (A) Shaft  
(B) Bolt

- (4) Raise the release fork and unfasten the release bearing tabs to free release fork.


### CAUTION:

**Step (4) is required to prevent interference with engine when removing the engine from transmission.**


- 18) Separate the torque converter clutch from drive plate. (AT vehicles)

- (1) Lower the vehicle.
- (2) Remove the service hole plug.
- (3) Remove the bolts which hold torque converter clutch to drive plate.
- (4) Remove the other bolts while rotating the engine using ST.

ST 499977300 CRANK PULLEY WRENCH




- 19) Remove the pitching stopper.




- 20) Disconnect the fuel delivery hose, return hose and evaporation hose.

### CAUTION:


- Catch fuel from hose into container.
- Disconnect the hose with its end wrapped with cloth to prevent fuel from splashing.



- 21) Remove the fuel filter and bracket.




- 22) Support the engine with a lifting device and wire ropes.



23) Support the transmission with a garage jack.

**CAUTION:**

Before moving the engine away from transmission, check to be sure no work has been overlooked. Doing this is very important in order to facilitate re-installation and because transmission lowers under its own weight.



25) Remove the engine from vehicle.

- (1) Slightly raise the engine.
- (2) Raise the transmission with garage jack.
- (3) Move the engine horizontally until the mainshaft is withdrawn from clutch cover.
- (4) Slowly move the engine away from engine compartment.

**CAUTION:**


Be careful not to damage adjacent parts or body panels with crank pulley, oil pressure gauge, etc.

26) Remove the front cushion rubbers.


24) Separation of engine and transmission.

- (1) Remove the starter. <Ref. to SC-6, REMOVAL, Starter.>
- (2) Install the ST to torque converter clutch case. (AT vehicles)

ST 498277200 STOPPER SET




(3) Remove the bolts which hold right upper side of transmission to engine.



## B: INSTALLATION


1) Install the clutch release fork and bearing onto transmission. (MT vehicles)

(1) Remove the release bearing from clutch cover with flat type screw driver.



(2) Install the release bearing on transmission.


(3) Install the release fork into release bearing tab.



- (A) Release fork
- (B) Release bearing

(4) Apply grease to the specified points.

- Spline FX2200
- Shaft SUNLIGHT 2




- (A) Spline (FX2200)
- (B) Shaft (SUNLIGHT 2)

(5) Insert the release fork shaft into release fork.

### CAUTION:

**Make sure the cutout portion of release fork shaft contacts spring pin.**




- (A) Release fork
- (B) Release shaft
- (C) Spring pin

(6) Tighten the plug.

**Tightening torque:**

**44 N·m (4.5 kgf-m, 32.5 ft-lb)**



2) Install the front cushion rubbers to engine.

**Tightening torque:**

**34 N·m (3.5 kgf-m, 25.3 ft-lb)**

3) Install the engine onto transmission.

(1) Position the engine in engine compartment and align it with transmission.

**CAUTION:**


**Be careful not to damage adjacent parts or body panels with crank pulley, oil pressure gauge, etc.**

(2) Apply a small amount of grease to splines of mainshaft. (MT vehicles)

4) Tighten the bolts which hold right upper side of transmission to engine.


**Tightening torque:**

**50 N·m (5.1 kgf-m, 36.9 ft-lb)**



5) Remove the lifting device and wire ropes.

6) Remove the garage jack.




7) Install the pitching stopper.

**Tightening torque:**

**T1: 50 N·m (5.1 kgf-m, 37 ft-lb)**

**T2: 58 N·m (5.9 kgf-m, 43 ft-lb)**



8) Remove the ST from torque converter clutch case. (AT vehicles)

**NOTE:**

Be careful not to drop the ST into the torque converter clutch case when removing ST.

ST 498277200 STOPPER SET

9) Install the starter. <Ref. to SC-7, INSTALLATION, Starter.>

# ENGINE ASSEMBLY

## MECHANICAL

10) Install the torque converter clutch onto drive plate. (AT vehicles)

(1) Tighten the bolts which hold torque converter clutch to drive plate.

(2) Tighten other bolts while rotating the engine by using ST.


### CAUTION:

Be careful not to drop bolts into the torque converter clutch housing.

ST 499977300 CRANK PULLEY WRENCH


### Tightening torque:

25 N·m (2.5 kgf-m, 18.1 ft-lb)




(3) Clog the service hole with plug.

11) Install the fuel filter and bracket.



12) Install the power steering pump on bracket.


(1) Install the power steering tank on bracket.




(2) Install the power steering pump.

### Tightening torque:


20.1 N·m (2.05 kgf-m, 14.8 ft-lb)



(3) Install the power steering pipe bracket on right side intake manifold, and install the spark plug codes.



(4) Connect the power steering switch connector.




(5) Install the front side V-belt, and adjust it.  
<Ref. to ME(DOHC TURBO)-44, FRONT SIDE BELT, INSTALLATION, V-belt.>

13) Tighten the nuts which hold lower side of transmission to engine.

**Tightening torque:**

**50 N·m (5.1 kgf-m, 36.9 ft-lb)**




14) Tighten the nuts which install the front cushion rubber onto crossmember.

**Tightening torque:**

**83 N·m (8.5 kgf-m, 61 ft-lb)**

**CAUTION:**

**Make sure the front cushion rubber mounting bolts (A) and locator (B) are securely installed.**



15) Install the center exhaust pipe.  
<Ref. to EX(DOHC TURBO)-9, INSTALLATION, Center Exhaust Pipe.>

16) Connect the following hoses:

- (1) Fuel delivery hose, return hose and evaporation hose
- (2) Heater inlet and outlet hoses
- (3) Brake booster vacuum hose

17) Connect the following connectors and terminals:

- (1) Engine ground terminal
- (2) Engine harness connectors
- (3) Generator connector and terminal
- (4) A/C compressor connectors

18) Connect the following cables:

- (1) Accelerator cable
- (2) Clutch release spring

**CAUTION:**

**After connecting each cable, adjust them.**

19) Install the air intake system.

(1) Install the intercooler. <Ref. to IN(DOHC TURBO)-11, INSTALLATION, Intercooler.>

(2) Install the air cleaner element and air cleaner upper cover.

(3) Install the engine harness connector bracket.

(4) Install the filler hose to air cleaner case.


20) Install the A/C pressure hoses.

**CAUTION:**

**Use new O-rings.**

**Tightening torque:**

**25 N·m (2.5 kgf-m, 18.1 ft-lb)**



21) Install the radiator. <Ref. to CO-41, INSTALLATION, Radiator.>

22) Install the coolant filler tank. <Ref. to CO-51, INSTALLATION, Coolant Filler Tank.>

23) Install the window washer tank.

24) Install the battery in the vehicle, and connect cables.

25) Fill coolant.

<Ref. to CO-25, FILLING OF ENGINE COOLANT, REPLACEMENT, Engine Coolant.>

26) Charge the A/C system with refrigerant.

<Ref. to AC-17, OPERATION, Refrigerant Charging Procedure.>

27) Remove the front hood stay, and close the front hood.

28) Take off the vehicle from lift arms.

## 10. Engine Mounting

### A: REMOVAL

- 1) Remove the engine assembly. <Ref. to ME(DOHC TURBO)-33, REMOVAL, Engine Assembly.>
- 2) Remove the engine mounting from engine assembly.

### B: INSTALLATION

Install in the reverse order of removal.

#### *Tightening torque:*

#### *Engine mounting;*

*35 N·m (3.6 kgf-m, 25.8 ft-lb)*

### C: INSPECTION


Make sure there are no cracks or other damage.

## 11.Preparation for Overhaul

### A: PROCEDURE

1) After removing the engine from the body, secure it in the ST shown below.

ST1	498457000	ENGINE STAND ADAPTER RH
ST2	498457100	ENGINE STAND ADAPTER LH
ST3	499817000	ENGINE STAND



2) In this section the procedures described under each index are all connected and stated in order. It will be the complete procedure for overhauling of the engine itself when you go through all steps in the process.

Therefore, in this section, to conduct the particular procedure within the flow of a section, you need to go back and conduct the procedure described previously in order to do that particular procedure.

## 12.V-belt


### A: REMOVAL

#### 1. FRONT SIDE BELT


**NOTE:**

Perform the following procedures 1) to 4) with the engine installed to the body.

1) Remove the V-belt cover.




- 2) Loosen the lock bolt (A).
- 3) Loosen the slider bolt (B).
- 4) Remove the front side belt (C).




#### 2. REAR SIDE BELT

- 1) Loosen the lock nut (A).
- 2) Loosen the slider bolt (B).



3) Remove the A/C belt.

4) Remove the A/C belt tensioner.



### B: INSTALLATION

#### 1. FRONT SIDE BELT

**CAUTION:**

**Wipe off any oil or water on the belt and pulley.**

- 1) Install a belt, and tighten the slider bolt so as to obtain the specified belt tension <Ref. to ME(DOHC TURBO)-45, INSPECTION, V-belt.>
- 2) Tighten the lock bolt (A)
- 3) Tighten the slider bolt (B).


**Tightening torque:**

**Lock bolt through bolt:**

**25 N·m (2.5 kgf-m, 18 ft-lb)**

**Slider bolt:**

**8 N·m (0.8 kgf-m, 5.5 ft-lb)**




## 2. REAR SIDE BELT

- 1) Install a belt, and tighten the slider bolt (B) so as to obtain the specified belt tension. <Ref. to ME(DOHC TURBO)-45, INSPECTION, V-belt.>
- 2) Tighten the lock nut (A).

### Tightening torque:

**Lock nut (A);**

**22.6 N·m (2.3 kgf-m, 16.6 ft-lb)**



## C: INSPECTION

- 1) Replace the belts, if cracks, fraying or wear is found.
- 2) Check the drive belt tension and adjust it if necessary by changing generator installing position and/or idler pulley installing position.

### Belt tension

**(A)**

**replaced: 7 — 9 mm (0.276 — 0.354 in)**


**reused: 9 — 11 mm (0.354 — 0.433 in)**

**(B)\***

**replaced: 7.5 — 8.5 mm (0.295 — 0.335 in)**

**reused: 9.0 — 10.0 mm (0.354 — 0.394 in)**

**\*: With Air conditioner**



- C/P Crankshaft pulley
- GEN Generator
- P/S Power steering oil pump pulley
- A/C Air conditioning compressor pulley
- I/P Idler pulley

# CRANKSHAFT PULLEY

MECHANICAL

## 13. Crankshaft Pulley


### A: REMOVAL

1) Remove the V-belt. <Ref. to ME(DOHC TURBO)-44, REMOVAL, V-belt.>

2) Remove the crankshaft pulley bolt. To lock crankshaft, use ST.

ST 499977300

CRANKSHAFT PULLEY WRENCH



3) Remove the crankshaft pulley.

### B: INSTALLATION

1) Install the crankshaft pulley.

2) Install the pulley bolt.

To lock the crankshaft, use ST.

ST 499977300 CRANKSHAFT PULLEY WRENCH

(1) Clean the crankshaft pulley thread using an air gun.


(2) Apply engine oil to the crankshaft pulley bolt seat and thread.

(3) Tighten the bolts temporarily with tightening torque of 44 N·m (4.5 kgf-m, 33 ft-lb).

(4) Tighten the crankshaft pulley bolts.

**Tightening torque:**

**127 N·m (13 kgf-m, 94.0 ft-lb)**



3) Confirm that the tightening angle of the crankshaft pulley bolt is 45 degrees or more. If not, conduct the following procedures (1) through (4).

### CAUTION:

**If the tightening angle of crankshaft pulley bolt is less than 45 degrees, the bolt should be damaged. In this case, the bolt must be replaced.**

(1) Replace the crankshaft pulley bolts and clean them.

**Crankshaft pulley bolt:**

**12369AA011**

(2) Clean the crankshaft thread using an air gun.


(3) Tighten the bolts temporarily with tightening torque of 44 N·m (4.5 kgf-m, 33 ft-lb).

(4) Tighten the crankshaft pulley bolts keeping them in an angle between 65 degrees and 75 degrees.


### CAUTION:

**Conduct the tightening procedures by confirming the turning angle of the crankshaft pulley bolt referring to the gauge indicated on the belt cover.**

4) Install the A/C belt tensioner.



5) Install the A/C belt.



### C: INSPECTION


1) Make sure the V-belt is not worn or otherwise damaged.

2) Check the tension of the belt. <Ref. to ME(DOHC TURBO)-45, INSPECTION, V-belt.>

## 14. Belt Cover

### A: REMOVAL

- 1) Remove the V-belt. <Ref. to ME(DOHC TURBO)-44, REMOVAL, V-belt.>
- 2) Remove the crankshaft pulley. <Ref. to ME(DOHC TURBO)-46, REMOVAL, Crankshaft Pulley.>
- 3) Remove the left-hand belt cover (A).
- 4) Remove the right-hand belt cover (B).
- 5) Remove the front belt cover (C).



### B: INSTALLATION

- 1) Install the front belt cover (C).

**Tightening torque:**

**5 N·m (0.5 kgf-m, 3.6 ft-lb)**

- 2) Install the right-hand belt cover (B).


**Tightening torque:**

**5 N·m (0.5 kgf-m, 3.6 ft-lb)**

- 3) Install the left-hand belt cover (A).

**Tightening torque:**

**5 N·m (0.5 kgf-m, 3.6 ft-lb)**



- 4) Install the crankshaft pulley. <Ref. to ME(DOHC TURBO)-46, INSTALLATION, Crankshaft Pulley.>
- 5) Install the V-belt. <Ref. to ME(DOHC TURBO)-44, INSTALLATION, V-belt.>

# TIMING BELT ASSEMBLY





MECHANICAL

## 15. Timing Belt Assembly

### A: REMOVAL

#### 1. TIMING BELT


- 1) Remove the V-belt. <Ref. to ME(DOHC TURBO)-44, REMOVAL, V-belt.>
- 2) Remove the crankshaft pulley. <Ref. to ME(DOHC TURBO)-46, REMOVAL, Crankshaft Pulley.>
- 3) Remove the belt cover. <Ref. to ME(DOHC TURBO)-47, REMOVAL, Belt Cover.>
- 4) Remove the timing belt guides. (MT vehicle)





5) If the alignment mark and/or arrow mark (which indicates rotation direction) on timing belt fade away, put new marks before removing the timing belt as follows:

- (1) Turn the crankshaft using ST, and align alignment marks on crankshaft sprocket, left-hand intake camshaft sprocket, left-hand exhaust camshaft sprocket, right-hand intake camshaft sprocket and right hand exhaust camshaft sprocket with notches of belt cover and cylinder block.


ST 499987500 CRANKSHAFT SOCKET




(2) Using white paint, put alignment and/or arrow marks on the timing belts in relation to the sprockets.



**Z<sub>1</sub>: 54.5 tooth length**  
**Z<sub>2</sub>: 51 tooth length**  
**Z<sub>3</sub>: 28 tooth length**



6) Remove the belt idler (A).




7) Remove the timing belt.

**CAUTION:**


After the timing belt has been removed, never rotate the intake and exhaust, camshaft sprocket. If the camshaft sprocket is rotated, the intake and exhaust valve heads strike together and valve stems are bent.

**2. BELT IDLER AND AUTOMATIC BELT TENSION ADJUSTER ASSEMBLY**


1) Remove the belt idler (B) and (C).



2) Remove the belt idler No. 2.



3) Remove the automatic belt tension adjuster assembly.



# TIMING BELT ASSEMBLY

MECHANICAL

## B: INSTALLATION

### 1. AUTOMATIC BELT TENSION ADJUST-ER ASSEMBLY AND BELT IDLER


1) Preparation for installation of automatic belt tension adjuster assembly:

#### CAUTION:


- Always use a vertical type pressing tool to move the adjuster rod down.
- Do not use a lateral type vise.
- Push the adjuster rod vertically.
- Be sure to slowly move the adjuster rod down applying a pressure of 294 N (30 kgf, 66 lb).
- Press-in the push adjuster rod gradually taking more than three minutes.
- Do not allow press pressure to exceed 9,807 N (1,000 kgf, 2,205 lb).
- Press the adjuster rod as far as the end surface of the cylinder. Do not press the adjuster rod into the cylinder. Doing so may damage the cylinder.
- Do not release the press pressure until stopper pin is completely inserted.

(1) Attach the automatic belt tension adjuster assembly to the vertical pressing tool.

(2) Slowly move the adjuster rod down with a pressure of 294 N (30 kgf, 66 lb) until the adjuster rod is aligned with the stopper pin hole in the cylinder.




(3) With a 2 mm (0.08 in) dia. stopper pin or a 2 mm (0.08 in) (nominal) dia. hex bar wrench inserted into the stopper pin hole in the cylinder, secure the adjuster rod.



2) Install the automatic belt tension adjuster assembly.

#### Tightening torque:


**39 N·m (4.0 kgf-m, 28.9 ft-lb)**



3) Install the belt idler No. 2.

#### Tightening torque:


**39 N·m (4.0 kgf-m, 28.9 ft-lb)**



4) Install the belt idler.

#### Tightening torque:

**39 N·m (4.0 kgf-m, 28.9 ft-lb)**




## 2. TIMING BELT


1) Preparation for installation of automatic belt tension adjuster assembly. <Ref. to ME(DOHC TURBO)-50, AUTOMATIC BELT TENSION ADJUSTER ASSEMBLY AND BELT IDLER, Timing Belt Assembly.>

2) Crankshaft and camshaft sprocket alignment.

(1) Align mark (A) on the crankshaft sprocket with mark on the oil pump cover at cylinder block.




(2) Align single line mark (A) on the right-hand exhaust camshaft sprocket with notch (B) on belt cover.




(3) Align single line mark (A) on the right-hand intake camshaft sprocket with notch (B) on belt cover.

(Make sure double lines (C) on intake camshaft and exhaust camshaft sprockets are aligned.)




(4) Align single line mark (A) on left-hand exhaust camshaft sprocket with notch (B) on belt cover by turning the sprocket counterclockwise (as viewed from front of engine).



(5) Align single line mark (A) on left-hand intake camshaft sprocket with notch (B) on belt cover by turning the sprocket clockwise (as viewed from front of engine).

Ensure double lines (C) on intake and exhaust camshaft sprockets are aligned.




# TIMING BELT ASSEMBLY

## MECHANICAL

(6) Ensure camshaft and crankshaft sprockets are positioned properly.


### CAUTION:

• Intake and exhaust camshafts for this DOHC engine can be independently rotated with the timing belts removed. As can be seen from the figure, if the intake and exhaust valves are lifted simultaneously, their heads will interfere with each other, resulting in bent valves.




- (A) Intake camshaft
- (B) Exhaust camshaft

- When the timing belts are not installed, four camshafts are held at the “zero-lift” position, where all cams on camshafts do not push the intake and exhaust valves down. (Under this condition, all valves remain unlifted.)
- When the camshafts are rotated to install the timing belts, #2 intake and #4 exhaust cam of left-hand camshafts are held to push their corresponding valves down. (Under this condition, these valves are held lifted.) Right-side camshafts are held so that their cams do not push valves down.
- Left-hand camshafts must be rotated from the “zero-lift” position to the position where the timing belt is to be installed at as small an angle as possible, in order to prevent mutual interference of intake and exhaust valve heads.
- Do not allow the camshafts to rotate in the direction shown in the figure as this causes both intake and exhaust valves to lift simultaneously, resulting in interference with their heads.




### 3) Installation of timing belt:



Align the alignment mark on the timing belt with marks on the sprockets in the alphabetical order shown in the figure. While aligning marks, position the timing belt properly.

**CAUTION:**

- Disengagement of more than three timing belt teeth may result in interference between the valve and piston.
- Ensure the belt's rotating direction is correct.



# TIMING BELT ASSEMBLY

## MECHANICAL


4) Install the belt idlers.

**Tightening torque:**

**39 N·m (4.0 kgf·m, 28.9 ft·lb)**

**CAUTION:**

**Make sure that the marks on the timing belt and sprockets are aligned.**



5) After ensuring that the marks on the timing belt and sprockets are aligned, remove the stopper pin from tensioner adjuster.





6) Install the timing belt guide. (MT vehicle)

(1) Temporarily tighten the remaining bolts.

(2) Check and adjust clearance between the timing belt and timing belt guide.

**Clearance:**



**1.0±0.5 mm (0.039±0.020 in)**





(3) Tighten the remaining bolts.

**Tightening torque:**

**9.8 N·m (1.0 kgf·m, 7.2 ft·lb)**





## C: INSPECTION

### 1. TIMING BELT


- 1) Check the timing belt teeth for breaks, cracks, and wear. If any fault is found, replace the belt.
- 2) Check the condition of back side of belt; if any crack is found, replace the belt.

#### CAUTION:

- Be careful not to let oil, grease or coolant contact the belt. Remove quickly and thoroughly if this happens.
- Do not bend the belt sharply.

**Bending radius:  $h$**

**60 mm (2.36 in) or more**



7) Install the belt cover. <Ref. to ME(DOHC TURBO)-47, INSTALLATION, Belt Cover.>

8) Install the crankshaft pulley. <Ref. to ME(DOHC TURBO)-46, REMOVAL, Crankshaft Pulley.>

9) Install the V-belt. <Ref. to ME(DOHC TURBO)-44, INSTALLATION, V-belt.>

# TIMING BELT ASSEMBLY

## MECHANICAL

### 2. AUTOMATIC BELT TENSION ADJUST-ER

1) Visually check the oil seals for leaks, and rod ends for abnormal wear or scratches. If necessary, replace the automatic belt tension adjuster assembly.

#### CAUTION:

**Slight traces of oil at rod's oil seal does not indicate the a problem.**

2) Check that the adjuster rod does not move when a pressure of 294 N (30 kgf, 66 lb) is applied to it. This is to check adjuster rod stiffness.

3) If the adjuster rod is not stiff and moves freely when applying 294 N (30 kgf, 66 lb), check it using the following procedures:

(1) Slowly press the adjuster rod down to the end surface of the cylinder. Repeat this motion 2 or 3 times.

(2) With the adjuster rod moved all the way up, apply a pressure of 294 N (30 kgf, 66 lb) to it. Check the adjuster rod stiffness.

(3) If the the adjuster rod is not stiff and moves down, replace the automatic belt tension adjuster assembly with a new one.


#### CAUTION:

- Always use a vertical type pressing tool to move the adjuster rod down.
- Do not use a lateral type vise.
- Push the adjuster rod vertically.
- Press-in the push adjuster rod gradually taking more than three minutes.
- Do not allow press pressure to exceed 9,807 N (1,000 kgf, 2,205 lb).
- Press the adjuster rod as far as the end surface of the cylinder. Do not press the adjuster rod into the cylinder. Doing so may damage the cylinder.

4) Measure the extension of rod beyond the body. If it is not within specifications, replace with a new one.

#### Rod extension: H

$5.7 \pm 0.5 \text{ mm (0.224} \pm 0.020 \text{ in)}$



### 3. BELT TENSION PULLEY

- 1) Check the mating surfaces of timing belt and contact point of adjuster rod for abnormal wear or scratches. Replace the belt tension pulley if faulty.
- 2) Check the belt tension pulley for smooth rotation. Replace if noise or excessive play is noted.
- 3) Check the belt tension pulley for grease leakage.

### 4. BELT IDLER


- 1) Check the idler for smooth rotation. Replace if noise or excessive play is noted.
- 2) Check the outer contacting surfaces of idler pulley for abnormal wear and scratches.
- 3) Check the idler for grease leakage.

## 16. Camshaft Sprocket

### A: REMOVAL

- 1) Remove the V-belt. <Ref. to ME(DOHC TURBO)-44, REMOVAL, V-belt.>
- 2) Remove the crankshaft pulley. <Ref. to ME(DOHC TURBO)-46, REMOVAL, Crankshaft Pulley.>
- 3) Remove the belt cover. <Ref. to ME(DOHC TURBO)-47, REMOVAL, Belt Cover.>
- 4) Remove the timing belt assembly. <Ref. to ME(DOHC TURBO)-48, REMOVAL, Timing Belt Assembly.>
- 5) Remove the camshaft position sensor. <Ref. to FU(DOHC TURBO)-31, REMOVAL, Camshaft Position Sensor.>
- 6) Remove the camshaft sprockets. To lock the camshaft, use ST.

ST 499207400 CAMSHAFT SPROCKET WRENCH



### B: INSTALLATION


- 1) Install the camshaft sprocket No. 1. and No. 2. To lock camshaft, use ST.
- ST 499207100 CAMSHAFT SPROCKET WRENCH

#### Tightening torque:

**98 N·m (10 kgf·m, 72.4 ft·lb)**

#### CAUTION:

**Do not confuse left and right side camshaft sprockets during installation. The camshaft sprocket No. 2 is identified by a projection used to monitor camshaft position sensor.**



- 2) Install the camshaft position sensor. <Ref. to FU(DOHC TURBO)-31, INSTALLATION, Camshaft Position Sensor.>
- 3) Install the timing belt assembly. <Ref. to ME(DOHC TURBO)-50, INSTALLATION, Timing Belt Assembly.>
- 4) Install the belt cover. <Ref. to ME(DOHC TURBO)-47, INSTALLATION, Belt Cover.>
- 5) Install the crankshaft pulley. <Ref. to ME(DOHC TURBO)-46, INSTALLATION, Crankshaft Pulley.>
- 6) Install the V-belt. <Ref. to ME(DOHC TURBO)-44, INSTALLATION, V-belt.>

### C: INSPECTION

- 1) Check the sprocket teeth for abnormal wear and scratches.
- 2) Make sure there is no free play between sprocket and key.
- 3) Check the crankshaft sprocket notch used for sensor for damage and contamination of foreign matter.


# CRANKSHAFT SPROCKET

MECHANICAL

## 17. Crankshaft Sprocket


### A: REMOVAL

- 1) Remove the V-belt. <Ref. to ME(DOHC TURBO)-44, REMOVAL, V-belt.>
- 2) Remove the crankshaft pulley. <Ref. to ME(DOHC TURBO)-46, REMOVAL, Crankshaft Pulley.>
- 3) Remove the belt cover. <Ref. to ME(DOHC TURBO)-47, REMOVAL, Belt Cover.>
- 4) Remove the timing belt assembly. <Ref. to ME(DOHC TURBO)-48, REMOVAL, Timing Belt Assembly.>
- 5) Remove the camshaft sprocket. <Ref. to ME(DOHC TURBO)-57, REMOVAL, Camshaft Sprocket.>
- 6) Remove the crankshaft sprocket.



### B: INSTALLATION

- 1) Install the crankshaft sprocket.



- 2) Install the camshaft sprocket. <Ref. to ME(DOHC TURBO)-57, INSTALLATION, Camshaft Sprocket.>
- 3) Install the timing belt assembly. <Ref. to ME(DOHC TURBO)-50, INSTALLATION, Timing Belt Assembly.>
- 4) Install the belt cover. <Ref. to ME(DOHC TURBO)-47, INSTALLATION, Belt Cover.>
- 5) Install the crankshaft pulley. <Ref. to ME(DOHC TURBO)-46, INSTALLATION, Crankshaft Pulley.>
- 6) Install the V-belt. <Ref. to ME(DOHC TURBO)-44, INSTALLATION, V-belt.>


### C: INSPECTION

- 1) Check the sprocket teeth for abnormal wear and scratches.
- 2) Make sure there is no free play between sprocket and key.
- 3) Check the crankshaft sprocket notch used for sensor for damage and contamination of foreign matter.


## 18. Camshaft

### A: REMOVAL


- 1) Remove the V-belt. <Ref. to ME(DOHC TURBO)-44, INSTALLATION, V-belt.>
- 2) Remove the crankshaft pulley. <Ref. to ME(DOHC TURBO)-46, REMOVAL, Crankshaft Pulley.>
- 3) Remove the belt cover. <Ref. to ME(DOHC TURBO)-47, REMOVAL, Belt Cover.>
- 4) Remove the timing belt assembly. <Ref. to ME(DOHC TURBO)-48, REMOVAL, Timing Belt Assembly.>
- 5) Remove the camshaft sprocket. <Ref. to ME(DOHC TURBO)-57, REMOVAL, Camshaft Sprocket.>
- 6) Remove the crankshaft sprocket. <Ref. to ME(DOHC TURBO)-58, REMOVAL, Crankshaft Sprocket.>
- 7) Remove the right-hand belt cover No.2.




- 8) Remove the tensioner bracket.




- 9) Remove the left-hand belt cover No. 2.



- 10) Remove the oil level gauge guide. (LH side only)
- 11) Remove the spark plug cord.
- 12) Remove the rocker cover and gasket.
- 13) Loosen the intake camshaft cap bolts equally, a little at a time in alphabetical sequence shown in the figure.



- 14) Remove the camshaft caps and intake camshaft.
- 15) Loosen the exhaust camshaft cap bolts equally, a little at a time in alphabetical sequence shown in the figure.



- 16) Remove the camshaft caps and exhaust camshaft.

### CAUTION:

**Arrange camshaft caps in order so that they can be installed in their original positions.**

- 17) Similarly, remove the right-hand camshafts and related parts.

# CAMSHAFT

## MECHANICAL


### B: INSTALLATION

#### 1) Camshaft installation:

Apply engine oil to the cylinder head at camshaft bearing location before installing the camshaft. Install the camshaft so that each valve is close to or in contact with "base circle" of cam lobe.

#### CAUTION:

- When the camshafts are positioned as shown in the figure, camshafts need to be rotated at a minimum to align with the timing belt during installation.
- Right-hand camshaft need not be rotated when set at the position shown in the figure.
- Left-hand intake camshaft: Rotate 80° clockwise.
- Left-hand exhaust camshaft: Rotate 45° counterclockwise.



- A Left side cylinder head
- B Right side cylinder head
- (a) Intake camshaft
- (b) Exhaust camshaft

#### 2) Camshaft cap installation:


- (1) Apply fluid packing sparingly to the cap mating surface.

#### CAUTION:

**Do not apply fluid packing excessively. Failure to do so may cause excess packing to come out and flow toward oil seal, resulting in oil leaks.**

#### Fluid packing:

**THREE BOND 1215 or equivalent**




- (2) Apply engine oil to cap bearing surface and install the cap on camshaft as shown by identification mark (A).

- (3) Gradually tighten the cap in at least two stages in alphabetical sequence shown in the figure, and then tighten to specified torque.

#### Tightening torque:

**20 N·m (2.0 kgf·m, 14.5 ft·lb)**



- (4) Similarly, tighten the cap on exhaust side. After tightening the cap, ensure the camshaft rotates only slightly while holding it at "base" circle.

#### Tightening torque:


**20 N·m (2.0 kgf·m, 14.5 ft·lb)**

3) Camshaft oil seal installation:  
Apply grease to the new oil seal lips and press onto the front end of camshaft by using ST1 and ST2.

**CAUTION:**

**Use a new oil seal.**


- ST1 499587600 OIL SEAL INSTALLER
- ST2 499597200 OIL SEAL GUIDE



4) Rocker cover installation:  
(1) Install the gasket on rocker cover. Install the peripheral gasket and ignition coil gasket.  
(2) Apply fluid packing to four front open edges of peripheral gasket.

**Fluid packing:**

**THREE BOND 1215 or equivalent**




(3) Install the rocker cover on cylinder head. Ensure the gasket is properly positioned during installation.  
5) Install the spark plug cord.  
6) Similarly, install the parts on right-hand side.

7) Install the right-hand belt cover No. 2.

**Tightening torque:**


**5 N·m (0.5 kgf·m, 3.6 ft·lb)**



8) Install the tensioner bracket.

**Tightening torque:**


**25 N·m (2.5 kgf·m, 18.1 ft·lb)**



9) Install the left-hand belt cover No. 2.

**Tightening torque:**

**5 N·m (0.5 kgf·m, 3.6 ft·lb)**



10) Install the crankshaft sprocket. <Ref. to ME(DOHC TURBO)-58, INSTALLATION, Crankshaft Sprocket.>

11) Install the camshaft sprockets. <Ref. to ME(DOHC TURBO)-57, INSTALLATION, Camshaft Sprocket.>

12) Install the timing belt assembly. <Ref. to ME(DOHC TURBO)-50, INSTALLATION, Timing Belt Assembly.>

13) Install the belt cover. <Ref. to ME(DOHC TURBO)-47, INSTALLATION, Belt Cover.>

# CAMSHAFT

## MECHANICAL

14) Install the crankshaft pulley. <Ref. to ME(DOHC TURBO)-46, INSTALLATION, Crankshaft Pulley.>


15) Install the V-belt. <Ref. to ME(DOHC TURBO)-44, INSTALLATION, V-belt.>

## C: INSPECTION

1) Measure the bend, and repair or replace if necessary.

**Limit:**

**0.020 mm (0.0008 in)**



2) Check the journal for damage and wear. Replace if faulty.

3) Measure the outside diameter of camshaft journal. If the journal diameter is not as specified, check the oil clearance.


	Camshaft journal	
	Front	Center, rear
Standard	37.946 — 37.9635 mm (1.4939 — 1.4946 in)	29.946 — 29.963 mm (1.1790 — 1.1796 in)

4) Measurement of the camshaft journal oil clearance:

- (1) Clean the bearing caps and camshaft journals.
- (2) Place the camshafts on the cylinder head. (Without installing the valve rocker.)
- (3) Place a plastigauge across each of the camshaft journals.
- (4) Gradually tighten the cap in at least two stages in alphabetical sequence shown in the figure, and then tighten to specified torque.

**Tightening torque:**

**20 N·m (2.0 kgf·m, 14.5 ft·lb)**



**CAUTION:**  
Do not turn the camshaft.


- (5) Remove the bearing caps.  
 (6) Measure the widest point of the plastigauge on each journal.  
 If the oil clearance exceeds the limit, replace the camshaft. If necessary, replace the camshaft caps and cylinder head as a set.

**Standard:**

**0.037 — 0.072 mm (0.0015 — 0.0028 in)**

**Limit:**

**0.10 mm (0.0039 in)**



B2M1216

- (7) Completely remove the plastigauge.  
 5) Check the cam face condition; remove the minor faults by grinding with oil stone. Measure the cam height H; replace if the limit has been exceeded.

**Cam height: H****Standard:****Intake:**

**46.25 — 46.35 mm (1.821 — 1.825 in)**

**Exhaust:**

**46.15 — 46.25 mm (1.817 — 1.821 in)**

**Limit:****Intake:**


**46.15 mm (1.817 in)**

**Exhaust:**

**46.05 mm (1.813 in)**

**Cam base circle diameter A:**

**37.0 mm (1.457 in)**



B2M1209A


- 6) Measure the thrust clearance of camshaft with dial gauge. If the clearance exceeds the limit, replace the caps and cylinder head as a set. If necessary replace the camshaft.

**Standard:**

**0.015 — 0.070 mm (0.0006 — 0.0028 in)**

**Limit:**

**0.1 mm (0.004 in)**



B2M1217


## 19. Cylinder Head Assembly

### A: REMOVAL


- 1) Remove the V-belt. <Ref. to ME(DOHC TURBO)-44, REMOVAL, V-belt.>
- 2) Remove the crankshaft pulley. <Ref. to ME(DOHC TURBO)-46, REMOVAL, Crankshaft Pulley.>
- 3) Remove the belt cover. <Ref. to ME(DOHC TURBO)-47, REMOVAL, Belt Cover.>
- 4) Remove the timing belt assembly. <Ref. to ME(DOHC TURBO)-48, REMOVAL, Timing Belt Assembly.>
- 5) Remove the camshaft sprocket. <Ref. to ME(DOHC TURBO)-57, REMOVAL, Camshaft Sprocket.>
- 6) Remove the intake manifold. <Ref. to FU(DOHC TURBO)-15, REMOVAL, Intake Manifold.>
- 7) Remove the bolt which installs the A/C compressor bracket on cylinder head.
- 8) Remove the camshaft. <Ref. to ME(DOHC TURBO)-59, REMOVAL, Camshaft.>
- 9) Remove the cylinder head bolts in alphabetical sequence shown in the figure.

#### CAUTION:

Leave bolts (A) and (D) engaged by three or four threads to prevent the cylinder head from falling.



- 10) While tapping the cylinder head with a plastic hammer, separate it from cylinder block. Remove the bolts (A) and (D) to remove the cylinder head.



- 11) Remove the cylinder head gasket.

#### CAUTION:

Do not scratch the mating surface of cylinder head and cylinder block.

- 12) Similarly, remove the right side cylinder head.

### B: INSTALLATION


- 1) Install the cylinder head and gaskets on cylinder block.

#### CAUTION:


- Use new cylinder head gaskets.
- Be careful not to scratch the mating surface of cylinder head and cylinder block.

- 2) Tighten the cylinder head bolts.

- (1) Apply a coat of engine oil to washers and bolt threads.
- (2) Tighten all bolts to 29 N·m (3.0 kgf-m, 22 ft-lb) in alphabetical sequence. Then tighten all bolts to 69 N·m (7.0 kgf-m, 51 ft-lb) in alphabetical sequence.
- (3) Back off all bolts by 180° first; back them off by 180° again.
- (4) Tighten the bolts (A) and (B) to 34 N·m (3.5 kgf-m, 25 ft-lb).



(5) Tighten the bolts (C), (D), (E) and (F) to 15 N-m (1.5 kgf-m, 11 ft-lb).



(6) Tighten all bolts by 80 to 90° in alphabetical sequence.

**CAUTION:**

**Do not tighten the bolts more than 90°.**

(7) Further tighten all bolts by 80 to 90° in alphabetical sequence.

**CAUTION:**

**Ensure the total “re-tightening angle” [in the two previous steps] do not exceed 180°.**

3) Install the camshaft. <Ref. to ME(DOHC TURBO)-60, INSTALLATION, Camshaft.>

4) Install the A/C compressor bracket on cylinder head.

5) Install the intake manifold. <Ref. to FU(DOHC TURBO)-18, INSTALLATION, Intake Manifold.>

6) Install the camshaft sprocket. <Ref. to ME(DOHC TURBO)-57, INSTALLATION, Camshaft Sprocket.>

7) Install the timing belt assembly. <Ref. to ME(DOHC TURBO)-50, INSTALLATION, Timing Belt Assembly.>

8) Install the belt cover. <Ref. to ME(DOHC TURBO)-47, INSTALLATION, Belt Cover.>

9) Install the crankshaft pulley. <Ref. to ME(DOHC TURBO)-46, INSTALLATION, Crankshaft Pulley.>

10) Install the V-belt. <Ref. to ME(DOHC TURBO)-44, INSTALLATION, V-belt.>

## C: DISASSEMBLY

1) Remove the valve shims and valve lifters.

2) Compress the valve spring and remove the valve spring retainer key. Remove each valve and valve spring.

ST1 498267600 CYLINDER HEAD TABLE


ST2 499718000 VALVE SPRING REMOVER

**CAUTION:**

- Keep the removed parts in order for re-installation in their original positions.

- Mark each valve to prevent confusion.


- Use extreme care not to damage the lips of the intake valve oil seals and exhaust valve oil seals.



# CYLINDER HEAD ASSEMBLY

MECHANICAL

## D: ASSEMBLY



S2M1197A

- |                           |                  |                             |
|---------------------------|------------------|-----------------------------|
| (1) Exhaust valve         | (6) Valve spring | (11) Exhaust valve oil seal |
| (2) Intake valve          | (7) Retainer     | (12) Intake valve guide     |
| (3) Cylinder head         | (8) Retainer key | (13) Exhaust valve guide    |
| (4) Valve spring seat     | (9) Valve lifter |                             |
| (5) Intake valve oil seal | (10) Shim        |                             |

ME(DOHC TURBO)-66

- 1) Installation of valve spring and valve:
  - (1) Coat the stem of each valve with engine oil and insert the valve into valve guide.

**CAUTION:**


**When inserting the valve into valve guide, use special care not to damage the oil seal lip.**

- (2) Set the cylinder head on ST1.
- (3) Install the valve spring and retainer using ST2.

ST1 498267600 CYLINDER HEAD TABLE  
 ST2 499718000 VALVE SPRING REMOVER

**CAUTION:**

**Be sure to install the valve springs with their close-coiled end facing the seat on the cylinder head.**



- (4) Compress the valve spring and fit the valve spring retainer key.
  - (5) After installing, tap the valve spring retainers lightly with wooden hammer for better seating.
- 2) Apply oil to the surface of the valve lifter and valve shim.
  - 3) Install the valve lifter and valve shim.

## E: INSPECTION

### 1. CYLINDER HEAD

- 1) Make sure that no crack or other damage exists. In addition to visual inspection, inspect the important areas by means of red check.
- 2) Measure the warping of the cylinder head surface that mates with crankcase by using a straight edge (A) and thickness gauge (B). If the warping exceeds 0.05 mm (0.0020 in), re-grind the surface with a surface grinder.

**Warping limit:**

**0.05 mm (0.0020 in)**

**Grinding limit:**


**0.3 mm (0.012 in)**

**Standard height of cylinder head:**

**127.5 mm (5.02 in)**

**CAUTION:**

**Uneven torque for the cylinder head nuts can cause warping. When reassembling, pay special attention to the torque so as to tighten evenly.**



# CYLINDER HEAD ASSEMBLY

MECHANICAL

## 2. VALVE SEAT

Inspect the intake and exhaust valve seats, and correct the contact surfaces with valve seat cutter if they are defective or when valve guides are replaced.

**Valve seat width: *W***

**Intake**

**Standard**

**1.0 mm (0.039 in)**

**Limit**

**1.7 mm (0.067 in)**


**Exhaust**

**Standard**

**1.5 mm (0.059 in)**

**Limit**

**2.2 mm (0.087 in)**



## 3. VALVE GUIDE

1) Check the clearance between valve guide and stem. The clearance can be checked by measuring the outside diameter of valve stem and the inside diameter of valve guide with outside and inside micrometers respectively.

**Clearance between the valve guide and valve stem:**

**Standard**

**Intake**

**0.035 — 0.062 mm (0.0014 — 0.0024 in)**

**Exhaust**

**0.040 — 0.067 mm (0.0016 — 0.0026 in)**

**Limit**

**0.15 mm (0.0059 in)**

2) If the clearance between valve guide and stem exceeds the limit, replace the valve guide or valve itself whichever shows greater amount of wear. See the following procedure for valve guide replacement.

**Valve guide inner diameter:**

**6.000 — 6.012 mm (0.2362 — 0.2367 in)**

**Valve stem outer diameters:**

**Intake**

**5.950 — 5.965 mm (0.2343 — 0.2348 in)**


**Exhaust**

**5.945 — 5.960 mm (0.2341 — 0.2346 in)**

(1) Place the cylinder head on ST1 with the combustion chamber upward so that valve guides enter the holes in ST1.


(2) Insert the ST2 into valve guide and press it down to remove the valve guide.

ST1 498267600 CYLINDER HEAD TABLE  
ST2 499767200 VALVE GUIDE REMOVER



(3) Turn the cylinder head upside down and place ST as shown in the figure.


ST 498767700 VALVE GUIDE ADJUSTER



(4) Before installing a new valve guide, make sure that neither scratches nor damages exist on the inside surface of the valve guide holes in cylinder head.

(5) Put a new valve guide, coated with sufficient oil, in cylinder, and insert ST1 into valve guide. Press in until the valve guide upper end is flush with the upper surface of ST2.

ST1 499767200 VALVE GUIDE REMOVER  
ST2 498267700 VALVE GUIDE ADJUSTER



(6) Check the valve guide protrusion.

**Valve guide protrusion: L**  
**12.0 — 12.4 mm (0.472 — 0.488 in)**

(7) Ream the inside of valve guide with ST. Gently rotate the reamer clockwise while pressing it lightly into the valve guide, and return it also rotating clockwise. After reaming, clean the valve guide to remove chips.

ST 499767400 VALVE GUIDE REAMER

**CAUTION:**

- Apply engine oil to the reamer when reaming.
- If the inner surface of the valve guide is torn, the edge of the reamer should be slightly ground with an oil stone.
- If the inner surface of the valve guide becomes lustrous and the reamer does not chip, use a new reamer or remedy the reamer.

(8) Recheck the contact condition between valve and valve seat after replacing the valve guide.

## 4. INTAKE AND EXHAUST VALVE

1) Inspect the flange and stem of valve, and replace if damaged, worn, or deformed, or if "H" is less than the specified limit.

**H:**

**Intake**

**Standard**  
**1.2 mm (0.047 in)**

**Limit**  
**0.8 mm (0.031 in)**

**Exhaust**

**Standard**  
**1.5 mm (0.059 in)**

**Limit**  
**0.8 mm (0.031 in)**


**Valve overall length:**

**Intake**

**104.4 mm (4.110 in)**

**Exhaust**

**104.7 mm (4.122 in)**



2) Put a small amount of grinding compound on the seat surface and lap the valve and seat surface. Install a new intake valve oil seal after lapping.

# CYLINDER HEAD ASSEMBLY


MECHANICAL

## 5. VALVE SPRINGS

1) Check the valve springs for damage, free length, and tension. Replace the valve spring if it is not within specifications presented in the table.

2) To measure the squareness of the valve spring, stand the spring on a surface plate and measure its deflection at the top using a try square.

	Valve spring
Free length	44.67 mm (1.7587 in)
Tension/spring height	220.7±15.7 N (22.5 ± 1.6 kgf, 49.6±3.5 lb)/36.0 mm (1.417 in)
	510.9±25.5 N (52.1±2.6 kgf, 114.9±5.7 lb)/26.6 mm (1.047 in)
Squareness	2.5°, 2.0 mm (0.079 in)



## 6. INTAKE AND EXHAUST VALVE OIL SEAL

Replace the oil seal with a new one, if the lip is damaged or spring out of place, or when the surfaces of intake valve and valve seat are reconditioned or intake valve guide is replaced.

1) Place the cylinder head on ST1.

2) Press in the oil seal to the specified dimension indicated in the figure by using ST2.

ST1 498267600 CYLINDER HEAD TABLE

ST2 498857100 VALVE GUIDE REMOVER

### CAUTION:

- Apply engine oil to oil seal before force-fitting.
- Differentiate between the intake valve oil seal and exhaust valve oil seal by noting their difference in color.

**Color of rubber part:**


**Intake [Black]**

**Exhaust [Brown]**

**Color of spring part:**

**Intake [Silver]**

**Exhaust [Silver]**




## 7. VALVE LIFTER

- 1) Check the valve lifter visually.
- 2) Measure the outer diameter of valve lifter.

**Outer diameter:**


**34.959 — 34.975 mm (1.3763 — 1.3770 in)**



- 3) Measure the inner diameter of valve lifter mating part on cylinder head.

**Inner diameter:**

**34.994 — 35.016 mm (1.3777 — 1.3786 in)**



**CAUTION:**

If difference between outer diameter of valve lifter and inner diameter of valve lifter mating part is over the limit, replace the cylinder head.

**Standard:**

**0.019 — 0.057 mm (0.0007 — 0.0022 in)**

**Limit:**

**0.100 mm (0.0039 in)**

## 20. Cylinder Block


### A: REMOVAL

**NOTE:**

Before conducting this procedure, drain the engine oil completely if applicable.


- 1) Remove the intake manifold. <Ref. to FU(DOHC TURBO)-15, REMOVAL, Intake Manifold.>
- 2) Remove the V-belt. <Ref. to ME(DOHC TURBO)-44, REMOVAL, V-belt.>
- 3) Remove the crankshaft pulley. <Ref. to ME(DOHC TURBO)-46, REMOVAL, Crankshaft Pulley.>
- 4) Remove the belt cover. <Ref. to ME(DOHC TURBO)-47, REMOVAL, Belt Cover.>
- 5) Remove the timing belt assembly. <Ref. to ME(DOHC TURBO)-48, REMOVAL, Timing Belt Assembly.>
- 6) Remove the camshaft sprocket. <Ref. to ME(DOHC TURBO)-57, REMOVAL, Camshaft Sprocket.>
- 7) Remove the crankshaft sprocket. <Ref. to ME(DOHC TURBO)-58, REMOVAL, Crankshaft Sprocket.>
- 8) Remove the generator and A/C compressor with their brackets.
- 9) Remove the cylinder head assembly. <Ref. to ME(DOHC TURBO)-64, REMOVAL, Cylinder Head Assembly.>
- 10) Remove the clutch disc and cover. (MT vehicles) <Ref. to CL-11, REMOVAL, Clutch Disc and Cover.>
- 11) Remove the flywheel. (MT vehicles) <Ref. to CL-14, REMOVAL, Flywheel.>
- 12) Remove the drive plate. (AT vehicles)  
Using the ST, lock crankshaft.

ST 498497100 CRANKSHAFT STOPPER



- 13) Remove the oil separator cover.
- 14) Remove the water by-pass pipe for heater.
- 15) Remove the oil filter.


- 16) Remove the oil cooler.



- (a) Gasket
- (b) Oil cooler
- (c) Connector

- 17) Removal of oil pan:
  - (1) Turn the cylinder block with #2 and #4 piston sides facing upward.
  - (2) Remove the bolts which secure oil pan to cylinder block.
  - (3) Insert a oil pan cutter blade between cylinder block-to-oil pan clearance and remove the oil pan.

**CAUTION:**  
Do not use a screwdriver or similar tool in place of oil pan cutter.





- 18) Remove the oil strainer stay.
- 19) Remove the oil strainer.
- 20) Remove the baffle plate.
- 21) Remove the water pipes.
- 22) Remove the water pump.

# CYLINDER BLOCK

MECHANICAL

23) Remove the oil pump from cylinder block. Use a flat-bladed screwdriver as shown in the figure when removing the oil pump.

**CAUTION:**  
Be careful not to scratch the mating surface of cylinder block and oil pump.



(1) Service hole plug

(2) Gasket


(3) Circlip

(4) Piston pin


(5) Service hole cover

(6) O-ring

24) Remove the service hole cover and service hole plugs using the hexagon wrench [14 mm (0.55 in)].



25) Rotate the crankshaft to bring #1 and #2 pistons to bottom dead center position, then remove the piston circlip through service hole of #1 and #2 cylinders.



# CYLINDER BLOCK


## MECHANICAL

26) Draw out the piston pin from #1 and #2 pistons using ST.

ST 499097700 PISTON PIN REMOVER

### CAUTION:

Be careful not to confuse the original combination of piston, piston pin and cylinder.



27) Similarly remove the piston pins from #3 and #4 pistons.

28) Remove the bolts which connect cylinder block on the side of #2 and #4 cylinders.


29) Back off the bolts which connect cylinder block on the side of #1 and #3 cylinders two or three turns.

30) Set up the cylinder block so that #1 and #3 cylinders are on the upper side, then remove the cylinder block connecting bolts.

31) Separate the left-hand and right-hand cylinder blocks.

### CAUTION:

When separating the cylinder block, do not allow the connecting rod to fall and damage the cylinder block.



(1) Cylinder block

(3) Crankshaft

(5) Piston

(2) Rear oil seal

(4) Crankshaft bearing

32) Remove the rear oil seal.

33) Remove the crankshaft together with connecting rod.

34) Remove the crankshaft bearings from cylinder block using a hammer handle.

### CAUTION:

Do not confuse the combination of crankshaft bearings.


Press the bearing at the end opposite to locking lip.

35) Draw out each piston from cylinder block using a wooden bar or hammer handle.

### CAUTION:

Do not confuse the combination of piston and cylinder.

## B: INSTALLATION



B2M2407A

- (1) Crankshaft bearing
- (2) Crankshaft
- (3) Cylinder block
- (4) Rear oil seal

**Tightening torque: N·m (kgf-m, ft-lb)**

**T1: 25 (2.5, 18.1)**

**T2: 47 (4.8, 34.7)**

**CAUTION:**

Remove oil in the mating surface of bearing and cylinder block before installation. Also apply a coat of engine oil to crankshaft pins.


- 1) Position the crankshaft on the #2 and #4 cylinder block.
- 2) Apply fluid packing to the mating surface of #1 and #3 cylinder block, and position it on #2 and #4 cylinder block.

**Fluid packing:**

**THREE BOND 1215 or equivalent**

**CAUTION:**

Do not allow fluid packing to jut into O-ring grooves, oil passages, bearing grooves, etc.




S2M1826A

# CYLINDER BLOCK

## MECHANICAL


3) Temporarily tighten the 10 mm cylinder block connecting bolts in alphabetical sequence shown in the figure.



4) Tighten the 10 mm cylinder block connecting bolts in alphabetical sequence.

### Tightening torque:

**47 N·m (4.8 kgf·m, 34.7 ft·lb)**




5) Tighten the 8 mm and 6 mm cylinder block connecting bolts in alphabetical sequence shown in the figure.

### Tightening torque:

**(A) — (G): 25 N·m (2.5 kgf·m, 18.1 ft·lb)**


**(H): 6.4 N·m (0.65 kgf·m, 4.7 ft·lb)**



6) Install the rear oil seal using ST1 and ST2.

ST1 499597100 OIL SEAL GUIDE


ST2 499587200 OIL SEAL INSTALLER



(A) Rear oil seal


(B) Flywheel attaching bolt

7) Position the top ring gap at (A) or (B) in the figure.



8) Position the second ring gap at 180° on the reverse side for the top ring gap.

9) Position the upper rail gap at (C) or (D) in the figure.




10) Position the expander gap at 180° of the reverse side for the upper rail gap.


11) Position the lower rail gap at (E) or (F) in the figure.

**CAUTION:**


- Ensure ring gaps do not face the same direction.
- Ensure ring gaps are not within the piston skirt area.



**CAUTION:**  
Use new circlips.




**CAUTION:**  
Piston front mark faces towards the front of the engine.



(A) Front mark

12) Installing the circlip:  
Install the circlips in piston holes located opposite of the service holes in cylinder block, when positioning all pistons in the corresponding cylinders.



- |                |                       |
|----------------|-----------------------|
| (1) Piston     | (4) Gasket            |
| (2) Piston pin | (5) Service hole plug |
| (3) Circlip    |                       |

**Tightening torque: N·m (kgf·m, ft·lb)**  
T: 69 (7.0, 50.6)

# CYLINDER BLOCK

## MECHANICAL

### 13) Installing the piston:


(1) Turn the cylinder block so that #1 and #2 cylinders face upward.

(2) Using ST1, turn the crankshaft so that #1 and #2 connecting rods are set at bottom dead center.

ST1 499987500 CRANKSHAFT SOCKET

(3) Apply a coat of engine oil to the pistons and cylinders and insert pistons in their cylinders using ST2.

ST2 498744300 PISTON GUIDE




### 14) Installing piston pin:

(1) Insert ST3 into service hole to align piston pin hole with connecting rod small end.

#### **CAUTION:**

**Apply a coat of engine oil to ST3 before insertion.**

ST3 499017100 PISTON PIN GUIDE




(2) Apply a coat of engine oil to the piston pin and insert piston pin into piston and connecting rod through service hole.

(3) Install the circlip.

#### **CAUTION:**


**Use new circlips.**



(4) Apply fluid packing around the service hole plug.

#### **Fluid packing:**


**THREE BOND 1215 or equivalent**




(5) Install the service hole plug and gasket.

#### **CAUTION:**

**Use a new gasket.**





B2M1323K

- (1) Piston
- (2) Piston pin
- (3) Circlip
- (4) Gasket
- (5) Service hole plug
- (6) Service hole cover
- (7) O-ring

**Tightening torque: N-m (kgf-m, ft-lb)**

**T1: 6.4 (0.65, 4.7)**

**T2: 69 (7.0, 50.6)**

(6) Turn the cylinder block so that #3 and #4 cylinders face upward. Using the same procedures as used for #1 and #2 cylinders, install the pistons and piston pins.

- 15) Install the water pipe.
- 16) Install the baffle plate.

**Tightening torque:**

**6.4 N-m (0.65 kgf-m, 4.7 ft-lb)**

- 17) Install the oil strainer and O-ring

**Tightening torque:**


**10 N-m (1.0 kgf-m, 7 ft-lb)**

- 18) Install the oil strainer stay.

- 19) Apply fluid packing to matching surfaces and install the oil pan.

**Fluid packing:**

**THREE BOND 1215 or equivalent**



S2M1833A


# CYLINDER BLOCK

## MECHANICAL

20) Apply fluid packing to matching surfaces and install the oil separator cover.

**Fluid packing:**

**THREE BOND 1215 or equivalent**




21) Install the drive plate. (AT vehicles)

To lock the crankshaft, use ST.

ST 498497100 CRANKSHAFT STOPPER

**Tightening torque:**

**72 N·m (7.3 kgf·m, 52.8 ft·lb)**




22) Install the flywheel. (MT vehicles) <Ref. to CL-14, INSTALLATION, Flywheel.>

23) Install the clutch disc and cover. (MT vehicles) <Ref. to CL-11, INSTALLATION, Clutch Disc and Cover.>

24) Installation of oil pump:

(1) Discard the front oil seal after removal. Replace with a new one using ST.


ST 499587100 OIL SEAL INSTALLER



(2) Apply fluid packing to the matching surface of oil pump.


**Fluid packing:**

**THREE BOND 1215 or equivalent**



(A) O-ring

(3) Apply a coat of engine oil to the inside of the oil seal.



(4) Install the oil pump on cylinder block. Be careful not to damage the oil seal during installation.

**Tightening torque:**

**6.4 N·m (0.65 kgf·m, 4.7 ft·lb)**

**CAUTION:**

- Do not forget to install the O-ring and seal when installing the oil pump.
- Align the flat surface of oil pump's inner rotor with crankshaft before installation.

25) Install the water pump and gasket.


**Tightening torque:**

**First; 12 N·m (1.2 kgf-m, 8.7 ft-lb)**

**Second; 12 N·m (1.2 kgf-m, 8.7 ft-lb)**

**CAUTION:**

- Be sure to use a new gasket.
- When installing the water pump, tighten bolts in two stages in alphabetical sequence as shown in the figure.




26) Install the water by-pass pipe for heater.

27) Install the oil cooler.

**Tightening torque:**


**T1: 55 N·m (5.5 kgf-m, 40 ft-lb)**

**T2: 69 N·m (7.0 kgf-m, 50.6 ft-lb)**



- (A) O-ring
- (B) Oil cooler
- (C) Connector

29) Install the water by-pass pipe between oil cooler and water pump.



30) Install the water pipe.

**NOTE:**

Always use a new O-ring.

31) Install the cylinder head assembly. <Ref. to ME(DOHC TURBO)-64, INSTALLATION, Cylinder Head Assembly.>

32) Install the oil level gauge guide and tighten the attaching bolt (left side only).

33) Install the rocker cover.

34) Install the crankshaft sprocket. <Ref. to ME(DOHC TURBO)-58, INSTALLATION, Crankshaft Sprocket.>

35) Install the camshaft sprocket. <Ref. to ME(DOHC TURBO)-57, INSTALLATION, Camshaft Sprocket.>

36) Install the timing belt assembly. <Ref. to ME(DOHC TURBO)-50, INSTALLATION, Timing Belt Assembly.>

37) Install the belt cover. <Ref. to ME(DOHC TURBO)-47, INSTALLATION, Belt Cover.>

38) Install the crankshaft pulley. <Ref. to ME(DOHC TURBO)-46, INSTALLATION, Crankshaft Pulley.>

39) Install the generator and A/C compressor brackets on cylinder head.

40) Install the V-belt. <Ref. to ME(DOHC TURBO)-44, INSTALLATION, V-belt.>

41) Install the intake manifold. <Ref. to FU(DOHC TURBO)-15, REMOVAL, Intake Manifold.>


28) Install the oil filter using ST.

ST 498547000 OIL FILTER WRENCH

# CYLINDER BLOCK

MECHANICAL

## C: DISASSEMBLY



(1) Connecting rod cap

(2) Connecting rod bearing

(3) Top ring

(4) Second ring

(5) Oil ring

(6) Circlip

1) Remove the connecting rod cap.

2) Remove the connecting rod bearing.

**CAUTION:**

**Arrange the removed connecting rod, connecting rod cap and bearing in order to prevent confusion.**

3) Remove the piston rings using the piston ring expander.


4) Remove the oil ring by hand.

**CAUTION:**

**Arrange the removed piston rings in proper order to prevent confusion.**

5) Remove the circlip.

## D: ASSEMBLY



- |                            |                 |
|----------------------------|-----------------|
| (1) Connecting rod bearing | (5) Second ring |
| (2) Connecting rod         | (6) Top ring    |
| (3) Connecting rod cap     | (7) Circlip     |
| (4) Oil ring               |                 |

**Tightening torque: N·m (kgf·m, ft·lb)**

**T: 44.6 (4.55, 32.9)**

1) Install the connecting rod bearings on connecting rods and connecting rod caps.

**CAUTION:**

**Apply oil to the surfaces of the connecting rod bearings.**

2) Install the connecting rod on crankshaft.

**CAUTION:**

**Position each connecting rod with the side marked facing forward.**

3) Install the connecting rod cap with connecting rod nut.

Ensure the arrow on connecting rod cap faces the front during installation.

**CAUTION:**

- Each the connecting rod has its own mating cap. Make sure that they are assembled correctly by checking their matching number.

- When tightening the connecting rod nuts, apply oil on the threads.

4) Install the oil ring spacer, upper rail and lower rail in this order by hand. Then install the second ring and top ring with a piston ring expander.

## E: INSPECTION

## 1. CYLINDER BLOCK

1) Visually check for cracks and damage. Especially, inspect the important parts by means of red lead check.

2) Check the oil passages for clogging.

3) Inspect the crankcase surface that mates with cylinder head for warping by using a straight edge, and correct by grinding if necessary.

**Warping limit:**

**0.05 mm (0.0020 in)**

**Grinding limit:**

**0.1 mm (0.004 in)**

**Standard height of cylinder block:**

**201.0 mm (7.91 in)**

# CYLINDER BLOCK

## MECHANICAL

### 2. CYLINDER AND PISTON

1) The cylinder bore size is stamped on the cylinder block's front upper surface.

**CAUTION:**

Measurement should be performed at a temperature of 20°C (68°F).


**NOTE:**

Standard sized pistons are classified into two grades, "A" and "B". These grades should be used as a guide line in selecting a standard piston.

**Standard diameter:**

**A: 92.005 — 92.015 mm (3.6222 — 3.6226 in)**

**B: 91.995 — 92.005 mm (3.6218 — 3.6222 in)**



- (A) Main journal size mark
- (B) Cylinder block RH-LH combination mark
- (C) #1 cylinder bore size mark
- (D) #2 cylinder bore size mark
- (E) #3 cylinder bore size mark
- (F) #4 cylinder bore size mark

2) How to measure the inner diameter of each cylinder:

Measure the inner diameter of each cylinder in both the thrust and piston pin directions at the heights shown in the figure, using a cylinder bore gauge.

**CAUTION:**

Measurement should be performed at a temperature of 20°C (68°F).

**Taper:**

**Standard**

0.015 mm (0.0006 in)

**Limit**

0.050 mm (0.0020 in)


**Out-of-roundness:**

**Standard**

0.010 mm (0.0004 in)

**Limit**

0.050 mm (0.0020 in)



- (A) Piston pin direction
- (B) Thrust direction

3) When the piston is to be replaced due to general or cylinder wear, determine a suitable sized piston by measuring the piston clearance.

4) How to measure the outer diameter of each piston:

Measure the outer diameter of each piston at the height shown in the figure. (Thrust direction)

**CAUTION:**

Measurement should be performed at a temperature of 20°C (68°F).

**Piston grade point H:**

37.0 mm (1.457 in)

**Piston outer diameter:**

**Standard**

**A: 91.985 — 91.995 mm**

(3.6214 — 3.6218 in)

**B: 91.975 — 91.985 mm**

(3.6211 — 3.6214 in)

**0.25 mm (0.0098 in) oversize**


92.225 — 92.235 mm

(3.6309 — 3.6313 in)

**0.50 mm (0.0197 in) oversize**

92.475 — 92.485 mm

(3.6407 — 3.6411 in)



5) Calculate the clearance between cylinder and piston.

**CAUTION:**

Measurement should be performed at a temperature of 20°C (68°F).

**Cylinder to piston clearance at 20°C (68°F):**

**Standard**

0.010 — 0.030 mm (0.0004 — 0.0012 in)

**Limit**

0.050 mm (0.0020 in)

6) Boring and honing:

(1) If the value of taper, out-of-roundness, or cylinder-to-piston clearance measured exceeds the specified limit or if there is any damage on the cylinder wall, rebore it to use an oversize piston.

**CAUTION:**

When any of the cylinders needs reboring, all other cylinders must be bored at the same time, and use oversize pistons. Do not perform boring on one cylinder only, nor use an oversize piston for one cylinder only.

(2) If the cylinder inner diameter exceeds the limit after boring and honing, replace the crankcase.

**CAUTION:**

Immediately after reboring, the cylinder diameter may differ from its real diameter due to temperature rise. Thus, pay attention to this when measuring the cylinder diameter.

**Limit of cylinder enlarging (boring):**

0.5 mm (0.020 in)

# CYLINDER BLOCK

## MECHANICAL

### 3. PISTON AND PISTON PIN

1) Check the pistons and piston pins for damage, cracks, and wear and the piston ring grooves for wear and damage. Replace if defective.

2) Measure the piston-to-cylinder clearance at each cylinder. <Ref. to ME(DOHC TURBO)-84, CYLINDER AND PISTON, INSPECTION, Cylinder Block.> If any of the clearances is not within specification, replace the piston or bore the cylinder to use an oversize piston.

3) Make sure that the piston pin can be inserted into the piston pin hole with a thumb at 20°C (68°F). Replace if defective.



**Standard clearance between piston pin and hole in piston:**

**Standard**


**0.004 — 0.008 mm (0.0002 — 0.0003 in)**

**Limit**

**0.020 mm (0.0008 in)**



4) Check the circlip installation groove on the piston for burr (A). If necessary, remove burr from the groove so that the piston pin can lightly move.




5) Check the piston pin circlip for distortion, cracks and wear.

### 4. PISTON RING


1) If the piston ring is broken, damaged, or worn, or if its tension is insufficient, or when the piston is replaced, replace the piston ring with a new one of the same size as the piston.

**CAUTION:**

• "N" is marked on the end of the top and second rings. When installing the rings to the piston, face this mark upward.




• The oil ring is a combined ring consisting of two rails and a spacer in between. When installing, be careful to assemble correctly.



- (A) Top ring
- (B) Second ring
- (C) Oil ring
- (a) Upper rail
- (b) Spacer
- (c) Lower rail

2) Squarely place the piston ring and oil ring in cylinder, and measure the piston ring gap with a thickness gauge.

		Unit: mm (in)	
		Standard	Limit
Piston ring gap	Top ring	0.20 — 0.35 (0.0079 — 0.0138)	1.0 (0.039)
	Second ring	0.35 — 0.50 (0.0138 — 0.0197)	1.0 (0.039)
	Oil ring rail	0.20 — 0.70 (0.0079 — 0.0276)	1.5 (0.059)




3) Measure the clearance between piston ring and piston ring groove with a thickness gauge.

**CAUTION:**

Before measuring the clearance, clean the piston ring groove and piston ring.

		Unit: mm (in)	
		Standard	Limit
Clearance between piston ring and piston ring groove	Top ring	0.040 — 0.080 (0.0016 — 0.0031)	0.15 (0.0059)
	Second ring	0.030 — 0.070 (0.0012 — 0.0028)	0.15 (0.0059)




# CYLINDER BLOCK

## MECHANICAL

### 5. CONNECTING ROD

- 1) Replace the connecting rod, if the large or small end thrust surface is damaged.
- 2) Check for bend or twist using a connecting rod aligner. Replace the connecting rod if the bend or twist exceeds the limit.

**Limit of bend or twist per 100 mm (3.94 in) in length:**  
**0.10 mm (0.0039 in)**



(A) Thickness gauge  
 (B) Connecting rod

- 3) Install the connecting rod fitted with bearing to crankshaft and measure the side clearance (thrust clearance). Replace the connecting rod if the side clearance exceeds the specified limit.


**Connecting rod side clearance:**

**Standard**

**0.070 — 0.330 mm (0.0028 — 0.0130 in)**

**Limit**

**0.4 mm (0.016 in)**



- 4) Inspect the connecting rod bearing for scar, peeling, seizure, melting, wear, etc.
- 5) Measure the oil clearance on individual connecting rod bearings by means of plastigauge. If any oil clearance is not within specification, replace the defective bearing with a new one of standard size or undersize as necessary. (See the table below.)

**Connecting rod oil clearance:**

**Standard**

**0.020 — 0.046 mm (0.0008 — 0.0018 in)**

**Limit**

**0.05 mm (0.0020 in)**

Unit: mm (in)		
Bearing	Bearing size (Thickness at center)	Outer diameter of crank pin
Standard	1.492 — 1.501 (0.0587 — 0.0591)	47.984 — 48.000 (1.8891 — 1.8898)
0.03 (0.0012) undersize	1.510 — 1.513 (0.0594 — 0.0596)	47.954 — 47.970 (1.8879 — 1.8886)
0.05 (0.0020) undersize	1.520 — 1.523 (0.0598 — 0.0600)	47.934 — 47.950 (1.8872 — 1.8878)
0.25 (0.0098) undersize	1.620 — 1.623 (0.0638 — 0.0639)	47.734 — 47.750 (1.8793 — 1.8799)

6) Inspect the bushing at connecting rod small end, and replace if worn or damaged. Also measure the piston pin clearance at the connecting rod small end.



**Clearance between piston pin and bushing:**

**Standard**

0 — 0.022 mm (0 — 0.0009 in)


**Limit**

0.030 mm (0.0012 in)



- 7) Replacement procedure is as follows:
- (1) Remove the bushing from connecting rod with ST and press.
  - (2) Press the bushing with ST after applying oil on the periphery of bushing.

ST 499037100 CONNECTING ROD BUSHING REMOVER AND INSTALLER



- (3) Make two 3 mm (0.12 in) holes in bushing. Ream the inside of bushing.
- (4) After completion of reaming, clean the bushing to remove chips.

## 6. CRANKSHAFT AND CRANKSHAFT BEARING


- 1) Clean the crankshaft completely and check for cracks by means of red lead check etc., and replace if defective.
- 2) Measure the crankshaft bend, and correct or replace if it exceeds the limit.

**CAUTION:**

If a suitable V-block is not available, install #1 and #5 crankshaft bearing on cylinder block, position crankshaft on these bearings and measure the crankshaft bend using a dial gauge.

**Crankshaft bend limit:**

0.035 mm (0.0014 in)



3) Inspect the crank journal and crank pin for wear. If they are not within the specifications, replace the bearing with a suitable (undersize) one, and replace or recondition crankshaft as necessary. When grinding the crank journal or crank pin, finish them to the specified dimensions according to the undersize bearing to be used.

**Crank pin and crank journal:**

**Out-of-roundness**


0.020 mm (0.0008 in) or less

**Taper limit**

0.07 mm (0.0028 in)

**Grinding limit**

0.250 mm (0.0098 in)



# CYLINDER BLOCK

MECHANICAL

		Crank journal diameter		Crank pin diameter
		#1, #3, #5	#2, #4	
Standard	Journal O.D.	59.992 — 60.008 (2.3619 — 2.3625)	59.992 — 60.008 (2.3619 — 2.3625)	47.984 — 48.000 (1.8891 — 1.8898)
	Bearing size (Thickness at center)	1.998 — 2.011 (0.0787 — 0.0792)	2.000 — 2.013 (0.0787 — 0.0793)	1.492 — 1.510 (0.0587 — 0.0591)
0.03 (0.0012) undersize	Journal O.D.	59.962 — 59.978 (2.3607 — 2.3613)	59.962 — 59.978 (2.3607 — 2.3613)	47.954 — 47.970 (1.8879 — 1.8886)
	Bearing size (Thickness at center)	2.017 — 2.020 (0.0794 — 0.0795)	2.019 — 2.022 (0.0795 — 0.0796)	1.510 — 1.513 (0.0594 — 0.0596)
0.05 (0.0020) undersize	Journal O.D.	59.942 — 59.958 (2.3599 — 2.3605)	59.942 — 59.958 (2.3599 — 2.3605)	47.934 — 47.950 (1.8872 — 1.8878)
	Bearing size (Thickness at center)	2.027 — 2.030 (0.0798 — 0.0799)	2.029 — 2.032 (0.0799 — 0.0800)	1.520 — 1.523 (0.0598 — 0.0600)
0.25 (0.0098) undersize	Journal O.D.	59.742 — 59.758 (2.3520 — 2.3527)	59.742 — 59.758 (2.3520 — 2.3527)	47.734 — 47.750 (1.8793 — 1.8799)
	Bearing size (Thickness at center)	2.127 — 2.130 (0.0837 — 0.0839)	2.129 — 2.132 (0.0838 — 0.0839)	1.620 — 1.623 (0.0638 — 0.0639)

O.D.: Outer Diameter

4) Measure the thrust clearance of crankshaft at center bearing. If the clearance exceeds the limit, replace the bearing.


**Crankshaft thrust clearance:**

**Standard**

0.030 — 0.115 mm (0.0012 — 0.0045 in)

**Limit**

0.25 mm (0.0098 in)



5) Inspect individual crankshaft bearings for signs of flaking, seizure, melting, and wear.

6) Measure the oil clearance on each crankshaft bearing by means of plastigauge. If the measurement is not within the specification, replace the defective bearing with an undersize one, and replace or recondition the crankshaft as necessary.

Crankshaft oil clearance		Unit: mm (in)
Standard	0.010 — 0.030 (0.0004 — 0.0012)	
Limit	0.040 (0.0016)	

## 21.Engine Trouble in General

### A: INSPECTION

NOTE:  
 "RANK" shown in the chart refers to the possibility of reason for the trouble in order ("Very often" to "Rarely")

A — Very often  
 B — Sometimes  
 C — Rarely

TROUBLE	PROBLEM PARTS, ETC.	POSSIBLE CAUSE	RANK
1. Engine will not start.			
1) Starter does not turn.	• Starter	• Defective battery-to-starter harness	B
		• Defective starter switch	C
		• Defective inhibitor switch or neutral switch	C
		• Defective starter	B
	• Battery	• Poor terminal connection	A
		• Run-down battery	A
		• Defective charging system	B
	• Friction	• Seizure of crankshaft and connecting rod bearing	C
		• Seized camshaft	C
• Seized or stuck piston and cylinder		C	
2) Initial combustion does not occur.	• Starter	• Defective starter	C
	• Engine control system <Ref. to EN(DOHC TURBO)-2, Basic Diagnostic Procedure.>		A
	• Fuel line	• Defective fuel pump and relay	A
		• Lack of or insufficient fuel	B
	• Belt	• Defective	B
		• Defective timing	B
	• Compression	• Incorrect valve clearance	C
		• Loosened spark plugs or defective gasket	C
		• Loosened cylinder head bolts or defective gasket	C
		• Improper valve seating	C
		• Defective valve stem	C
		• Worn or broken valve spring	B
		• Worn or stuck piston rings, cylinder and piston	C
		• Incorrect valve timing	B
• Improper engine oil (low viscosity)	B		
3) Initial combustion occur.	• Engine control system <Ref. to EN(DOHC TURBO)-2, Basic Diagnostic Procedure.>		A
	• Intake system	• Defective intake manifold gasket	B
		• Defective throttle body gasket	B
	• Fuel line	• Defective fuel pump and relay	C
		• Clogged fuel line	C
		• Lack of or insufficient fuel	B
	• Belt	• Defective	B
		• Defective timing	B
	• Compression	• Incorrect valve clearance	C
		• Loosened spark plugs or defective gasket	C
		• Loosened cylinder head bolts or defective gasket	C
		• Improper valve seating	C
		• Defective valve stem	C
		• Worn or broken valve spring	B
		• Worn or stuck piston rings, cylinder and piston	C
		• Incorrect valve timing	B
	• Improper engine oil (low viscosity)	B	

# ENGINE TROUBLE IN GENERAL

MECHANICAL

TROUBLE	PROBLEM PARTS, ETC.	POSSIBLE CAUSE	RANK
4) Engine stalls after initial combustion.	• Engine control system <Ref. to EN(DOHC TURBO)-2, Basic Diagnostic Procedure.>		A
	• Intake system	• Loosened or cracked intake duct	B
		• Loosened or cracked PCV hose	C
		• Loosened or cracked vacuum hose	C
		• Defective intake manifold gasket	B
		• Defective throttle body gasket	B
		• Dirty air cleaner element	C
	• Fuel line	• Clogged fuel line	C
		• Lack of or insufficient fuel	B
	• Belt	• Defective	B
		• Defective timing	B
	• Compression	• Incorrect valve clearance	C
		• Loosened spark plugs or defective gasket	C
		• Loosened cylinder head bolts or defective gasket	C
		• Improper valve seating	C
		• Defective valve stem	C
		• Worn or broken valve spring	B
• Worn or stuck piston rings, cylinder and piston		C	
• Incorrect valve timing		B	
• Improper engine oil (low viscosity)		B	
2. Rough idle and engine stall	• Engine control system <Ref. to EN(DOHC TURBO)-2, Basic Diagnostic Procedure.>		A
	• Intake system	• Loosened or cracked intake duct	A
		• Loosened or cracked PCV hose	A
		• Loosened or cracked vacuum hose	A
		• Defective intake manifold gasket	B
		• Defective throttle body gasket	B
		• Defective PCV valve	C
		• Loosened oil filler cap	B
		• Dirty air cleaner element	C
	• Fuel line	• Defective fuel pump and relay	C
		• Clogged fuel line	C
		• Lack of or insufficient fuel	B
	• Belt	• Defective timing	C
	• Compression	• Incorrect valve clearance	B
		• Loosened spark plugs or defective gasket	B
		• Loosened cylinder head bolts or defective gasket	B
		• Improper valve seating	B
		• Defective valve stem	C
		• Worn or broken valve spring	B
		• Worn or stuck piston rings, cylinder and piston	B
		• Incorrect valve timing	A
		• Improper engine oil (low viscosity)	B
	• Lubrication system	• Incorrect oil pressure	B
		• Defective rocker cover gasket	C
	• Cooling system	• Overheating	C
	• Others	• Malfunction of evaporative emission control system	A
		• Stuck or damaged throttle valve	B
		• Accelerator cable out of adjustment	C

# ENGINE TROUBLE IN GENERAL

MECHANICAL

TROUBLE	PROBLEM PARTS, ETC.	POSSIBLE CAUSE	RANK
3. Low output, hesitation and poor acceleration	• Engine control system <Ref. to EN(DOHC TURBO)-2, Basic Diagnostic Procedure.>		A
	• Intake system	• Loosened or cracked intake duct	A
		• Loosened or cracked PCV hose	A
		• Loosened or cracked vacuum hose	B
		• Defective intake manifold gasket	B
		• Defective throttle body gasket	B
		• Defective PCV valve	B
		• Loosened oil filler cap	B
		• Dirty air cleaner element	A
	• Fuel line	• Defective fuel pump and relay	B
		• Clogged fuel line	B
		• Lack of or insufficient fuel	C
	• Belt	• Defective timing	B
	• Compression	• Incorrect valve clearance	B
		• Loosened spark plugs or defective gasket	B
		• Loosened cylinder head bolts or defective gasket	B
		• Improper valve seating	B
		• Defective valve stem	C
		• Worn or broken valve spring	B
		• Worn or stuck piston rings, cylinder and piston	C
		• Incorrect valve timing	A
	• Improper engine oil (low viscosity)	B	
• Lubrication system	• Incorrect oil pressure	B	
• Cooling system	• Overheating	C	
	• Over cooling	C	
• Others	• Malfunction of evaporative emission control system	A	
4. Surging	• Engine control system <Ref. to EN(DOHC TURBO)-2, Basic Diagnostic Procedure.>		A
	• Intake system	• Loosened or cracked intake duct	A
		• Loosened or cracked PCV hose	A
		• Loosened or cracked vacuum hose	A
		• Defective intake manifold gasket	B
		• Defective throttle body gasket	B
		• Defective PCV valve	B
		• Loosened oil filler cap	B
		• Dirty air cleaner element	B
	• Fuel line	• Defective fuel pump and relay	B
		• Clogged fuel line	B
		• Lack of or insufficient fuel	C
	• Belt	• Defective timing	B
	• Compression	• Incorrect valve clearance	B
		• Loosened spark plugs or defective gasket	C
		• Loosened cylinder head bolts or defective gasket	C
		• Improper valve seating	C
		• Defective valve stem	C
		• Worn or broken valve spring	C
		• Worn or stuck piston rings, cylinder and piston	C
		• Incorrect valve timing	A
	• Improper engine oil (low viscosity)	B	
• Cooling system	• Overheating	B	
• Others	• Malfunction of evaporative emission control system	C	

# ENGINE TROUBLE IN GENERAL

## MECHANICAL

TROUBLE	PROBLEM PARTS, ETC.	POSSIBLE CAUSE	RANK
5. Engine does not return to idle.	• Engine control system <Ref. to EN(DOHC TURBO)-2, Basic Diagnostic Procedure.>		A
	• Intake system	• Loosened or cracked vacuum hose	A
	• Others	• Stuck or damaged throttle valve	A
		• Accelerator cable out of adjustment	B
6. Dieseling (Run-on)	• Engine control system <Ref. to EN(DOHC TURBO)-2, Basic Diagnostic Procedure.>		A
	• Cooling system	• Overheating	B
	• Others	• Malfunction of evaporative emission control system	B
7. After burning in exhaust system	• Engine control system <Ref. to EN(DOHC TURBO)-2, Basic Diagnostic Procedure.>		A
	• Intake system	• Loosened or cracked intake duct	C
		• Loosened or cracked PCV hose	C
		• Loosened or cracked vacuum hose	B
		• Defective PCV valve	B
		• Loosened oil filler cap	C
	• Belt	• Defective timing	B
	• Compression	• Incorrect valve clearance	B
		• Loosened spark plugs or defective gasket	C
		• Loosened cylinder head bolts or defective gasket	C
		• Improper valve seating	B
		• Defective valve stem	C
		• Worn or broken valve spring	C
		• Worn or stuck piston rings, cylinder and piston	C
	• Incorrect valve timing	A	
• Lubrication system	• Incorrect oil pressure	C	
• Cooling system	• Over cooling	C	
• Others	• Malfunction of evaporative emission control system	C	
8. Knocking	• Engine control system <Ref. to EN(DOHC TURBO)-2, Basic Diagnostic Procedure.>		A
	• Intake system	• Loosened oil filler cap	B
	• Belt	• Defective timing	B
	• Compression	• Incorrect valve clearance	C
		• Incorrect valve timing	B
	• Cooling system	• Overheating	A
9. Excessive engine oil consumption	• Intake system	• Loosened or cracked PCV hose	A
		• Defective PCV valve	B
		• Loosened oil filler cap	C
	• Compression	• Defective valve stem	A
		• Worn or stuck piston rings, cylinder and piston	A
	• Lubrication system	• Loosened oil pump attaching bolts and defective gasket	B
		• Defective oil filter o-ring	B
		• Defective crankshaft oil seal	B
		• Defective rocker cover gasket	B
		• Loosened oil drain plug or defective gasket	B
	• Loosened oil pan fitting bolts or defective oil pan	B	

# ENGINE TROUBLE IN GENERAL

MECHANICAL

TROUBLE	PROBLEM PARTS, ETC.	POSSIBLE CAUSE	RANK	
10. Excessive fuel consumption	• Engine control system <Ref. to EN(DOHC TURBO)-2, Basic Diagnostic Procedure.>		A	
	• Intake system	• Dirty air cleaner element	A	
	• Belt	• Defective timing	B	
	• Compression	• Incorrect valve clearance		B
		• Loosened spark plugs or defective gasket		C
		• Loosened cylinder head bolts or defective gasket		C
		• Improper valve seating		B
		• Defective valve stem		C
		• Worn or broken valve spring		C
		• Worn or stuck piston rings, cylinder and piston		B
		• Incorrect valve timing		B
	• Lubrication system	• Incorrect oil pressure		C
	• Cooling system	• Over cooling		C
• Others	• Accelerator cable out of adjustment		B	

# ENGINE NOISE

MECHANICAL

## 22.Engine Noise

### A: INSPECTION

Type of sound	Condition	Possible cause
Regular clicking sound	Sound increases as engine speed increases.	<ul style="list-style-type: none"> <li>• Valve mechanism is defective.</li> <li>• Incorrect valve clearance</li> <li>• Worn valve rocker</li> <li>• Worn camshaft</li> <li>• Broken valve spring</li> </ul>
Heavy and dull clank	Oil pressure is low.	<ul style="list-style-type: none"> <li>• Worn crankshaft main bearing</li> <li>• Worn connecting rod bearing (big end)</li> </ul>
	Oil pressure is normal.	<ul style="list-style-type: none"> <li>• Loose flywheel mounting bolts</li> <li>• Damaged engine mounting</li> </ul>
High-pitched clank (Spark knock)	Sound is noticeable when accelerating with an overload.	<ul style="list-style-type: none"> <li>• Ignition timing advanced</li> <li>• Accumulation of carbon inside combustion chamber</li> <li>• Wrong spark plug</li> <li>• Improper gasoline</li> </ul>
Clank when engine speed is medium (1,000 to 2,000 rpm).	Sound is reduced when fuel injector connector of noisy cylinder is disconnected. (NOTE*)	<ul style="list-style-type: none"> <li>• Worn crankshaft main bearing</li> <li>• Worn bearing at crankshaft end of connecting rod</li> </ul>
Knocking sound when engine is operating under idling speed and engine is warm	Sound is reduced when fuel injector connector of noisy cylinder is disconnected. (NOTE*)	<ul style="list-style-type: none"> <li>• Worn cylinder liner and piston ring</li> <li>• Broken or stuck piston ring</li> <li>• Worn piston pin and hole at piston end of connecting rod</li> </ul>
	Sound is not reduced if each fuel injector connector is disconnected in turn. (NOTE*)	<ul style="list-style-type: none"> <li>• Unusually worn valve lifter</li> <li>• Worn cam gear</li> <li>• Worn camshaft journal bore in crankcase</li> </ul>
Squeaky sound	—	<ul style="list-style-type: none"> <li>• Insufficient generator lubrication</li> </ul>
Rubbing sound	—	<ul style="list-style-type: none"> <li>• Defective generator brush and rotor contact</li> </ul>
Gear scream when starting engine	—	<ul style="list-style-type: none"> <li>• Defective ignition starter switch</li> <li>• Worn gear and starter pinion</li> </ul>
Sound like polishing glass with a dry cloth	—	<ul style="list-style-type: none"> <li>• Loose drive belt</li> <li>• Defective water pump shaft</li> </ul>
Hissing sound	—	<ul style="list-style-type: none"> <li>• Loss of compression</li> <li>• Air leakage in air intake system, hoses, connections or manifolds</li> </ul>
Timing belt noise	—	<ul style="list-style-type: none"> <li>• Loose timing belt</li> <li>• Belt contacting case/adjacent part</li> </ul>
Valve tappet noise	—	<ul style="list-style-type: none"> <li>• Incorrect valve clearance</li> </ul>

**NOTE\*:**

When disconnecting the fuel injector connector, Malfunction Indicator Light (CHECK ENGINE light) illuminates and trouble code is stored in ECM memory.

Therefore, carry out the CLEAR MEMORY MODE <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and INSPECTION MODE <Ref. to EN(DOHC TURBO)-46, OPERATION, Inspection Mode.> after connecting the fuel injector connector.

# EXHAUST

# *EX(DOHC TURBO)*

---

	<b>Page</b>
1. General Description .....	2
2. Front Exhaust Pipe.....	6
3. Center Exhaust Pipe .....	8
4. Joint Pipe .....	12
5. Rear Exhaust Pipe .....	13
6. Muffler .....	14


# GENERAL DESCRIPTION

## EXHAUST

### 1. General Description

#### A: COMPONENT

#### 1. FRONT EXHAUST PIPE



EN1183

# GENERAL DESCRIPTION

EXHAUST

---

(1) Gasket	(11) Front exhaust pipe lower insulator (RH)	(21) Turbocharger joint pipe
(2) Upper exhaust manifold cover (RH)	(12) Front exhaust pipe lower insulator (LH)	(22) Gasket
(3) Exhaust manifold (RH)	(13) Front exhaust pipe lower cover	(23) Front oxygen (A/F) sensor
(4) Lower exhaust manifold cover (RH)	(14) Front exhaust pipe lower clamp	(24) Precatalytic converter
(5) Front exhaust pipe upper clamp	(15) Gasket	(25) Exhaust temperature sensor
(6) Front exhaust pipe upper cover	(16) Gasket	
(7) Front exhaust pipe upper insulator (RH)	(17) Upper exhaust manifold cover (LH)	
(8) Front exhaust pipe upper insulator (LH)	(18) Exhaust manifold (LH)	
(9) Gasket	(19) Lower exhaust manifold cover (LH)	
(10) Front exhaust pipe	(20) Gasket	

---

**Tightening torque: N·m (kgf-m, ft-lb)**

**T1: 19 (1.9, 13.7)**

**T2: 25 (2.5, 18.1)**

**T3: 35 (3.6, 26.0)**


**T4: 40 (4, 28.9)**

---

# GENERAL DESCRIPTION

## EXHAUST

### 2. CENTER AND REAR EXHAUST PIPE, AND MUFFLER



EN1113

(1) Gasket	(14) Rear catalytic converter	(25) Upper rear exhaust pipe cover (Rear)
(2) Front catalytic converter	(15) Upper clamp	(26) Gasket
(3) Upper center pipe cover (Front)	(16) Gasket	(27) Muffler
(4) Center exhaust pipe (Front)	(17) Rear exhaust pipe	(28) Cushion
(5) Lower center pipe cover (Front)	(18) Lower rear exhaust pipe cover (Front)	(29) Muffler cutter
(6) Bracket	(19) Chamber	(30) Center exhaust pipe (Rear)
(7) Gasket	(20) Lower rear exhaust pipe cover (Rear)	
(8) Upper center pipe cover (Rear)	(21) Cushion	
(9) Lower center pipe cover (Rear)	(22) Spring	
(10) Upper rear catalytic converter cover	(23) Bolt	
(11) Lower clamp	(24) Upper rear exhaust pipe cover (Front)	
(12) Lower rear catalytic converter cover		
(13) Rear oxygen sensor		

#### Tightening torque: N·m (kgf·m, ft·lb)

**T1: 13 (1.3, 9.6)**

**T2: 18 (1.8, 13.0)**

**T3: 30 (3.1, 22.4)**

**T4: 35 (3.6, 26.0)**

**T5: 48 (4.9, 35.4)**

**EX(DOHC TURBO)-4**

## **B: CAUTION**

- Wear working clothing, including a cap, protective goggles, and protective shoes during operation.
- Remove contamination including dirt and corrosion before removal, installation or disassembly.
- Keep the disassembled parts in order and protect them from dust or dirt.
- Before removal, installation or disassembly, be sure to clarify the failure. Avoid unnecessary removal, installation, disassembly, and replacement.
- Be careful not to burn your hands, because each part on the vehicle is hot after running.
- Be sure to tighten fasteners including bolts and nuts to the specified torque.
- Place shop jacks or safety stands at the specified points.
- Before disconnecting electrical connectors of sensors or units, be sure to disconnect the negative terminal from battery.


# FRONT EXHAUST PIPE

## EXHAUST


### 2. Front Exhaust Pipe

#### A: REMOVAL


- 1) Disconnect the ground terminal from battery.



- 2) Remove the front oxygen (A/F) sensor. <Ref. to FU(DOHC TURBO)-42, REMOVAL, Front Oxygen (A/F) Sensor.>
- 3) Remove the under cover.
- 4) Remove the lower exhaust manifold cover (RH).
- 5) Remove the lower and upper exhaust manifold covers (LH).




- 6) Remove the bolts and nuts which hold the front exhaust pipe assembly to turbocharger joint pipe.
- 7) While holding the front exhaust pipe assembly with one hand, remove the nuts which hold the front exhaust pipe assembly to cylinder head exhaust port.



- 8) Remove the front exhaust pipe assembly.
- 9) Remove the covers from exhaust manifold and front exhaust pipe.

- 10) Separate the front exhaust pipe from exhaust manifolds.



#### B: INSTALLATION


##### CAUTION:

**Replace the gaskets with new ones.**

- 1) Assemble the front exhaust pipe and exhaust manifolds.

##### **Tightening torque:**

**35 N·m (3.6 kgf·m, 26.0 ft-lb)**



- 2) Install the front exhaust pipe covers.

##### **Tightening torque:**

**25 N·m (2.5 kgf·m, 18.1 ft-lb)**

- 3) Install the upper exhaust manifold cover (RH).

##### **Tightening torque:**

**19 N·m (1.9 kgf·m, 13.7 ft-lb)**

- 4) Install the front exhaust pipe assembly.


##### **Tightening torque:**

**35 N·m (3.6 kgf·m, 26.0 ft-lb)**

5) Connect the exhaust manifold (RH) to turbo-charger joint pipe.

**Tightening torque:**

**35 N·m (3.6 kgf-m, 26.0 ft-lb)**



6) Install the upper and lower exhaust manifold covers (LH).


**Tightening torque:**

**19 N·m (1.9 kgf-m, 13.7 ft-lb)**

7) Install the lower exhaust manifold cover (RH).

**Tightening torque:**


**19 N·m (1.9 kgf-m, 13.7 ft-lb)**



8) Install the front oxygen (A/F) sensor. <Ref. to FU(DOHC TURBO)-43, INSTALLATION, Front Oxygen (A/F) Sensor.>

9) Install the under cover.

10) Connect the battery ground terminal to battery.




# CENTER EXHAUST PIPE

## EXHAUST

### 3. Center Exhaust Pipe

#### A: REMOVAL


- 1) Set the vehicle on the lift.
- 2) Disconnect the ground terminal from battery.
- 3) Remove the intercooler. <Ref. to IN(DOHC TURBO)-10, REMOVAL, Intercooler.>
- 4) Remove the intercooler bracket.




- 5) Lift-up the vehicle.
- 6) Remove the under cover.
- 7) Remove the bolts which install the lower side of turbocharger upper cover.

#### CAUTION:


Be careful, the turbocharger and exhaust pipe are hot.




- 8) Lower the vehicle.
- 9) Remove the turbocharger upper cover.




- 10) Remove the bolts which install the lower upper side of turbocharger upper cover, and remove it.




- 11) Separate the center exhaust pipe from turbocharger.




- 12) Lift-up the vehicle.
- 13) Disconnect the connector from rear oxygen sensor.




- 14) Vertically draw out clip from crossmember.



15) Separate the center exhaust pipe from rear exhaust pipe.




16) Remove the bolt which holds center exhaust pipe bracket to transmission.




17) Remove the intercooler bracket.

18) Remove the bolt which holds center exhaust pipe to hanger bracket.

**CAUTION:**  
Be careful not to pull down the center exhaust pipe.



19) Remove the center exhaust pipe.



## B: INSTALLATION


**CAUTION:**

Replace the gaskets with new ones.

- 1) Install the center exhaust pipe and temporarily tighten the bolt which holds center exhaust pipe to hanger bracket.
- 2) Temporarily tighten the bolt which holds the center pipe to transmission.
- 3) Connect the center exhaust pipe to turbocharger.

**Tightening torque:**


**35 N·m (3.6 kgf-m, 26.0 ft-lb)**




4) Install the center exhaust pipe to rear exhaust pipe.

**Tightening torque:**

**18 N·m (1.8 kgf-m, 13.0 ft-lb)**




5) Connect the connector to rear oxygen sensor.



# CENTER EXHAUST PIPE

## EXHAUST


6) Secure clip on the crossmember.



7) Tighten the bolt which holds the center exhaust pipe bracket to transmission.

**Tightening torque:**


**30 N·m (3.1 kgf-m, 22.4 ft-lb)**



8) Tighten the bolt which holds the center exhaust pipe to hanger bracket.

**Tightening torque:**

**35 N·m (3.6 kgf-m, 26.0 ft-lb)**



9) Tighten the bolts which hold the intercooler bracket.

**Tightening torque:**

**35 N·m (3.6 kgf-m, 26.0 ft-lb)**

10) Lower the vehicle.

11) Place the turbocharger lower cover, and tighten the bolts which install the upper side of lower cover.

**Tightening torque:**


**7.4 N·m (0.75 kgf-m, 5.4 ft-lb)**



12) Place the turbocharger upper cover, and tighten the bolts which install the upper side of upper cover.

**Tightening torque:**

**7.4 N·m (0.75 kgf-m, 5.4 ft-lb)**




13) Lift-up the vehicle.

14) Tighten the bolts which install the under side of turbocharger upper cover.

**Tightening torque:**


**7.4 N·m (0.75 kgf-m, 5.4 ft-lb)**



15) Install the under cover.

16) Lower the vehicle.

17) Install the intercooler bracket.



18) Install the intercooler. <Ref. to IN(DOHC TURBO)-11, INSTALLATION, Intercooler.>


# JOINT PIPE

## EXHAUST


### 4. Joint Pipe

#### A: REMOVAL


1) Disconnect the ground terminal from battery.



2) Remove the solenoid valve cover.




3) Disconnect the exhaust temperature sensor connector.




4) Remove the front oxygen (A/F) sensor. <Ref. to FU(DOHC TURBO)-42, REMOVAL, Front Oxygen (A/F) Sensor.>

5) Remove the under cover.

6) Remove the lower exhaust manifold cover (RH).



7) Remove the nuts which hold the front exhaust manifold to joint pipe.



8) Remove the center exhaust pipe. <Ref. to EX(DOHC TURBO)-8, REMOVAL, Center Exhaust Pipe.>

9) Remove the turbocharger. <Ref. to IN(DOHC TURBO)-12, REMOVAL, Turbocharger.>


10) Take off the joint pipe in the upward direction.

#### B: INSTALLATION

Install in the reverse order of removal.

**Tightening torque:**


**T: 35 N·m (3.6 kgf·m, 26.0 ft·lb)**



## 5. Rear Exhaust Pipe


### A: REMOVAL

- 1) Disconnect the ground terminal from battery.




- 2) Lift up the vehicle.
- 3) Separate the rear exhaust pipe from center exhaust pipe.

**CAUTION:**  
Be careful, the exhaust pipe is hot.



- 4) Separate the rear exhaust pipe from muffler.

**CAUTION:**  
Be careful not to pull down the rear exhaust pipe.




- 5) Remove the rear exhaust pipe.

### B: INSTALLATION


- CAUTION:**  
Replace the gaskets with new ones.
- 1) Install the rear exhaust pipe to muffler.

**Tightening torque:**  
48 N·m (4.9 kgf·m, 35.4 ft·lb)




- 2) Install the rear exhaust pipe to center exhaust pipe.

**Tightening torque:**  
18 N·m (1.8 kgf·m, 13.0 ft·lb)



- 3) Lower the vehicle.
- 4) Connect the battery ground terminal to battery.



### C: INSPECTION

- 1) Make sure there are no exhaust leaks from connections and welds.
- 2) Make sure there are no holes or rusting.
- 3) Make sure the cushion rubber is not worn or cracked.

# MUFFLER

## EXHAUST


### 6. Muffler

#### A: REMOVAL

1) Separate the muffler from rear exhaust pipe.

#### CAUTION:

Be careful, the exhaust pipe is hot.



2) Remove the rubber cushions, and detach muffler.


#### CAUTION:

Be careful not to drop the muffler during removal.

#### NOTE:

To facilitate removal, apply a coat of SUBARU CRC to the mating area of rubber cushions in advance.

**SUBARU CRC (Part No. 004301003)**



#### B: INSTALLATION


1) Install in the reverse order of removal.

#### CAUTION:

Replace the gasket with a new one.

#### Tightening torque:

48 N·m (4.9 kgf-m, 35.4 ft-lb)



#### C: INSPECTION

- 1) Make sure there are no exhaust leaks from connections and welds.
- 2) Make sure there are no holes or rusting.
- 3) Make sure the cushion rubber is not worn or cracked.

# IGNITION

# *IG(DOHC TURBO)*

---

	<b>Page</b>
1. General Description .....	2
2. Spark Plug.....	4
3. Ignition Coil and Ignitor Assembly.....	8

# GENERAL DESCRIPTION


IGNITION

## 1. General Description

### A: SPECIFICATIONS

Item		Designation
Ignition coil and ignitor assembly	Model	FK0140
	Manufacturer	DIAMOND
Spark plug	Type and manufacturer	PFR6G: NGK
	Thread size mm	14, P = 1.25
	Spark gap mm (in)	0.7 — 0.8 (0.028 — 0.031)

### B: COMPONENT



- (1) Spark plug
- (2) Ignition coil and ignitor ASSY

**Tightening torque: N-m (kgf-m, ft-lb)**

**T1: 21 (2.1, 15)**

**T2: 16 (1.6, 11.7)**

### C: CAUTION

- Wear working clothing, including a cap, protective goggles, and protective shoes during operation.
- Remove contamination including dirt and corrosion before removal, installation or disassembly.
- Keep the disassembled parts in order and protect them from dust or dirt.
- Before removal, installation or disassembly, be sure to clarify the failure. Avoid unnecessary removal, installation, disassembly, and replacement.

- Be careful not to burn your hands, because each part on the vehicle is hot after running.
- Be sure to tighten fasteners including bolts and nuts to the specified torque.
- Place shop jacks or safety stands at the specified points.
- Before disconnecting electrical connectors of sensors or units, be sure to disconnect the negative terminal from battery.

# SPARK PLUG

## IGNITION

### 2. Spark Plug

#### A: REMOVAL

##### CAUTION:


All spark plugs installed on an engine, must be of the same heat range.

Spark plug:

NGK: PFR6G


#### 1. RH SIDE

1) Disconnect the ground terminal from battery.




2) Remove the air cleaner lower case. <Ref. to IN(DOHC TURBO)-7, REMOVAL, Air Cleaner.>


3) Disconnect the connector from ignition coil.



4) Remove the ignition coil.




5) Remove the spark plugs with the spark plug sockets.




#### 2. LH SIDE

1) Disconnect the battery terminals, and then remove the battery and battery carrier.




2) Disconnect the washer motor connector.




3) Disconnect the rear window glass washer hose from washer motor, then plug connection with a suitable cap.


4) Remove the two bolts which hold the washer tank, then take the tank away from the working area.




5) Disconnect the connector from ignition coil.



6) Remove the ignition coil.



7) Remove the spark plug with the spark plug sockets.



## B: INSTALLATION

### 1. RH SIDE

1) Install in the reverse order of removal.

**Tightening torque (Spark plug):**  
21 N·m (2.1 kgf-m, 15 ft-lb)

**Tightening torque (Ignition coil):**  
16 N·m (1.63 kgf-m, 11.8 ft-lb)

#### CAUTION:

The above torque should be only applied to new spark plugs without oil on their threads. In case their threads are lubricated, the torque should be reduced by approximately 1/3 of the specified torque in order to avoid over-stressing.

### 2. LH SIDE

1) Install in the reverse order of removal.

**Tightening torque (Spark plug):**  
21 N·m (2.1 kgf-m, 15 ft-lb)

**Tightening torque (Ignition coil):**  
16 N·m (1.63 kgf-m, 11.8 ft-lb)

#### CAUTION:


The above torque should be only applied to new spark plugs without oil on their threads. In case their threads are lubricated, the torque should be reduced by approximately 1/3 of the specified torque in order to avoid over-stressing.

# SPARK PLUG

## IGNITION

### C: INSPECTION


Check the electrodes and inner and outer porcelain of plugs, noting the type of deposits and the degree of electrode erosion.



- (A) Electrode gap
- (B) Carbon accumulation or wear
- (C) Cracks
- (D) Damage
- (E) Damaged gasket

#### 1) Normal:


Brown to grayish-tan deposits and slight electrode wear indicate correct spark plug heat range.



#### 2) Carbon fouled:


Dry fluffy carbon deposits on insulator and electrode are mostly caused by slow speed driving in city, weak ignition, too rich fuel mixture, dirty air cleaner, etc.

It is advisable to replace with plugs having hotter heat range.




#### 3) Oil fouled:

Wet black deposits show excessive oil entrance into combustion chamber through worn rings and pistons or excessive clearance between valve guides and stems. If the same condition remains after repair, use a hotter plug.



#### 4) Overheating:

White or light gray insulator with black or gray brown spots and bluish burnt electrodes indicate engine overheating. Moreover, the appearance results from incorrect ignition timing, loose spark plugs, wrong selection of fuel, hotter range plug, etc. It is advisable to replace with plugs having colder heat range.



**D: ADJUSTMENT**


Clean the spark plugs in a sand blast type cleaner. Avoid excessive blasting. Clean and remove the carbon or oxide deposits, but do not wear away porcelain.

If deposits are too stubborn, replace the plugs.

After cleaning the spark plugs, recondition the firing surface of electrodes with file. Then correct the spark plug gap using a gap gauge.

**Spark plug gap: L**

**0.7 — 0.8 mm (0.028 — 0.031 in)**

**NOTE:**

Replace with a new spark plug if this area is worn to "ball" shape.

# IGNITION COIL AND IGNITOR ASSEMBLY

## IGNITION

---

### 3. Ignition Coil and Ignitor Assembly

#### A: REMOVAL

Direct ignition type has been adopted.  
Refer to the "Spark Plug Removal" for removal procedure. <Ref. to IG(DOHC TURBO)-4, REMOVAL, Spark Plug.>

#### B: INSTALLATION

Install in the reverse order of removal.

#### *Tightening torque:*

**16 N·m (1.63 kgf·m, 11.8 ft·lb)**

#### C: INSPECTION

Ignitor is integrated with the coil. Therefore resistance cannot be measured.

# ENGINE (DIAGNOSTICS)

# *EN(DOHC TURBO)*

---

	<b>Page</b>
1. Basic Diagnostic Procedure .....	2
2. Check List for Interview .....	4
3. General Description .....	6
4. Electrical Components Location.....	9
5. Engine Control Module (ECM) I/O Signal .....	26
6. Engine Condition Data .....	30
7. Transmission Control Module (TCM) I/O Signal .....	32
8. Data Link Connector .....	35
9. OBD-II General Scan Tool .....	36
10. Subaru Select Monitor.....	38
11. Read Diagnostic Trouble Code .....	45
12. Inspection Mode.....	46
13. Clear Memory Mode.....	49
14. Compulsory Valve Operation Check Mode .....	50
15. Engine Malfunction Indicator Lamp (MIL) .....	52
16. Diagnostics for Engine Starting Failure.....	63
17. List of Diagnostic Trouble Code (DTC) .....	80
18. Diagnostic Procedure with Diagnostic Trouble Code (DTC) .....	88
19. General Diagnostic Table.....	372

# BASIC DIAGNOSTIC PROCEDURE

## ENGINE (DIAGNOSTICS)

### 1. Basic Diagnostic Procedure

#### A: PROCEDURE

##### 1. ENGINE

Step	Check	Yes	No
<b>1 CHECK ENGINE START FAILURE.</b> 1)Ask the customer when and how the trouble occurred using the interview check list. <Ref. to EN(DOHC TURBO)-4, CHECK, Check List for Interview.> 2)Start the engine.	Does the engine start?	Go to step 2.	Inspection using "Diagnostics for Engine Start Failure". <Ref. to EN(DOHC TURBO)-63, Diagnostics for Engine Starting Failure.>
<b>2 CHECK ILLUMINATION OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL).</b>	Does CHECK ENGINE malfunction indicator lamp illuminate?	Go to step 3.	Inspection using "General Diagnostics Table". <Ref. to EN(DOHC TURBO)-372, General Diagnostic Table.>
<b>3 CHECK INDICATION OF DTC ON DISPLAY.</b> 1)Turn the ignition switch to OFF. 2)Connect the Subaru Select Monitor or the OBD-II general scan tool to data link connector. 3)Turn the ignition switch to ON and the Subaru Select Monitor or OBD-II general scan tool switch to ON. 4)Read the DTC on the Subaru Select Monitor or OBD-II general scan tool.	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC?	Record the diagnostic trouble code. Repair the trouble cause. <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).> Go to step 4.	Repair the related parts. <b>NOTE:</b> If DTC is not shown on display although the MIL illuminates, perform diagnostics of MIL (CHECK ENGINE malfunction indicator lamp) circuit or combination meter. <Ref. to EN(DOHC TURBO)-52, Engine Malfunction Indicator Lamp (MIL).>
<b>4 PERFORM THE DIAGNOSIS.</b> 1)Perform the clear memory mode. <Ref. to EN(DOHC TURBO)-49, Clear Memory Mode.> 2)Perform the inspection mode. <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC?	Inspect using "Diagnostics Procedure with Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-88, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Complete the diagnosis.

**2. AUTOMATIC TRANSMISSION**

When the trouble code about automatic transmission is shown on display, carry out the following basic check. After that, carry out the replacement or repair work.

- 1) ATF level check <Ref. to AT-9, Automatic Transmission Fluid.>
- 2) Differential gear oil level check <Ref. to AT-11, Differential Gear Oil.>
- 3) ATF leak check <Ref. to AT-9, Automatic Transmission Fluid.>
- 4) Differential gear oil leak check <Ref. to AT-11, Differential Gear Oil.>
- 5) Stall test <Ref. to AT-13, Stall Test.>
- 6) Line pressure test <Ref. to AT-16, Line Pressure Test.>
- 7) Transfer clutch pressure test <Ref. to AT-18, Transfer Clutch Pressure Test.>
- 8) Time lag test <Ref. to AT-15, Time Lag Test.>
- 9) Road test <Ref. to AT-12, Road Test.>
- 10) Shift characteristics <Ref. to AT-18, Transfer Clutch Pressure Test.>

# CHECK LIST FOR INTERVIEW

ENGINE (DIAGNOSTICS)

## 2. Check List for Interview

Check the following items when problem has occurred.

### A: CHECK

NOTE:

#### 1. CHECK LIST NO. 1

Use copies of this page for interviewing customers.

Customer's name		Engine no.	
Date of sale		Fuel brand	
Date of repair		Odometer reading	km
Vin no.			miles
Weather	<input type="checkbox"/> Fine <input type="checkbox"/> Cloudy <input type="checkbox"/> Rainy <input type="checkbox"/> Snowy <input type="checkbox"/> Various/Others:		
Outdoor temperature	°C (°F)		
	<input type="checkbox"/> Hot <input type="checkbox"/> Warm <input type="checkbox"/> Cool <input type="checkbox"/> Cold		
Place	<input type="checkbox"/> Highway <input type="checkbox"/> Suburbs <input type="checkbox"/> Inner city <input type="checkbox"/> Uphill <input type="checkbox"/> Downhill <input type="checkbox"/> Rough road <input type="checkbox"/> Others:		
	<input type="checkbox"/> Cold <input type="checkbox"/> Warming-up <input type="checkbox"/> After warming-up <input type="checkbox"/> Any temperature <input type="checkbox"/> Others:		
Engine speed	rpm		
Vehicle speed	MPH		
Driving conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> At starting <input type="checkbox"/> While idling <input type="checkbox"/> At racing <input type="checkbox"/> While accelerating <input type="checkbox"/> While cruising <input type="checkbox"/> While decelerating <input type="checkbox"/> While turning (RH/LH)		
Headlight	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF	Rear defogger	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF
Blower	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF	Radio	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF
A/C compressor	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF	CD/Cassette	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF
Cooling fan	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF	Car phone	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF
Front wiper	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF	CB	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF
Rear wiper	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF		

# CHECK LIST FOR INTERVIEW

ENGINE (DIAGNOSTICS)

## 2. CHECK LIST NO. 2

Check the following items about the vehicle's state when MIL turns on.

NOTE:

Use copies of this page for interviewing customers.

a) Other warning lights or indicators turn on. <input type="checkbox"/> Yes/ <input type="checkbox"/> No
<input type="checkbox"/> Low fuel warning light <input type="checkbox"/> Charge indicator light <input type="checkbox"/> AT diagnostics indicator light <input type="checkbox"/> ABS warning light <input type="checkbox"/> Engine oil pressure warning light
b) Fuel level
<ul style="list-style-type: none"><li>• Lack of gasoline: <input type="checkbox"/> Yes/<input type="checkbox"/> No</li><li>• Indicator position of fuel gauge:</li></ul>
c) Intentional connecting or disconnecting of harness connectors or spark plug cords: <input type="checkbox"/> Yes/ <input type="checkbox"/> No
<ul style="list-style-type: none"><li>• What:</li></ul>
d) Intentional connecting or disconnecting of hoses: <input type="checkbox"/> Yes/ <input type="checkbox"/> No
<ul style="list-style-type: none"><li>• What:</li></ul>
e) Installing of parts other than genuine parts: <input type="checkbox"/> Yes/ <input type="checkbox"/> No
<ul style="list-style-type: none"><li>• What:</li><li>• Where:</li></ul>
f) Occurrence of noise: <input type="checkbox"/> Yes/ <input type="checkbox"/> No
<ul style="list-style-type: none"><li>• From where:</li><li>• What kind:</li></ul>
g) Occurrence of smell: <input type="checkbox"/> Yes/ <input type="checkbox"/> No
<ul style="list-style-type: none"><li>• From where:</li><li>• What kind:</li></ul>
h) Intrusion of water into engine compartment or passenger compartment: <input type="checkbox"/> Yes/ <input type="checkbox"/> No
i) Troubles occurred
<input type="checkbox"/> Engine does not start. <input type="checkbox"/> Engine stalls during idling. <input type="checkbox"/> Engine stalls while driving. <input type="checkbox"/> Engine speed decreases. <input type="checkbox"/> Engine speed does not decrease. <input type="checkbox"/> Rough idling <input type="checkbox"/> Poor acceleration <input type="checkbox"/> Back fire <input type="checkbox"/> After fire <input type="checkbox"/> No shift <input type="checkbox"/> Excessive shift shock

# GENERAL DESCRIPTION

## ENGINE (DIAGNOSTICS)

### 3. General Description

#### A: CAUTION

1) Airbag system wiring harness is routed near the engine control module (ECM), main relay and fuel pump relay.

#### CAUTION:

- All Airbag system wiring harness and connectors are colored yellow. Do not use electrical test equipment on these circuit.

- Be careful not to damage the Airbag system wiring harness when servicing the engine control module (ECM), transmission control module (TCM), main relay and fuel pump relay.

2) Never connect the battery in reverse polarity.

- The ECM will be destroyed instantly.
- The fuel injector and other part will be damaged in just a few minutes more.

3) Do not disconnect the battery terminals while the engine is running.

- A large counter electromotive force will be generated in the generator, and this voltage may damage electronic parts such as ECM, etc.

4) Before disconnecting the connectors of each sensor and the ECM, be sure to turn OFF the ignition switch.

5) Poor contact has been identified as a primary cause of this problem. To measure the voltage and/or resistance of individual sensors or all electrical control modules at the harness side connector, use a tapered pin with a diameter of less than 0.64 mm (0.025 in). Do not insert the pin more than 5 mm (0.20 in) into the part.

6) Before removing the ECM from the located position, disconnect two cables on battery.


- Otherwise, the the ECM may be damaged.

#### CAUTION:


**When replacing the ECM, be careful not to use the wrong spec. ECM to avoid any damage on fuel injection system.**

7) The connectors to each sensor in the engine compartment and the harness connectors on the engine side and body side are all designed to be waterproof. However, it is still necessary to take care not to allow water to get into the connectors when washing the vehicle, or when servicing the vehicle on a rainy day.


8) Use ECM mounting stud bolts at the body head grounding point when measuring voltage and resistance inside the passenger compartment.



9) Use engine grounding terminal or engine proper as the grounding point to the body when measuring voltage and resistance in the engine compartment.



10) Use TCM mounting stud bolts at the body head grounding point when measuring voltage and resistance inside the passenger compartment.



11) Every MFI-related part is a precision part. Do not drop them.

12) Observe the following cautions when installing a radio in MFI equipped models.

**CAUTION:**

- The antenna must be kept as far apart as possible from the control unit.  
(The ECM is located under the steering column, inside of the instrument panel lower trim panel.)
- The antenna feeder must be placed as far apart as possible from the ECM and MFI harness.
- Carefully adjust the antenna for correct matching.
- When mounting a large power type radio, pay special attention to the three items above mentioned.
- Incorrect installation of the radio may affect the operation of the ECM.

13) Before disconnecting the fuel hose, disconnect the fuel pump connector and crank the engine for more than five seconds to release pressure in the fuel system. If engine starts during this operation, run it until it stops.

14) Problems in the electronic-controlled automatic transmission may be caused by failure of the engine, the electronic control system, the transmission proper, or by a combination of these. These three causes must be distinguished clearly when performing diagnostics.

15) Diagnostics should be conducted by rotating with simple, easy operations and proceeding to complicated, difficult operations. The most important thing in diagnostics is to understand the customer's complaint, and distinguish between the three causes.

16) On ABS vehicle, when performing driving test in jacked-up or lifted-up position, sometimes the warning light may be lit, but this is not a malfunction of the system. The reason for this is the speed difference between the front and rear wheels. After diagnosis of engine control system, perform the ABS memory clearance procedure of self-diagnosis system.

## B: INSPECTION

Before performing diagnostics, check the following items which might affect engine problems:

### 1. BATTERY

1) Measure battery voltage and specific gravity of electrolyte.


**Standard voltage: 12 V**

**Specific gravity: Above 1.260**

2) Check the condition of the main and other fuses, and harnesses and connectors. Also check for proper grounding.

## 2. ENGINE GROUNDING

Make sure the engine grounding terminal is properly connected to the engine.



## C: NOTE

### 1. DESCRIPTION

- The on-board diagnostics (OBD) system detects and indicates a fault in various inputs and outputs of the complex electronic control. CHECK ENGINE malfunction indicator lamp (MIL) in the combination meter indicates occurrence of a fault or trouble.
- Further, against such a failure or sensors as may disable the drive, the fail-safe function is provided to ensure the minimal driveability.
- The OBD system incorporated with the vehicles within this engine family complies with Section 1968.1, California Code of Regulations (OBD-II regulation). The OBD system monitors the components and the system malfunction listed in Engine Section which affects on emissions.
- When the system decides that a malfunction occurs, MIL illuminates. At the same time of the MIL illumination or blinking, a diagnostic trouble code (DTC) and a freeze frame engine conditions are stored into on-board computer.
- The OBD system stores freeze frame engine condition data (engine load, engine coolant temperature, fuel trim, engine speed and vehicle speed, etc.) into on-board computer when it detects a malfunction first.
- If the OBD system detects the various malfunctions including the fault of fuel trim or misfire, the OBD system first stores freeze frame engine conditions about the fuel trim or misfire.
- When the malfunction does not occur again for three consecutive driving cycles, MIL is turned off, but DTC remains at on-board computer.
- The OBD-II system is capable of communication with a general scan tool (OBD-II general scan tool) formed by ISO 9141 CARB.

# GENERAL DESCRIPTION

## ENGINE (DIAGNOSTICS)

- The OBD-II diagnostics procedure is different from the usual diagnostics procedure. When troubleshooting OBD-II vehicles, connect Subaru Select Monitor or the OBD-II general scan tool to the vehicle.

### 2. ENGINE AND EMISSION CONTROL SYSTEM

- The Multipoint Fuel Injection (MFI) system is a system that supplies the optimum air-fuel mixture to the engine for all the various operating conditions through the use of the latest electronic technology.

With this system fuel, which is pressurized at a constant pressure, is injected into the intake air passage of the cylinder head. The injection quantity of fuel is controlled by an intermittent injection system where the electro-magnetic injection valve (fuel injector) opens only for a short period of time, de-


pending on the quantity of air required for one cycle of operation. In actual operation, the injection quantity is determined by the duration of an electric pulse applied to the fuel injector and this permits simple, yet highly precise metering of the fuel.

- Further, all the operating conditions of the engine are converted into electric signals, and this results in additional features of the system, such as large improved adaptability, easier addition of compensating element, etc.

The MFI system also has the following features:

- Reduced emission of harmful exhaust gases.
- Reduced in fuel consumption.
- Increased engine output.
- Superior acceleration and deceleration.
- Superior startability and warm-up performance in cold weather since compensation is made for coolant and intake air temperature.

### D: PREPARATION TOOL


ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p>B2M3876</p>	24082AA150 (Newly adopted tool)	CARTRIDGE	Troubleshooting for electrical systems.
 <p>B2M3877</p>	22771AA030	SELECT MONITOR KIT	Troubleshooting for electrical systems. <ul style="list-style-type: none"> <li>• English: 22771AA030 (Without printer)</li> <li>• German: 22771AA070 (Without printer)</li> <li>• French: 22771AA080 (Without printer)</li> <li>• Spanish: 22771AA090 (Without printer)</li> </ul>

## 4. Electrical Components Location

### A: LOCATION


#### 1. ENGINE

##### • MODULE




EN1064


- |   |                         |
|---|-------------------------|
| (1) Engine control module (ECM)                   | (3) Test mode connector |
| (2) CHECK ENGINE malfunction indicator lamp (MIL) | (4) Data link connector |




B3M1575A



EN1065



EN0716




EN1066

# ELECTRICAL COMPONENTS LOCATION

## ENGINE (DIAGNOSTICS)

### • SENSOR











EN0946

- |                                       |   |  |
|---------------------------------------|---|--|
| (1) Pressure sensor                   | (4) Knock sensor                                    | (8) Tumble generator valve position sensor |
| (2) Engine coolant temperature sensor | (5) Camshaft position sensor                        |  |
| (3) Throttle position sensor          | (6) Crankshaft position sensor                      |  |
|                                       | (7) Mass air flow and intake air temperature sensor |  |


# ELECTRICAL COMPONENTS LOCATION

ENGINE (DIAGNOSTICS)



# ELECTRICAL COMPONENTS LOCATION

ENGINE (DIAGNOSTICS)








(1) Front oxygen (A/F) sensor  
(2) Precatalytic converter

(3) Exhaust temperature sensor  
(4) Front catalytic converter

(5) Rear oxygen sensor  
(6) Rear catalytic converter

# ELECTRICAL COMPONENTS LOCATION


ENGINE (DIAGNOSTICS)




**SUBARU**

# ELECTRICAL COMPONENTS LOCATION

## ENGINE (DIAGNOSTICS)



- (1) Fuel level sensor
- (2) Fuel temperature sensor
- (3) Fuel tank pressure sensor
- (4) Fuel sub level sensor



# ELECTRICAL COMPONENTS LOCATION

ENGINE (DIAGNOSTICS)


---

EN(DOHC TURBO)-15

# ELECTRICAL COMPONENTS LOCATION

## ENGINE (DIAGNOSTICS)

### • SOLENOID VALVE, ACTUATOR, EMISSION CONTROL SYSTEM PARTS AND IGNITION SYSTEM PARTS




EN0951


- |                                      |                                  |                                     |
|--------------------------------------|----------------------------------|-------------------------------------|
| (1) Wastegate control solenoid valve | (3) Purge control solenoid valve | (5) Tumble generator valve actuator |
| (2) Idle air control solenoid valve  | (4) Ignition coil                |                                     |

# ELECTRICAL COMPONENTS LOCATION


ENGINE (DIAGNOSTICS)




EN1021




EN1022



EN1023



EN1024




EN0952


SUBARU

# ELECTRICAL COMPONENTS LOCATION

ENGINE (DIAGNOSTICS)




- (1) Pressure control solenoid valve
- (2) Canister
- (3) Drain valve
- (4) Drain filter





# ELECTRICAL COMPONENTS LOCATION

ENGINE (DIAGNOSTICS)




EN1190


- |                     |                               |                              |
|---------------------|-------------------------------|------------------------------|
| (1) Fuel pump       | (4) Fuel pump controller      | (7) Radiator sub fan relay 1 |
| (2) Main relay      | (5) Radiator main fan relay 1 | (8) Radiator sub fan relay 2 |
| (3) Fuel pump relay | (6) Radiator main fan relay 2 | (9) Starter                  |

# ELECTRICAL COMPONENTS LOCATION


ENGINE (DIAGNOSTICS)




EN1191




EN1070



EN1029



EN0954



EN1030


**SUBARU**

# ELECTRICAL COMPONENTS LOCATION

## ENGINE (DIAGNOSTICS)

### 2. TRANSMISSION


#### • Module




EN0751

(1) Transmission Control Module (TCM) (for AT vehicles)

(2) AT diagnostic indicator light (for AT vehicles)



EN1071









EN1072

# ELECTRICAL COMPONENTS LOCATION

ENGINE (DIAGNOSTICS)

## • Sensor




- (1) Vehicle speed sensor 1 (for AT vehicles)
- (2) Vehicle speed sensor 2 (for MT vehicles)
- (3) Vehicle speed sensor 2 (for AT vehicles)
- (4) Torque converter turbine speed sensor (for AT vehicles)
- (5) ATF temperature sensor (for AT vehicles)
- (6) Brake light switch


# ELECTRICAL COMPONENTS LOCATION

## ENGINE (DIAGNOSTICS)

### • Solenoid Valve And Switch (AT Vehicles)



### • Solenoid Valve And Switch (MT Vehicles)



# ELECTRICAL COMPONENTS LOCATION

ENGINE (DIAGNOSTICS)


---

# ENGINE CONTROL MODULE (ECM) I/O SIGNAL

ENGINE (DIAGNOSTICS)

## 5. Engine Control Module (ECM) I/O Signal

### A: ELECTRICAL SPECIFICATION



EN0955

Content		Con- nector No.	Termi- nal No.	Signal (V)		Note
				Ignition SW ON (Engine OFF)	Engine ON (Idling)	
Crank- shaft position sensor	Signal (+)	B135	2	0	-7 — +7	Sensor output waveform
	Signal (-)	B135	11	0	0	—
	Shield	B135	21	0	0	—
Camshaft position sensor	Signal (+)	B135	1	0	-7 — +7	Sensor output waveform
	Signal (-)	B135	10	0	0	—
	Shield	B135	21	0	0	—
Throttle position sensor	Signal	B135	7			
	Power supply	B135	9	5	5	—
	GND (sensor)	B135	19	0	0	—
Rear oxygen sensor	Signal	B135	17	0	0 — 0.9	—
	Shield	B135	26	0	0	—
	GND (sensor)	B135	19	0	0	—
Front oxygen (A/F) sensor heater	Signal 1	B137	4	0 — 1.0	0 — 1.0	—
	Signal 2	B137	5	0 — 1.0	0 — 1.0	—
Rear oxygen sensor heater signal		B136	13	0 — 1.0	0 — 1.0	—
Engine coolant temperature sensor	Signal	B135	18	1.0 — 1.4	1.0 — 1.4	After warm-up the engine.
	GND (sensor)	B135	19	0	0	After warm-up the engine.
Vehicle speed signal		B134	1	0 or 5	0 or 5	"5" and "0" are repeatedly displayed when vehicle is driven.

# ENGINE CONTROL MODULE (ECM) I/O SIGNAL

ENGINE (DIAGNOSTICS)

Content		Con- nector No.	Termi- nal No.	Signal (V)		Note
				Ignition SW ON (Engine OFF)	Engine ON (Idling)	
Mass air flow sen- sor	Signal	B84	13	—	0.3 — 4.5	—
	Shield	B84	8	0	0	—
	GND	B84	7	0	0	—
Intake air temperature sensor signal		B135	27	—	—	—
Exhaust gas tem- perature sensor	Signal	B135	16	—	—	—
	GND (sensor)	B135	19	0	0	—
Tumble generator valve posi- tion sensor RH	Signal	B84	23	Fully closed: 0.2 — 1.0 Fully opened: 4.2 — 4.7		—
	Power supply	B135	9	5	5	—
	GND (sensor)	B135	19	0	0	—
Tumble generator valve posi- tion sensor LH	Signal	B84	13	Fully closed: 0.2 — 1.0 Fully opened: 4.2 — 4.7		—
	Power supply	B135	9	5	5	—
	GND (sensor)	B135	19	0	0	—
Tumble generator valve RH (open)		B84	4	0 or 5	0 or 5	—
Tumble generator valve RH (close)		B84	5	0 or 5	0 or 5	—
Tumble generator valve LH (open)		B84	11	0 or 5	0 or 5	—
Tumble generator valve LH (close)		B84	10	0 or 5	0 or 5	—
Wastegate control sole- noid valve		B137	24	10 — 13	13 — 14	—
Starter switch		B134	16	0	0	Cranking: 8 — 14
A/C switch		B134	2	ON: 10 — 13 OFF: 0	ON: 13 — 14 OFF: 0	—
Ignition switch		B134	5	10 — 13	13 — 14	—
Neutral position switch		B134	8	ON: 12±0.5 OFF: 0		Switch is ON when gear is in neutral position.
Test mode connector		B134	14	5	5	When connected: 0
Knock sensor	Signal	B135	4	2.8	2.8	—
	Shield	B135	22	0	0	—
Back-up power supply		B137	10	10 — 13	13 — 14	Ignition switch "OFF": 10 — 13
Control unit power sup- ply		B137	2	10 — 13	13 — 14	—
		B137	3	10 — 13	13 — 14	—
Sensor power supply		B135	9	5	5	—
Line end check 1		B134	10	0	0	—
Ignition control	#1	B136	24	0	13 — 14	Waveform
	#2	B136	23	0	13 — 14	Waveform
	#3	B136	22	0	13 — 14	Waveform
	#4	B136	21	0	13 — 14	Waveform

# ENGINE CONTROL MODULE (ECM) I/O SIGNAL

## ENGINE (DIAGNOSTICS)

Content		Connector No.	Terminal No.	Signal (V)		Note
				Ignition SW ON (Engine OFF)	Engine ON (Idling)	
Fuel injector	#1	B137	1	10 — 13	1 — 14	Waveform
	#2	B136	6	10 — 13	1 — 14	Waveform
	#3	B136	5	10 — 13	1 — 14	Waveform
	#4	B136	4	10 — 13	1 — 14	Waveform
Idle air control solenoid valve	Signal	B136	10	0 or 13 — 14	0 or 13 — 14	Waveform
Fuel pump controller	Signal 1	B134	13	—	—	—
	Signal 2	B136	15	—	—	—
A/C relay control		B137	27	ON: 0.5, or less OFF: 10 — 13	ON: 0.5, or less OFF: 13 — 14	—
Radiator fan relay 1 control		B137	17	ON: 0.5, or less OFF: 10 — 13	ON: 0.5, or less OFF: 13 — 14	—
Radiator fan relay 2 control		B137	28	ON: 0.5, or less OFF: 10 — 13	ON: 0.5, or less OFF: 13 — 14	With A/C vehicles only
Malfunction indicator lamp		B137	15	—	—	Light "ON": 1, or less Light "OFF": 10 — 14
Engine speed output		B136	9	—	0 — 13, or more	Waveform
Purge control solenoid valve		B137	16	ON: 1, or less OFF: 10 — 13	ON: 1, or less OFF: 13 — 14	—
Torque control 1 signal		B134	19	5	5	—
Torque control 2 signal		B134	18	5	5	—
Torque control cut signal		B136	14	8	8	—
Fuel temperature sensor		B135	6	2.5 — 3.8	2.5 — 3.8	Ambient temperature: 25°C (75°F)
Fuel tank pressure sensor	Signal	B135	15	2.3 — 2.7	2.3 — 2.7	The value obtained after the fuel filler cap was removed once and recapped.
	GND (sensor)	B134	19	0	0	
Fuel tank pressure control solenoid valve		B137	22	ON: 1, or less OFF: 10 — 13	ON: 1, or less OFF: 13 — 14	—
Drain valve		B137	11	ON: 1, or less OFF: 10 — 13	ON: 1, or less OFF: 13 — 14	—
AT diagnosis input signal		B135	20	Less than 1 ←→ More than 4	Less than 1 ←→ More than 4	Waveform
AT load signal		B135	28	4.3 — 4.4	0.9 — 1.4	—
Pressure sensor	Signal	B135	8	1.7 — 2.4	1.1 — 1.6	—
	Power supply	B135	9	5	5	
	GND (sensor)	B135	19	0	0	
Fuel level sensor		B135	25	0.12 — 4.75	0.12 — 4.75	—
Small light switch		B134	17	ON: 0 OFF: 10 — 13	ON: 0 OFF: 13 — 14	—
Blower fan switch		B134	9	ON: 0 OFF: 10 — 13	ON: 0 OFF: 13 — 14	—
Rear defogger switch		B134	3	ON: 0 OFF: 10 — 13	ON: 0 OFF: 13 — 14	—
Power steering oil pressure switch		B135	24	10 — 13	ON: 0 OFF: 13 — 14	—

# ENGINE CONTROL MODULE (ECM) I/O SIGNAL

ENGINE (DIAGNOSTICS)

Content	Con- nector No.	Termi- nal No.	Signal (V)		Note
			Ignition SW ON (Engine OFF)	Engine ON (Idling)	
Front oxygen (A/F) sen- sor signal (+)	B137	19	2.8 — 3.2	2.8 — 3.2	—
Front oxygen (A/F) sen- sor signal (-)	B137	29	2.4 — 2.7	2.4 — 2.7	—
Front oxygen (A/F) sen- sor shield	B136	7	0	0	—
SSM/GST communica- tion line	B134	21	Less than 1 ↔ More than 4	Less than 1 ↔ More than 4	—
GND (sensors)	B135	19	0	0	—
GND (injectors)	B136	8	0	0	—
GND (ignition system)	B136	18	0	0	—
GND (power supply)	B136	17	0	0	—
	B134	22	0	0	—
GND (control systems)	B134	7	0	0	—
	B134	15	0	0	—
GND (oxygen sensor heater 1)	B137	9	0	0	—
GND (oxygen sensor heater 2)	B137	8	0	0	—

# ENGINE CONDITION DATA

ENGINE (DIAGNOSTICS)

## 6. Engine Condition Data

### A: ELECTRICAL SPECIFICATION

Content	Specified data
Engine load	1.6 — 2.9 (%): Idling
	6.4 — 12.8 (%): 2,500 rpm racing

Measuring condition:

- After engine is warmed-up.
- Gear position is in neutral position. (MT vehicle)
- Gear position is in "N" or "P" position. (AT vehicle)
- A/C is turned OFF.
- All accessory switches are turned OFF.




# TRANSMISSION CONTROL MODULE (TCM) I/O SIGNAL

ENGINE (DIAGNOSTICS)

## 7. Transmission Control Module (TCM) I/O Signal

### A: ELECTRICAL SPECIFICATION



S2M2131

**NOTE:**

Check with ignition switch ON.

Content		Connector No.	Terminal No.	Measuring conditions	Voltage (V)	Resistance to body (ohms)
Back-up power supply		B56	1	Ignition switch OFF	10 — 13	—
Ignition power supply		B54	23	Ignition switch ON (with engine OFF)	10 — 13	—
		B54	24			
Inhibitor switch	“P” range switch	B55	1	Select lever in “P” range	Less than 1	—
				Select lever in any other than “P” range (except “N” range)	More than 8	
	“N” range switch	B55	14	Select lever in “N” range	Less than 1	—
				Select lever in any other than “N” range (except “P” range)	More than 8	
	“R” range switch	B55	3	Select lever in “R” range	Less than 1	—
				Select lever in any other than “R” range	More than 8	
	“D” range switch	B55	4	Select lever in “D” range	Less than 1	—
				Select lever in any other than “D” range	More than 8	
	“3” range switch	B55	5	Select lever in “3” range	Less than 1	—
				Select lever in any other than “3” range	More than 8	
	“2” range switch	B55	6	Select lever in “2” range	Less than 1	—
				Select lever in any other than “2” range	More than 8	
	“1” range switch	B55	7	Select lever in “1” range	Less than 1	—
				Select lever in any other than “1” range	More than 8	
Brake switch		B55	12	Brake pedal depressed.	More than 10.5	—
				Brake pedal released.	Less than 1	
AT OIL TEMP warning light		B56	11	Light ON	Less than 1	—
				Light OFF	More than 9	

# TRANSMISSION CONTROL MODULE (TCM) I/O SIGNAL

ENGINE (DIAGNOSTICS)

Content	Connector No.	Terminal No.	Measuring conditions	Voltage (V)	Resistance to body (ohms)
Throttle position sensor	B54	3	Throttle fully closed.	Approx. 0.5	—
			Throttle fully open.	Approx. 4.3	
Throttle position sensor power supply	B54	2	Ignition switch ON (With engine OFF)	Approx. 5.0	—
ATF temperature sensor	B54	11	ATF temperature 20°C (68°F)	2.9 — 4.0	2.1 — 2.9 k
			ATF temperature 80°C (176°F)	0.5 — 0.8	275 — 375
Rear vehicle speed sensor	B55	24	Vehicle stopped.	0	450 — 650
			Vehicle speed at least 20 km/h (12 MPH)	More than 1 (AC range)	
Front vehicle speed sensor	B55	18	Vehicle stopped.	0	450 — 650
			Vehicle speed at least 20 km/h (12 MPH)	More than 1 (AC range)	
Torque converter turbine speed sensor	B55	8	Engine idling after warm-up. (D range)	0	450 — 650
			Engine idling after warm-up. (N range)	More than 1 (AC range)	
Vehicle speed output signal	B56	17	Vehicle speed at most 10 km/h (6 MPH)	Less than 1 ← → More than 5	—
Engine speed signal	B55	17	Ignition switch ON (with engine OFF)	0	—
			Ignition switch ON (with engine ON)	8 — 11	
Cruise set signal	B55	22	When cruise control is set (SET lamp ON)	Less than 1	—
			When cruise control is not set (SET lamp OFF)	More than 6.5	
Torque control signal 1	B56	5	Ignition switch ON (with engine ON)	More than 4.8	—
Torque control signal 2	B56	14	Ignition switch ON (with engine ON)	More than 4.8	—
Torque control cut signal	B55	10	Ignition switch ON	8	—
Shift solenoid 1	B54	22	1st or 4th gear	More than 9	10 — 16
			2nd or 3rd gear	Less than 1	
Shift solenoid 2	B54	5	1st or 2nd gear	More than 9	10 — 16
			3rd or 4th gear	Less than 1	
Line pressure duty solenoid	B54	9	Throttle fully closed (with engine OFF) after warm-up.	1.5 — 5.0	2.0 — 4.5
			Throttle fully open (with engine OFF) after warm-up.	Less than 0.5	
Lock-up duty solenoid	B54	7	When lock up occurs.	More than 8.5	10 — 17
			When lock up is released.	Less than 0.5	
Transfer duty solenoid	B54	6	Fuse on FWD switch	More than 8.5	10 — 17
			Fuse removed from FWD switch (with throttle fully open and with select lever in 1st gear).	Less than 0.5	
2-4 brake duty solenoid	B54	18	Throttle fully closed (with engine OFF) after warm-up.	1.5 — 5.0	2.0 — 4.5
			Throttle fully open (with engine OFF) after warm-up.	Less than 0.5	

# TRANSMISSION CONTROL MODULE (TCM) I/O SIGNAL

## ENGINE (DIAGNOSTICS)

Content	Connector No.	Terminal No.	Measuring conditions	Voltage (V)	Resistance to body (ohms)
2-4 brake dropping resistor	B54	17	Throttle fully closed (with engine OFF) after warm-up.	More than 8.5	9 — 15
			Throttle fully open (with engine OFF) after warm-up.	Less than 0.5	
2-4 brake timing solenoid	B54	16	1st gear	Less than 1	10 — 16
			3rd gear	More than 9	
Low clutch timing solenoid	B54	15	2nd gear	Less than 1	10 — 16
			4th gear	More than 9	
Sensor ground line 1	B54	19	—	0	Less than 1
Sensor ground line 2	B55	9	—	0	Less than 1
System ground line	B56	19	—	0	Less than 1
	B54	20			
AT diagnosis signal	B56	21	Ignition switch ON	Less than 1 ← → More than 4	—
Data link signal (Subaru Select Monitor)	B56	15	—	—	—
		6	—	—	—


## 8. Data Link Connector

### A: NOTE

- 1) This connector is used both for OBD-II general scan tools and the Subaru Select Monitor.
- 2) Terminal No. 4 to No. 6 of the data link connector is used for the Subaru Select Monitor signal.

### CAUTION:

**Do not connect any scan tools other than the OBD-II general scan tools and the Subaru Select Monitor, because the circuit for the Subaru Select Monitor may be damaged.**




Terminal No.	Contents	Terminal No.	Contents
1	Power supply	9	Blank
2	Blank	10	K line of ISO 9141 CARB
3	Blank	11	Blank
4	Blank	12	Ground
5	Blank	13	Ground
6	Line end check signal 1	14	Blank
7	Blank	15	Blank
8	Line end check signal 2	16	Blank

## 9. OBD-II General Scan Tool

### A: OPERATION

#### 1. HOW TO USE OBD-II GENERAL SCAN TOOL

- 1) Prepare a general scan tool (OBD-II general scan tool) required by SAE J1978.
- 2) Open the cover and connect the OBD-II general scan tool to the data link connector located in the lower portion of the instrument panel (on the driver's side).



- 3) Using the OBD-II general scan tool, call up diagnostic trouble code(s) and freeze frame data.

OBD-II general scan tool functions consist of:

- (1) MODE \$01: Current powertrain diagnostic data
- (2) MODE \$02: Powertrain freeze frame data
- (3) MODE \$03: Emission-related powertrain diagnostic trouble codes
- (4) MODE \$04: Clear/Reset emission-related diagnostic information

Read out data according to repair procedures. (For detailed operation procedures, refer to the OBD-II General Scan Tool Operation Manual.)

**NOTE:**

For details concerning diagnostic trouble codes, refer to the List of Diagnostic Trouble Code (DTC). <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>

#### 2. MODE \$01 (CURRENT POWERTRAIN DIAGNOSTIC DATA)

Refers to data denoting the current operating condition of analog input/output, digital input/output and/or the powertrain system.

A list of the support data and PID (Parameter Identification) codes are shown in the following table.

PID	Data	Unit of measure
01	Number of emission-related powertrain trouble codes and MIL status	ON/OFF
03	Fuel system control status	—
04	Calculated engine load value	%
05	Engine coolant temperature	°C
06	Short term fuel trim	%
07	Long term fuel trim	%
0B	Intake manifold absolute pressure	kPa
0C	Engine revolution	rpm
0D	Vehicle speed	km/h
0E	Ignition timing advance	°
0F	Intake air temperature	°C
10	Air flow rate from pressure sensor	g/sec
11	Throttle valve opening angle	%
13	Check whether oxygen sensor is installed.	—
15	Oxygen sensor output voltage and short term fuel trim associated with oxygen sensor—bank 2	V and %
24	A/F sensor 1 output voltage and short term fuel trim associated with A/F sensor 1	V and %
1C	On-board diagnosis system	—

**NOTE:**

Refer to OBD-II general scan tool manufacturer's instruction manual to access generic OBD-II PIDs (MODE \$01).

**3. MODE \$02 (POWERTRAIN FREEZE FRAME DATA)**

Refers to data denoting the operating condition when trouble is sensed by the on-board diagnosis system. A list of the support data and PID (Parameter Identification) codes are shown in the following table.

PID	Data	Unit of measure
02	Trouble code that caused CARB required freeze frame data storage	—
03	Fuel system control status	—
04	Calculated engine load value	%
05	Engine coolant temperature	°C
06	Short term fuel trim	%
07	Long term fuel trim	%
0B	Intake manifold absolute pressure	kPa
0C	Engine revolution	rpm
0D	Vehicle speed	km/h

**NOTE:**

Refer to OBD-II general scan tool manufacturer's instruction manual to access freeze frame data (MODE \$02).

**4. MODE \$03 (EMISSION-RELATED POWERTRAIN DIAGNOSTIC TROUBLE CODE)**

Refer to Read Diagnostic Trouble Code for information about data denoting emission-related powertrain diagnostic trouble codes. <Ref. to EN(DOHC TURBO)-45, Read Diagnostic Trouble Code.>

**5. MODE \$04 (CLEAR/RESET EMISSION-RELATED DIAGNOSTIC INFORMATION)**

Refers to the mode used to clear or reset emission-related diagnostic information (OBD-II trouble diagnostic information).

**NOTE:**

Refer to OBD-II general scan tool manufacturer's instruction manual to clear or reset emission-related diagnostic information (MODE \$04).

# SUBARU SELECT MONITOR


ENGINE (DIAGNOSTICS)

## 10. Subaru Select Monitor

### A: OPERATION


#### 1. HOW TO USE SUBARU SELECT MONITOR

1) Prepare the Subaru Select Monitor kit. <Ref. to EN(DOHC TURBO)-8, PREPARATION TOOL, General Description.>




2) Connect the diagnosis cable to Subaru Select Monitor.

3) Insert the cartridge into Subaru Select Monitor. <Ref. to EN(DOHC TURBO)-8, PREPARATION TOOL, General Description.>



4) Connect the Subaru Select Monitor to data link connector.

(1) Data link connector located in the lower portion of the instrument panel (on the driver's side).




(2) Connect the diagnosis cable to data link connector.

#### CAUTION:

Do not connect scan tools except for Subaru Select Monitor and OBD-II general scan tool.

5) Turn the ignition switch to ON (engine OFF) and Subaru Select Monitor switch to ON.



6) Using the Subaru Select Monitor, call up diagnostic trouble code(s) and various data, then record them.

#### 2. READ DIAGNOSTIC TROUBLE CODE (DTC) FOR ENGINE. (NORMAL MODE)

Refer to Read Diagnostic Trouble Code for information about how to indicate DTC. <Ref. to EN(DOHC TURBO)-45, Read Diagnostic Trouble Code.>

#### 3. READ DIAGNOSTIC TROUBLE CODE (DTC) FOR ENGINE. (OBD MODE)

Refer to Read Diagnostic Trouble Code for information about how to indicate DTC. <Ref. to EN(DOHC TURBO)-45, Read Diagnostic Trouble Code.>

## 4. READ CURRENT DATA FOR ENGINE. (NORMAL MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
  - 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
  - 3) Press the [YES] key after displayed the information of engine type.
  - 4) On the «Engine Diagnosis» display screen, select the {Current Data Display & Save} and press the [YES] key.
  - 5) On the «Data Display Menu» display screen, select the {Data Display} and press the [YES] key.
  - 6) Using the scroll key, move the display screen up or down until the desired data is shown.
- A list of the support data is shown in the following table.

Contents	Display	Unit of measure
Battery voltage	Battery Voltage	V
Vehicle speed signal	Vehicle Speed	km/h or MPH
Engine speed signal	Engine Speed	rpm
Engine coolant temperature signal	Coolant Temp.	°C or °F
Ignition timing signal	Ignition Timing	deg
Throttle position signal	Throttle Opening Angle	%
Throttle position signal	Throttle Sensor Voltage	V
Injection pulse width	Fuel Injection #1 Pulse	ms
Idle air control signal	ISC Valve Duty Ratio	%
Fuel pump duty control signal	Fuel Pump Duty	%
A/F sensor current	A/F Sensor #1 Current	mA
A/F sensor resistance	A/F Sensor #1 Resistance	Ω
Front oxygen (A/F) sensor output signal	A/F Sensor #1	—
Rear oxygen sensor output signal	Rear O2 Sensor	V
Short term fuel trim	A/F Correction #1	%
Knock sensor signal	Knocking Correction	deg
Atmospheric absolute pressure signal	Atmosphere Pressure	mmHg or kPa or inHg or psi
Intake manifold relative pressure signal	Mani. Relative Pressure	mmHg or kPa or inHg or psi
Intake manifold absolute pressure signal	Mani. Absolute Pressure	mmHg or kPa or inHg or psi
A/F correction (short term fuel trim) by rear oxygen sensor	A/F Correction #3	%
Long term whole fuel trim	A/F Learning #1	%
Front oxygen (A/F) sensor heater current	A/F Heater Current 1	A
Rear oxygen sensor heater voltage	Rear O2 Heater Voltage	V
Canister purge control solenoid valve duty ratio	CPC Valve Duty Ratio	%
Primary supercharged pressure control signal	Primary Control	%
Tumble generator valve position sensor signal (right side)	TGV Position Sensor R	V
Tumble generator valve position sensor signal (left side)	TGV Position Sensor L	V
Tumble generator valve drive signal	TGV Drive	OPEN or CLOSE
Fuel level signal	Fuel Level	V
Intake air temperature signal	Intake Air Temp.	°C or °F
Learned ignition timing	Learned Ignition Timing	deg
Mass air flow sensor signal	Mass Air Flow	g/s
Mass air flow sensor signal	Air Flow Sensor Voltage	V
Fuel tank pressure signal	Fuel Tank Pressure	mmHg or kPa or inHg or psi
Fuel temperature signal	Fuel Temp	°C or °F
Exhaust gas temperature signal	Exhaust Gas Temperature	°C or °F
MT/AT identification signal	AT Vehicle ID Signal	ON or OFF
Fuel pressure control solenoid valve signal	PCV Solenoid Valve	ON or OFF

# SUBARU SELECT MONITOR

## ENGINE (DIAGNOSTICS)

Contents	Display	Unit of measure
Drain valve signal	Vent. Solenoid Valve	ON or OFF
Ignition switch signal	Ignition Switch	ON or OFF
Test mode connector signal	Test Mode Signal	ON or OFF
Neutral position switch signal	Neutral Position Switch	ON or OFF
Air conditioning switch signal	A/C Switch	ON or OFF
Air conditioning signal	A/C Compressor Signal	ON or OFF
Radiator main fan relay signal	Radiator Fan Relay #1	ON or OFF
Fuel pump relay signal	Fuel Pump Relay	ON or OFF
Knocking signal	Knocking Signal	ON or OFF
Radiator sub fan relay signal	Radiator Fan Relay #2	ON or OFF
Power steering switch signal	P/S Switch	ON or OFF
Engine torque control signal #1	Torque Control Signal #1	ON or OFF
Engine torque control signal #2	Torque Control Signal #2	ON or OFF
Engine torque control permission signal	Torque Permission Signal	ON or OFF
Rear oxygen sensor rich signal	Rear O2 Rich Signal	ON or OFF
Starter switch signal	Starter Switch	ON or OFF
Idle switch signal	Idle Switch	ON or OFF
Crankshaft position sensor signal	Crankshaft Position Sig.	ON or OFF
Camshaft position sensor signal	Camshaft Position Sig.	ON or OFF
Rear defogger switch signal	Rear Defogger SW	ON or OFF
Blower fan switch signal	Blower Fan SW	ON or OFF
Small light switch signal	Light Switch	ON or OFF
Tumble generator valve output signal	TGV Output	ON or OFF

### NOTE:

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

## 5. READ CURRENT DATA FOR ENGINE. (OBD MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
  - 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
  - 3) Press the [YES] key after displayed the information of engine type.
  - 4) On the «Engine Diagnosis» display screen, select the {OBD System} and press the [YES] key.
  - 5) On the «OBD Menu» display screen, select the {Current Data Display & Save} and press the [YES] key.
  - 6) On the «Data Display Menu» display screen, select the {Data Display} and press the [YES] key.
  - 7) Using the scroll key, move the display screen up or down until the desired data is shown.
- A list of the support data is shown in the following table.

Contents	Display	Unit of measure
Number of diagnosis code	Number of Diagnosis Code	—
Malfunction indicator lamp status	MI (MIL)	ON or OFF
Monitoring test of misfire	Misfire monitoring	Complete or incomplete
Monitoring test of fuel system	Fuel system monitoring	Complete or incomplete
Monitoring test of comprehensive component	Component monitoring	Complete or incomplete
Test of catalyst	Catalyst Diagnosis	Complete or incomplete
Test of heated catalyst	Heated catalyst	No support
Test of evaporative emission purge control system	Evaporative purge system	Complete or incomplete
Test of secondary air system	Secondary air system	No support
Test of air conditioning system refrigerant	A/C system refrigerant	No support
Test of oxygen sensor	Oxygen sensor	Complete or incomplete
Test of oxygen sensor heater	O2 Heater Diagnosis	Complete or incomplete
Test of EGR system	EGR system	No support
Air fuel ratio control system for bank 1	Fuel System for Bank 1	—
Engine load data	Calculated load value	%
Engine coolant temperature signal	Coolant Temp.	°C or °F
Short term fuel trim by front oxygen (A/F) sensor	Short term fuel trim B1	%
Long term fuel trim by front oxygen (A/F) sensor	Long term fuel trim B1	%
Intake manifold absolute pressure signal	Mani. Absolute Pressure	mmHg or kPa or inHg or psi
Engine speed signal	Engine Speed	rpm
Vehicle speed signal	Vehicle Speed	km/h or MPH
Ignition timing advance for #1 cylinder	Ignition timing adv. #1	°
Intake air temperature signal	Intake Air Temp.	°C or °F
Intake air amount	Mass Air Flow	g/s
Throttle position signal	Throttle Opening Angle	%
A/F sensor signal	A/F sensor #11	V
Rear oxygen sensor output signal	Oxygen Sensor #12	V
Air fuel ratio correction by rear oxygen sensor	Short term fuel trim #12	%
On-board diagnostic system	OBD System	—

**NOTE:**

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

# SUBARU SELECT MONITOR

## ENGINE (DIAGNOSTICS)

### 6. READ FREEZE FRAME DATA FOR ENGINE. (OBD MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
  - 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
  - 3) Press the [YES] key after displayed the information of engine type.
  - 4) On the «Engine Diagnosis» display screen, select the {OBD System} and press the [YES] key.
  - 5) On the «OBD Menu» display screen, select the {Freeze Frame Data} and press the [YES] key.
- A list of the support data is shown in the following table.

Contents	Display	Unit of measure
Diagnostic trouble code (DTC) for freeze frame data	Freeze frame data	DTC
Air fuel ratio control system for bank 1	Fuel system for Bank1	ON or OFF
Engine load data	Calculated load valve	%
Engine coolant temperature signal	Coolant Temp.	°C or °F
Short term fuel trim by front oxygen (A/F) sensor	Short term fuel trim B1	%
Long term fuel trim by front oxygen (A/F) sensor	Long term fuel trim B1	%
Intake manifold absolute pressure signal	Mani. Absolute Pressure	mmHg or kPa or inHg or psi
Engine speed signal	Engine Speed	rpm
Vehicle speed signal	Vehicle Speed	km/h or MPH

#### NOTE:

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

**7. LED OPERATION MODE FOR ENGINE**

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
  - 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
  - 3) Press the [YES] key after displayed the information of engine type.
  - 4) On the «Engine Diagnosis» display screen, select the {Current Data Display & Save} and press the [YES] key.
  - 5) On the «Data Display Menu» display screen, select the {Data & LED Display} and press the [YES] key.
  - 6) Using the scroll key, move the display screen up or down until the desired data is shown.
- A list of the support data is shown in the following table.

Contents	Display	Message	LED "ON" requirements
Ignition switch signal	Ignition Switch	ON or OFF	When ignition switch is turned ON.
Test mode connector signal	Test Mode Signal	ON or OFF	When test mode connector is connected.
Neutral position switch signal	Neutral Position Switch	ON or OFF	When neutral position signal is entered.
Air conditioning switch signal	A/C Switch	ON or OFF	When air conditioning switch is turned ON.
Air conditioning relay signal	A/C Compressor Signal	ON or OFF	When air conditioning compressor is in function.
Radiator main fan relay signal	Radiator Fan Relay #1	ON or OFF	When radiator main fan relay is in function.
Knocking signal	Knocking Signal	ON or OFF	When knocking signal is entered.
Radiator sub fan relay signal	Radiator Fan Relay #2	ON or OFF	When radiator sub fan relay is in function.
Engine torque control signal #1	Torque Control Signal #1	ON or OFF	When engine torque control signal 1 is entered.
Engine torque control signal #2	Torque Control Signal #2	ON or OFF	When engine torque control signal 2 is entered.
Engine torque control permission signal	Torque Control Permission	ON or OFF	When engine torque control permission signal is entered.
Rear oxygen sensor rich signal	Rear O2 Rich Signal	ON or OFF	When rear oxygen sensor mixture ratio is rich.
Starter switch signal	Starter Switch	ON or OFF	When starter switch signal is entered.
Idle switch signal	Idle Switch Signal	ON or OFF	When idle switch signal is entered.
Crankshaft position sensor signal	Crankshaft Position Signal	ON or OFF	When crankshaft position sensor signal is entered.
Camshaft position sensor signal	Camshaft Position Signal	ON or OFF	When camshaft position sensor signal is entered.
Power steering switch signal	P/S Switch	ON or OFF	When power steering switch is entered.
Rear defogger switch signal	Rear Defogger Switch	ON or OFF	When rear defogger switch is turned ON.
Blower fan switch signal	Blower Fan Switch	ON or OFF	When blower fan switch is turned ON.
Light switch signal	Light Switch	ON or OFF	When small light switch is turned ON.
Tumble generator valve actuator signal	TGV Output	ON or OFF	When TGV actuator signal is entered.
Tumble generator valve drive signal	TGV Drive	OPEN or CLOSE	When TGV moves and valve opens.
Fuel pressure control solenoid valve signal	PCV Solenoid Valve	ON or OFF	When fuel pressure control solenoid valve is in function.
Drain valve signal	Vent. Solenoid Valve	ON or OFF	When drain valve is in function.

**NOTE:**

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

# SUBARU SELECT MONITOR

## ENGINE (DIAGNOSTICS)

### 8. READ CURRENT DATA FOR AT

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
  - 2) On the «System Selection Menu» display screen, select the {Transmission Control System} and press the [YES] key.
  - 3) Press the [YES] key after displayed the information of transmission type.
  - 4) On the «Transmission Diagnosis» display screen, select the {Current Data Display & Save} and press the [YES] key.
  - 5) On the «Data Display Menu» display screen, select the {Data Display} and press the [YES] key.
  - 6) Using the scroll key, move the display screen up or down until the desired data is shown.
- A list of the support data is shown in the following table.

Contents	Display	Unit of measure
Battery voltage	Battery Voltage	V
Rear vehicle speed sensor signal	Rear Wheel Speed	km/h or MPH
Front vehicle speed sensor signal	Front Wheel Speed	km/h or MPH
Engine speed signal	Engine Speed	rpm
Automatic transmission fluid temperature signal	ATF Temp.	°C or °F
Mass air flow sensor signal	Air Flow Sensor Voltage	V
Throttle position signal	Throttle Sensor Voltage	V
Gear position	Gear Position	—
Line pressure control duty ratio	Line Pressure Duty Ratio	%
Lock up clutch control duty ratio	Lock Up Duty Ratio	%
Transfer clutch control duty ratio	Transfer Duty Ratio	%
Power supply for throttle position sensor	Throttle Sensor Power	V
Torque converter turbine speed signal	Turbine Revolution Speed	rpm
2-4 brake timing pressure control duty ratio	Brake Clutch Duty Ratio	%
Stop lamp switch signal	Stop Light Switch	ON or OFF
Anti lock brake system signal	ABS Signal	ON or OFF
Cruise control system signal	Cruise Control Signal	ON or OFF
Neutral/Parking range signal	N/P Range Signal	ON or OFF
Reverse range signal	R Range Signal	ON or OFF
Drive range signal	D Range Signal	ON or OFF
3rd range signal	3rd Range Signal	ON or OFF
2nd range signal	2nd Range Signal	ON or OFF
1st range signal	1st Range Signal	ON or OFF
Shift control solenoid A	Shift Solenoid #1	ON or OFF
Shift control solenoid B	Shift Solenoid #2	ON or OFF
Torque control output signal #1	Torque Control Signal #1	ON or OFF
Torque control output signal #2	Torque Control Signal #2	ON or OFF
Torque control cut signal	Torque Control Cut Sig.	ON or OFF
2-4 brake timing control solenoid valve	2-4 Brake Timing Sol.	ON or OFF
Low clutch timing control solenoid valve	Low Clutch Timing Sol.	ON or OFF
Automatic transmission diagnosis indicator lamp	Diagnosis Lamp	ON or OFF

**NOTE:**

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

## 11. Read Diagnostic Trouble Code

### A: OPERATION

#### 1. SUBARU SELECT MONITOR (NORMAL MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
- 3) Press the [YES] key after displayed the information of engine type.
- 4) On the «Engine Diagnosis» display screen, select the {Diagnostic Code(s) Display} and press the [YES] key.
- 5) On the «Diagnostic Code(s) Display» display screen, select the {Current Diagnostic Code(s)} or {History Diagnostic Code(s)} and press the [YES] key.

**NOTE:**

- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.
- For detailed concerning diagnostic trouble codes, refer to the List of Diagnostic Trouble Code (DTC). <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>

#### 2. SUBARU SELECT MONITOR (OBD MODE)

- 1) On the «Main Menu» display screen, select the {2. Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
- 3) Press the [YES] key after displayed the information of engine type.
- 4) On the «Engine Diagnosis» display screen, select the {OBD System} and press the [YES] key.
- 5) On the «OBD Menu» display screen, select the {Diagnosis Code(s) Display} and press the [YES] key.
- 6) Make sure that a diagnostic trouble code (DTC) is shown on the display screen.

**NOTE:**

- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.
- For detailed concerning diagnostic trouble codes, refer to the List of Diagnostic Trouble Code (DTC). <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>

#### 3. OBD-II GENERAL SCAN TOOL

Refers to data denoting emission-related powertrain diagnostic trouble codes.

For details concerning diagnostic trouble codes, refer to the List of Diagnostic Trouble Code (DTC). <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>

**NOTE:**

Refer to OBD-II general scan tool manufacturer's instruction manual to access emission-related powertrain diagnostic trouble codes (MODE \$03).

## 12. Inspection Mode


### A: OPERATION

#### 1. PREPARATION FOR THE INSPECTION MODE

Raise the vehicle using a garage jack and place on safety stands or drive the vehicle onto free rollers.

**WARNING:**

- Before raising the vehicle, ensure parking brakes are applied.
- Do not use a pantograph jack in place of a safety stand.
- Secure a rope or wire to the front and rear towing or tie-down hooks to prevent the lateral runout of front wheels.
- Do not abruptly depress/release the clutch pedal or accelerator pedal during works even when engine is operating at low speeds since this may cause the vehicle to jump off free rollers.
- In order to prevent the vehicle from slipping due to vibration, do not place any wooden blocks or similar items between the safety stands and the vehicle.
- Since the rear wheels will also rotate, do not place anything near them. Also, make sure that nobody goes in front of the vehicle.




#### 2. SUBARU SELECT MONITOR

After performing diagnostics and clearing the memory, check for any remaining unresolved trouble data.


- 1) Prepare the Subaru Select Monitor kit. <Ref. to EN(DOHC TURBO)-8, PREPARATION TOOL, General Description.>



- 2) Connect the diagnosis cable to Subaru Select Monitor.
- 3) Insert the cartridge into Subaru Select Monitor. <Ref. to EN(DOHC TURBO)-8, PREPARATION TOOL, General Description.>




- 4) Connect the test mode connector at the lower portion of instrument panel (on the driver's side), to the side of the center console box.



5) Connect the Subaru Select Monitor to data link connector.

(1) Connect the Subaru Select Monitor to data link connector located in the lower portion of the instrument panel (on the driver's side).




(2) Connect the diagnosis cable to data link connector.

**CAUTION:**

Do not connect scan tools except for Subaru Select Monitor and OBD-II general scan tool.

6) Turn the ignition switch to ON (engine OFF) and Subaru Select Monitor switch to ON.



7) On the «Main Menu» display screen, select the {2. Each System Check} and press the [YES] key.

8) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.

9) Press the [YES] key after displayed the information of engine type.

10) On the «Engine Diagnosis» display screen, select the {Dealer Check Mode Procedure} and press the [YES] key.

11) When the "Perform Inspection (Dealer Check Mode?)" is shown on the display screen, press the [YES] key.

12) Perform subsequent procedures as instructed on the display screen.

- If trouble still remains in the memory, the corresponding diagnostic trouble code (DTC) appears on the display screen.

**NOTE:**

- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

- For detailed concerning diagnostic trouble codes, refer to the List of Diagnostic Trouble Code (DTC). <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>


- Release the parking brake.

- The speed difference between front and rear wheels may light either the ABS warning light, but this indicates no malfunctions. When engine control diagnosis is finished, perform the ABS memory clearance procedure of self-diagnosis system.

### 3. OBD-II GENERAL SCAN TOOL

After performing the diagnostics and clearing the memory, check for any remaining unresolved trouble data:

1) Connect the test mode connector (A) at the lower side of the instrument panel (on the driver's side), to the side of the center console box.



# INSPECTION MODE


## ENGINE (DIAGNOSTICS)

---

2) Connect the OBD-II general scan tool to its data link connector in the lower portion of the instrument panel (on the driver's side).

**CAUTION:**

**Do not connect scan tools except for Subaru Select Monitor and OBD-II general scan tool.**



3) Start the engine.

**NOTE:**

Depress the clutch pedal when starting the engine.

4) Using the shift lever, turn the "N" position switch to ON.

5) Keep the engine speed in the 2,500 — 3,000 rpm range for 40 seconds.

6) Place the shift lever in the "1st" gear and drive the vehicle at 5 to 10 km/h (3 to 6 MPH).

**NOTE:**

The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunctions. When engine control diagnosis is finished, perform the ABS memory clearance procedure of self-diagnosis system.

7) Using the OBD-II general scan tool, check for diagnostic trouble code(s) and record the result(s).

**NOTE:**

- For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

- For detailed concerning diagnostic trouble codes, refer to the List of Diagnostic Trouble Code (DTC). <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>

## 13. Clear Memory Mode

### A: OPERATION

#### 1. SUBARU SELECT MONITOR (NORMAL MODE)

- 1) On the «Main Menu» display screen, select the {2. Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
- 3) Press the [YES] key after displayed the information of engine type.
- 4) On the «Engine Diagnosis» display screen, select the {Clear Memory} and press the [YES] key.
- 5) When the `Done' and `Turn Ignition Switch OFF' are shown on the display screen, turn the Subaru Select Monitor and ignition switch to OFF.

NOTE:

- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

#### 2. SUBARU SELECT MONITOR (OBD MODE)

- 1) On the «Main Menu» display screen, select the {2. Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
- 3) Press the [YES] key after displayed the information of engine type.
- 4) On the «Engine Diagnosis» display screen, select the {OBD System} and press the [YES] key.
- 5) On the «OBD Menu» display screen, select the {4. Diagnosis Code(s) Cleared} and press the [YES] key.
- 6) When the `Clear Diagnostic Code?' is shown on the display screen, press the [YES] key.
- 7) Turn the Subaru Select Monitor and ignition switch to OFF.

NOTE:

- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

#### 3. OBD-II GENERAL SCAN TOOL

For clear memory procedures using the OBD-II general scan tool, refer to the OBD-II General Scan Tool Instruction Manual.


# COMPULSORY VALVE OPERATION CHECK MODE

ENGINE (DIAGNOSTICS)

## 14. Compulsory Valve Operation Check Mode


### A: OPERATION

1) Prepare the Subaru Select Monitor kit. <Ref. to EN(DOHC TURBO)-8, PREPARATION TOOL, General Description.>




2) Connect the diagnosis cable to Subaru Select Monitor.

3) Insert the cartridge into Subaru Select Monitor. <Ref. to EN(DOHC TURBO)-8, PREPARATION TOOL, General Description.>




4) Connect the test mode connector (A) at the lower portion of instrument panel (on the driver's side), to the side of the center console box.



5) Connect the Subaru Select Monitor to data link connector.

(1) Connect the Subaru Select Monitor to data link connector located in the lower portion of the instrument panel (on the driver's side).




(2) Connect the diagnosis cable to data link connector.

### CAUTION:

**Do not connect scan tools except for Subaru Select Monitor and OBD-II general scan tool.**

6) Turn the ignition switch to ON (engine OFF) and Subaru Select Monitor switch to ON.



7) On the «Main Menu» display screen, select the {2. Each System Check} and press the [YES] key.

8) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.

9) Press the [YES] key after displayed the information of engine type.

10) On the «Engine Diagnosis» display screen, select the {System Operation Check Mode} and press the [YES] key.

11) On the «System Operation Check Mode» display screen, select the {Actuator ON/OFF Operation} and press the [YES] key.

12) Select the desired compulsory actuator on the «Actuator ON/OFF Operation» display screen and press the [YES] key.

13) Pressing the [NO] key completes the compulsory operation check mode. The display will then return to the «Actuator ON/OFF Operation» screen.

# COMPULSORY VALVE OPERATION CHECK MODE

ENGINE (DIAGNOSTICS)

- A list of the support data is shown in the following table.

Contents	Display
Compulsory fuel pump relay operation check	Fuel Pump Relay
Compulsory radiator fan relay operation check	Radiator Fan Relay
Compulsory air conditioning relay operation check	A/C Compressor Relay
Compulsory purge control solenoid valve operation check	CPC Solenoid Valve
Compulsory fuel pressure control solenoid valve operation check	PCV Solenoid Valve
Compulsory drain valve operation check	Vent Control Solenoid Valve
Compulsory fuel tank pressure sensor control valve operation check	Fuel Tank Sensor Control Valve

## NOTE:

- The following parts will be displayed but not functional because they are not installed on the vehicle.

Display
EGR Solenoid Valve
ASV Solenoid Valve
FICD Solenoid
Pressure Switching Sol. 1
Pressure Switching Sol. 2
AAI Solenoid Valve

- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

# ENGINE MALFUNCTION INDICATOR LAMP (MIL)

ENGINE (DIAGNOSTICS)

## 15. Engine Malfunction Indicator Lamp (MIL)

### A: PROCEDURE

1. Activation of check engine malfunction indicator lamp (MIL). <Ref. to EN(DOHC TURBO)-53, ACTIVATION OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL), Engine Malfunction Indicator Lamp (MIL).>
↓
2. Check engine malfunction indicator lamp (MIL) does not come on. <Ref. to EN(DOHC TURBO)-54, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) DOES NOT COME ON., Engine Malfunction Indicator Lamp (MIL).>
↓
3. Check engine malfunction indicator lamp (MIL) does not go off. <Ref. to EN(DOHC TURBO)-56, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) DOES NOT GO OFF., Engine Malfunction Indicator Lamp (MIL).>
↓
4. Check engine malfunction indicator lamp (MIL) does not blink at a cycle of 3 Hz. <Ref. to EN(DOHC TURBO)-57, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) DOES NOT BLINK AT A CYCLE OF 3 HZ., Engine Malfunction Indicator Lamp (MIL).>
↓
5. Check engine malfunction indicator lamp (MIL) remains blinking at a cycle of 3 Hz. <Ref. to EN(DOHC TURBO)-60, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) REMAINS BLINKING AT A CYCLE OF 3 HZ., Engine Malfunction Indicator Lamp (MIL).>



### B: ACTIVATION OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL)

1) When the ignition switch is turned to ON (engine off), the CHECK ENGINE malfunction indicator lamp (MIL) in the combination meter illuminates.


**NOTE:**

If the MIL does not illuminate, perform diagnostics of the CHECK ENGINE light circuit or the combination meter circuit. <Ref. to EN(DOHC TURBO)-54, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) DOES NOT COME ON., Engine Malfunction Indicator Lamp (MIL).>


4) When the ignition switch is turned to ON (engine off) or to "START" with the test mode connector connected, the MIL blinks at a cycle of 3 Hz.



2) After starting the engine, the MIL goes out. If it does not, either the engine or the emission control system is malfunctioning.



3) If the diagnosis system senses a misfire which could damage the catalyzer, the MIL will blink at a cycle of 1 Hz.





# ENGINE MALFUNCTION INDICATOR LAMP (MIL)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>CHECK POOR CONTACT.</b>	Does the MIL come on when shaking or pulling ECM connector and harness?	Repair poor contact in ECM connector.	Go to step 3.
<b>CHECK ECM CONNECTOR.</b>	Is the ECM connector correctly connected?	Replace the ECM. Ref. to FU(DOHC TURBO)-47, Engine Control Module.>	Repair connection of ECM connector.
<b>CHECK HARNESS BETWEEN COMBINATION METER AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Remove the combination meter. <Ref. to IDI-11, Combination Meter Assembly.> 3) Disconnect the connector from ECM and combination meter. 4) Measure the resistance of harness between ECM and combination meter connector. <b>Connector &amp; terminal</b> <b>(B137) No. 15 — (i12) No. 6:</b>	Is the resistance less than 1 Ω?	Go to step 5.	Repair harness and connector. <b>NOTE:</b> In this case, repair the following: • Open circuit in harness between ECM and combination meter connector • Poor contact in coupling connector
<b>CHECK POOR CONTACT.</b> Check poor contact in combination meter connector.	Is there poor contact in combination meter connector?	Repair poor contact in combination meter connector.	Go to step 6.
<b>CHECK HARNESS BETWEEN COMBINATION METER AND IGNITION SWITCH CONNECTOR.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between combination meter connector and chassis ground. <b>Connector &amp; terminal</b> <b>(i10) No. 7 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V?	Go to step 7.	Check the following and repair if necessary. <b>NOTE:</b> • Broken down ignition relay. • Blown out fuse (No. 5). • If replaced fuse (No. 5) blows easily, check the harness for short circuit of harness between fuse (No. 5) and ignition relay connector. • Open or short circuit in harness between fuse (No. 5) and battery terminal • Open circuit in harness between fuse (No. 5) and ignition relay connector • Poor contact in ignition relay connector • Poor contact in ignition switch connector
<b>CHECK LAMP BULB.</b> Remove the engine malfunction indicator lamp bulb.	Is the lamp bulb condition OK?	Repair combination meter connector.	Replace the lamp bulb.

# ENGINE MALFUNCTION INDICATOR LAMP (MIL)

## ENGINE (DIAGNOSTICS)

### D: CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) DOES NOT GO OFF.


**DIAGNOSIS:**

- The CHECK ENGINE malfunction indicator lamp (MIL) circuit is shorted.

**TROUBLE SYMPTOM:**

- Although MIL comes on when the engine runs, trouble code is not shown on the Subaru select monitor or OBD-II general scan tool display.

**WIRING DIAGRAM:**



EN1137

Step	Check	Yes	No	
1	<b>CHECK HARNESS BETWEEN COMBINATION METER AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Turn the ignition switch to ON.	Does the MIL come on?	Repair short circuit in harness between combination meter and ECM connector.	Replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>

## **E: CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) DOES NOT BLINK AT A CYCLE OF 3 HZ.**

- **DIAGNOSIS:**

- The CHECK ENGINE malfunction indicator lamp (MIL) circuit is open or shorted.
- Test mode connector circuit is in open.



- **TROUBLE SYMPTOM:**

- When in inspection mode, MIL does not blink at a cycle of 3 Hz.

# ENGINE MALFUNCTION INDICATOR LAMP (MIL)

ENGINE (DIAGNOSTICS)

• WIRING DIAGRAM:



EN1138

# ENGINE MALFUNCTION INDICATOR LAMP (MIL)

ENGINE (DIAGNOSTICS)



Step	Check	Yes	No
<b>1 CHECK STATUS OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL).</b> 1) Turn the ignition switch to OFF. 2) Disconnect the test mode connector. 3) Turn the ignition switch to ON. (engine OFF)	Does the MIL come on?	Go to step 2.	Repair the MIL circuit. <Ref. to EN(DOHC TURBO)-54, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) DOES NOT COME ON., Engine Malfunction Indicator Lamp (MIL).>
<b>2 CHECK HARNESS BETWEEN COMBINATION METER AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Turn the ignition switch to ON.	Does the MIL come on?	Repair ground short circuit in harness between combination meter and ECM connector.	Go to step 3.
<b>3 CHECK HARNESS BETWEEN TEST MODE CONNECTOR AND CHASSIS GROUND.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between test mode connector and chassis ground. <i>Connector &amp; terminal (B76) No. 1 — Chassis ground:</i>	Is the resistance less than 1 $\Omega$ ?	Go to step 4.	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between test mode connector and chassis ground
<b>4 CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Go to step 5.
<b>5 CHECK HARNESS BETWEEN ECM AND TEST MODE CONNECTOR.</b> 1) Connect the test mode connector. 2) Measure the resistance of harness between ECM and chassis ground. <i>Connector &amp; terminal (B134) No. 14 — Chassis ground:</i>	Is the resistance less than 1 $\Omega$ ?	Go to step 6.	Repair open circuit in harness between ECM and test mode connector.
<b>6 CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>

# ENGINE MALFUNCTION INDICATOR LAMP (MIL)

ENGINE (DIAGNOSTICS)

## F: CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) REMAINS BLINKING AT A CYCLE OF 3 HZ.

- **DIAGNOSIS:**
  - Test mode connector circuit is shorted.
- **TROUBLE SYMPTOM:**
  - MIL blinks at a cycle of 3 Hz when the ignition switch is turned to ON.
- **WIRING DIAGRAM:**



EN1138

# ENGINE MALFUNCTION INDICATOR LAMP (MIL)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<b>CHECK TEST MODE CONNECTOR.</b> 1) Disconnect the test mode connector. 2) Turn the ignition switch to ON.	Does the MIL flash on and off?	Go to step 2.	System is in good order. <b>NOTE:</b> MIL blinks at a cycle of 3 Hz when test mode connector is connected.
2	<b>CHECK HARNESS BETWEEN ECM CONNECTOR AND ENGINE GROUNDING TERMINAL.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B134) No. 14 — Chassis ground:</b>	Is the resistance less than 5 $\Omega$ ?	Repair short circuit in harness between ECM and test mode connector.	Replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>

# ENGINE MALFUNCTION INDICATOR LAMP (MIL)

ENGINE (DIAGNOSTICS)

---

EN(DOHC TURBO)-62

## 16. Diagnostics for Engine Starting Failure

### A: PROCEDURE

1. Inspection of starter motor circuit. <Ref. to EN(DOHC TURBO)-64, STARTER MOTOR CIRCUIT, Diagnostics for Engine Starting Failure.>
↓
2. Inspection of ECM power supply and ground line. <Ref. to EN(DOHC TURBO)-68, CONTROL MODULE POWER SUPPLY AND GROUND LINE, Diagnostics for Engine Starting Failure.>
↓
3. Inspection of ignition control system. <Ref. to EN(DOHC TURBO)-72, IGNITION CONTROL SYSTEM, Diagnostics for Engine Starting Failure.>
↓
4. Inspection of fuel pump circuit. <Ref. to EN(DOHC TURBO)-76, FUEL PUMP CIRCUIT, Diagnostics for Engine Starting Failure.>
↓
5. Inspection of fuel injector circuit. <Ref. to EN(DOHC TURBO)-78, FUEL INJECTOR CIRCUIT, Diagnostics for Engine Starting Failure.>

# DIAGNOSTICS FOR ENGINE STARTING FAILURE



## ENGINE (DIAGNOSTICS)

### B: STARTER MOTOR CIRCUIT

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to EN(DOHC TURBO)-49, Clear Memory Mode.> and INSPECTION MODE <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• WIRING DIAGRAM:



EN1139

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1</b>	<b>CHECK OPERATION OF STARTER MOTOR.</b> Does the starter motor operate when the switch starts?	Go to step 2.	Go to step 3.
<b>2</b>	<b>CHECK DTC.</b> <Ref. to EN(DOHC TURBO)-45, OPERATION, Read Diagnostic Trouble Code.>	Record the DTC. Repair the trouble case. <Ref. to EN(DOHC TURBO)-80, LIST, List of Diagnostic Trouble Code (DTC).>	Go to step 3.
<b>3</b>	<b>CHECK INPUT SIGNAL FOR STARTER MOTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from starter motor. 3) Turn the ignition switch to ST. 4) Measure the power supply voltage between starter motor connector terminal and engine ground. <b>Connector &amp; terminal</b> <b>(B14) No. 1 (+) — Engine ground (-):</b>	Is the voltage more than 10 V?	Go to step 4.
<b>4</b>	<b>CHECK GROUND CIRCUIT OF STARTER MOTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the terminal from starter motor. 3) Measure the resistance of ground cable between ground cable terminal and engine ground.	Is the resistance less than 5 Ω?	Go to step 4.
<b>5</b>	<b>CHECK HARNES BETWEEN ECM AND STARTER MOTOR CIRCUIT.</b> 1) Turn the ignition switch to OFF. 2) Measure the resistance between starter motor and ECM. <b>Connector &amp; terminal</b> <b>(B14) No. 1 — Engine ground:</b>	Is the resistance less than 1 Ω?	Repair ground short circuit.
<b>6</b>	<b>CHECK HARNES BETWEEN ECM AND STARTER MOTOR CIRCUIT.</b> 1) Turn the ignition switch to START. 2) Measure the resistance of fuse. <b>Connector &amp; terminal</b> <b>(B14) No. 1 — Engine ground:</b>	Is the resistance less than 1 Ω?	Go to step 7.
<b>7</b>	<b>CHECK HARNES BETWEEN BATTERY AND IGNITION SWITCH CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ignition switch. 3) Measure the power supply voltage between ignition switch the connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B72) No. 1 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V?	Go to step 8.
<b>8</b>	<b>CHECK HARNES BETWEEN BATTERY AND IGNITION SWITCH CONNECTOR.</b> 1) Connect the connector to ignition switch. 2) Turn the ignition switch to START. 3) Measure the voltage between ignition switch and chassis ground. <b>Connector &amp; terminal</b> <b>(B72) No. 3 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V?	Repair open circuit between ignition switch and starter motor circuit.

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

## ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
9	<b>CHECK POOR CONTACT.</b> Check poor contact in ignition switch connector.	Is there poor contact in ignition switch connector?	Repair poor contact in ignition switch connector.	Replace the ignition switch.

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

---

EN(DOHC TURBO)-67

# DIAGNOSTICS FOR ENGINE STARTING FAILURE








ENGINE (DIAGNOSTICS)

## C: CONTROL MODULE POWER SUPPLY AND GROUND LINE

### CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to EN(DOHC TURBO)-49, Clear Memory Mode.> and INSPECTION MODE. <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>

### • WIRING DIAGRAM:



EN1171

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>CHECK MAIN RELAY.</b>                      1) Turn the ignition switch to OFF.                      2) Remove the main relay.                      3) Connect the battery to main relay terminals No. 1 and No. 2.                      4) Measure the resistance between main relay terminals.</p> <p><b>Terminals</b>  <b>No. 3 — No. 5:</b>  <b>No. 4 — No. 6:</b></p>	Is the resistance less than 10 Ω?	Go to step 2.	Replace the main relay.
<p><b>CHECK GROUND CIRCUIT OF ECM.</b>                      1) Disconnect the connector from ECM.                      2) Measure the resistance of harness between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B134) No. 7 — Chassis ground:</b>  <b>(B134) No. 15 — Chassis ground:</b>  <b>(B134) No. 22 — Chassis ground:</b>  <b>(B136) No. 8 — Chassis ground:</b>  <b>(B136) No. 17 — Chassis ground:</b>  <b>(B136) No. 18 — Chassis ground:</b>  <b>(B137) No. 8 — Chassis ground:</b>  <b>(B137) No. 9 — Chassis ground:</b>  <b>(B84) No. 1 — Chassis ground: (MT vehicle)</b></p>	Is the resistance less than 5 Ω?	Go to step 3.	Repair open circuit in harness between ECM connector and engine grounding terminal.
<p><b>CHECK INPUT VOLTAGE OF ECM.</b>                      Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B137) No. 10 (+) — Chassis ground (-):</b>  <b>(B134) No. 5 (+) — Chassis ground (-):</b></p>	Is the voltage more than 10 V?	Go to step 4.	Repair open or ground short circuit of power supply circuit.
<p><b>CHECK HARNESS BETWEEN ECM AND MAIN RELAY CONNECTOR.</b>                      1) Turn the ignition switch to OFF.                      2) Disconnect the connector from ECM.                      3) Measure the resistance between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B134) No. 6 — Chassis ground:</b></p>	Is the resistance more than 1 Ω?	Go to step 5.	Repair ground short circuit in harness between ECM connector and main relay connector, then replace the ECM.
<p><b>CHECK OUTPUT VOLTAGE FROM ECM.</b>                      1) Connect the connector to ECM.                      2) Turn the ignition switch to ON.                      3) Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B134) No. 6 (+) — Chassis ground (-):</b></p>	Is the voltage more than 10 V?	Go to step 6.	Replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>
<p><b>CHECK INPUT VOLTAGE OF MAIN RELAY.</b>                      Check the voltage between main relay connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B47) No. 2 (+) — Chassis ground (-):</b></p>	Is the voltage more than 10 V?	Go to step 7.	Repair open circuit in harness between ECM connector and main relay connector.
<p><b>CHECK GROUND CIRCUIT OF MAIN RELAY.</b>                      1) Turn the ignition switch to OFF.                      2) Measure the resistance between main relay connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B47) No. 1 — Chassis ground:</b></p>	Is the resistance less than 5 Ω?	Go to step 8.	Repair open circuit between main relay and chassis ground.

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>8</b> <b>CHECK INPUT VOLTAGE OF MAIN RELAY.</b> Measure the voltage between main relay connector and chassis ground. <i><b>Connector &amp; terminal</b></i> <i><b>(B47) No. 5 (+) — Chassis ground (-):</b></i> <i><b>(B47) No. 6 (+) — Chassis ground (-):</b></i>	Is the voltage more than 10 V?	Go to step 9.	Repair open or ground short circuit in harness of power supply circuit.
<b>CHECK INPUT VOLTAGE OF ECM.</b> 1)Connect the main relay connector. 2)Turn the ignition switch to ON. 3)Measure the voltage between ECM connector and chassis ground. <i><b>Connector &amp; terminal</b></i> <i><b>(B137) No. 2 (+) — Chassis ground (-):</b></i> <i><b>(B137) No. 3 (+) — Chassis ground (-):</b></i>	Is the voltage more than 10 V?	Check ignition control system. <Ref. to EN(DOHC TURBO)-72, IGNITION CONTROL SYSTEM, Diagnostics for Engine Starting Failure.>	Repair open or ground short circuit in harness between ECM connector and main relay connector.

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

---

EN(DOHC TURBO)-71

# DIAGNOSTICS FOR ENGINE STARTING FAILURE


## ENGINE (DIAGNOSTICS)

### D: IGNITION CONTROL SYSTEM

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to EN(DOHC TURBO)-49, Clear Memory Mode.> and INSPECTION MODE <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>

• WIRING DIAGRAM:



# DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>CHECK SPARK PLUG CONDITION.</b>                      1) Remove the spark plug. &lt;Ref. to IG(DOHC TURBO)-5, INSTALLATION, Spark Plug.&gt;                      2) Check the spark plug condition. &lt;Ref. to IG(DOHC TURBO)-6, INSPECTION, Spark Plug.&gt;</p>	Is the spark plug's status OK?	Go to step 2.	Replace the spark plug.
<p><b>CHECK IGNITION SYSTEM FOR SPARKS.</b>                      1) Connect the spark plug to ignition coil.                      2) Release the fuel pressure. &lt;Ref. to FU(DOHC TURBO)-51, RELEASING OF FUEL PRESSURE, OPERATION, Fuel.&gt;                      3) Contact the spark plug's thread portion on engine.                      4) While opening the throttle valve fully, crank the engine to check that spark occurs at each cylinder.</p>	Does spark occur at each cylinder?	Check fuel pump system. <Ref. to EN(DOHC TURBO)-76, FUEL PUMP CIRCUIT, Diagnostics for Engine Starting Failure.>	Go to step 3.
<p><b>CHECK POWER SUPPLY CIRCUIT FOR IGNITION COIL &amp; IGNITOR ASSEMBLY.</b>                      1) Turn the ignition switch to OFF.                      2) Disconnect the connector from ignition coil &amp; ignitor assembly.                      3) Turn the ignition switch to ON.                      4) Measure the power supply voltage between ignition coil &amp; ignitor assembly connector and engine ground.</p> <p><b>Connector &amp; terminal</b>                      (E31) No. 3 (+) — Engine ground (-):                      (E32) No. 3 (+) — Engine ground (-):                      (E33) No. 3 (+) — Engine ground (-):                      (E34) No. 3 (+) — Engine ground (-):</p>	Is the voltage more than 10 V?	Go to step 4.	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between ignition coil & ignitor assembly, and ignition switch connector • Poor contact in coupling connectors
<p><b>CHECK HARNESS OF IGNITION COIL &amp; IGNITOR ASSEMBLY GROUND CIRCUIT.</b>                      1) Turn the ignition switch to OFF.                      2) Measure the resistance between ignition coil &amp; ignitor assembly connector and engine ground.</p> <p><b>Connector &amp; terminal</b>                      (E31) No. 2 — Engine ground:                      (E32) No. 2 — Engine ground:                      (E33) No. 2 — Engine ground:                      (E34) No. 2 — Engine ground:</p>	Is the resistance between less than 5 Ω?	Go to step 5.	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between ignition coil & ignitor assembly connector and engine grounding terminal
<p><b>CHECK HARNESS BETWEEN ECM AND IGNITION COIL &amp; IGNITOR ASSEMBLY CONNECTOR.</b>                      1) Turn the ignition switch to OFF.                      2) Disconnect the connector from ECM.                      3) Disconnect the connector from ignition coil &amp; ignitor assembly.                      4) Measure the resistance of harness between ECM and ignition coil &amp; ignitor assembly connector.</p> <p><b>Connector &amp; terminal</b>                      (B136) No. 21 — (E34) No. 1:                      (B136) No. 22 — (E33) No. 1:                      (B136) No. 23 — (E32) No. 1:                      (B136) No. 24 — (E31) No. 1:</p>	Is the resistance less than 1 Ω?	Go to step 6.	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between ECM and ignition coil & ignitor assembly connector • Poor contact in coupling connectors

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

## ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
6	<b>CHECK HARNESS BETWEEN ECM AND IGNITION COIL &amp; IGNITOR ASSEMBLY CONNECTOR.</b> Measure the resistance of harness between ECM and engine ground. <b>Connector &amp; terminal:</b> <b>(B136) No. 21 — Engine ground:</b> <b>(B136) No. 22 — Engine ground:</b> <b>(B136) No. 23 — Engine ground:</b> <b>(B136) No. 24 — Engine ground:</b>	Is the resistance more than 1 M $\Omega$ ?	Go to step 7.	Repair ground short circuit in harness between ECM and ignition coil & ignitor assembly connector.
7	<b>CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Replace the ignition coil and ignitor assembly.

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

---

EN(DOHC TURBO)-75

# DIAGNOSTICS FOR ENGINE STARTING FAILURE


ENGINE (DIAGNOSTICS)

## E: FUEL PUMP CIRCUIT

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to EN(DOHC TURBO)-49, Clear Memory Mode.> and INSPECTION MODE <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• WIRING DIAGRAM:



EN1141

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<p><b>CHECK OPERATING SOUND OF FUEL PUMP.</b> Make sure that fuel pump is in operation for two seconds when turning the ignition switch to ON.</p> <p>NOTE: Fuel pump operation can also be executed using Subaru Select Monitor (Function mode: FD01). For the procedure, refer to "Compulsory Valve Operation Check Mode". &lt;Ref. to EN(DOHC TURBO)-50, Compulsory Valve Operation Check Mode.&gt;</p>	Does the fuel pump produce operating sound?	Check the fuel injector circuit. <Ref. to EN(DOHC TURBO)-78, FUEL INJECTOR CIRCUIT, Diagnostics for Engine Starting Failure.>	Record the DTC. Repair the trouble case. <Ref. to EN(DOHC TURBO)-88, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>









# DIAGNOSTICS FOR ENGINE STARTING FAILURE

## ENGINE (DIAGNOSTICS)

### F: FUEL INJECTOR CIRCUIT

#### CAUTION:

- Check or repair only faulty parts.
- After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to EN(DOHC TURBO)-49, Clear Memory Mode.> and INSPECTION MODE. <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>
- WIRING DIAGRAM:



# DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No	
1	<p><b>CHECK OPERATION OF EACH FUEL INJECTOR.</b> While cranking the engine, check that each fuel injector emits "operating" sound. Use a sound scope or attach a screwdriver to the injector for this check.</p>	Is the fuel injector emits "operating" sound?	Check the fuel pressure. <Ref. to ME(DOHC TURBO)-27, INSPECTION, Fuel Pressure.>	Go to step 2.
2	<p><b>CHECK POWER SUPPLY TO EACH FUEL INJECTOR.</b> 1)Turn the ignition switch to OFF. 2)Disconnect the connector from #1 cylinder fuel injector. 3)Turn the ignition switch to ON. 4)Measure the power supply voltage between the fuel injector terminal and engine ground. <b>Connector &amp; terminal</b> #1 (E5) No. 2 (+) — Engine ground (-): #2 (E16) No. 2 (+) — Engine ground (-): #3 (E6) No. 2 (+) — Engine ground (-): #4 (E17) No. 2 (+) — Engine ground (-):</p>	Is the voltage more than 10 V?	Go to step 3.	<p>Repair harness and connector. <b>NOTE:</b> In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between main relay and fuel injector connector</li> <li>• Poor contact in main relay connector</li> <li>• Poor contact in coupling connector</li> <li>• Poor contact in fuel injector connector</li> </ul>
3	<p><b>CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b> 1)Disconnect the connector from ECM. 2)Measure the resistance of harness between ECM and fuel injector connector. <b>Connector &amp; terminal</b> (B137) No. 1 — (E5) No. 1: (B136) No. 6 — (E16) No. 1: (B136) No. 5 — (E6) No. 1: (B136) No. 4 — (E6) No. 1:</p>	Is the resistance less than 1 $\Omega$ ?	Go to step 4.	<p>Repair harness and connector. <b>NOTE:</b> In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and fuel injector connector</li> <li>• Poor contact in coupling connector</li> </ul>
4	<p><b>CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b> Measure the resistance of harness between ECM and fuel injector connector. <b>Connector &amp; terminal</b> (B137) No. 1 — Chassis ground: (B136) No. 6 — Chassis ground: (B136) No. 5 — Chassis ground: (B136) No. 4 — Chassis ground:</p>	Is the resistance less than 1 $\Omega$ ?	Repair ground short circuit in harness between ECM and fuel injector connector.	Go to step 5.
5	<p><b>CHECK EACH FUEL INJECTOR.</b> 1)Turn the ignition switch to OFF. 2)Measure the resistance between each fuel injector terminals. <b>Terminals</b> No. 1 — No. 2:</p>	Is the resistance between 5 and 20 $\Omega$ ?	Go to step 6.	Replace the faulty fuel injector.
6	<p><b>CHECK POOR CONTACT.</b> Check poor contact in ECM connector.</p>	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	<p>Inspection using "General Diagnostic Table". &lt;Ref. to EN(DOHC TURBO)-372, INSPECTION, General Diagnostic Table.&gt;</p>

# LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## 17. List of Diagnostic Trouble Code (DTC)

### A: LIST

DTC No.	Item	Index
P0031	Front oxygen (A/F) sensor heater circuit low input	<Ref. to EN(DOHC TURBO)-88, DTC P0031 — FRONT OXYGEN (A/F) SENSOR HEATER CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0032	Front oxygen (A/F) sensor heater circuit high input	<Ref. to EN(DOHC TURBO)-92, DTC P0032 — FRONT OXYGEN (A/F) SENSOR HEATER CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0037	Rear oxygen sensor heater circuit malfunction	<Ref. to EN(DOHC TURBO)-94, DTC P0037 — REAR OXYGEN SENSOR HEATER CIRCUIT MALFUNCTION —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0038	Rear oxygen sensor heater circuit high input	<Ref. to EN(DOHC TURBO)-98, DTC P0038 — REAR OXYGEN SENSOR HEATER CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0101	Mass air flow sensor circuit range/performance problem (high input)	<Ref. to EN(DOHC TURBO)-100, DTC P0101 — MASS AIR FLOW SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (HIGH INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0102	Mass air flow sensor circuit low input	<Ref. to EN(DOHC TURBO)-102, DTC P0102 — MASS AIR FLOW SENSOR CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0103	Mass air flow sensor circuit high input	<Ref. to EN(DOHC TURBO)-106, DTC P0103 — MASS AIR FLOW SENSOR CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0106	Pressure sensor circuit range/performance problem (low input)	<Ref. to EN(DOHC TURBO)-108, DTC P0106 — PRESSURE SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (LOW INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0107	Pressure sensor circuit low input	<Ref. to EN(DOHC TURBO)-110, DTC P0107 — PRESSURE SENSOR CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0108	Pressure sensor circuit high input	<Ref. to EN(DOHC TURBO)-114, DTC P0108 — PRESSURE SENSOR CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0111	Intake air temperature sensor circuit range/performance problem	<Ref. to EN(DOHC TURBO)-118, DTC P0111 — INTAKE AIR TEMPERATURE SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0112	Intake air temperature sensor circuit low input	<Ref. to EN(DOHC TURBO)-120, DTC P0112 — INTAKE AIR TEMPERATURE SENSOR CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0113	Intake air temperature sensor circuit high input	<Ref. to EN(DOHC TURBO)-122, DTC P0113 — INTAKE AIR TEMPERATURE SENSOR CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0117	Engine coolant temperature sensor circuit low input	<Ref. to EN(DOHC TURBO)-126, DTC P0117 — ENGINE COOLANT TEMPERATURE SENSOR CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0118	Engine coolant temperature sensor circuit high input	<Ref. to EN(DOHC TURBO)-128, DTC P0118 — ENGINE COOLANT TEMPERATURE SENSOR CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0121	Throttle position sensor circuit range/performance problem (high input)	<Ref. to EN(DOHC TURBO)-132, DTC P0121 — THROTTLE POSITION SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (HIGH INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0122	Throttle position sensor circuit low input	<Ref. to EN(DOHC TURBO)-134, DTC P0122 — THROTTLE POSITION SENSOR CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

DTC No.	Item	Index
P0123	Throttle position sensor circuit high input	<Ref. to EN(DOHC TURBO)-138, DTC P0123 — THROTTLE POSITION SENSOR CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0125	Insufficient coolant temperature for closed loop fuel control	<Ref. to EN(DOHC TURBO)-140, DTC P0125 — INSUFFICIENT COOLANT TEMPERATURE FOR CLOSED LOOP FUEL CONTROL —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0128	Thermostat malfunction	<Ref. to EN(DOHC TURBO)-142, DTC P0128 — THERMOSTAT MALFUNCTION —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0131	Front oxygen (A/F) sensor circuit range/performance problem (low input)	<Ref. to EN(DOHC TURBO)-143, DTC P0131 — FRONT OXYGEN (A/F) SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (LOW INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0132	Front oxygen (A/F) sensor circuit range/performance problem (high input)	<Ref. to EN(DOHC TURBO)-144, DTC P0132 — FRONT OXYGEN (A/F) SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (HIGH INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0133	Front oxygen (A/F) sensor circuit slow response	<Ref. to EN(DOHC TURBO)-146, DTC P0133 — FRONT OXYGEN (A/F) SENSOR CIRCUIT SLOW RESPONSE —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0136	Rear oxygen sensor circuit malfunction	<Ref. to EN(DOHC TURBO)-148, DTC P0136 — REAR OXYGEN SENSOR CIRCUIT MALFUNCTION —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0139	Rear oxygen sensor circuit slow response	<Ref. to EN(DOHC TURBO)-150, DTC P0139 — REAR OXYGEN SENSOR CIRCUIT SLOW RESPONSE —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0171	Fuel trim malfunction (A/F too lean)	<Ref. to EN(DOHC TURBO)-152, DTC P0171 — FUEL TRIM MALFUNCTION (A/F TOO LEAN) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0172	Fuel trim malfunction (A/F too rich)	<Ref. to EN(DOHC TURBO)-153, DTC P0172 — FUEL TRIM MALFUNCTION (A/F TOO RICH) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0181	Fuel temperature sensor A circuit range/performance problem	<Ref. to EN(DOHC TURBO)-156, DTC P0181 — FUEL TEMPERATURE SENSOR A CIRCUIT RANGE/PERFORMANCE PROBLEM —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0182	Fuel temperature sensor A circuit low input	<Ref. to EN(DOHC TURBO)-158, DTC P0182 — FUEL TEMPERATURE SENSOR A CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0183	Fuel temperature sensor A circuit high input	<Ref. to EN(DOHC TURBO)-160, DTC P0183 — FUEL TEMPERATURE SENSOR A CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0244	Wastegate control solenoid valve malfunction (high input)	<Ref. to EN(DOHC TURBO)-164, DTC P0244 — WASTEGATE CONTROL SOLENOID VALVE MALFUNCTION (HIGH INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0245	Wastegate control solenoid valve circuit low input	<Ref. to EN(DOHC TURBO)-166, DTC P0245 — WASTEGATE CONTROL SOLENOID VALVE CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0246	Wastegate control solenoid valve circuit high input	<Ref. to EN(DOHC TURBO)-170, DTC P0246 — WASTEGATE CONTROL SOLENOID VALVE CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0301	Cylinder 1 misfire detected	<Ref. to EN(DOHC TURBO)-172, DTC P0301 — CYLINDER 1 MISFIRE DETECTED —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0302	Cylinder 2 misfire detected	<Ref. to EN(DOHC TURBO)-172, DTC P0302 — CYLINDER 2 MISFIRE DETECTED —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0303	Cylinder 3 misfire detected	<Ref. to EN(DOHC TURBO)-172, DTC P0303 — CYLINDER 3 MISFIRE DETECTED —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0304	Cylinder 4 misfire detected	<Ref. to EN(DOHC TURBO)-173, DTC P0304 — CYLINDER 4 MISFIRE DETECTED —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

DTC No.	Item	Index
P0327	Knock sensor circuit low input	<Ref. to EN(DOHC TURBO)-182, DTC P0327 — KNOCK SENSOR CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0328	Knock sensor circuit high input	<Ref. to EN(DOHC TURBO)-184, DTC P0328 — KNOCK SENSOR CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0335	Crankshaft position sensor circuit malfunction	<Ref. to EN(DOHC TURBO)-186, DTC P0335 — CRANKSHAFT POSITION SENSOR CIRCUIT MALFUNCTION —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0336	Crankshaft position sensor circuit range/performance problem	<Ref. to EN(DOHC TURBO)-188, DTC P0336 — Crankshaft Position Sensor Circuit Range/Performance Problem —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0340	Camshaft position sensor circuit malfunction	<Ref. to EN(DOHC TURBO)-190, DTC P0340 — CAMSHAFT POSITION SENSOR CIRCUIT MALFUNCTION —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0341	Camshaft position sensor circuit range/performance problem	<Ref. to EN(DOHC TURBO)-192, DTC P0341 — CAMSHAFT POSITION SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0420	Catalyst system efficiency below threshold	<Ref. to EN(DOHC TURBO)-196, DTC P0420 — CATALYST SYSTEM EFFICIENCY BELOW THRESHOLD —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0442	Evaporative emission control system malfunction	<Ref. to EN(DOHC TURBO)-199, DTC P0442 — EVAPORATIVE EMISSION CONTROL SYSTEM MALFUNCTION —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0444	Evaporative emission control system purge control valve circuit low input	<Ref. to EN(DOHC TURBO)-204, DTC P0444 — EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0445	Evaporative emission control system purge control valve circuit high input	<Ref. to EN(DOHC TURBO)-208, DTC P0445 — EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0447	Evaporative emission control system vent control low input	<Ref. to EN(DOHC TURBO)-210, DTC P0447 — EVAPORATIVE EMISSION CONTROL SYSTEM VENT CONTROL LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0448	Evaporative emission control system vent control high input	<Ref. to EN(DOHC TURBO)-214, DTC P0448 — EVAPORATIVE EMISSION CONTROL SYSTEM VENT CONTROL HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0451	Evaporative emission control system pressure sensor range/performance problem	<Ref. to EN(DOHC TURBO)-216, DTC P0451 — EVAPORATIVE EMISSION CONTROL SYSTEM PRESSURE SENSOR RANGE/PERFORMANCE PROBLEM —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0452	Evaporative emission control system pressure sensor low input	<Ref. to EN(DOHC TURBO)-218, DTC P0452 — EVAPORATIVE EMISSION CONTROL SYSTEM PRESSURE SENSOR LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0453	Evaporative emission control system pressure sensor high input	<Ref. to EN(DOHC TURBO)-222, DTC P0453 — EVAPORATIVE EMISSION CONTROL SYSTEM PRESSURE SENSOR HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0461	Fuel level sensor circuit range/performance problem	<Ref. to EN(DOHC TURBO)-225, DTC P0461 — FUEL LEVEL SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0462	Fuel level sensor circuit low input	<Ref. to EN(DOHC TURBO)-228, DTC P0462 — FUEL LEVEL SENSOR CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0463	Fuel level sensor circuit high input	<Ref. to EN(DOHC TURBO)-232, DTC P0463 — FUEL LEVEL SENSOR CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

DTC No.	Item	Index
P0464	Fuel level sensor intermittent input	<Ref. to EN(DOHC TURBO)-236, DTC P0464 — FUEL LEVEL SENSOR INTERMITTENT INPUT—, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0480	Cooling fan relay 1 circuit low input	<Ref. to EN(DOHC TURBO)-239, DTC P0480 — COOLING FAN RELAY 1 CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0483	Cooling fan function problem	<Ref. to EN(DOHC TURBO)-243, DTC P0483 — COOLING FAN FUNCTION PROBLEM —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0500	Vehicle speed sensor malfunction	<Ref. to EN(DOHC TURBO)-246, DTC P0500 — VEHICLE SPEED SENSOR MALFUNCTION —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0506	Idle control system RPM lower than expected	<Ref. to EN(DOHC TURBO)-248, DTC P0506 — IDLE CONTROL SYSTEM RPM LOWER THAN EXPECTED —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0507	Idle control system RPM higher than expected	<Ref. to EN(DOHC TURBO)-250, DTC P0507 — IDLE CONTROL SYSTEM RPM HIGHER THAN EXPECTED —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0508	Idle control system circuit low input	<Ref. to EN(DOHC TURBO)-252, DTC P0508 — IDLE CONTROL SYSTEM CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0509	Idle control system circuit high input	<Ref. to EN(DOHC TURBO)-254, DTC P0509 — IDLE CONTROL SYSTEM CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0512	Starter switch circuit high input	<Ref. to EN(DOHC TURBO)-257, DTC P0512 — STARTER SWITCH CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0545	Exhaust gas temperature sensor circuit low input	<Ref. to EN(DOHC TURBO)-260, DTC P0545 — EXHAUST GAS TEMPERATURE SENSOR CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0546	Exhaust gas temperature sensor circuit high input	<Ref. to EN(DOHC TURBO)-262, DTC P0546 — EXHAUST GAS TEMPERATURE SENSOR CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0604	Internal control module memory check sum error	<Ref. to EN(DOHC TURBO)-266, DTC P0604 — INTERNAL CONTROL MODULE MEMORY CHECK SUM ERROR —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0703	Brake switch input malfunction	<Ref. to EN(DOHC TURBO)-268, DTC P0703 — BRAKE SWITCH INPUT MALFUNCTION —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0705	Transmission range sensor circuit malfunction	<Ref. to AT-115, CHECK INHIBITOR SWITCH., Diagnostic Procedure for No-Diagnostic Trouble Code (DTC).>
P0710	Transmission fluid temperature sensor circuit malfunction	<Ref. to AT-48, DTC 27 ATF TEMPERATURE SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0715	Torque converter turbine speed sensor circuit malfunction	<Ref. to AT-62, DTC 36 TORQUE CONVERTER TURBINE SPEED SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0720	Output speed sensor (vehicle speed sensor 2) circuit malfunction	<Ref. to AT-57, DTC 33 FRONT VEHICLE SPEED SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0725	Engine speed input circuit malfunction	<Ref. to AT-44, DTC 11 ENGINE SPEED SIGNAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0731	Gear 1 incorrect ratio	<Ref. to EN(DOHC TURBO)-270, DTC P0731 — GEAR 1 INCORRECT RATIO —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0732	Gear 2 incorrect ratio	<Ref. to EN(DOHC TURBO)-270, DTC P0732 — GEAR 2 INCORRECT RATIO —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0733	Gear 3 incorrect ratio	<Ref. to EN(DOHC TURBO)-270, DTC P0733 — GEAR 3 INCORRECT RATIO —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

DTC No.	Item	Index
P0734	Gear 4 incorrect ratio	<Ref. to EN(DOHC TURBO)-270, DTC P0734 — GEAR 4 INCORRECT RATIO —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0741	Torque converter clutch system malfunction	<Ref. to EN(DOHC TURBO)-272, DTC P0741 — TORQUE CONVERTER CLUTCH SYSTEM MALFUNCTION —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0743	Torque converter clutch system (Lock-up duty solenoid) electrical	<Ref. to AT-94, DTC 77 LOCK-UP DUTY SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0748	Pressure control solenoid (Line pressure duty solenoid) electrical	<Ref. to AT-86, DTC 75 LINE PRESSURE DUTY SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0753	Shift solenoid A (Shift solenoid 1) electrical	<Ref. to AT-70, DTC 71 SHIFT SOLENOID 1, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0758	Shift solenoid B (Shift solenoid 2) electrical	<Ref. to AT-74, DTC 72 SHIFT SOLENOID 2, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0778	2-4 brake pressure control solenoid valve (2-4 brake duty solenoid) circuit malfunction	<Ref. to AT-90, DTC 76 2-4 BRAKE DUTY SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P0785	2-4 brake timing control solenoid valve (2-4 brake timing solenoid) circuit malfunction	<Ref. to AT-82, DTC 74 2-4 BRAKE TIMING SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1086	Tumble generator valve #2 (LH) position sensor circuit low input	<Ref. to EN(DOHC TURBO)-274, DTC P1086 — TUMBLE GENERATOR VALVE #2 (LH) POSITION SENSOR CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1087	Tumble generator valve #2 (LH) position sensor circuit high input	<Ref. to EN(DOHC TURBO)-278, DTC P1087 — TUMBLE GENERATOR VALVE #2 (LH) POSITION SENSOR CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1088	Tumble generator valve #1 (RH) position sensor circuit low input	<Ref. to EN(DOHC TURBO)-280, DTC P1088 — TUMBLE GENERATOR VALVE #1 (RH) POSITION SENSOR CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1089	Tumble generator valve #1 (RH) position sensor circuit high input	<Ref. to EN(DOHC TURBO)-284, DTC P1089 — TUMBLE GENERATOR VALVE #1 (RH) POSITION SENSOR CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1090	Tumble generator valve #1(RH) malfunction (stuck open)	<Ref. to EN(DOHC TURBO)-286, DTC P1090 — TUMBLE GENERATOR VALVE SYSTEM #1 (RH) MALFUNCTION (STUCK OPEN) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1091	Tumble generator valve #1(RH) malfunction (stuck close)	<Ref. to EN(DOHC TURBO)-287, DTC P1091 — TUMBLE GENERATOR VALVE SYSTEM #1 (RH) MALFUNCTION (STUCK CLOSE) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1092	Tumble generator valve #2(LH) malfunction (stuck open)	<Ref. to EN(DOHC TURBO)-288, DTC P1092 — TUMBLE GENERATOR VALVE SYSTEM #2 (LH) MALFUNCTION (STUCK OPEN) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1093	Tumble generator valve #2(LH) malfunction (stuck close)	<Ref. to EN(DOHC TURBO)-289, DTC P1093 — TUMBLE GENERATOR VALVE SYSTEM #2 (LH) MALFUNCTION (STUCK CLOSE) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1094	Tumble generator valve circuit #1 (opencircuit)	<Ref. to EN(DOHC TURBO)-290, DTC P1094 — TUMBLE GENERATOR VALVE CIRCUIT #1 (OPEN CIRCUIT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1095	Tumble generator valve circuit #1 (overcurrent)	<Ref. to EN(DOHC TURBO)-292, DTC P1095 — TUMBLE GENERATOR VALVE CIRCUIT #1 (OVERCURRENT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1096	Tumble generator valve circuit #2 (opencircuit)	<Ref. to EN(DOHC TURBO)-294, DTC P1096 — TUMBLE GENERATOR VALVE CIRCUIT #2 (OPEN CIRCUIT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1097	Tumble generator valve circuit #2 (overcurrent)	<Ref. to EN(DOHC TURBO)-296, DTC P1097 — TUMBLE GENERATOR VALVE CIRCUIT #2 (OVERCURRENT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

DTC No.	Item	Index
P1110	Atmospheric pressure sensor low input	<Ref. to EN(DOHC TURBO)-297, DTC P1110 — ATMOSPHERIC PRESSURE SENSOR CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1111	Atmospheric pressure sensor high input	<Ref. to EN(DOHC TURBO)-297, DTC P1111 — ATMOSPHERIC PRESSURE SENSOR CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1112	Atmospheric pressure sensor range/performance problem	<Ref. to EN(DOHC TURBO)-298, DTC P1112 — ATMOSPHERIC PRESSURE SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1130	Front oxygen sensor circuit malfunction (open circuit)	<Ref. to EN(DOHC TURBO)-300, DTC P1130 — FRONT OXYGEN (A/F) SENSOR CIRCUIT MALFUNCTION (OPEN CIRCUIT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1131	Front oxygen sensor circuit malfunction (short circuit)	<Ref. to EN(DOHC TURBO)-302, DTC P1131 — FRONT OXYGEN (A/F) SENSOR CIRCUIT MALFUNCTION (SHORT CIRCUIT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1134	Front oxygen (A/F) sensor micro-computer problem	<Ref. to EN(DOHC TURBO)-304, DTC P1134 — FRONT OXYGEN (A/F) SENSOR MICRO-COMPUTER PROBLEM —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1139	Front oxygen (A/F) sensor #1 heater circuit performance/range problem	<Ref. to EN(DOHC TURBO)-306, DTC P1139 — FRONT OXYGEN (A/F) SENSOR #1 HEATER CIRCUIT RANGE/PERFORMANCE PROBLEM —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1141	Mass air flow sensor circuit range/performance problem (low input)	<Ref. to EN(DOHC TURBO)-308, DTC P1141 — MASS AIR FLOW SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (LOW INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1142	Throttle position sensor circuit range/performance problem (low input)	<Ref. to EN(DOHC TURBO)-310, DTC P1142 — THROTTLE POSITION SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (LOW INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1146	Pressure sensor circuit range/performance problem (high input)	<Ref. to EN(DOHC TURBO)-312, DTC P1146 — PRESSURE SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (HIGH INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1230	Fuel pump control unit malfunction	<Ref. to EN(DOHC TURBO)-314, DTC P1230 — FUEL PUMP CONTROLLER MALFUNCTION —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1244	Wastegate control solenoid valve malfunction (low input)	<Ref. to EN(DOHC TURBO)-318, DTC P1244 — WASTEGATE CONTROL SOLENOID VALVE RANGE/PERFORMANCE PROBLEM (LOW INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1245	Wastegate control solenoid valve malfunction (fail-safe)	<Ref. to EN(DOHC TURBO)-320, DTC P1245 — WASTEGATE CONTROL SOLENOID VALVE MALFUNCTION (FAIL-SAFE) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1301	Fire due to increased exhaust temperature	<Ref. to EN(DOHC TURBO)-322, DTC P1301 — FIRE DUE TO INCREASED EXHAUST TEMPERATURE —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1312	Exhaust temperature sensor malfunction	<Ref. to EN(DOHC TURBO)-324, DTC P1312 — EXHAUST GAS TEMPERATURE CIRCUIT MALFUNCTION —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1400	Fuel tank pressure control solenoid valve circuit low input	<Ref. to EN(DOHC TURBO)-326, DTC P1400 — FUEL TANK PRESSURE CONTROL SOLENOID VALVE CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1420	Fuel tank pressure control solenoid valve circuit high input	<Ref. to EN(DOHC TURBO)-330, DTC P1420 — FUEL TANK PRESSURE CONTROL SOLENOID VALVE CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1443	Evaporative emission control system vent control function problem	<Ref. to EN(DOHC TURBO)-332, DTC P1443 — EVAPORATIVE EMISSION CONTROL SYSTEM VENT CONTROL FUNCTION PROBLEM —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1480	Cooling fan relay 1 circuit high input	<Ref. to EN(DOHC TURBO)-335, DTC P1480 — COOLING FAN RELAY 1 CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

## LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

### ENGINE (DIAGNOSTICS)

DTC No.	Item	Index
P1507	Idle control system malfunction (fail-safe)	<Ref. to EN(DOHC TURBO)-338, DTC P1507 — IDLE CONTROL SYSTEM MALFUNCTION (FAIL-SAFE) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1518	Starter switch circuit low input	<Ref. to EN(DOHC TURBO)-341, DTC P1518 — STARTER SWITCH CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1544	High exhaust temperature detected	<Ref. to EN(DOHC TURBO)-344, DTC P1544 — HIGH EXHAUST TEMPERATURE DETECTED —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1560	Back-up voltage circuit malfunction	<Ref. to EN(DOHC TURBO)-347, DTC P1560 — Back-up Voltage Circuit Malfunction —.>
P1590	Neutral position switch circuit high input	<Ref. to EN(DOHC TURBO)-350, DTC P1590 — NEUTRAL POSITION SWITCH CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1591	Neutral position switch circuit low input	<Ref. to EN(DOHC TURBO)-354, DTC P1591 — NEUTRAL POSITION SWITCH CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1594	Automatic transmission diagnosis input signal circuit malfunction	<Ref. to EN(DOHC TURBO)-356, DTC P1594 — AUTOMATIC TRANSMISSION DIAGNOSIS INPUT SIGNAL CIRCUIT MALFUNCTION —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1595	Automatic transmission diagnosis input signal circuit low input	<Ref. to EN(DOHC TURBO)-358, DTC P1595 — AUTOMATIC TRANSMISSION DIAGNOSIS INPUT SIGNAL CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1596	Automatic transmission diagnosis input signal circuit high input	<Ref. to EN(DOHC TURBO)-360, DTC P1596 — AUTOMATIC TRANSMISSION DIAGNOSIS INPUT SIGNAL CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1698	Engine torque control cut signal circuit low input	<Ref. to EN(DOHC TURBO)-362, DTC P1698 — ENGINE TORQUE CONTROL CUT SIGNAL CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1699	Engine torque control cut signal circuit high input	<Ref. to EN(DOHC TURBO)-364, DTC P1699 — ENGINE TORQUE CONTROL CUT SIGNAL CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1700	Throttle position sensor circuit malfunction for automatic transmission	<Ref. to AT-52, DTC 31 THROTTLE POSITION SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1701	Cruise control set signal circuit malfunction for automatic transmission	<Ref. to EN(DOHC TURBO)-366, DTC P1701 — CRUISE CONTROL SET SIGNAL CIRCUIT MALFUNCTION FOR AUTOMATIC TRANSMISSION —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1703	Low clutch timing control solenoid valve circuit malfunction	<Ref. to AT-78, DTC 73 LOW CLUTCH TIMING SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1711	Engine torque control signal 1 circuit malfunction	<Ref. to EN(DOHC TURBO)-368, DTC P1711 — ENGINE TORQUE CONTROL SIGNAL 1 CIRCUIT MALFUNCTION —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1712	Engine torque control signal 2 circuit malfunction	<Ref. to EN(DOHC TURBO)-370, DTC P1712 — ENGINE TORQUE CONTROL SIGNAL 2 CIRCUIT MALFUNCTION —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

---

EN(DOHC TURBO)-87

## 18. Diagnostic Procedure with Diagnostic Trouble Code (DTC)


### A: DTC P0031 — FRONT OXYGEN (A/F) SENSOR HEATER CIRCUIT LOW INPUT —

- DTC DETECTING CONDITION:
  - Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- WIRING DIAGRAM:



EN1143

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No	
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0031 and P0037 at the same time?	Go to step 2.	Go to step 5.
2	<b>CHECK POWER SUPPLY TO FRONT OXYGEN (A/F) SENSOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from front oxygen (A/F) sensor. 3) Turn the ignition switch to ON. 4) Measure the voltage between front oxygen (A/F) sensor connector and engine ground. <b>Connector &amp; terminal</b> <b>(B18) No. 2 (+) — Engine ground (-):</b>	Is the voltage more than 10 V?	Go to step 3.	Repair power supply line. <b>NOTE:</b> In this case, repair the following: • Open circuit in harness between main relay and front oxygen (A/F) sensor connector • Poor contact in front oxygen (A/F) sensor connector • Poor contact in main relay connector
3	<b>CHECK GROUND CIRCUIT OF ECM.</b> Measure the resistance of harness between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B137) No. 8 — Chassis ground:</b> <b>(B137) No. 9 — Chassis ground:</b>	Is the resistance less than 5 Ω?	Go to step 4.	Repair harness and connector. <b>NOTE:</b> In this case, repair the following: • Open circuit in harness between ECM and engine ground terminal • Poor contact in ECM connector • Poor contact in coupling connector
4	<b>CHECK CURRENT DATA.</b> 1) Start the engine. 2) Read the data of front oxygen (A/F) sensor heater current using Subaru Select Monitor or OBD-II general scan tool. <b>NOTE:</b> • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.> • OBD-II scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.	Is the value more than 0.2 A?	Repair poor contact in connector. <b>NOTE:</b> In this case, repair the following: • Poor contact in front oxygen (A/F) sensor connector • Poor contact in ECM connector	Go to step 5.
5	<b>CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Start and idle the engine. 2) Measure the voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B137) No. 4 (+) — Chassis ground (-):</b> <b>(B137) No. 5 (+) — Chassis ground (-):</b>	Is the voltage less than 1.0 V?	Go to step 7.	Go to step 6.
6	<b>CHECK OUTPUT SIGNAL FROM ECM.</b> Measure the voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B137) No. 4 (+) — Chassis ground (-):</b> <b>(B137) No. 5 (+) — Chassis ground (-):</b>	Does the voltage change less than 1.0 V by shaking harness and connector of ECM while monitoring the value with voltage meter?	Repair poor contact in ECM connector.	Go to step 7.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>7</p> <p><b>CHECK FRONT OXYGEN (A/F) SENSOR.</b>            1) Turn the ignition switch to OFF.            2) Measure the resistance between front oxygen (A/F) sensor connector terminals.</p> <p><b>Terminals</b>  <b>No. 2 — No. 1:</b></p>	<p>Is the resistance less than 10 <math>\Omega</math>?</p>	<p>Repair harness and connector.</p> <p><b>NOTE:</b>            In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open or ground short circuit in harness between front oxygen (A/F) sensor and ECM connector</li> <li>• Poor contact in front oxygen (A/F) sensor connector</li> <li>• Poor contact in ECM connector</li> </ul>	<p>Replace the front oxygen (A/F) sensor. &lt;Ref. to FU(DOHC TURBO)-42, Front Oxygen (A/F) Sensor.&gt;</p>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### B: DTC P0032 — FRONT OXYGEN (A/F) SENSOR HEATER CIRCUIT HIGH INPUT —

- DTC DETECTING CONDITION:
  - Immediately at fault recognition

#### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- WIRING DIAGRAM:



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<p><b>CHECK OUTPUT SIGNAL FROM ECM.</b>                      1) Turn the ignition switch to ON.                      2) Measure the voltage between ECM connector and chassis ground.  <b>Connector &amp; terminal</b>  <i>(B137) No. 4 (+) — Chassis ground (-):</i>  <i>(B137) No. 5 (+) — Chassis ground (-):</i></p>	Is the voltage more than 8 V?	Go to step 3.	Go to step 2.
2	<p><b>CHECK FRONT OXYGEN (A/F) SENSOR HEATER CURRENT.</b>                      1) Turn the ignition switch to OFF.                      2) Repair the battery short circuit in harness between ECM and front oxygen (A/F) sensor connector.                      3) Turn the ignition switch to ON.                      4) Read the data of front oxygen (A/F) sensor heater current using Subaru Select Monitor or the OBD-II general scan tool.  <b>NOTE:</b>                      •Subaru Select Monitor                      For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;                      •OBD-II general scan tool                      For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</p>	Is the value more than 2.3 A?	Replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>	END
3	<p><b>CHECK OUTPUT SIGNAL FROM ECM.</b>                      Measure the voltage between ECM connector and chassis ground.  <b>Connector &amp; terminal</b>  <i>(B137) No. 4 (+) — Chassis ground (-):</i>  <i>(B137) No. 5 (+) — Chassis ground (-):</i></p>	Does the voltage change more than 8 V by shaking harness and connector of ECM while monitoring the value with voltage meter?	Repair battery short circuit in harness between ECM and front oxygen (A/F) sensor connector.	END

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## C: DTC P0037 — REAR OXYGEN SENSOR HEATER CIRCUIT MALFUNCTION

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>

• **WIRING DIAGRAM:**



EN1144

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK GROUND CIRCUIT OF ECM.</b>                      1) Turn the ignition switch to OFF.                      2) Disconnect the connector from ECM.                      3) Measure the resistance of harness between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B137) No. 8 — Chassis ground:</b>  <b>(B137) No. 9 — Chassis ground:</b></p>	<p>Is the resistance less than 5 <math>\Omega</math>?</p>	<p>Go to step 2.</p>	<p>Repair harness and connector.</p> <p><b>NOTE:</b>                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and engine ground terminal</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>2</b></p> <p><b>CHECK CURRENT DATA.</b>                      1) Start the engine.                      2) Read the data of rear oxygen sensor heater current using Subaru Select Monitor or OBD-II general scan tool.</p> <p><b>NOTE:</b>                      • Subaru Select Monitor                      For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;                      • OBD-II scan tool                      For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value more than 0.2 A?</p>	<p>Repair the connector.</p> <p><b>NOTE:</b>                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Poor contact in rear oxygen sensor connector</li> <li>• Poor contact in rear oxygen sensor connecting harness connector</li> <li>• Poor contact in ECM connector</li> </ul>	<p>Go to step 3.</p>
<p><b>3</b></p> <p><b>CHECK OUTPUT SIGNAL FROM ECM.</b>                      1) Start and idle the engine.                      2) Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B136) No. 13 (+) — Chassis ground (-):</b></p>	<p>Is the voltage less than 1.0 V?</p>	<p>Go to step 6.</p>	<p>Go to step 4.</p>
<p><b>4</b></p> <p><b>CHECK OUTPUT SIGNAL FROM ECM.</b>                      Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B136) No. 13 (+) — Chassis ground (-):</b></p>	<p>Does the voltage change less than 1.0 V by shaking harness and connector of ECM while monitoring the value with voltage meter?</p>	<p>Repair poor contact in ECM connector.</p>	<p>Go to step 5.</p>
<p><b>5</b></p> <p><b>CHECK OUTPUT SIGNAL FROM ECM.</b>                      1) Disconnect the connector from rear oxygen sensor.                      2) Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B136) No. 13 (+) — Chassis ground (-):</b></p>	<p>Is the voltage less than 1.0 V?</p>	<p>Replace the ECM.                      &lt;Ref. to FU(DOHC TURBO)-47, Engine Control Module.&gt;</p>	<p>Repair battery short circuit in harness between ECM and rear oxygen sensor connector. After repair, replace the ECM. &lt;Ref. to FU(DOHC TURBO)-47, Engine Control Module.&gt;</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
6	<p><b>CHECK POWER SUPPLY TO REAR OXYGEN SENSOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from rear oxygen sensor.</p> <p>3) Turn the ignition switch to ON.</p> <p>4) Measure the voltage between rear oxygen sensor connector and engine ground or chassis ground.</p> <p><b>Connector &amp; terminal</b> <b>(B19) No. 2 (+) — Chassis ground (-):</b></p>	Is the voltage more than 10 V?	Go to step 7.	<p>Repair power supply line.</p> <p><b>NOTE:</b> In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between main relay and rear oxygen sensor connector</li> <li>• Poor contact in rear oxygen sensor connector</li> <li>• Poor contact in coupling connector</li> </ul>
7	<p><b>CHECK REAR OXYGEN SENSOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Measure the resistance between rear oxygen sensor connector terminals.</p> <p><b>Terminals</b> <b>No. 1 — No. 2:</b></p>	Is the resistance less than 30 Ω?	<p>Repair harness and connector.</p> <p><b>NOTE:</b> In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between rear oxygen sensor and ECM connector</li> <li>• Poor contact in rear oxygen sensor connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>	<p>Replace the rear oxygen sensor.</p> <p>&lt;Ref. to FU(DOHC TURBO)-44, Rear Oxygen Sensor.&gt;</p>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)

## D: DTC P0038 — REAR OXYGEN SENSOR HEATER CIRCUIT HIGH INPUT —


### DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

### WIRING DIAGRAM:



EN1144

Step	Check	Yes	No
1	<b>CHECK INPUT SIGNAL FOR ECM.</b> Measure the voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 13 (+) — Chassis ground (-):</b>	Go to step 2.	Go to step 3.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
2	<p><b>CHECK CURRENT DATA.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Repair the battery short circuit in harness between ECM and rear oxygen sensor connector.</p> <p>3) Turn the ignition switch to ON.</p> <p>4) Read the data of rear oxygen sensor heater current using Subaru Select Monitor or the OBD-II general scan tool.</p> <p><b>NOTE:</b></p> <ul style="list-style-type: none"><li>• Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;</li><li>• OBD-II general scan tool For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</li></ul>	Is the value more than 7 A?	Replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>	END
3	<p><b>CHECK POOR CONTACT.</b></p> <p>Check poor contact in ECM connector.</p>	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	END

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## E: DTC P0101 — MASS AIR FLOW SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (HIGH INPUT) —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN1145

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)


ENGINE (DIAGNOSTICS)

Step	Check	Yes	No	
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0102 or P0103?	Inspect DTC P0102 or P0103 using "Diagnostics Chart with Trouble Code".  NOTE: In this case, it is not necessary to inspect DTC P0101.	Replace the mass air flow and intake air temperature sensor. <Ref. to FU(DOHC TURBO)-34, Mass Air Flow and Intake Air Temperature Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)

## F: DTC P0102 — MASS AIR FLOW SENSOR CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performanc
- **WIRING DIAGRAM:**



EN1145

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>CONNECT SUBARU SELECT MONITOR OR THE OBD-II GENERAL SCAN TOOL, AND READ DATA.</b></p> <p>1) Turn the ignition switch to OFF.                  2) Connect the Subaru Select Monitor or the OBD-II general scan tool to data link connector.                  3) Turn the ignition switch to ON and Subaru Select Monitor or the OBD-II general scan tool switch to ON.                  4) Start the engine.                  5) Read the data of mass air flow sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:                  • Subaru Select Monitor                  For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;                  • OBD-II general scan tool                  For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value equal to or more than 1.3 g/sec (0.172 lb/min) or 1.3 V and equal to or less than 140 g/sec (32 lb/min) or 4.58 V?</p>	<p>Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in the mass air flow sensor.</p> <p>NOTE:                  In this case, repair the following:                  • Open or ground short circuit in harness between mass air flow sensor and ECM connector                  • Poor contact in mass air flow sensor or ECM connector</p>	<p>Go to step 2.</p>
<p><b>CHECK INPUT SIGNAL FOR ECM.</b>                  Measure the voltage between ECM connector and chassis ground while engine is idling.  <b>Connector &amp; terminal</b>  <b>(B84) No. 13 (+) — Chassis ground (-):</b></p>	<p>Is the voltage less than 0.2 V?</p>	<p>Go to step 4.</p>	<p>Go to step 3.</p>
<p><b>CHECK INPUT SIGNAL FOR ECM (USING SUBARU SELECT MONITOR).</b>                  Measure the voltage between ECM connector and chassis ground while engine is idling.</p>	<p>Does the voltage change more than 0.2 V by shaking harness and connector of ECM while monitoring the value with Subaru select monitor?</p>	<p>Repair poor contact in ECM connector.</p>	<p>Contact with SOA (distributor) service.                  NOTE:                  Inspection by DTV is required, because probable cause is deterioration of multiple parts.</p>
<p><b>CHECK POWER SUPPLY TO MASS AIR FLOW SENSOR.</b></p> <p>1) Turn the ignition switch to OFF.                  2) Disconnect the connector from mass air flow sensor.                  3) Turn the ignition switch to ON.                  4) Measure voltage between mass air flow sensor connector and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B3) No. 1 (+) — Chassis ground (-):</b></p>	<p>Is the voltage more than 10V?</p>	<p>Go to step 5.</p>	<p>Repair open circuit between mass air flow sensor and main relay</p>
<p><b>CHECK HARNESS BETWEEN ECM AND MASS AIR FLOW SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.                  2) Disconnect the connector from ECM.                  3) Measure the resistance of harness between ECM and mass air flow sensor connector.  <b>Connector &amp; terminal</b>  <b>(B84) No. 13 — (B3) No. 3:</b>  <b>(B135) No. 27 — (B3) No. 4:</b>  <b>(B135) No. 19 — (B3) No. 5:</b></p>	<p>Is the resistance less than 1Ω?</p>	<p>Go to step 6.</p>	<p>Repair open circuit between ECM and mass air flow sensor connector.</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
6	<b>CHECK HARNESS BETWEEN ECM AND MASS AIR FLOW SENSOR CONNECTOR</b> Measure the resistance of harness between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B84) No. 13 — Chassis ground:</b> <b>(B135) No. 27 — Chassis ground:</b> <b>(B135) No. 19 — Chassis ground:</b>	Is the resistance more than 1M $\Omega$ ?	Go to step 7.	Repair ground short circuit between ECM and mass air flow sensor connector.
7	<b>CHECK POOR CONTACT</b> Check poor contact in mass air flow sensor connector.	Is there poor contact in mass air flow sensor connector?	Repair poor contact in mass air flow sensor connector.	Replace the mass air flow and intake air temperature sensor. <Ref. to FU(DOHC TURBO)-34, Mass Air Flow and Intake Air Temperature Sensor.>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### G: DTC P0103 — MASS AIR FLOW SENSOR CIRCUIT HIGH INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN1145

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)





Step	Check	Yes	No
<p><b>1</b></p> <p><b>CONNECT SUBARU SELECT MONITOR OR THE OBD-II GENERAL SCAN TOOL, AND READ DATA.</b></p> <p>1) Turn the ignition switch to OFF.                  2) Connect the Subaru Select Monitor or the OBD-II general scan tool to data link connector.                  3) Turn the ignition switch to ON and Subaru Select Monitor or the OBD-II general scan tool switch to ON.                  4) Start the engine.                  5) Read the data of mass air flow sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:                  •Subaru Select Monitor                  For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;                  •OBD-II general scan tool                  For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value equal to or more than 1.3 g/sec (0.172 lb/min) or 0.3 V and equal to or less than 240 g/sec (32 lb/min) or 4.58 V?</p>	<p>Even if MIL lights up, the circuit has returned to a normal condition at this time.</p>	<p>Go to step 2.</p>
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND MASS AIR FLOW SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF and Subaru Select Monitor or the OBD-II general scan tool switch to OFF.                  2) Disconnect the connector from mass air flow sensor.                  3) Turn the ignition switch to ON and Subaru Select Monitor or the OBD-II general scan tool switch to ON.                  4) Read the data of mass air flow sensor signal using Subaru select monitor or OBD-II general scan tool.</p> <p>NOTE:                  •Subaru Select Monitor                  For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;                  •OBD-II general scan tool                  For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value more than 240 g/sec (32 lb/min) or 4.58 V in function mode F06?</p>	<p>Repair battery short circuit in harness between mass air flow sensor and ECM connector. After repair, replace the ECM.</p>	<p>Replace the mass air flow sensor.</p>

**H: DTC P0106 — PRESSURE SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (LOW INPUT) —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Failure of engine to start

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.



EN1146

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>CHECK IDLE SWITCH SIGNAL.</b></p> <p>1) Turn the ignition switch to ON.</p> <p>2) Operate the LED operation mode for engine using Subaru Select Monitor.</p> <p>NOTE: • Subaru Select Monitor</p> <p>For detailed operation procedure, refer to the "LED OPERATION MODE FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;</p>	<p>Does the LED of {Idle Switch signal} come on?</p>	<p>Go to step 2.</p>	<p>Check the throttle position sensor circuit. &lt;Ref. to EN(DOHC TURBO)-132, DTC P0121 — THROTTLE POSITION SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (HIGH INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</p> <p>NOTE: In this case, it is not necessary to inspect DTC P0106.</p>
<p><b>CHECK ANY OTHER DTC ON DISPLAY.</b></p>	<p>Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0107 or P0108?</p>	<p>Inspect DTC P0107 or P0108 using "List of Diagnostic Trouble Code (DTC)". &lt;Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).&gt;</p> <p>NOTE: In this case, it is not necessary to inspect DTC P0106.</p>	<p>Go to step 3.</p>
<p><b>CHECK CONDITION OF PRESSURE SENSOR.</b></p>	<p>Is the pressure sensor installation bolt tightened securely?</p>	<p>Go to step 4.</p>	<p>Tighten pressure sensor installation bolt securely.</p>
<p><b>CHECK CONDITION OF THROTTLE BODY.</b></p>	<p>Is the throttle body installation bolt tightened securely?</p>	<p>Replace the pressure sensor. &lt;Ref. to FU(DOHC TURBO)-35, Pressure Sensor.&gt;</p>	<p>Tighten throttle body installation bolt securely.</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### I: DTC P0107 — PRESSURE SENSOR CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>CHECK CURRENT DATA.</b></p> <p>1) Start the engine.</p> <p>2) Read the data of intake manifold absolute pressure signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor</li> </ul> <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>• OBD-II general scan tool</li> </ul> <p>For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value less than -7.2 kPa (-54 mmHg, -2.1 inHg)?</p>	<p>Go to step 3.</p>	<p>Go to step 2.</p>
<p><b>CHECK POOR CONTACT.</b></p> <p>Check poor contact in ECM and pressure sensor connector.</p>	<p>Is there poor contact in ECM or pressure sensor connector?</p>	<p>Repair poor contact in ECM or pressure sensor connector.</p>	<p>Even if MIL lights up, the circuit has returned to a normal condition at this time.</p>
<p><b>CHECK INPUT SIGNAL FOR ECM.</b></p> <p>Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b> <b>(B135) No. 9 (+) — Chassis ground (-):</b></p>	<p>Is the voltage more than 4.5 V?</p>	<p>Go to step 5.</p>	<p>Go to step 4.</p>
<p><b>CHECK INPUT SIGNAL FOR ECM.</b></p> <p>Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b> <b>(B135) No. 9 (+) — Chassis ground (-):</b></p>	<p>Does the voltage change more than 4.5 V by shaking harness and connector of ECM while monitoring the value with voltage meter?</p>	<p>Repair poor contact in ECM connector.</p>	<p>Contact with SOA (distributor) service.</p> <p>NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p>
<p><b>CHECK INPUT SIGNAL FOR ECM.</b></p> <p>Measure the voltage between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b> <b>(B135) No. 8 (+) — Chassis ground (-):</b></p>	<p>Is the voltage less than 0.7 V?</p>	<p>Go to step 6.</p>	<p>Contact with SOA (distributor) service.</p> <p>NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p>
<p><b>CHECK HARNESS BETWEEN ECM AND PRESSURE SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from pressure sensor.</p> <p>3) Turn the ignition switch to ON.</p> <p>4) Measure the voltage between pressure sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(E21) No. 3 (+) — Engine ground (-):</b></p>	<p>Is the voltage more than 4.5 V?</p>	<p>Go to step 7.</p>	<p>Repair open circuit in harness between ECM and pressure sensor connector.</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
7	<b>CHECK HARNESS BETWEEN ECM AND PRESSURE SENSOR CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between ECM and pressure sensor connector. <b>Connector &amp; terminal</b> <b>(B135) No. 19 — (E21) No. 2:</b>	Is the resistance less than 1 $\Omega$ ?	Go to step 8.  Repair open circuit in harness between ECM and pressure sensor connector.
8	<b>CHECK HARNESS BETWEEN ECM AND PRESSURE SENSOR CONNECTOR.</b> Measure the resistance of harness between pressure sensor connector and engine ground. <b>Connector &amp; terminal</b> <b>(E21) No. 1 — Engine ground:</b>	Is the resistance more than 1 M $\Omega$ ?	Go to step 9.  Repair ground short circuit in harness between ECM and pressure sensor connector.
9	<b>CHECK POOR CONTACT.</b> Check poor contact in pressure sensor connector.	Is there poor contact in pressure sensor connector?	Repair poor contact in pressure sensor connector.  Replace the pressure sensor. <Ref. to FU(DOHC TURBO)-35, Pressure Sensor.>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)





### J: DTC P0108 — PRESSURE SENSOR CIRCUIT HIGH INPUT —

- DTC DETECTING CONDITION:
  - Immediately at fault recognition

#### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- WIRING DIAGRAM:



EN1146

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK CURRENT DATA.</b>                      1)Start the engine.                      2)Read the data of intake manifold absolute pressure signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:                      •Subaru Select Monitor                      For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;                      •OBD-II general scan tool                      For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value more than 282 kPa (2121 mmHg, 83.50 inHg)?</p>	<p>Go to step 9.</p>	<p>Go to step 2.</p>
<p><b>2</b></p> <p><b>CHECK INPUT SIGNAL FOR ECM.</b>                      Measure the voltage between ECM connector and chassis ground.  <i>Connector &amp; terminal</i>  <i>(B135) No. 9 (+) — Chassis ground (-):</i></p>	<p>Is the voltage more than 4.5 V?</p>	<p>Go to step 4.</p>	<p>Go to step 3.</p>
<p><b>3</b></p> <p><b>CHECK INPUT SIGNAL FOR ECM.</b>                      Measure the voltage between ECM connector and chassis ground.  <i>Connector &amp; terminal</i>  <i>(B135) No. 9 (+) — Chassis ground (-):</i></p>	<p>Does the voltage change more than 4.5 V by shaking harness and connector of ECM while monitoring the value with voltage meter?</p>	<p>Repair poor contact in ECM connector.</p>	<p>Contact with SOA (distributor) service.                      NOTE:                      Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p>
<p><b>4</b></p> <p><b>CHECK INPUT SIGNAL FOR ECM.</b>                      Measure the voltage between ECM connector and chassis ground.  <i>Connector &amp; terminal</i>  <i>(B135) No. 8 (+) — Chassis ground (-):</i></p>	<p>Is the voltage less than 0.7 V?</p>	<p>Go to step 5.</p>	<p>Contact with SOA (distributor) service.                      NOTE:                      Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p>
<p><b>5</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND PRESSURE SENSOR CONNECTOR.</b>                      1)Turn the ignition switch to OFF.                      2)Disconnect the connector from pressure sensor.                      3)Turn the ignition switch to ON.                      4)Measure the voltage between pressure sensor connector and engine ground.  <i>Connector &amp; terminal</i>  <i>(E21) No. 3 (+) — Engine ground (-):</i></p>	<p>Is the voltage more than 4.5 V?</p>	<p>Go to step 6.</p>	<p>Repair open circuit in harness between ECM and pressure sensor connector.</p>
<p><b>6</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND PRESSURE SENSOR CONNECTOR.</b>                      1)Turn the ignition switch to OFF.                      2)Disconnect the connector from ECM.                      3)Measure the resistance of harness between ECM and pressure sensor connector.  <i>Connector &amp; terminal</i>  <i>(B135) No. 8 — (E21) No. 1:</i></p>	<p>Is the resistance less than 1 <math>\Omega</math>?</p>	<p>Go to step 7.</p>	<p>Repair open circuit in harness between ECM and pressure sensor connector.</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
7	<b>CHECK HARNESS BETWEEN ECM AND PRESSURE SENSOR CONNECTOR.</b> Measure the resistance of harness between ECM and pressure sensor connector. <b>Connector &amp; terminal (B135) No. 19 — (E21) No. 2:</b>	Is the resistance less than 1 $\Omega$ ?	Go to step 8.	Repair open circuit in harness between ECM and pressure sensor connector.
8	<b>CHECK POOR CONTACT.</b> Check poor contact in pressure sensor connector.	Is there poor contact in pressure sensor connector?	Repair poor contact in pressure sensor connector.	Replace the pressure sensor. <Ref. to FU(DOHC TURBO)-35, Pressure Sensor.>
9	<b>CHECK HARNESS BETWEEN ECM AND PRESSURE SENSOR CONNECTOR.</b> 1)Turn the ignition switch to OFF and Subaru Select Monitor or the OBD-II general scan tool switch to OFF. 2)Disconnect the connector from pressure sensor. 3)Turn the ignition switch to ON and Subaru Select Monitor or the OBD-II general scan tool switch to ON. 4)Read the data of intake manifold absolute pressure signal using Subaru Select Monitor or OBD-II general scan tool. NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.> •OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.	Is the value more than 282 kPa (2121 mmHg, 83.50 inHg)?	Repair battery short circuit in harness between ECM and pressure sensor connector.	Replace the pressure sensor. <Ref. to FU(DOHC TURBO)-35, Pressure Sensor.>



**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
**ENGINE (DIAGNOSTICS)**


**K: DTC P0111 — INTAKE AIR TEMPERATURE SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN1145

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1</b> <b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0112, P0113, P0117, P0118 or P0125?	Inspect DTC P0112, P0113, P0117, P0118 or P0125 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).> <b>NOTE:</b> In this case, it is not necessary to inspect DTC P0111.	Go to step 2.
<b>2</b> <b>CHECK ENGINE COOLANT TEMPERATURE.</b> 1) Start the engine and warm it up completely. 2) Measure the engine coolant temperature using Subaru Select Monitor or OBD-II general scan tool.  <b>NOTE:</b> •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.> •OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.	Is the engine coolant temperature between 75°C (167°F) and 95°C (203°F)?	Replace the mass air flow and intake air temperature sensor. <Ref. to FU(DOHC TURBO)-34, Mass Air Flow and Intake Air Temperature Sensor.>	Inspect DTC P0125 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## L: DTC P0112 — INTAKE AIR TEMPERATURE SENSOR CIRCUIT LOW INPUT

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN1145

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<p><b>CHECK CURRENT DATA.</b></p> <p>1)Start the engine.</p> <p>2)Read the data of intake air temperature sensor signal using Subaru Select Monitor or the OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>•Subaru Select Monitor</li> </ul> <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>•OBD-II general scan tool</li> </ul> <p>For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value greater than 55°C (131°F)?</p>	<p>Go to step 2.</p>	<p>Repair poor contact.</p> <p>NOTE:</p> <p>In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Poor contact mass air flow and intake air temperature sensor</li> <li>• Poor contact in ECM</li> <li>• Poor contact in joint connector</li> </ul>
2	<p><b>CHECK HARNESS BETWEEN MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>1)Turn the ignition switch to OFF.</p> <p>2)Disconnect the connector from mass air flow and intake air temperature sensor.</p> <p>3)Turn the ignition switch to ON.</p> <p>4)Read the data of intake air temperature sensor signal using Subaru Select Monitor or the OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>•Subaru Select Monitor</li> </ul> <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>•OBD-II general scan tool</li> </ul> <p>For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value less than -36°C (-97°F)?</p>	<p>Replace the mass air flow and intake air temperature sensor. &lt;Ref. to FU(DOHC TURBO)-34, Mass Air Flow and Intake Air Temperature Sensor.&gt;</p>	<p>Repair ground short circuit in harness between mass air flow and intake air temperature sensor and ECM connector.</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## M: DTC P0113 — INTAKE AIR TEMPERATURE SENSOR CIRCUIT HIGH INPUT

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>

• **WIRING DIAGRAM:**



EN1145

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1 CHECK CURRENT DATA.</b>                      1) Start the engine.                      2) Read the data of intake air temperature sensor signal using Subaru Select Monitor or the OBD-II general scan tool.</p> <p>NOTE:                      • Subaru Select Monitor                      For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;                      • OBD-II general scan tool                      For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</p>	Is the value less than $-36^{\circ}\text{C}$ ( $-97^{\circ}\text{F}$ )?	Go to step 2.	Repair poor contact. NOTE: In this case, repair the following: • Poor contact in mass air flow and intake air temperature sensor • Poor contact in ECM • Poor contact in joint connector
<p><b>2 CHECK HARNESS BETWEEN MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR AND ECM CONNECTOR.</b>                      1) Turn the ignition switch to OFF.                      2) Disconnect the connector from mass air flow and intake air temperature sensor.                      3) Measure the voltage between mass air flow and intake air temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B3) No. 2 (+) — Engine ground (-):</b></p>	Is the voltage more than 10 V?	Repair battery short circuit in harness between mass air flow and intake air temperature sensor and ECM connector.	Go to step 3.
<p><b>3 CHECK HARNESS BETWEEN INTAKE AIR TEMPERATURE AND PRESSURE SENSOR AND ECM CONNECTOR.</b>                      1) Turn the ignition switch to ON.                      2) Measure the voltage between mass air flow and intake air temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B3) No. 2 (+) — Engine ground (-):</b></p>	Is the voltage more than 10 V?	Repair battery short circuit in harness between mass air flow and intake air temperature sensor and ECM connector.	Go to step 4.
<p><b>4 CHECK HARNESS BETWEEN MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR AND ECM CONNECTOR.</b>                      Measure the voltage between mass air flow and intake air temperature sensor and pressure sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B3) No. 2 (+) — Engine ground (-):</b></p>	Is the voltage more than 3 V?	Go to step 5.	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between mass air flow and intake air temperature sensor and ECM connector • Poor contact in mass air flow and intake air temperature sensor • Poor contact in ECM • Poor contact in joint connector

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
5	<p><b>CHECK HARNESS BETWEEN MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Measure the resistance of harness between mass air flow and intake air temperature sensor and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(B3) No. 5 — Engine ground:</b></p>	Is the resistance less than 5 $\Omega$ ?	Replace the mass air flow and intake air temperature sensor. <Ref. to FU(DOHC TURBO)-34, Mass Air Flow and Intake Air Temperature Sensor.>	<p>Repair harness and connector.</p> <p><b>NOTE:</b> In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between mass air flow and intake air temperature sensor and ECM connector</li> <li>• Poor contact in mass air flow and intake air temperature sensor</li> <li>• Poor contact in ECM</li> <li>• Poor contact in joint connector</li> </ul>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

---

EN(DOHC TURBO)-125

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### N: DTC P0117 — ENGINE COOLANT TEMPERATURE SENSOR CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Hard to start
  - Erroneous idling
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<p><b>CHECK CURRENT DATA.</b></p> <p>1)Start the engine.</p> <p>2)Read the data of engine coolant temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>•Subaru Select Monitor</li> </ul> <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>•OBD-II general scan tool</li> </ul> <p>For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value greater than 150°C (302°F)?</p>	<p>Go to step 2.</p>	<p>Repair poor contact.</p> <p>NOTE:</p> <p>In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Poor contact in engine coolant temperature sensor</li> <li>• Poor contact in ECM</li> <li>• Poor contact in coupling connector</li> <li>• Poor contact in joint connector</li> </ul>
2	<p><b>CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>1)Turn the ignition switch to OFF.</p> <p>2)Disconnect the connector from engine coolant temperature sensor.</p> <p>3)Turn the ignition switch to ON.</p> <p>4)Read the data of engine coolant temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>•Subaru Select Monitor</li> </ul> <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>•OBD-II general scan tool</li> </ul> <p>For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value less than -40°C (-40°F)?</p>	<p>Replace the engine coolant temperature sensor. &lt;Ref. to FU(DOHC TURBO)-29, Engine Coolant Temperature Sensor.&gt;</p>	<p>Repair ground short circuit in harness between engine coolant temperature sensor and ECM connector.</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## O: DTC P0118 — ENGINE COOLANT TEMPERATURE SENSOR CIRCUIT HIGH INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Hard to start
  - Erroneous idling
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN1147

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK CURRENT DATA.</b> 1) Start the engine. 2) Read the data of engine coolant temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.  <b>NOTE:</b> • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.	Is the value less than $-40^{\circ}\text{C}$ ( $-40^{\circ}\text{F}$ )?	Go to step 2.	Repair poor contact.  <b>NOTE:</b> In this case, repair the following: • Poor contact in engine coolant temperature sensor • Poor contact in ECM • Poor contact in coupling connector • Poor contact in joint connector
<b>2 CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from engine coolant temperature sensor. 3) Measure the voltage between engine coolant temperature sensor connector and engine ground.  <b>Connector &amp; terminal</b> <b>(E8) No. 2 (+) — Engine ground (-):</b>	Is the voltage more than 10 V?	Repair battery short circuit in harness between ECM and engine coolant temperature sensor connector.	Go to step 3.
<b>3 CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between engine coolant temperature sensor connector and engine ground.  <b>Connector &amp; terminal</b> <b>(E8) No. 2 (+) — Engine ground (-):</b>	Is the voltage more than 10 V?	Repair battery short circuit in harness between ECM and engine coolant temperature sensor connector.	Go to step 4.
<b>4 CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</b> Measure the voltage between engine coolant temperature sensor connector and engine ground.  <b>Connector &amp; terminal</b> <b>(E8) No. 2 (+) — Engine ground (-):</b>	Is the voltage more than 4 V?	Go to step 5.	Repair harness and connector.  <b>NOTE:</b> In this case, repair the following: • Open circuit in harness between ECM and engine coolant temperature sensor connector • Poor contact in engine coolant temperature sensor connector • Poor contact in ECM connector • Poor contact in coupling connector • Poor contact in joint connector

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
5	<p><b>CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF. 2) Measure the resistance of harness between engine coolant temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(E8) No. 1 — Engine ground:</b></p>	Is the resistance less than 5 $\Omega$ ?	Replace the engine coolant temperature sensor. <Ref. to FU(DOHC TURBO)-29, Engine Coolant Temperature Sensor.>	Repair harness and connector.  NOTE: In this case, repair the following: <ul style="list-style-type: none"><li>• Open circuit in harness between ECM and engine coolant temperature sensor connector</li><li>• Poor contact in engine coolant temperature sensor connector</li><li>• Poor contact in ECM connector</li><li>• Poor contact in coupling connector</li><li>• Poor contact in joint connector</li></ul>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## P: DTC P0121 — THROTTLE POSITION SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (HIGH INPUT) —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance
  - Fuel is cut.

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN1148

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No	
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0122, P0123 or P1507?	Inspect DTC P0122, P0123 or P1507 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0121.	Replace the throttle position sensor. <Ref. to FU(DOHC TURBO)-33, Throttle Position Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## Q: DTC P0122 — THROTTLE POSITION SENSOR CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN1148

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>CHECK CURRENT DATA.</b>                      1) Start the engine.                      2) Read the data of throttle position sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:                      • Subaru Select Monitor                      For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;                      • OBD-II general scan tool                      For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	Is the value less than 0.1 V?	Go to step 2.	Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause NOTE: In this case, repair the following: • Poor contact in throttle position sensor connector • Poor contact in ECM connector • Poor contact in coupling connector
<p><b>CHECK INPUT SIGNAL FOR ECM.</b>                      Measure the voltage between ECM connector and chassis ground while throttle valve is fully closed.                      * <b>Connector &amp; terminal</b>                      (B135) No. 9 (+) — Chassis ground (-):</p>	Is the voltage more than 4.5 V?	Go to step 4.	Go to step 3.
<p><b>CHECK INPUT SIGNAL FOR ECM.</b>                      Measure the voltage between ECM connector and chassis ground.                      * <b>Connector &amp; terminal</b>                      (B135) No. 9 (+) — Chassis ground (-):</p>	Does the voltage change more than 4.5 V by shaking harness and connector of ECM while monitoring the value with voltage meter?	Repair poor contact in ECM connector.	Contact with SOA (distributor) service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.
<p><b>CHECK INPUT SIGNAL FOR ECM.</b>                      Measure the voltage between ECM connector and chassis ground.                      * <b>Connector &amp; terminal</b>                      (B135) No. 7 (+) — Chassis ground (-):</p>	Is the voltage less than 0.1 V?	Go to step 6.	Go to step 5.
<p><b>CHECK INPUT SIGNAL FOR ECM. (USING SUBARU SELECT MONITOR.)</b>                      Measure the voltage between ECM connector and chassis ground.</p>	Does the voltage change more than 0.1 V by shaking harness and connector of ECM while monitoring the value with Subaru Select Monitor?	Repair poor contact in ECM connector.	Go to step 6.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
6	<p><b>CHECK HARNESS BETWEEN ECM AND THROTTLE POSITION SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.                      2) Disconnect the connectors from throttle position sensor.                      3) Turn the ignition switch to ON.                      4) Measure the voltage between throttle position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E13) No. 1 (+) — Engine ground (-):</b></p>	Is the voltage more than 4.5 V?	Go to step 7.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between throttle position sensor and ECM connector</li> <li>• Poor contact in throttle position sensor connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> <li>• Poor contact in joint connector</li> </ul>
7	<p><b>CHECK HARNESS BETWEEN ECM AND THROTTLE POSITION SENSOR CONNECTOR.</b></p> <p>*1) Turn the ignition switch to OFF.                      2) Measure the resistance of harness between ECM connector and throttle position sensor connector.</p> <p><b>Connector &amp; terminal</b>  <b>(B135) No. 7 — (E13) No. 3:</b></p>	Is the resistance less than 1 $\Omega$ ?	Go to step 8.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between throttle position sensor and ECM connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in throttle position sensor connector</li> <li>• Poor contact in coupling connector</li> </ul>
8	<p><b>CHECK HARNESS BETWEEN ECM AND THROTTLE POSITION SENSOR CONNECTOR.</b></p> <p>Measure the resistance of harness between throttle position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E13) No. 3 — Engine ground:</b></p>	Is the resistance less than 10 $\Omega$ ?	Repair ground short circuit in harness between throttle position sensor and ECM connector.	Go to step 9.
9	<p><b>CHECK POOR CONTACT.</b></p> <p>Check poor contact in throttle position sensor connector.</p>	Is there poor contact in throttle position sensor connector?	Repair poor contact in throttle position sensor connector.	Replace the throttle position sensor. <Ref. to FU(DOHC TURBO)-33, Throttle Position Sensor.>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## R: DTC P0123 — THROTTLE POSITION SENSOR CIRCUIT HIGH INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN1148

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK CURRENT DATA.</b></p> <p>1) Start the engine.</p> <p>2) Read the data of throttle position sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor</li> </ul> <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>• OBD-II general scan tool</li> </ul> <p>For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value more than 4.9 V?</p>	<p>Go to step 2.</p>	<p>Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause.</p> <p>NOTE:</p> <p>In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Poor contact in throttle position sensor connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN THROTTLE POSITION SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from throttle position sensor.</p> <p>3) Measure the resistance of harness between throttle position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(E13) No. 2 — Engine ground:</b></p>	<p>Is the resistance less than 5 Ω?</p>	<p>Go to step 3.</p>	<p>Repair harness and connector.</p> <p>NOTE:</p> <p>In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between throttle position sensor and ECM connector</li> <li>• Poor contact in coupling connector</li> <li>• Poor contact in joint connector</li> </ul>
<p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN THROTTLE POSITION SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn the ignition switch to ON.</p> <p>2) Measure the voltage between throttle position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(E13) No. 3 (+) — Engine ground (-):</b></p>	<p>Is the voltage more than 4.9 V?</p>	<p>Repair battery short circuit in harness between throttle position sensor and ECM connector. After repair, replace the ECM. &lt;Ref. to FU(DOHC TURBO)-47, Engine Control Module.&gt;</p>	<p>Replace the throttle position sensor. &lt;Ref. to FU(DOHC TURBO)-33, Throttle Position Sensor.&gt;</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)



## S: DTC P0125 — INSUFFICIENT COOLANT TEMPERATURE FOR CLOSED LOOP FUEL CONTROL —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Engine would not return to idling.

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1</b> <b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0117 or P0118?	Inspect DTC P0117 or P0118 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>  NOTE: In this case, it is not necessary to inspect DTC P0125.	Go to step 2.
<b>2</b> <b>CHECK ENGINE COOLING SYSTEM.</b>  NOTE: Check the following items. <ul style="list-style-type: none"> <li>•Thermostat open stuck</li> <li>•Coolant level</li> <li>•Coolant freeze</li> <li>•Tire diameter</li> </ul>	Is there a fault in engine cooling system?	Replace the thermostat. <Ref. to CO-35, Thermostat.>	Replace the engine coolant temperature sensor. <Ref. to FU(DOHC TURBO)-29, Engine Coolant Temperature Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### T: DTC P0128 — THERMOSTAT MALFUNCTION —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Thermostat remains open.

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

Step	Check	Yes	No
1	<b>CHECK VEHICLE CONDITION.</b>	Has engine operated at idle or has vehicle been driven with part of engine submerged under water?	In this case, it is not necessary to inspect DTC P0128.  Go to step 2.
2	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0125, P0301, P0302, P0303, P0304, P0305 and P0306 at same time?	Go to step 3.  Inspect DTC P0125, P0301, P0302, P0303, P0304, P0305 and P0306 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>
3	<b>CHECK ENGINE COOLANT.</b>	Are coolant level and mixture ratio of cooling water to anti-freeze solution correct?	Go to step 4.  Replace the engine coolant. <Ref. to CO-25, REPLACEMENT, Engine Coolant.>
4	<b>CHECK RADIATOR FAN.</b> 1)Start the engine. 2)Check radiator fan operation.	Does the radiator fan continuously rotate for more than 3 minutes during idling?	Repair radiator fan circuit. <Ref. to CO-46, Radiator Main Fan and Fan Motor.> and <Ref. to CO-48, Radiator Sub Fan and Fan Motor.>  Replace the thermostat. <Ref. to CO-35, Thermostat.>

**U: DTC P0131 — FRONT OXYGEN (A/F) SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (LOW INPUT) —**

**NOTE:**

For the diagnostic procedure, refer to DTC P0132. <Ref. to EN(DOHC TURBO)-144, DTC P0132 — FRONT OXYGEN (A/F) SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (HIGH INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### V: DTC P0132 — FRONT OXYGEN (A/F) SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (HIGH INPUT) —

- DTC DETECTING CONDITION:
  - Two consecutive driving cycles with fault

#### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

#### • WIRING DIAGRAM:



EN1143

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0031, P0032, P1131, P1134 or P1139?	Inspect DTC P0031, P0032, P1131, P1134 or P1139 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
<b>CHECK FRONT (A/F) OXYGEN SENSOR DATA.</b> 1) Start the engine. 2) While observing the Subaru Select Monitor or OBD-II general scan tool screen, warm-up the engine until coolant temperature is above 70°C (158°F). If the engine is already warmed-up, operate at idle speed for at least 1 minute. 3) Read the data of front oxygen (A/F) sensor signal using Subaru Select Monitor or OBD-II general scan tool. <b>NOTE:</b> • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.	Is the value equal to or more than 0.85 and equal to less than 1.15 in idling?	Go to step 3.	Go to step 4.
<b>CHECK REAR OXYGEN SENSOR SIGNAL.</b> 1) Race the engine at speeds from idling to 5,000 rpm for a total of 5 cycles. <b>NOTE:</b> To increase engine speed to 5,000 rpm, slowly depress accelerator pedal, taking approximately 5 seconds, and quickly release accelerator pedal to decrease engine speed. 2) Operate the LED operation mode for engine. <b>NOTE:</b> • Subaru Select Monitor For detailed operation procedure, refer to the "LED OPERATION MODE FOR ENGINE". <Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.>	Does the LED of {Rear O2 Rich Signal} blink?	Repair poor contact in front oxygen (A/F) sensor and rear oxygen sensor connector.	Check rear oxygen sensor circuit. <Ref. to FU(DOHC TURBO)-44, Rear Oxygen Sensor.>
<b>CHECK EXHAUST SYSTEM.</b> Check exhaust system parts. <b>NOTE:</b> Check the following items. • Loose installation of portions • Damage (crack, hole etc.) of parts • Looseness of front oxygen (A/F) sensor • Looseness and ill fitting of parts between front oxygen (A/F) sensor and rear oxygen sensor	Is there a fault in exhaust system?	Repair or replace faulty parts.	Replace the front oxygen (A/F) sensor. <Ref. to FU(DOHC TURBO)-42, Front Oxygen (A/F) Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## W: DTC P0133 — FRONT OXYGEN (A/F) SENSOR CIRCUIT SLOW RESPONSE

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



EN1143

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0031, P0032, P0131, P0132, P1130, P1131, P1134 or P1139?	Inspect DTC P0031, P0032, P0131, P0132, P1130, P1131, P1134 or P1139 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).> <b>NOTE:</b> In this case, it is not necessary to inspect DTC P0133.	Go to step 2.
2	<b>CHECK EXHAUST SYSTEM.</b> <b>NOTE:</b> Check the following items. <ul style="list-style-type: none"><li>•Loose installation of front portion of exhaust pipe onto cylinder heads</li><li>•Loose connection between front exhaust pipe and front catalytic converter</li><li>•Damage of exhaust pipe resulting in a hole</li></ul>	Is there a fault in exhaust system?	Repair exhaust system.	Replace the front oxygen (A/F) sensor. <Ref. to FU(DOHC TURBO)-42, Front Oxygen (A/F) Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### X: DTC P0136 — REAR OXYGEN SENSOR CIRCUIT MALFUNCTION —


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

**WIRING DIAGRAM:**



EN1144

Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b> Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0131 or P0132?	Go to step 2.	Go to step 3.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>CHECK FAILURE CAUSE OF P0131 or P0132.</b> Inspect DTC P0131 or P0132 using "List of Diagnostic Trouble Code (DTC)". &lt;Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).&gt;</p>	Is the failure cause of P0131 or P0132 in the fuel system?	Check fuel system.  <b>NOTE:</b> In this case, it is not necessary to inspect DTC P0136.	Go to step 3.
<p><b>CHECK REAR OXYGEN SENSOR DATA.</b> 1) Warm-up the engine until engine coolant temperature is above 70°C (158°F), and keep the engine speed at 2,000 rpm to 3,000 rpm for two minutes. 2) Read the data of rear oxygen sensor signal using Subaru Select Monitor or OBD-II general scan tool. <b>NOTE:</b> • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt; • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	Does the value fluctuate?	Go to step 7.	Go to step 4.
<p><b>CHECK REAR OXYGEN SENSOR DATA.</b> Read the data of rear oxygen sensor signal using Subaru Select Monitor or OBD-II General Scan Tool.</p>	Is the value fixed between 0.2 and 0.4 V?	Go to step 5.	Replace the rear oxygen sensor. <Ref. to FU(DOHC TURBO)-44, Rear Oxygen Sensor.>
<p><b>CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM and rear oxygen sensor. 3) Measure the resistance of harness between ECM and rear oxygen sensor connector. <b>Connector &amp; terminal</b> <b>(B135) No. 26 — (B19) No. 4:</b></p>	Is the resistance more than 3 Ω?	Repair open circuit in harness between ECM and rear oxygen sensor connector.	Go to step 6.
<p><b>CHECK HARNESS BETWEEN REAR OXYGEN SENSOR AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from rear oxygen sensor. 3) Turn the ignition switch to ON. 4) Measure voltage between rear oxygen sensor harness connector and engine ground or chassis ground. <b>Connector &amp; terminal</b> <b>(B19) No. 3 (+) — Engine ground (-):</b></p>	Is the voltage more than 0.2 V?	Replace the rear oxygen sensor. <Ref. to FU(DOHC TURBO)-44, Rear Oxygen Sensor.>	Repair harness and connector. <b>NOTE:</b> In this case, repair the following: • Open circuit in harness between rear oxygen sensor and ECM connector • Poor contact in rear oxygen sensor connector • Poor contact in ECM connector
<p><b>CHECK EXHAUST SYSTEM.</b> Check exhaust system parts. <b>NOTE:</b> Check the following items. • Loose installation of portions • Damage (crack, hole etc.) of parts • Looseness and ill fitting of parts between front oxygen (A/F) sensor and rear oxygen sensor</p>	Is there a fault in exhaust system?	Repair or replace faulty parts.	Replace the rear oxygen sensor. <Ref. to FU(DOHC TURBO)-44, Rear Oxygen Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### Y: DTC P0139 — REAR OXYGEN SENSOR CIRCUIT SLOW RESPONSE —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



EN1144

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 <b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0136?	Inspect DTC P0136 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>  NOTE: In this case, it is not necessary to inspect DTC P0139.	Replace the rear oxygen sensor. <Ref. to FU(DOHC TURBO)-44, Rear Oxygen Sensor.>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**Z: DTC P0171 — FUEL TRIM MALFUNCTION (A/F TOO LEAN) —**

**NOTE:**

For the diagnostic procedure, refer to DTC P0172. <Ref. to EN(DOHC TURBO)-153, DTC P0172 — FUEL TRIM MALFUNCTION (A/F TOO RICH) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

## AA:DTC P0172 — FUEL TRIM MALFUNCTION (A/F TOO RICH) —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

**After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.**

Step	Check	Yes	No
1	<b>CHECK EXHAUST SYSTEM.</b>	Are there holes or loose bolts on exhaust system?	Repair exhaust system. Go to step 2.
2	<b>CHECK AIR INTAKE SYSTEM.</b>	Are there holes, loose bolts or disconnection of hose on air intake system?	Repair air intake system. Go to step 3.
3	<b>CHECK FUEL PRESSURE.</b> <b>Warning:</b> •Place "NO FIRE" signs near the working area. •Be careful not to spill fuel on the floor. 1)Release fuel pressure. (1) Disconnect the connector from fuel pump relay. (2) Start the engine and run it until it stalls. (3) After the engine stalls, crank it for five more seconds. (4) Turn the ignition switch to OFF. 2)Connect the connector to fuel pump relay. 3)Disconnect the fuel delivery hose from fuel filter, and connect fuel pressure gauge. 4)Install the fuel filler cap. 5)Start the engine and idle while gear position is neutral. 6)Measure the fuel pressure while disconnecting pressure regulator vacuum hose from intake manifold.  <b>Warning:</b> Before removing the fuel pressure gauge, release fuel pressure.  <b>NOTE:</b> If fuel pressure does not increase, squeeze fuel return hose 2 to 3 times, then measure fuel pressure again.	Is fuel pressure between 284 and 314 kPa (2.9 — 3.2 kg/cm <sup>2</sup> , 41 — 46 psi)?	Go to step 4.  Repair the following items. <b>Fuel pressure too high</b> <ul style="list-style-type: none"> <li>• Clogged fuel return line or bent hose</li> </ul> <b>Fuel pressure too low</b> <ul style="list-style-type: none"> <li>• Improper fuel pump discharge</li> <li>• Clogged fuel supply line</li> </ul>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>4 CHECK FUEL PRESSURE.</b> After connecting the pressure regulator vacuum hose, measure fuel pressure.</p> <p><b>Warning:</b> <b>Before removing the fuel pressure gauge, release fuel pressure.</b></p> <p><b>NOTE:</b> •If fuel pressure does not increase, squeeze fuel return hose 2 to 3 times, then measure fuel pressure again. •If out of specification as measured at this step, check or replace pressure regulator and pressure regulator vacuum hose.</p>	<p>Is fuel pressure between 206 and 235 kPa (2.1 — 2.4 kg/cm<sup>2</sup>, 30 — 34 psi)?</p>	<p>Go to step 5.</p>	<p>Repair the following items. <b>Fuel pressure too high</b></p> <ul style="list-style-type: none"> <li>• Faulty pressure regulator</li> <li>• Clogged fuel return line or bent hose</li> </ul> <p><b>Fuel pressure too low</b></p> <ul style="list-style-type: none"> <li>• Faulty pressure regulator</li> <li>• Improper fuel pump discharge</li> <li>• Clogged fuel supply line</li> </ul>
<p><b>5 CHECK ENGINE COOLANT TEMPERATURE SENSOR.</b> 1)Start the engine and warm-up completely. 2)Read the data of engine coolant temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p><b>NOTE:</b> •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt; •OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is temperature greater than 60°C (140°F)?</p>	<p>Go to step 6.</p>	<p>Replace the engine coolant temperature sensor. &lt;Ref. to FU(DOHC TURBO)-29, Engine Coolant Temperature Sensor.&gt;</p>
<p><b>6 CHECK PRESSURE SENSOR.</b> 1)Start the engine and warm-up engine until coolant temperature is greater than 60°C (140°F). 2)Place the shift lever in neutral position. 3)Turn the A/C switch to OFF. 4)Turn all accessory switches to OFF. 5)Read the data of pressure sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p><b>NOTE:</b> •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt; •OBD-II general scan tool For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</p> <p><b>Specification:</b> •Intake manifold absolute pressure</p> <p><b>Ignition ON</b> 73.3 — 106.6 kPa (550 — 800 mmHg, 21.65 — 31.50 inHg)</p> <p><b>Idling</b> 24.0 — 41.3 kPa (180 — 310 mmHg, 7.09 — 12.20 inHg)</p>	<p>Is the value within the specifications?</p>	<p>Go to step 7.</p>	<p>Replace the mass air flow and pressure sensor. &lt;Ref. to FU(DOHC TURBO)-34, Mass Air Flow and Intake Air Temperature Sensor.&gt;</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>7 CHECK INTAKE AIR TEMPERATURE SENSOR.</b></p> <p>1)Start the engine and warm-up engine until coolant temperature is greater than 60°C (140°F).</p> <p>2)Place the shift lever in neutral position.</p> <p>3)Turn the A/C switch to OFF.</p> <p>4)Turn all accessory switches to OFF.</p> <p>5)Open the front hood.</p> <p>6)Measure the ambient temperature.</p> <p>7)Read the data of pressure sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"><li>•Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;</li><li>•OBD-II general scan tool For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</li></ul>	<p>Is value obtained when ambient temperature is subtracted from intake air temperature greater than -10°C (14°F) and less than 50°C (122°F)?</p>	<p>Contact with SOA (distributor) service.</p> <p>NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p>	<p>Check mass air flow and intake air temperature sensor. &lt;Ref. to FU(DOHC TURBO)-34, Mass Air Flow and Intake Air Temperature Sensor.&gt;</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### AB:DTC P0181 — FUEL TEMPERATURE SENSOR A CIRCUIT RANGE/PERFORMANCE PROBLEM —

- DTC DETECTING CONDITION:
  - Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- WIRING DIAGRAM:



EN1149

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 <b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0182 or P0183?	Inspect DTC P0182 or P0183 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>  NOTE: In this case, it is not necessary to inspect DTC P0181.	Replace the fuel temperature sensor. <Ref. to EC(DOHC TURBO)-9, Fuel Temperature Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### AC:DTC P0182 — FUEL TEMPERATURE SENSOR A CIRCUIT LOW INPUT —

- DTC DETECTING CONDITION:
  - Immediately at fault recognition

#### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

#### • WIRING DIAGRAM:



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK CURRENT DATA.</b></p> <p>1) Start the engine.</p> <p>2) Read the data of fuel temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p><b>NOTE:</b></p> <ul style="list-style-type: none"><li>•Subaru Select Monitor</li></ul> <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"><li>•OBD-II general scan tool</li></ul> <p>For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value greater than 120°C (248°F)?</p>	<p>Go to step 2.</p>	<p>Even if MIL lights up, the circuit has returned to a normal condition at this time.</p>
<p><b>2</b></p> <p><b>CHECK CURRENT DATA.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Remove the access hole lid.</p> <p>3) Disconnect the connector from fuel pump.</p> <p>4) Turn the ignition switch to ON.</p> <p>5) Read the data of fuel temperature sensor signal using Subaru Select Monitor or the OBD-II general scan tool.</p> <p><b>NOTE:</b></p> <ul style="list-style-type: none"><li>•Subaru Select Monitor</li></ul> <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"><li>•OBD-II general scan tool</li></ul> <p>For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value less than -40°C (-40°F)?</p>	<p>Replace the fuel temperature sensor. &lt;Ref. to EC(DOHC TURBO)-9, Fuel Temperature Sensor.&gt;</p>	<p>Repair ground short circuit in harness between fuel pump and ECM connector.</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### AD:DTC P0183 — FUEL TEMPERATURE SENSOR A CIRCUIT HIGH INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1</b> <b>CHECK CURRENT DATA.</b> 1) Start the engine. 2) Read the data of fuel temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.  NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.	Is the value less than $-40^{\circ}\text{C}$ ( $-40^{\circ}\text{F}$ )?	Go to step 2.	Repair poor contact.  NOTE: In this case, repair the following: • Poor contact in fuel pump connector • Poor contact in ECM connector • Poor contact in coupling connectors • Poor contact in joint connector
<b>2</b> <b>CHECK HARNESS BETWEEN FUEL TEMPERATURE SENSOR AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Remove the access hole lid. 3) Disconnect the connector from fuel pump. 4) Measure the voltage between fuel pump connector and chassis ground.  <i>Connector &amp; terminal</i> <i>(R58) No. 5 (+) — Chassis ground (-):</i>	Is the voltage more than 10 V?	Repair battery short circuit in harness between ECM and fuel pump connector.	Go to step 3.
<b>3</b> <b>CHECK HARNESS BETWEEN FUEL TEMPERATURE SENSOR AND ECM CONNECTOR.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between fuel pump connector and chassis ground.  <i>Connector &amp; terminal</i> <i>(R58) No. 5 (+) — Chassis ground (-):</i>	Is the voltage more than 10 V?	Repair battery short circuit in harness between ECM and fuel pump connector.	Go to step 4.
<b>4</b> <b>CHECK HARNESS BETWEEN FUEL TEMPERATURE SENSOR AND ECM CONNECTOR.</b> Measure the voltage between fuel pump connector and chassis ground.  <i>Connector &amp; terminal</i> <i>(R58) No. 5 (+) — Chassis ground (-):</i>	Is the voltage more than 4 V?	Go to step 5.	Repair harness and connector.  NOTE: In this case, repair the following: • Open circuit in harness between ECM and fuel pump connector • Poor contact in fuel pump connector • Poor contact in ECM connector • Poor contact in coupling connectors

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>5</b></p> <p><b>CHECK HARNESS BETWEEN FUEL TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Measure the resistance of harness between fuel pump connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(R58) No. 4 — Chassis ground:</b></p>	<p>Is the resistance less than 5 <math>\Omega</math>?</p>	<p>Replace the fuel temperature sensor. &lt;Ref. to EC(DOHC TURBO)-9, Fuel Temperature Sensor.&gt;</p>	<p>Repair harness and connector.</p> <p><b>NOTE:</b>            In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and fuel pump connector</li> <li>• Poor contact in fuel pump connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connectors</li> <li>• Poor contact in joint connector</li> </ul>



**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)


**AE:DTC P0244 — WASTEGATE CONTROL SOLENOID VALVE MALFUNCTION (HIGH INPUT) —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN1150

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK ANY OTHER DTC ON DISPLAY.	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0245 or P0246?	Inspect DTC P0245 or P0246 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0244.	Replace the wastegate control solenoid valve. <Ref. to FU(DOHC TURBO)-41, Wastegate Control Solenoid Valve.>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)


**AF:DTC P0245 — WASTEGATE CONTROL SOLENOID VALVE CIRCUIT LOW INPUT —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK OUTPUT SIGNAL FROM ECM.</b>                      1) Turn the ignition switch to ON.                      2) Measure the voltage between ECM and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B137) No. 24 (+) — Chassis ground (-):</b></p>	<p>Is the voltage more than 10 V?</p>	<p>Even if MIL lights up, the circuit has returned to a normal condition at this time. Contact with SOA (distributor) service.</p> <p><b>NOTE:</b>                      Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p>	<p>Go to step 2.</p>
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN WASTEGATE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b>                      1) Turn the ignition switch to OFF.                      2) Disconnect the connectors from wastegate control solenoid valve and ECM.                      3) Measure the resistance of harness between wastegate control solenoid valve connector and engine ground.  <b>Connector &amp; terminal</b>  <b>(B127) No. 1 — Engine ground:</b></p>	<p>Is the resistance less than 10 <math>\Omega</math>?</p>	<p>Repair ground short circuit in harness between ECM and wastegate control solenoid valve connector.</p>	<p>Go to step 3.</p>
<p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN WASTEGATE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b>                      Measure the resistance of harness between ECM and wastegate control solenoid valve of harness connector.  <b>Connector &amp; terminal</b>  <b>(B137) No. 24 — (B127) No. 1:</b></p>	<p>Is the resistance less than 1 <math>\Omega</math>?</p>	<p>Go to step 4.</p>	<p>Repair open circuit in harness between ECM and wastegate control solenoid valve connector.</p> <p><b>NOTE:</b>                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and wastegate control solenoid valve connector</li> </ul>
<p><b>4</b></p> <p><b>CHECK WASTEGATE CONTROL SOLENOID VALVE.</b>                      1) Remove the purge control solenoid valve.                      2) Measure the resistance between purge control solenoid valve terminals.  <b>Terminals</b>  <b>No. 1 — No. 2:</b></p>	<p>Is the resistance between 30 and 34 <math>\Omega</math>?</p>	<p>Go to step 5.</p>	<p>Replace the wastegate control solenoid valve.                      &lt;Ref. to FU(DOHC TURBO)-41, Wastegate Control Solenoid Valve.&gt;</p>
<p><b>5</b></p> <p><b>CHECK POWER SUPPLY TO WASTEGATE CONTROL SOLENOID VALVE.</b>                      1) Turn the ignition switch to ON.                      2) Measure the voltage between wastegate control solenoid valve and engine ground.  <b>Connector &amp; terminal</b>  <b>(B127) No. 2 (+) — Engine ground (-):</b></p>	<p>Is the voltage more than 10 V?</p>	<p>Go to step 6.</p>	<p>Repair open circuit in harness between main relay and wastegate control solenoid valve connector.</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
6	<b>CHECK POOR CONTACT.</b> Check poor contact in wastegate control solenoid valve connector.	Is there poor contact in wastegate control solenoid valve connector?	Repair poor contact in wastegate control solenoid valve connector.	Contact with SOA (distributor) service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## AG:DTC P0246 — WASTEGATE CONTROL SOLENOID VALVE CIRCUIT HIGH INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

### • WIRING DIAGRAM:



EN1150

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. <i>Connector &amp; terminal</i> <i>(B137) No. 24 (+) — Chassis ground (-):</i>	Is the voltage more than 10 V?	Go to step 3.	Go to step 2.
<b>2 CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>
<b>3 CHECK HARNESS BETWEEN WASTEGATE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from wastegate control solenoid valve. 3) Turn the ignition switch to ON. 4) Measure the voltage between ECM and chassis ground. <i>Connector &amp; terminal</i> <i>(B137) No. 24 (+) — Chassis ground (-):</i>	Is the voltage more than 10 V?	Repair battery short circuit in harness between ECM and wastegate control solenoid valve connector. After repair, replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>	Go to step 4.
<b>4 CHECK WASTEGATE CONTROL SOLENOID VALVE.</b> 1) Turn the ignition switch to OFF. 2) Measure the resistance between wastegate control solenoid valve terminals. <i>Terminals</i> <i>No. 1 — No. 2:</i>	Is the resistance less than 1 $\Omega$ ?	Replace the wastegate control solenoid valve <Ref. to FU(DOHC TURBO)-41, Wastegate Control Solenoid Valve.> and ECM <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>	Go to step 5.
<b>5 CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**AH:DTC P0301 — CYLINDER 1 MISFIRE DETECTED —**

NOTE:

For the diagnostic procedure, refer to DTC P0304. <Ref. to EN(DOHC TURBO)-173, DTC P0304 — CYLINDER 4 MISFIRE DETECTED —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

**AI: DTC P0302 — CYLINDER 2 MISFIRE DETECTED —**

NOTE:

For the diagnostic procedure, refer to DTC P0304. <Ref. to EN(DOHC TURBO)-173, DTC P0304 — CYLINDER 4 MISFIRE DETECTED —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

**AJ:DTC P0303 — CYLINDER 3 MISFIRE DETECTED —**

NOTE:

For the diagnostic procedure, refer to DTC P0304. <Ref. to EN(DOHC TURBO)-173, DTC P0304 — CYLINDER 4 MISFIRE DETECTED —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

**AK:DTC P0304 — CYLINDER 4 MISFIRE DETECTED —**

**• DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault
- Immediately at fault recognition (A misfire which could damage catalyst occurs.)

**• TROUBLE SYMPTOM:**

- Engine stalls.
- Erroneous idling
- Rough driving



**CAUTION:**

**After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### • WIRING DIAGRAM:



EN1142

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No	
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0106, P0107, P0108, P0117, P0118 or P0125?	Inspect DTC P0106, P0107, P0108, P0117, P0118 or P0125 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>  NOTE: In this case, it is not necessary to inspect DTC P0301, P0302, P0303 and P0304.	Go to step 2.
2	<b>CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM connector and chassis ground on faulty cylinders. <b>Connector &amp; terminal</b> #1 (B137) No. 1 (+) — Chassis ground (-): #2 (B136) No. 6 (+) — Chassis ground (-): #3 (B136) No. 5 (+) — Chassis ground (-): #4 (B136) No. 4 (+) — Chassis ground (-):	Is the voltage more than 10 V?	Go to step 7.	Go to step 3.
3	<b>CHECK HARNESS BETWEEN FUEL INJECTOR AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from fuel injector on faulty cylinders. 3) Disconnect the connector from ECM. 4) Measure the voltage between ECM connector and engine ground on faulty cylinders. <b>Connector &amp; terminal</b> #1 (E5) No. 1 (+) — Engine ground (-): #2 (E16) No. 1 (+) — Engine ground (-): #3 (E6) No. 1 (+) — Engine ground (-): #4 (E17) No. 1 (+) — Engine ground (-):	Is the resistance less than 10 $\Omega$ ?	Repair ground short circuit in harness between fuel injector and ECM connector.	Go to step 4.
4	<b>CHECK HARNESS BETWEEN FUEL INJECTOR AND ECM CONNECTOR.</b> Measure the resistance of harness connector between ECM connector and fuel injector on faulty cylinders. <b>Connector &amp; terminal</b> #1 (B137) No. 1 — (E5) No. 1: #2 (B136) No. 6 — (E16) No. 1: #3 (B136) No. 5 — (E6) No. 1: #4 (B136) No. 4 — (E17) No. 1:	Is the resistance less than 1 $\Omega$ ?	Go to step 5.	Repair harness and connector.  NOTE: In this case, repair the following: • Open circuit in harness between ECM and fuel injector connector • Poor contact in coupling connector
5	<b>CHECK FUEL INJECTOR.</b> Measure the resistance between fuel injector terminals on faulty cylinder. <b>Terminals</b> No. 1 — No. 2:	Is the resistance between 5 and 20 $\Omega$ ?	Go to step 6.	Replace the faulty fuel injector. <Ref. to FU(DOHC TURBO)-37, Fuel Injector.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>6</b>      <b>CHECK POWER SUPPLY LINE.</b>                      1) Turn the ignition switch to ON.                      2) Measure the voltage between fuel injector and engine ground on faulty cylinders.  <b>Connector &amp; terminal</b>                      #1 (E5) No. 2 (+) — Engine ground (-):                      #2 (E16) No. 2 (+) — Engine ground (-):                      #3 (E6) No. 2 (+) — Engine ground (-):                      #4 (E17) No. 2 (+) — Engine ground (-):</p>	Is the voltage more than 10 V?	Repair poor contact in all connectors in fuel injector circuit.	Repair harness and connector.  NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between main relay and fuel injector connector on faulty cylinders</li> <li>• Poor contact in coupling connector</li> <li>• Poor contact in main relay connector</li> <li>• Poor contact in fuel injector connector on faulty cylinders</li> </ul>
<p><b>7</b>      <b>CHECK HARNESS BETWEEN FUEL INJECTOR AND ECM CONNECTOR.</b>                      1) Turn the ignition switch to OFF.                      2) Disconnect the connector from fuel injector on faulty cylinder.                      3) Turn the ignition switch to ON.                      4) Measure the voltage between ECM connector and chassis ground on faulty cylinders.  <b>Connector &amp; terminal</b>                      #1 (B137) No. 1 (+) — Chassis ground (-):                      #2 (B136) No. 6 (+) — Chassis ground (-):                      #3 (B136) No. 5 (+) — Chassis ground (-):                      #4 (B136) No. 4 (+) — Chassis ground (-):</p>	Is the voltage more than 10 V?	Repair battery short circuit in harness between ECM and fuel injector. After repair, replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>	Go to step 8.
<p><b>8</b>      <b>CHECK FUEL INJECTOR.</b>                      1) Turn the ignition switch to OFF.                      2) Measure the resistance between fuel injector terminals on faulty cylinder.  <b>Terminals</b>                      No. 1 — No. 2:</p>	Is the resistance less than 1 Ω?	Replace the faulty fuel injector <Ref. to FU(DOHC TURBO)-37, Fuel Injector.> and ECM <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>	Go to step 9.
<p><b>9</b>      <b>CHECK INSTALLATION OF CAMSHAFT POSITION SENSOR/CRANKSHAFT POSITION SENSOR.</b></p>	Is the camshaft position sensor or crankshaft position sensor loosely installed?	Tighten camshaft position sensor or crankshaft position sensor.	Go to step 10.
<p><b>10</b>     <b>CHECK CRANKSHAFT SPROCKET.</b>                      Remove the timing belt cover.</p>	Is the crankshaft sprocket rusted or does it have broken teeth?	Replace the crankshaft sprocket. <Ref. to ME(DOHC TURBO)-58, Crankshaft Sprocket.>	Go to step 11.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>11 CHECK INSTALLATION CONDITION OF TIMING BELT.</b> Turn the crankshaft using ST, and align alignment mark on crankshaft sprocket with alignment mark on cylinder block. ST 499987500 CRANKSHAFT SOCKET	Is the timing belt dislocated from its proper position?	Repair installation condition of timing belt. <Ref. to ME(DOHC TURBO)-48, Timing Belt Assembly.>	Go to step 12.
<b>12 CHECK FUEL LEVEL.</b>	Is the fuel meter indication higher than the "Lower" level?	Go to step 13.	Replenish fuel so fuel meter indication is higher than the "Lower" level. After replenishing fuel, Go to step 13.
<b>13 CHECK STATUS OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL).</b> 1) Clear the memory using Subaru Select Monitor. <Ref. to EN(DOHC TURBO)-49, Clear Memory Mode.> 2) Start the engine, and drive the vehicle more than 10 minutes.	Is the MIL coming on or blinking?	Go to step 15.	Go to step 14.
<b>14 CHECK CAUSE OF MISFIRE DIAGNOSED.</b>	Was the cause of misfire diagnosed when the engine is running?	Finish diagnostics operation, if the engine has no abnormality.  NOTE: Ex. Remove the spark plug cord, etc.	Repair poor contact.  NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Poor contact in ignitor connector</li> <li>• Poor contact in ignition coil connector</li> <li>• Poor contact in fuel injector connector on faulty cylinders</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>
<b>15 CHECK AIR INTAKE SYSTEM.</b>	Is there a fault in air intake system?	Repair air intake system.  NOTE: Check the following items: <ul style="list-style-type: none"> <li>• Are there air leaks or air suction caused by loose or dislocated nuts and bolts?</li> <li>• Are there cracks or any disconnection of hoses?</li> </ul>	Go to step 16.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>16 CHECK MISFIRE SYMPTOM.</b> 1) Turn the ignition switch to ON. 2) Read the diagnostic trouble code (DTC). • Subaru Select Monitor <Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Operation Manual. NOTE: Perform diagnosis according to the items listed below.	Does the Subaru Select Monitor or OBD-II general scan tool indicate only one DTC?	Go to step 21.	Go to step 17.
<b>17 CHECK DIAGNOSTIC TROUBLE CODE (DTC) ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0301 and P0302?	Go to step 22.	Go to step 18.
<b>18 CHECK DIAGNOSTIC TROUBLE CODE (DTC) ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0303 and P0304?	Go to step 23.	Go to step 19.
<b>19 CHECK DIAGNOSTIC TROUBLE CODE (DTC) ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0301 and P0303?	Go to step 24.	Go to step 20.
<b>20 CHECK DIAGNOSTIC TROUBLE CODE (DTC) ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0302 and P0304?	Go to step 25.	Go to step 26.
<b>21 ONLY ONE CYLINDER</b>	Is there a fault in that cylinder?	Repair or replace faulty parts. NOTE: Check the following items. • Spark plug • Spark plug cord • Fuel injector • Compression ratio	Go to DTC P0171 and P0172. <Ref. to EN(DOHC TURBO)-152, DTC P0171 — FUEL TRIM MALFUNCTION (A/F TOO LEAN) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
22	<b>GROUP OF #1 AND #2 CYLINDERS</b>	Repair or replace faulty parts. NOTE: • Check the following items. <ul style="list-style-type: none"> <li>• Spark plugs</li> <li>• Fuel injectors</li> <li>• Ignition coil</li> <li>• Compression ratio</li> </ul> • If no abnormal is discovered, check for "IGNITION CONTROL SYSTEM" of #1 and #2 cylinders side. <Ref. to EN(DOHC TURBO)-72, IGNITION CONTROL SYSTEM, Diagnostics for Engine Starting Failure.>	Go to DTC P0171 and P0172. <Ref. to EN(DOHC TURBO)-152, DTC P0171 — FUEL TRIM MALFUNCTION (A/F TOO LEAN) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
23	<b>GROUP OF #3 AND #4 CYLINDERS</b>	Repair or replace faulty parts. NOTE: • Check the following items. <ul style="list-style-type: none"> <li>• Spark plugs</li> <li>• Fuel injectors</li> <li>• Ignition coil</li> </ul> • If no abnormal is discovered, check for "IGNITION CONTROL SYSTEM" of #3 and #4 cylinders side. <Ref. to EN(DOHC TURBO)-72, IGNITION CONTROL SYSTEM, Diagnostics for Engine Starting Failure.>	Go to DTC P0171 and P0172. <Ref. to EN(DOHC TURBO)-152, DTC P0171 — FUEL TRIM MALFUNCTION (A/F TOO LEAN) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
24	<b>GROUP OF #1 AND #3 CYLINDERS</b>	Repair or replace faulty parts. NOTE: Check the following items. <ul style="list-style-type: none"> <li>• Spark plugs</li> <li>• Fuel injectors</li> <li>• Skipping timing belt teeth</li> </ul>	Go to DTC P0171 and P0172. <Ref. to EN(DOHC TURBO)-152, DTC P0171 — FUEL TRIM MALFUNCTION (A/F TOO LEAN) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>25</b> <b>GROUP OF #2 AND #4 CYLINDERS</b>	Are there faults in #2 and #4 cylinders?	Repair or replace faulty parts. NOTE: Check the following items. <ul style="list-style-type: none"><li>• Spark plugs</li><li>• Fuel injectors</li><li>• Compression ratio</li><li>• Skipping timing belt teeth</li></ul>	Go to DTC P0171 and P0172. <Ref. to EN(DOHC TURBO)-152, DTC P0171 — FUEL TRIM MALFUNCTION (A/F TOO LEAN) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
<b>26</b> <b>CYLINDER AT RANDOM</b>	Is the engine idle rough?	Go to DTC P0171 and P0172. <Ref. to EN(DOHC TURBO)-152, DTC P0171 — FUEL TRIM MALFUNCTION (A/F TOO LEAN) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Repair or replace faulty parts. NOTE: Check the following items. <ul style="list-style-type: none"><li>• Spark plugs</li><li>• Fuel injectors</li><li>• Compression ratio</li></ul>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## AL:DTC P0327 — KNOCK SENSOR CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Poor driving performance
  - Knocking occurs.

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



EN0975

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1</b> <b>CHECK HARNESS BETWEEN KNOCK SENSOR AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance between ECM harness connector and chassis ground. <i>Connector &amp; terminal</i> <i>(B135) No. 4 — Chassis ground:</i>	Is the resistance more than 700 k $\Omega$ ?	Go to step 2.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between knock sensor and ECM connector</li> <li>• Poor contact in knock sensor connector</li> <li>• Poor contact in coupling connector</li> </ul>
<b>2</b> <b>CHECK KNOCK SENSOR.</b> 1) Disconnect the connector from knock sensor. 2) Measure the resistance between knock sensor connector terminal and engine ground. <i>Terminal</i> <i>No. 2 — Engine ground:</i>	Is the resistance more than 700 k $\Omega$ ?	Go to step 3.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between knock sensor and ECM connector</li> <li>• Poor contact in knock sensor connector</li> <li>• Poor contact in coupling connector</li> </ul>
<b>3</b> <b>CHECK CONDITION OF KNOCK SENSOR INSTALLATION.</b>	Is the knock sensor installation bolt tightened securely?	Replace the knock sensor. <Ref. to FU(DOHC TURBO)-32, Knock Sensor.>	Tighten knock sensor installation bolt securely.


**AM:DTC P0328 — KNOCK SENSOR CIRCUIT HIGH INPUT —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Poor driving performance
  - Knocking occurs.

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN0975

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1</b> <b>CHECK HARNESS BETWEEN KNOCK SENSOR AND ECM CONNECTOR.</b> Measure the resistance of harness between ECM connector and chassis ground. <i>Connector &amp; terminal</i> <i>(B135) No. 4 — Chassis ground:</i>	Is the resistance less than 400 k $\Omega$ ?	Go to step 2.	Go to step 3.
<b>2</b> <b>CHECK KNOCK SENSOR.</b> 1)Disconnect the connector from knock sensor. 2)Measure the resistance between knock sensor connector terminal and engine ground. <i>Terminal</i> <i>No. 2 — Engine ground:</i>	Is the resistance less than 400 k $\Omega$ ?	Replace the knock sensor. <Ref. to FU(DOHC TURBO)-32, Knock Sensor.>	Repair ground short circuit in harness between knock sensor connector and ECM connector.  NOTE: The harness between both connectors is shielded. Repair short circuit of harness together with shield.
<b>3</b> <b>CHECK INPUT SIGNAL FOR ECM.</b> 1)Connect the connectors to ECM and knock sensor. 2)Turn the ignition switch to ON. 3)Measure the voltage between ECM and chassis ground. <i>Connector &amp; terminal</i> <i>(B135) No. 4 (+) — Chassis ground (-):</i>	Is the voltage more than 2 V?	Even if MIL lights up, the circuit has returned to a normal condition at this time. (However, the possibility of poor contact still remains.)  NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Poor contact in knock sensor connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>	Repair poor contact in ECM connector.


**AN:DTC P0335 — CRANKSHAFT POSITION SENSOR CIRCUIT MALFUNCTION**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Engine stalls.
  - Failure of engine to start

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN0976

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b>     <b>CHECK HARNESS BETWEEN CRANKSHAFT POSITION SENSOR AND ECM CONNECTOR.</b>            1) Turn the ignition switch to OFF.            2) Disconnect the connector from crankshaft position sensor.            3) Measure the resistance of harness between crankshaft position sensor connector and engine ground.  <b>Connector &amp; terminal</b>  <b>(E10) No. 1 — Engine ground:</b></p>	<p>Is the resistance more than 100 k<math>\Omega</math>?</p>	<p>Repair harness and connector.            NOTE:            In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between crankshaft position sensor and ECM connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>	<p>Go to step 2.</p>
<p><b>2</b>     <b>CHECK HARNESS BETWEEN CRANKSHAFT POSITION SENSOR AND ECM CONNECTOR.</b>            Measure the resistance of harness between crankshaft position sensor connector and engine ground.  <b>Connector &amp; terminal</b>  <b>(E10) No. 1 — Engine ground:</b></p>	<p>Is the resistance less than 10 <math>\Omega</math>?</p>	<p>Repair ground short circuit in harness between crankshaft position sensor and ECM connector.            NOTE:            The harness between both connectors are shielded. Repair ground short circuit in harness together with shield.</p>	<p>Go to step 3.</p>
<p><b>3</b>     <b>CHECK HARNESS BETWEEN CRANKSHAFT POSITION SENSOR AND ECM CONNECTOR.</b>            Measure the resistance of harness between crankshaft position sensor connector and engine ground.  <b>Connector &amp; terminal</b>  <b>(E10) No. 2 — Engine ground:</b></p>	<p>Is the resistance less than 5 <math>\Omega</math>?</p>	<p>Go to step 4.</p>	<p>Repair harness and connector.            NOTE:            In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between crankshaft position sensor and ECM connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>4</b>     <b>CHECK CONDITION OF CRANKSHAFT POSITION SENSOR.</b></p>	<p>Is the crankshaft position sensor installation bolt tightened securely?</p>	<p>Go to step 5.</p>	<p>Tighten the crankshaft position sensor installation bolt securely.</p>
<p><b>5</b>     <b>CHECK CRANKSHAFT POSITION SENSOR.</b>            1) Remove the crankshaft position sensor.            2) Measure the resistance between connector terminals of crankshaft position sensor.  <b>Terminals</b>  <b>No. 1 — No. 2:</b></p>	<p>Is the resistance between 1 and 4 k<math>\Omega</math>?</p>	<p>Repair poor contact in crankshaft position sensor connector.</p>	<p>Replace the crankshaft position sensor. &lt;Ref. to FU(DOHC TURBO)-30, Crankshaft Position Sensor.&gt;</p>


**AO:DTC P0336 — CRANKSHAFT POSITION SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Engine stalls.
  - Failure of engine to start

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Inspect DTC P0335 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
2	<b>CHECK CONDITION OF CRANKSHAFT POSITION SENSOR.</b> Turn the ignition switch to OFF.	Is the crankshaft position sensor installation bolt tightened securely?	Go to step 3.  Tighten crankshaft position sensor installation bolt securely.
3	<b>CHECK CRANKSHAFT SPROCKET.</b> Remove the front belt cover.	Are crankshaft sprocket teeth cracked or damaged?	Replace the crankshaft sprocket. <Ref. to FU(DOHC TURBO)-30, Crankshaft Position Sensor.>  Go to step 4.
4	<b>CHECK INSTALLATION CONDITION OF TIMING BELT.</b> Turn the crankshaft using ST, and align alignment mark on crankshaft sprocket with alignment mark on cylinder block. ST 499987500 CRANKSHAFT SOCKET	Is the timing belt dislocated from its proper position?	Repair installation condition of timing belt. <Ref. to ME(DOHC TURBO)-48, Timing Belt Assembly.>  Replace the crankshaft position sensor. <Ref. to FU(DOHC TURBO)-30, Crankshaft Position Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## AP:DTC P0340 — CAMSHAFT POSITION SENSOR CIRCUIT MALFUNCTION —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Engine stalls.
  - Failure of engine to start

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from camshaft position sensor. 3) Measure the resistance of harness between camshaft position sensor connector and engine ground. <i>Connector &amp; terminal</i> <i>(E15) No. 1 — Engine ground:</i>	Is the resistance more than 100 k $\Omega$ ?	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between camshaft position sensor and ECM connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>	Go to step 2.
<b>2 CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.</b> Measure the resistance of harness between camshaft position sensor connector and engine ground. <i>Connector &amp; terminal</i> <i>(E15) No. 1 — Engine ground:</i>	Is the resistance less than 10 $\Omega$ ?	Repair ground short circuit in harness between camshaft position sensor and ECM connector. NOTE: The harness between both connectors are shielded. Repair ground short circuit in harness together with shield.	Go to step 3.
<b>3 CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.</b> Measure the resistance of harness between camshaft position sensor connector and engine ground. <i>Connector &amp; terminal</i> <i>(E15) No. 2 — Engine ground:</i>	Is the resistance less than 5 $\Omega$ ?	Go to step 4.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between camshaft position sensor and ECM connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>
<b>4 CHECK CONDITION OF CAMSHAFT POSITION SENSOR.</b>	Is the camshaft position sensor installation bolt tightened securely?	Go to step 5.	Tighten camshaft position sensor installation bolt securely.
<b>5 CHECK CAMSHAFT POSITION SENSOR.</b> 1) Remove the camshaft position sensor. 2) Measure the resistance between connector terminals of camshaft position sensor. <i>Terminals</i> <i>No. 1 — No. 2:</i>	Is the resistance between 1 and 4 k $\Omega$ ?	Repair poor contact in camshaft position sensor connector.	Replace the camshaft position sensor. <Ref. to FU(DOHC TURBO)-31, Camshaft Position Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### AQ:DTC P0341 — CAMSHAFT POSITION SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Engine stalls.
  - Failure of engine to start

#### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



EN0977

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1</b> <b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0340?	Inspect DTC P0340 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
<b>2</b> <b>CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from camshaft position sensor. 3) Measure the resistance of harness between camshaft position sensor connector and engine ground. <b>Connector &amp; terminal</b> <b>(E15) No. 1 — Engine ground:</b>	Is the resistance more than 100 k $\Omega$ ?	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between camshaft position sensor and ECM connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>	Go to step 3.
<b>3</b> <b>CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.</b> Measure the resistance of harness between camshaft position sensor connector and engine ground. <b>Connector &amp; terminal</b> <b>(E15) No. 1 — Engine ground:</b>	Is the resistance less than 10 $\Omega$ ?	Repair ground short circuit in harness between camshaft position sensor and ECM connector. NOTE: The harness between both connectors are shielded. Repair ground short circuit in harness together with shield.	Go to step 4.
<b>4</b> <b>CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.</b> Measure the resistance of harness between camshaft position sensor connector and engine ground. <b>Connector &amp; terminal</b> <b>(E15) No. 2 — Engine ground:</b>	Is the resistance less than 5 $\Omega$ ?	Go to step 5.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between camshaft position sensor and ECM connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>
<b>5</b> <b>CHECK CONDITION OF CAMSHAFT POSITION SENSOR.</b>	Is the camshaft position sensor installation bolt tightened securely?	Go to step 6.	Tighten camshaft position sensor installation bolt securely.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>6 CHECK CAMSHAFT POSITION SENSOR.</b> 1) Remove the camshaft position sensor. 2) Measure the resistance between connector terminals of camshaft position sensor. <i>Terminals</i> <i>No. 1 — No. 2:</i>	Is the resistance between 1 and 4 k $\Omega$ ?	Go to step 7.	Replace the camshaft position sensor. <Ref. to FU(DOHC TURBO)-31, Camshaft Position Sensor.>
<b>7 CHECK CONDITION OF CAMSHAFT POSITION SENSOR.</b> Turn the ignition switch to OFF.	Is the camshaft position sensor installation bolt tightened securely?	Go to step 8.	Tighten camshaft position sensor installation bolt securely.
<b>8 CHECK CAMSHAFT SPROCKET.</b> Remove the front belt cover. <Ref. to ME(SOHC)-46, Belt Cover.>	Are camshaft sprocket teeth cracked or damaged?	Replace the camshaft sprocket. <Ref. to ME(DOHC TURBO)-57, Camshaft Sprocket.>	Go to step 9.
<b>9 CHECK INSTALLATION CONDITION OF TIMING BELT.</b> Turn the camshaft using ST, and align alignment mark on camshaft sprocket with alignment mark on timing belt cover LH. ST 499207100 CAMSHAFT SPROCKET WRENCH	Is the timing belt dislocated from its proper position?	Repair installation condition of timing belt. <Ref. to ME(DOHC TURBO)-48, Timing Belt Assembly.>	Replace the camshaft position sensor. <Ref. to FU(DOHC TURBO)-31, Camshaft Position Sensor.>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### AR:DTC P0420 — CATALYST SYSTEM EFFICIENCY BELOW THRESHOLD —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Engine stalls.
  - Idle mixture is out of specifications.

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN1151

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No	
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0031, P0032, P0131, P0132, P0133, P1130, P1131, P1134, P1139, P0037, P0038, P0136 and P0139?	Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).> <b>NOTE:</b> In this case, it is not necessary to inspect DTC P0420.	Go to step 2.
2	<b>CHECK EXHAUST SYSTEM.</b> Check for gas leaks or air suction caused by loose or dislocated nuts and bolts, and open hole at exhaust pipes. <b>NOTE:</b> Check the following positions. •Between cylinder head and front exhaust pipe •Between front exhaust pipe and front catalytic converter •Between front catalytic converter and rear catalytic converter	Is there a fault in exhaust system?	Repair or replace the exhaust system. <Ref. to EX(DOHC TURBO)-2, General Description.>	Go to step 3.
3	<b>CHECK REAR CATALYTIC CONVERTER.</b> Separate rear catalytic converter from rear exhaust pipe.	Is there damage at rear face of rear catalyst?	Replace the front catalytic converter <Ref. to EC(DOHC TURBO)-3, Front Catalytic Converter.> and rear catalytic converter <Ref. to EC(DOHC TURBO)-4, Rear Catalytic Converter.>	Go to step 4.
4	<b>CHECK FRONT CATALYTIC CONVERTER.</b> Remove the front catalytic converter.	Is there damage at rear face or front face of front catalyst?	Replace the front catalytic converter. <Ref. to EC(DOHC TURBO)-3, Front Catalytic Converter.>	Contact with SOA (distributor) service. <b>NOTE:</b> Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**AS:DTC P0442 — EVAPORATIVE EMISSION CONTROL SYSTEM MALFUNCTION —**

• **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

• **TROUBLE SYMPTOM:**


- Gasoline smell
- There is a hole of more than 1.0 mm (0.04 in) dia. in evaporation system or fuel tank.

**CAUTION:**

**After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, Operation.> OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)

## • WIRING DIAGRAM:



EN1152

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
2	<b>CHECK FUEL FILLER CAP.</b> 1) Turn the ignition switch to OFF. 2) Check the fuel filler cap.  NOTE: The DTC code is stored in memory if fuel filler cap is or was loose or if the cap chain was caught while tightening.	Is the fuel filler cap tightened securely?	Go to step 3.  Tighten fuel filler cap securely.
3	<b>CHECK FUEL FILLER PIPE PACKING.</b>	Is there any damage to the seal between fuel filler cap and fuel filler pipe?	Repair or replace the fuel filler cap and fuel filler pipe. <Ref. to FU(DOHC TURBO)-55, Fuel Filler Pipe.>  Go to step 4.
4	<b>CHECK DRAIN VALVE.</b> 1) Connect the test mode connector. 2) Turn the ignition switch to ON. 3) Operate the drain valve.  NOTE: Drain valve operation can also be executed using Subaru Select Monitor. For the procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(DOHC TURBO)-50, Compulsory Valve Operation Check Mode.>	Does the drain valve produce operating sound?	Go to step 5.  Replace the drain valve. <Ref. to EC(DOHC TURBO)-17, Drain Valve.>
5	<b>CHECK PURGE CONTROL SOLENOID VALVE.</b> Operate the purge control solenoid valve.  NOTE: Purge control solenoid valve operation can also be executed using Subaru Select Monitor. For the procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(DOHC TURBO)-50, Compulsory Valve Operation Check Mode.>	Does the purge control solenoid valve produce operating sound?	Go to step 6.  Replace the purge control solenoid valve. <Ref. to EC(DOHC TURBO)-7, Purge Control Solenoid Valve.>
6	<b>CHECK PRESSURE CONTROL SOLENOID VALVE.</b> Operate the pressure control solenoid valve.  NOTE: Pressure control solenoid valve operation can also be executed using Subaru Select Monitor. For the procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(DOHC TURBO)-50, Compulsory Valve Operation Check Mode.>	Does the pressure control solenoid valve produce operating sound?	Go to step 7.  Replace the pressure control solenoid valve. <Ref. to EC(DOHC TURBO)-12, Pressure Control Solenoid Valve.>
7	<b>CHECK EVAPORATIVE EMISSION CONTROL SYSTEM LINE.</b> Turn the ignition switch to OFF.	Is there a hole of more than 1.0 mm (0.04 in) dia. on fuel line?	Repair or replace the fuel line. <Ref. to FU(DOHC TURBO)-68, Fuel Delivery, Return and Evaporation Lines.>  Go to step 8.

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
**ENGINE (DIAGNOSTICS)**

Step	Check	Yes	No
<b>8</b> <b>CHECK CANISTER.</b>	Is the canister damaged or is there a hole of more than 1.0 mm (0.04 in) dia. in it?	Repair or replace the canister. <Ref. to EC(DOHC TURBO)-6, Canister.>	Go to step 9.
<b>9</b> <b>CHECK FUEL TANK.</b> Remove the fuel tank. <Ref. to FU(DOHC TURBO)-52, Fuel Tank.>	Is the fuel tank damaged or is there a hole of more than 1.0 mm (0.04 in) dia. in it?	Repair or replace the fuel tank. <Ref. to FU(DOHC TURBO)-52, Fuel Tank.>	Go to step 10.
<b>10</b> <b>CHECK ANY OTHER MECHANICAL TROUBLE IN EVAPORATIVE EMISSION CONTROL SYSTEM.</b>	Are there holes of more than 1.0 mm (0.04 in) dia., cracks, clogging or disconnections of hoses or pipes in evaporative emission control system?	Repair or replace the hoses or pipes.	Contact with SOA (distributor) service.  NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## AT:DTC P0444 — EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN1153

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B137) No. 16 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V?	Even if MIL lights up, the circuit has returned to a normal condition at this time. Contact with SOA (distributor) service.  NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.	Go to step 2.
<b>2 CHECK HARNESS BETWEEN PURGE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from purge control solenoid valve and ECM. 3) Measure the resistance of harness between purge control solenoid valve connector and engine ground. <b>Connector &amp; terminal</b> <b>(E4) No. 2 — Engine ground:</b>	Is the resistance less than 10 $\Omega$ ?	Repair ground short circuit in harness between ECM and purge control solenoid valve connector.	Go to step 3.
<b>3 CHECK HARNESS BETWEEN PURGE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b> Measure the resistance of harness between ECM and purge control solenoid valve of harness connector. <b>Connector &amp; terminal</b> <b>(B137) No. 16 — (E4) No. 2:</b>	Is the resistance less than 1 $\Omega$ ?	Go to step 4.	Repair open circuit in harness between ECM and purge control solenoid valve connector.  NOTE: In this case, repair the following: • Open circuit in harness between ECM and purge control solenoid valve connector • Poor contact in coupling connector
<b>4 CHECK PURGE CONTROL SOLENOID VALVE.</b> 1) Remove the purge control solenoid valve. 2) Measure the resistance between purge control solenoid valve terminals. <b>Terminals</b> <b>No. 1 — No. 2:</b>	Is the resistance between 10 and 100 $\Omega$ ?	Go to step 5.	Replace the purge control solenoid valve. <Ref. to EC(DOHC TURBO)-7, Purge Control Solenoid Valve.>
<b>5 CHECK POWER SUPPLY TO PURGE CONTROL SOLENOID VALVE.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between purge control solenoid valve and engine ground. <b>Connector &amp; terminal</b> <b>(E4) No. 1 (+) — Engine ground (-):</b>	Is the voltage more than 10 V?	Go to step 6.	Repair open circuit in harness between main relay and purge control solenoid valve connector.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
6	<b>CHECK POOR CONTACT.</b> Check poor contact in purge control solenoid valve connector.	Is there poor contact in purge control solenoid valve connector?	Repair poor contact in purge control solenoid valve connector.	Contact with SOA (distributor) service. <b>NOTE:</b> Inspection by DTM is required, because probable cause is deterioration of multiple parts.



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## AU:DTC P0445 — EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT HIGH INPUT —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN1153

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Turn the ignition switch to OFF. 2) Connect the test mode connector at the lower portion of instrument panel (on the driver's side), to the side of the center console box. 3) Turn the ignition switch to ON. 4) While operating the purge control solenoid valve, measure voltage between ECM and chassis ground.  NOTE: Purge control solenoid valve operation can be executed using Subaru Select Monitor. For procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(DOHC TURBO)-50, Compulsory Valve Operation Check Mode.>  <b>Connector &amp; terminal</b> <b>(B137) No. 16 (+) — Chassis ground (-):</b>	Does the voltage change between 0 and 10 V?	Go to step 2.	Even if MIL light up, the circuit has returned to a normal condition at this time. In this case, repair poor contact in ECM connector.
<b>2 CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground.  <b>Connector &amp; terminal</b> <b>(B137) No. 16 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V?	Go to step 4.	Go to step 3.
<b>3 CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>
<b>4 CHECK HARNESS BETWEEN PURGE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from purge control solenoid valve. 3) Turn the ignition switch to ON. 4) Measure the voltage between ECM and chassis ground.  <b>Connector &amp; terminal</b> <b>(B137) No. 16 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V?	Repair battery short circuit in harness between ECM and purge control solenoid valve connector. After repair, replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>	Go to step 5.
<b>5 CHECK PURGE CONTROL SOLENOID VALVE.</b> 1) Turn the ignition switch to OFF. 2) Measure the resistance between purge control solenoid valve terminals.  <b>Terminals</b> <b>No. 1 — No. 2:</b>	Is the resistance less than 1 $\Omega$ ?	Replace the purge control solenoid valve <Ref. to EC(DOHC TURBO)-7, Purge Control Solenoid Valve.> and ECM <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>	Go to step 6.
<b>6 CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## AV:DTC P0447 — EVAPORATIVE EMISSION CONTROL SYSTEM VENT CONTROL LOW INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



EN1154

Step	Check	Yes	No	
1	<b>CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. <i>Connector &amp; terminal</i> (B137) No. 11 (+) — Chassis ground (-):	Is the voltage more than 10 V?	Go to step 2.	Go to step 3.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>2</b></p> <p><b>CHECK POOR CONTACT.</b> Check poor contact in ECM connector.</p>	<p>Is there poor contact in ECM connector?</p>	<p>Repair poor contact in ECM connector.</p>	<p>Even if MIL lights up, the circuit has returned to a normal condition at this time. (However, the possibility of poor contact still remains.)</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Poor contact in drain valve connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connectors</li> </ul>
<p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN DRAIN VALVE AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from drain valve and ECM. 3) Measure the resistance of harness between drain valve connector and chassis ground. <i>Connector &amp; terminal</i> <i>(R69) No. 2 — Chassis ground:</i></p>	<p>Is the resistance less than 10 <math>\Omega</math>?</p>	<p>Repair ground short circuit in harness between ECM and drain valve connector.</p>	<p>Go to step 4.</p>
<p><b>4</b></p> <p><b>CHECK HARNESS BETWEEN DRAIN VALVE AND ECM CONNECTOR.</b> Measure the resistance of harness between ECM and drain valve connector. <i>Connector &amp; terminal</i> <i>(B137) No. 11 — (R69) No. 2:</i></p>	<p>Is the voltage less than 1 <math>\Omega</math>?</p>	<p>Go to step 5.</p>	<p>Repair harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and drain valve connector</li> <li>• Poor contact in coupling connectors</li> </ul>
<p><b>5</b></p> <p><b>CHECK DRAIN VALVE.</b> Measure the resistance between drain valve terminals. <i>Terminals</i> <i>No. 1 — No. 2:</i></p>	<p>Is the resistance between 10 and 100 <math>\Omega</math>?</p>	<p>Go to step 6.</p>	<p>Replace the drain valve. &lt;Ref. to EC(DOHC TURBO)-17, Drain Valve.&gt;</p>
<p><b>6</b></p> <p><b>CHECK POWER SUPPLY TO DRAIN VALVE.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between drain valve and chassis ground. <i>Connector &amp; terminal</i> <i>(R69) No. 1 (+) — Chassis ground (-):</i></p>	<p>Is the voltage more than 10 V?</p>	<p>Go to step 7.</p>	<p>Repair harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between main relay and drain valve</li> <li>• Poor contact in coupling connectors</li> <li>• Poor contact in main relay connector</li> </ul>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
7	<b>CHECK POOR CONTACT.</b> Check poor contact in drain valve connector.	Is there poor contact in drain valve connector?	Repair poor contact in drain valve connector.	Contact with SOA (distributor) service. <b>NOTE:</b> Inspection by DTM is required, because probable cause is deterioration of multiple parts.



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## AW:DTC P0448 — EVAPORATIVE EMISSION CONTROL SYSTEM VENT CONTROL HIGH INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



EN1154

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Turn the ignition switch to OFF. 2) Connect the test mode connector at the lower portion of instrument panel (on the driver's side), to the side of the center console box. 3) Turn the ignition switch to ON. 4) While operating the drain valve, measure voltage between ECM and chassis ground.  <b>NOTE:</b> Drain valve operation can be executed using Subaru Select Monitor. For procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(DOHC TURBO)-50, Compulsory Valve Operation Check Mode.>  <b>Connector &amp; terminal</b> <b>(B137) No. 11 (+) — Chassis ground (-):</b>	Does the voltage change between 0 and 10 V?	Go to step 2.	Even if MIL lights up, the circuit has returned to a normal condition at this time. In this case, repair poor contact in ECM connector.
<b>2 CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground.  <b>Connector &amp; terminal</b> <b>(B137) No. 11 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V?	Go to step 4.	Go to step 3.
<b>3 CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>
<b>4 CHECK HARNESS BETWEEN DRAIN VALVE AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from drain valve. 3) Turn the ignition switch to ON. 4) Measure the voltage between ECM and chassis ground.  <b>Connector &amp; terminal</b> <b>(B137) No. 11 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V?	Repair battery short circuit in harness between ECM and drain valve connector. After repair, replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>	Go to step 5.
<b>5 CHECK DRAIN VALVE.</b> 1) Turn the ignition switch to OFF. 2) Measure the resistance between drain valve terminals.  <b>Terminals</b> <b>No. 1 — No. 2:</b>	Is the resistance less than 1 $\Omega$ ?	Replace the drain valve <Ref. to EC(DOHC TURBO)-17, Drain Valve.> and ECM <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>	Go to step 6.
<b>6 CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
**ENGINE (DIAGNOSTICS)**


**AX:DTC P0451 — EVAPORATIVE EMISSION CONTROL SYSTEM PRESSURE SENSOR RANGE/PERFORMANCE PROBLEM —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



EN1155

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1</b> <b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Is there any DTC on display?	Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
<b>2</b> <b>CHECK FUEL FILLER CAP.</b> 1) Turn the ignition switch to OFF. 2) Open the fuel flap.	Is the fuel filler cap tightened securely?	Go to step 3.	Tighten fuel filler cap securely.
<b>3</b> <b>CHECK PRESSURE/VACUUM LINE.</b> NOTE: Check the following items. • Disconnection, leakage and clogging of the vacuum hoses and pipes between fuel tank pressure sensor and fuel tank • Disconnection, leakage and clogging of air ventilation hoses and pipes between fuel filler pipe and fuel tank	Is there a fault in pressure/vacuum line?	Repair or replace the hoses and pipes.	Replace the fuel tank pressure sensor. <Ref. to EC(DOHC TURBO)-11, Fuel Tank Pressure Sensor.>


**AY:DTC P0452 — EVAPORATIVE EMISSION CONTROL SYSTEM PRESSURE SENSOR LOW INPUT —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



EN1155

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1</b> <b>CHECK CURRENT DATA.</b> 1) Turn the ignition switch to OFF. 2) Remove the fuel filler cap. 3) Install the fuel filler cap. 4) Turn the ignition switch to ON. 5) Read the data of fuel tank pressure sensor signal using Subaru Select Monitor or the OBD-II general scan tool.  NOTE:  •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.>  •OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.	Is the value less than -2.8 kPa (-21.0 mmHg, -0.827 inHg)?	Go to step 2.	Even if MIL lights up, the circuit has returned to a normal condition at this time.
<b>2</b> <b>CHECK POWER SUPPLY TO FUEL TANK PRESSURE SENSOR.</b> Measure the voltage between ECM connector and chassis ground.  <i>Connector &amp; terminal</i> <i>(B135) No. 9 (+) — Chassis ground (-):</i>	Is the voltage more than 4.5 V?	Go to step 4.	Go to step 3.
<b>3</b> <b>CHECK POWER SUPPLY TO FUEL TANK PRESSURE SENSOR.</b> Measure the voltage between ECM connector and chassis ground.  <i>Connector &amp; terminal</i> <i>(B135) No. 9 (+) — Chassis ground (-):</i>	Does the voltage change more than 4.5 V by shaking harness and connector of ECM while monitoring the value with voltage meter?	Repair poor contact in ECM connector.	Contact with SOA (distributor) service.  NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.
<b>4</b> <b>CHECK INPUT SIGNAL FOR ECM.</b> Measure the voltage between ECM and chassis ground.  <i>Connector &amp; terminal</i> <i>(B135) No. 15 (+) — Chassis ground (-):</i>	Is the voltage less than 0.2 V?	Go to step 6.	Go to step 5.
<b>5</b> <b>CHECK INPUT SIGNAL FOR ECM. (USING SUBARU SELECT MONITOR.)</b> Read the data of fuel tank pressure sensor signal using Subaru Select Monitor.  NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.>	Does the value change more than -2.8 kPa (-21.0 mmHg, -0.827 inHg) by shaking harness and connector of ECM while monitoring the value with Subaru Select Monitor?	Repair poor contact in ECM connector.	Go to step 6.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>6 CHECK HARNESS BETWEEN ECM AND COUPLING CONNECTOR IN REAR WIRING HARNESS.</b></p> <p>1) Turn the ignition switch to OFF.                      2) Remove the rear seat cushion (Sedan) or move rear seat cushion (Wagon).                      3) Separate rear wiring harness and fuel tank cord.                      4) Turn the ignition switch to ON.                      5) Measure the voltage between rear wiring harness connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <i>(R15) No. 9 (+) — Chassis ground (-):</i></p>	Is the voltage more than 4.5 V?	Go to step 7.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and rear wiring harness connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>7 CHECK HARNESS BETWEEN ECM AND COUPLING CONNECTOR IN REAR WIRING HARNESS.</b></p> <p>1) Turn the ignition switch to OFF.                      2) Disconnect the connector from ECM.                      3) Measure the resistance of harness between ECM and rear wiring harness connector.</p> <p><b>Connector &amp; terminal</b>  <i>(B135) No. 19 — (R15) No. 11:</i></p>	Is the resistance less than 1 $\Omega$ ?	Go to step 8.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and rear wiring harness connector</li> <li>• Poor contact in coupling connector</li> <li>• Poor contact in joint connector</li> </ul>
<p><b>8 CHECK HARNESS BETWEEN ECM AND COUPLING CONNECTOR IN REAR WIRING HARNESS.</b></p> <p>Measure the resistance of harness between rear wiring harness connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <i>(R15) No. 11 — Chassis ground:</i></p>	Is the resistance more than 500 k $\Omega$ ?	Go to step 9.	Repair ground short circuit in harness between ECM and rear wiring harness connector.
<p><b>9 CHECK FUEL TANK CORD.</b></p> <p>1) Disconnect the connector from fuel tank pressure sensor.                      2) Measure the resistance of fuel tank cord.</p> <p><b>Connector &amp; terminal</b>  <i>(R57) No. 9 — (R47) No. 3:</i></p>	Is the resistance less than 1 $\Omega$ ?	Go to step 10.	Repair open circuit in fuel tank cord.
<p><b>10 CHECK FUEL TANK CORD.</b></p> <p>Measure the resistance of fuel tank cord.</p> <p><b>Connector &amp; terminal</b>  <i>(R57) No. 11 — (R47) No. 1:</i></p>	Is the resistance less than 1 $\Omega$ ?	Go to step 11.	Repair open circuit in fuel tank cord.
<p><b>11 CHECK FUEL TANK CORD.</b></p> <p>Measure the resistance of harness between fuel tank pressure sensor connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <i>(R47) No. 2 — Chassis ground:</i></p>	Is the resistance more than 500 k $\Omega$ ?	Go to step 12.	Repair ground short circuit in fuel tank cord.
<p><b>12 CHECK POOR CONTACT.</b></p> <p>Check poor contact in fuel tank pressure sensor connector.</p>	Is there poor contact in fuel tank pressure sensor connector?	Repair poor contact in fuel tank pressure sensor connector.	Replace the fuel tank pressure sensor. <Ref. to EC(DOHC TURBO)-11, Fuel Tank Pressure Sensor.>




**AZ:DTC P0453 — EVAPORATIVE EMISSION CONTROL SYSTEM PRESSURE SENSOR HIGH INPUT —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



EN1155

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK CURRENT DATA.</b> 1) Turn the ignition switch to OFF. 2) Remove the fuel filler cap. 3) Install the fuel filler cap. 4) Turn the ignition switch to ON. 5) Read the data of fuel tank pressure sensor signal using Subaru Select Monitor or OBD-II general scan tool.  NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.	Is the value more than 2.8 kPa (21.0 mmHg, 0.827 inHg)?	Go to step 12.	Go to step 2.
<b>2 CHECK POWER SUPPLY TO FUEL TANK PRESSURE SENSOR.</b> Measure the voltage between ECM connector and chassis ground.  <i>Connector &amp; terminal</i> <i>(B135) No. 9 (+) — Chassis ground (-):</i>	Is the voltage more than 4.5 V?	Go to step 4.	Go to step 3.
<b>3 CHECK POWER SUPPLY TO FUEL TANK PRESSURE SENSOR.</b> Measure the voltage between ECM connector and chassis ground.  <i>Connector &amp; terminal</i> <i>(B135) No. 9 (+) — Chassis ground (-):</i>	Does the voltage change more than 4.5 V by shaking harness and connector of ECM while monitoring the value with voltage meter?	Repair poor contact in ECM connector.	Replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>
<b>4 CHECK INPUT SIGNAL FOR ECM.</b> Measure the voltage between ECM and chassis ground.  <i>Connector &amp; terminal</i> <i>(B135) No. 15 (+) — Chassis ground (-):</i>	Is the voltage less than 0.2 V?	Go to step 6.	Go to step 5.
<b>5 CHECK INPUT SIGNAL FOR ECM. (USING SUBARU SELECT MONITOR.)</b> Read the data of fuel tank pressure sensor signal using Subaru Select Monitor.  NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.>	Does the value change more than -2.8 kPa (-21.0 mmHg, -0.827 inHg) by shaking harness and connector of ECM while monitoring the value with Subaru Select Monitor?	Repair poor contact in ECM connector.	Go to step 6.
<b>6 CHECK HARNESS BETWEEN ECM AND COUPLING CONNECTOR IN REAR WIRING HARNESS.</b> 1) Turn the ignition switch to OFF. 2) Remove the rear seat cushion (Sedan) or move rear seat cushion (Wagon). 3) Separate rear wiring harness and fuel tank cord. 4) Turn the ignition switch to ON. 5) Measure the voltage between rear wiring harness connector and chassis ground.  <i>Connector &amp; terminal</i> <i>(R15) No. 9 (+) — Chassis ground (-):</i>	Is the voltage more than 4.5 V?	Go to step 7.	Repair harness and connector.  NOTE: In this case, repair the following: • Open circuit in harness between ECM and rear wiring harness connector • Poor contact in coupling connector

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>7</b> <b>CHECK HARNESS BETWEEN ECM AND COUPLING CONNECTOR IN REAR WIRING HARNESS.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between ECM and rear wiring harness connector. <b>Connector &amp; terminal</b> <b>(B135) No. 15 — (R15) No. 10:</b>	Is the resistance less than 1 $\Omega$ ?	Go to step 8.	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between ECM and rear wiring harness connector • Poor contact in coupling connector
<b>8</b> <b>CHECK HARNESS BETWEEN ECM AND COUPLING CONNECTOR IN REAR WIRING HARNESS.</b> Measure the resistance of harness between rear wiring harness connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B135) No. 9 — (R15) No. 9:</b>	Is the resistance less than 1 $\Omega$ ?	Go to step 9.	Repair ground short circuit in harness between ECM and rear wiring harness connector.
<b>9</b> <b>CHECK FUEL TANK CORD.</b> 1) Disconnect the connector from fuel tank pressure sensor. 2) Measure the resistance of fuel tank cord. <b>Connector &amp; terminal</b> <b>(R57) No. 11 — (R47) No. 2:</b>	Is the resistance less than 1 $\Omega$ ?	Go to step 10.	Repair open circuit in fuel tank cord.
<b>10</b> <b>CHECK FUEL TANK CORD.</b> Measure the resistance of fuel tank cord. <b>Connector &amp; terminal</b> <b>(R57) No. 10 — (R47) No. 1:</b>	Is the resistance less than 1 $\Omega$ ?	Go to step 11.	Repair open circuit in fuel tank cord.
<b>11</b> <b>CHECK POOR CONTACT.</b> Check poor contact in fuel tank pressure sensor connector.	Is there poor contact in fuel tank pressure sensor connector?	Repair poor contact in fuel tank pressure sensor connector.	Replace the fuel tank pressure sensor. <Ref. to EC(DOHC TURBO)-11, Fuel Tank Pressure Sensor.>
<b>12</b> <b>CHECK HARNESS BETWEEN ECM AND FUEL TANK PRESSURE SENSOR CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from fuel tank pressure sensor. 3) Turn the ignition switch to ON. 4) Read the data of fuel tank pressure sensor signal using Subaru Select Monitor or the OBD-II general scan tool. NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.	Is the value more than 2.8 kPa (21.0 mmHg, 0.827 inHg)?	Repair battery short circuit in harness between ECM and fuel tank pressure sensor connector.	Replace the fuel tank pressure sensor. <<Ref. to EC(DOHC TURBO)-11, Fuel Tank Pressure Sensor.>

**BA:DTC P0461 — FUEL LEVEL SENSOR CIRCUIT RANGE/PERFORMANCE  
PROBLEM —**

**• DTC DETECTING CONDITION:**



- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)

## • WIRING DIAGRAM:



EN1156

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Inspect DTC P0462 or P0463 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect this trouble.	Replace the fuel level sensor <Ref. to FU(DOHC TURBO)-62, Fuel Level Sensor.> and fuel sub level sensor <Ref. to FU(DOHC TURBO)-63, Fuel Sub Level Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## BB:DTC P0462 — FUEL LEVEL SENSOR CIRCUIT LOW INPUT —


### • DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

### • WIRING DIAGRAM:



EN1156

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No	
1	<b>CHECK SPEEDOMETER AND TACHOMETER OPERATION IN COMBINATION METER.</b>	Does the speedometer and tachometer operate normally?	Go to step 2.	Repair or replace the combination meter. <Ref. to IDI-4, Combination Meter System.>
2	<b>CHECK INPUT SIGNAL FOR ECM.</b> 1) Turn the ignition switch to ON. (Engine OFF) 2) Measure the voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B135) No. 25 (+) — Chassis ground (-):</b>	Is the voltage less than 0.12 V?	Go to step 6.	Go to step 3.
3	<b>CHECK INPUT SIGNAL FOR ECM. (USING SUBARU SELECT MONITOR.)</b> Read the data of fuel level sensor signal using Subaru Select Monitor. NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.>	Does the value change less than 0.12 V by shaking harness and connector of ECM while monitoring the value with Subaru Select Monitor?	Repair poor contact in ECM connector.	Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause. NOTE: In this case, repair the following: • Poor contact in combination meter connector • Poor contact in ECM connector • Poor contact in coupling connectors
4	<b>CHECK INPUT VOLTAGE OF ECM.</b> 1) Turn the ignition switch to OFF. 2) Separate fuel tank cord connector (R57) and rear wiring harness connector (R15). 3) Turn the ignition switch to ON. 4) Measure the voltage of harness between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B135) No. 25 (+) — Chassis ground (-):</b>	Is the voltage more than 0.12 V?	Go to step 4.	Go to step 7.
5	<b>CHECK HARNESS BETWEEN ECM AND COMBINATION METER.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from connector (i10), (i12) and ECM connector. 3) Measure the resistance between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B135) No. 25 — Chassis ground:</b>	Is the resistance more than 1 MΩ?	Go to step 6.	Repair ground short circuit in harness between ECM and combination meter connector.
6	<b>CHECK HARNESS BETWEEN ECM AND COMBINATION METER.</b> Measure the resistance between ECM and combination meter connector. <b>Connector &amp; terminal</b> <b>(B135) No. 25 — (i12) No. 2:</b>	Is the resistance less than 10 Ω?	Repair or replace the combination meter. <Ref. to IDI-4, Combination Meter System.>	Repair open circuit between ECM and combination meter connector. NOTE: In this case, repair the following: Poor contact in coupling connector

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>CHECK FUEL TANK CORD.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from fuel sub level sensor. 3) Measure the resistance between fuel sub level sensor and chassis ground. <b>Connector &amp; terminal</b> <b>(R59) No. 1 — Chassis ground:</b>	Is the resistance more than 1 M $\Omega$ ?	Go to step 8.	Repair ground short circuit in fuel tank cord.
<b>CHECK FUEL TANK CORD.</b> 1) Disconnect the connector from fuel pump assembly. 2) Measure the resistance between fuel pump assembly and chassis ground. <b>Connector &amp; terminal</b> <b>(R59) No. 2 — Chassis ground:</b>	Is the resistance more than 1 M $\Omega$ ?	Go to step 9.	Repair ground short circuit in fuel tank cord.
<b>CHECK FUEL LEVEL SENSOR.</b> 1) Remove the fuel pump assembly. <Ref. to FU(DOHC TURBO)-60, Fuel Pump.> 2) Measure the resistance between fuel level sensor and terminals with its float set to the full position. <b>Terminals</b> <b>No. 2 — No. 3:</b>	Is the resistance between 0.5 and 2.5 $\Omega$ ?	Go to step 10.	Replace the fuel level sensor.
<b>CHECK FUEL SUB LEVEL SENSOR.</b> 1) Remove the fuel sub level sensor. <Ref. to FU(DOHC TURBO)-63, Fuel Sub Level Sensor.> 2) Measure the resistance between fuel sub level sensor and terminals with its float set to the full position. <b>Terminals</b> <b>No. 1 — No. 2:</b>	Is the resistance between 0.5 and 2.5 $\Omega$ ?	Repair poor contact in harness between ECM and combination meter connector.	Replace the fuel sub level sensor.



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### BC:DTC P0463 — FUEL LEVEL SENSOR CIRCUIT HIGH INPUT —



**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

**WIRING DIAGRAM:**



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1</b> <b>CHECK SPEEDOMETER AND TACHOMETER OPERATION IN COMBINATION METER.</b>	Does the speedometer and tachometer operate normally?	Go to step 2.	Repair or replace the combination meter. <Ref. to IDI-4, Combination Meter System.>
<b>2</b> <b>CHECK INPUT SIGNAL FOR ECM.</b> 1) Turn the ignition switch to ON. (Engine OFF) 2) Measure the voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B135) No. 25 (+) — Chassis ground (-):</b>	Is the voltage more than 4.75 V?	Go to step 3.	Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause.  NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Poor contact in fuel pump connector</li> <li>• Poor contact in coupling connector</li> </ul>
<b>3</b> <b>CHECK INPUT VOLTAGE OF ECM.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the combination meter connector (i10) and ECM connector. 3) Turn the ignition switch to ON. 4) Measure the voltage of harness between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B135) No. 25 (+) — Chassis ground (-):</b>	Is the voltage more than 4.75 V?	Go to step 4.	Repair battery short circuit between ECM and combination meter connector.
<b>4</b> <b>CHECK HARNESS BETWEEN ECM AND FUEL TANK CORD.</b> 1) Turn the ignition switch to OFF. 2) Separate fuel tank cord connector (R57) and rear wiring harness connector (R15). 3) Measure the resistance between ECM and fuel tank cord. <b>Connector &amp; terminal</b> <b>(B135) No. 25 — (R15) No. 2:</b>	Is the resistance less than 5 $\Omega$ ?	Go to step 5.	Repair open circuit between ECM and fuel tank cord.
<b>5</b> <b>CHECK HARNESS BETWEEN FUEL TANK CORD AND CHASSIS GROUND.</b> Measure the resistance between fuel tank cord and chassis ground. <b>Connector &amp; terminal</b> <b>(R15) No. 8 — Chassis ground:</b>	Is the resistance less than 5 $\Omega$ ?	Go to step 6.	Repair open circuit between fuel tank cord and chassis ground.  NOTE: In this case, repair the following: Poor contact in coupling connectors
<b>6</b> <b>CHECK FUEL TANK CORD.</b> 1) Disconnect the connector from fuel level sensor. 2) Measure the resistance between fuel level sensor and coupling connector. <b>Connector &amp; terminal</b> <b>(R57) No. 8 — (R58) No. 2:</b>	Is the resistance less than 10 $\Omega$ ?	Go to step 7.	Repair open circuit between coupling connector and fuel level sensor.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>7 CHECK FUEL TANK CORD.</b> 1) Disconnect the connector from fuel sub level sensor. 2) Measure the resistance between fuel level sensor and fuel sub level sensor. <b>Connector &amp; terminal</b> <b>(R58) No. 3 — (R59) No. 2:</b>	Is the resistance less than 10 $\Omega$ ?	Go to step 8.	Repair open circuit between fuel level sensor and fuel sub level sensor.
<b>8 CHECK FUEL TANK CORD.</b> Measure the resistance between fuel sub level sensor and coupling connector. <b>Connector &amp; terminal</b> <b>(R57) No. 3 — (R59) No. 1:</b>	Is the resistance less than 10 $\Omega$ ?	Go to step 9.	Repair open circuit between coupling connector and fuel sub level sensor.
<b>9 CHECK FUEL LEVEL SENSOR.</b> 1) Remove the fuel pump assembly. <Ref. to FU(DOHC TURBO)-60, Fuel Pump.> 2) While moving the fuel level sensor float up and down, measure resistance between fuel level sensor terminals. <b>Terminals</b> <b>No. 2 — No. 3:</b>	Is the resistance more than 53 $\Omega$ ?	Replace the fuel level sensor. <Ref. to FU(DOHC TURBO)-62, Fuel Level Sensor.>	Go to step 10.
<b>10 CHECK FUEL SUB LEVEL SENSOR.</b> 1) Remove the fuel sub level sensor. <Ref. to FU(DOHC TURBO)-63, Fuel Sub Level Sensor.> 2) While moving the fuel sub level sensor float up and down, measure resistance between fuel sub level sensor terminals. <b>Terminals</b> <b>No. 1 — No. 2:</b>	Is the resistance more than 45 $\Omega$ ?	Replace the fuel sub level sensor. <Ref. to FU(DOHC TURBO)-63, Fuel Sub Level Sensor.>	Replace the combination meter. <Ref. to IDI-11, Combination Meter Assembly.>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## BD:DTC P0464 — FUEL LEVEL SENSOR INTERMITTENT INPUT—



**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

**WIRING DIAGRAM:**



EN1156

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1	<p><b>CHECK ANY OTHER DTC ON DISPLAY.</b></p>	<p>Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0462 or P0463?</p>	<p>Inspect DTC P0462 or P0463 using "List of Diagnostic Trouble Code (DTC)". &lt;Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).&gt;</p>
2	<p><b>CHECK FUEL LEVEL SENSOR.</b> 1)Remove the fuel pump assembly. &lt;Ref. to FU(DOHC TURBO)-60, Fuel Pump.&gt; 2)While moving the fuel level sensor float up and down, make sure that the resistance between fuel level sensor terminals changes smoothly. <b>Terminals</b> <b>No. 2 — No. 3:</b></p>	<p>Does the resistance change smoothly between approx. 0.5 Ω and approx. 52 Ω?</p>	<p>Go to step 3.</p> <p>Replace the fuel level sensor. &lt;Ref. to FU(DOHC TURBO)-62, Fuel Level Sensor.&gt;</p>
3	<p><b>CHECK FUEL SUB LEVEL SENSOR.</b> 1)Remove the fuel sub level sensor. &lt;Ref. to FU(DOHC TURBO)-63, Fuel Sub Level Sensor.&gt; 2)While moving the fuel sub level sensor float up and down, make sure that the resistance between fuel level sensor terminals changes smoothly. <b>Terminals</b> <b>No. 1 — No. 2:</b></p>	<p>Does the resistance change smoothly between approx. 0.5 Ω and approx. 44 Ω?</p>	<p>Repair poor contact in ECM, combination meter and coupling connectors.</p> <p>Replace the fuel sub level sensor. &lt;Ref. to FU(DOHC TURBO)-63, Fuel Sub Level Sensor.&gt;</p>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**BE:DTC P0480 — COOLING FAN RELAY 1 CIRCUIT LOW INPUT —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Radiator fan does not operate properly.
  - Overheating



**CAUTION:**

**After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

• WIRING DIAGRAM:



EN1157

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No	
1	<p><b>CHECK OUTPUT SIGNAL FROM ECM.</b></p> <p>1)Turn the ignition switch to OFF. 2)Connect the test mode connector at the lower portion of instrument panel (on the driver's side), to the side of the center console box. 3)Turn the ignition switch to ON. 4)While operating the radiator fan relay, measure voltage between ECM terminal and ground.</p> <p>NOTE: Radiator fan relay operation can be executed using Subaru Select Monitor. For procedure, refer to "Compulsory Valve Operation Check Mode".&lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;</p> <p><b>Connector &amp; terminal</b> <b>(B137) No. 17 (+) — Chassis ground (-):</b> <b>(B137) No. 28 (+) — Chassis ground (-):</b></p>	Does the voltage change between 0 and 10 V?	Repair poor contact in ECM connector.	Go to step 2.
2	<p><b>CHECK GROUND SHORT CIRCUIT IN RADIATOR MAIN FAN RELAY CONTROL CIRCUIT.</b></p> <p>1)Turn the ignition switch to OFF. 2)Disconnect the connectors from ECM. 3)Measure the resistance of harness between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b> <b>(B137) No. 17 — Chassis ground:</b> <b>(B137) No. 28 — Chassis ground:</b></p>	Is the resistance less than 10 $\Omega$ ?	Repair ground short circuit in radiator main fan relay control circuit.	Go to step 3.
3	<p><b>CHECK POWER SUPPLY FOR RELAY.</b></p> <p>1)Remove the main fan relay 1 and 2 from A/C relay holder. 2)Turn the ignition switch to ON. 3)Measure the voltage between fuse and relay box (F/B) connector and chassis ground.</p> <p><b>Connector &amp; terminal</b> <b>(F66) No. 27 (+) — Chassis ground (-):</b> <b>(F30) No. 22 (+) — Chassis ground (-):</b></p>	Is the voltage more than 10 V?	Go to step 4.	Repair open circuit in harness between ignition switch and fuse and relay box (F/B) connector.
4	<p><b>CHECK MAIN FAN RELAY.</b></p> <p>1)Turn the ignition switch to OFF. 2)Measure the resistance between main fan relay terminals.</p> <p><b>Terminal</b> <b>No. 27 — No. 28:(Main fan relay 1)</b> <b>No. 22 — No. 21:(Main fan relay 2)</b></p>	Is the resistance between 87 and 107 $\Omega$ ?	Go to step 5.	Replace the main fan relay.
5	<p><b>CHECK OPEN CIRCUIT IN MAIN FAN RELAY CONTROL CIRCUIT.</b></p> <p>Measure the resistance of harness between ECM and main fan relay connector.</p> <p><b>Connector &amp; terminal</b> <b>(B137) No. 17 — (F66) No. 28:</b> <b>(B137) No. 28 — (F30) No. 21:</b></p>	Is the resistance less than 1 $\Omega$ ?	Go to step 6.	<p>Repair harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and main fan relay connector</li> <li>• Poor contact in coupling connector</li> </ul>
6	<p><b>CHECK POOR CONTACT.</b></p> <p>Check poor contact in ECM or main fan relay connector.</p>	Is there poor contact in ECM or main fan relay connector?	Repair poor contact in ECM or main fan relay connector.	Contact with SOA (distributor) service.

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**BF:DTC P0483 — COOLING FAN FUNCTION PROBLEM —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Occurrence of noise
  - Overheating

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.



**NOTE:**

If the vehicle, with the engine idling, is placed very close to a wall or another vehicle, preventing normal cooling function, the OBD system may detect malfunction.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### • WIRING DIAGRAM:



EN1157

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 <b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Is there any other DTC on display?	Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>	Check radiator fan, fan motor and thermostat. <Ref. to CO-9, Radiator Main Fan System.> and <Ref. to CO-17, Radiator Sub Fan System.> If thermostat is stuck, replace thermostat.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### BG:DTC P0500 — VEHICLE SPEED SENSOR MALFUNCTION —

- DTC DETECTING CONDITION:
  - Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>

• WIRING DIAGRAM:



EN1158

Step	Check	Yes	No
1	CHECK TRANSMISSION TYPE.	Is the transmission type AT?	Go to step 2.
		Go to step 2.	Go to step 3.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>2</b> <b>CHECK DTC P0720 ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0720?	Check front vehicle speed sensor signal circuit. <Ref. to AT-57, DTC 33 FRONT VEHICLE SPEED SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Go to step 3.
<b>3</b> <b>CHECK SPEEDOMETER OPERATION IN COMBINATION METER.</b>	Does speedometer operate normally?	Go to step 4.	Check speedometer and vehicle speed sensor. <Ref. to IDI-13, Speedometer.> and <Ref. to AT-32, Front Vehicle Speed Sensor.>
<b>4</b> <b>CHECK HARNESS BETWEEN ECM AND COMBINATION METER CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from combination meter. 3) Measure resistance between ECM and combination meter. <b>Connector &amp; terminal</b> <b>(B134) No. 1 — (i10) No. 2:</b>	Is the resistance less than 10 $\Omega$ ?	Repair poor contact in ECM connector.	Repair harness and connector. <b>NOTE:</b> In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and combination meter connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in combination meter connector</li> <li>• Poor contact in coupling connector</li> </ul>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)

## BH:DTC P0506 — IDLE CONTROL SYSTEM RPM LOWER THAN EXPECTED —

### • DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault


### • TROUBLE SYMPTOM:

- Engine is difficult to start.
- Engine does not start.
- Erroneous idling
- Engine stalls.

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

### • WIRING DIAGRAM:



EN1160

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0508 or P509?	Inspect DTC P0505 or P1505 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>  NOTE: In this case, it is not necessary to inspect DTC P0506.	Go to step 2.
2	<b>CHECK IDLE AIR CONTROL SOLENOID VALVE.</b> 1)Turn the ignition switch to OFF. 2)Remove the idle air control solenoid valve from throttle body. <Ref. to FU(DOHC TURBO)-36, REMOVAL, Idle Air Control Solenoid Valve.> 3)Using an air gun, force air into the idle air control solenoid valve by-pass air inlet. Confirm that forced air subsequently escapes from both main air passage and assist air passage.	Does air flow out?	Go to step 4.	Replace the idle air control solenoid valve. <Ref. to FU(DOHC TURBO)-36, Idle Air Control Solenoid Valve.> After replace, Go to step 3.
3	<b>CHECK IDLE AIR CONTROL SOLENOID VALVE DUTY RATIO.</b> 1)Turn the ignition switch to ON. 2)Start the engine, and warm-up the engine. 3)Turn all accessory switches to OFF. 4)Read the data of idle air control solenoid valve duty ratio using Subaru Select Monitor or OBD-II general scan tool.  NOTE: •Subaru Select Monitor For detailed operation procedures, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.> •OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.	Is the value more than 60%?	Go to step 4.	END.
4	<b>CHECK BY-PASS AIR LINE.</b> 1)Turn the ignition switch to OFF. 2)Remove the idle air control solenoid valve from throttle body. <Ref. to FU(DOHC TURBO)-36, REMOVAL, Idle Air Control Solenoid Valve.> 3)Remove the throttle body to intake manifold. <Ref. to FU(DOHC TURBO)-14, REMOVAL, Throttle Body.> 4)Using an air gun, force air into the solenoid valve installation area and throttle valve interior. Confirm that forced air subsequently escapes from both these areas.	Does air flow out?	Replace the idle air control solenoid valve. <Ref. to FU(DOHC TURBO)-36, Idle Air Control Solenoid Valve.>	Replace the throttle body. <Ref. to FU(DOHC TURBO)-14, Throttle Body.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### BI: DTC P0507 — IDLE CONTROL SYSTEM RPM HIGHER THAN EXPECTED —

**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault


**TROUBLE SYMPTOM:**

- Engine keeps running at higher revolution than specified idling revolution.

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

**WIRING DIAGRAM:**



EN1160

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1</b> <b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0508 or P0509?	Inspect DTC P0508 or P0509 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>  NOTE: In this case, it is not necessary to inspect DTC P0507.	Go to step 2.
<b>2</b> <b>CHECK THROTTLE CABLE.</b>	Does the throttle cable have play for adjustment?	Go to step 3.	Adjust throttle cable. <Ref. to SP-7, INSTALLATION, Accelerator Control Cable.>
<b>3</b> <b>CHECK AIR INTAKE SYSTEM.</b> 1) Turn the ignition switch to ON. 2) Start the engine, and idle it. 3) Check the following items. • Loose installation of intake manifold, idle air control solenoid valve and throttle body • Cracks of intake manifold gasket, idle air control solenoid valve gasket and throttle body gasket • Disconnections of vacuum hoses	Is there a fault in air intake system?	Repair air suction and leaks.	Replace the idle air control solenoid valve. <Ref. to FU(DOHC TURBO)-36, Idle Air Control Solenoid Valve.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### BJ:DTC P0508 — IDLE CONTROL SYSTEM CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Engine breathing

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN1160

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>CHECK OUTPUT SIGNAL FROM ECM.</b>                      1) Turn the ignition switch to ON.                      2) Measure the voltage between ECM and chassis ground.  <i>Connector &amp; terminal</i>  <i>(B136) No. 10 (+) — Chassis ground (-):</i></p>	Is the voltage more than 3 V?	Repair poor contact in ECM connector.	Go to step 2.
<p><b>CHECK POWER SUPPLY TO IDLE AIR CONTROL SOLENOID VALVE.</b>                      1) Turn the ignition switch to OFF.                      2) Disconnect the connector from idle air control solenoid valve.                      3) Turn the ignition switch to ON.                      4) Measure the voltage between idle air control solenoid valve and engine ground.  <i>Connector &amp; terminal</i>  <i>(E7) No. 2 (+) — Engine ground (-):</i></p>	Is the voltage more than 10 V?	Go to step 3.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between idle air control solenoid valve and main relay connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>CHECK HARNESS BETWEEN ECM AND IDLE AIR CONTROL SOLENOID VALVE</b></p>	Is the resistance less than 1 $\Omega$ ?	Go to step 4.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and idle air control solenoid valve connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>CHECK HARNESS BETWEEN ECM AND IDLE AIR CONTROL SOLENOID VALVE CONNECTOR.</b>                      Measure the resistance of harness between ECM and chassis ground.  <i>Connector &amp; terminal</i>  <i>(B136) No. 10 — Chassis ground:</i></p>	Is the resistance less than 10 $\Omega$ ?	Repair ground short circuit in harness between ECM and idle air control solenoid valve connector.	Go to step 5.
<p><b>CHECK GROUND CIRCUIT OF IDLE AIR CONTROL SOLENOID VALVE.</b>                      Measure the resistance of harness between idle air control solenoid valve connector and engine ground.  <i>Connector &amp; terminal</i>  <i>(E7) No. 3 — Engine ground:</i></p>	Is the resistance less than 5 $\Omega$ ?	Go to step 6.	Repair open circuit in harness between idle air control solenoid valve connector and engine ground terminal.
<p><b>CHECK POOR CONTACT.</b>                      Check poor contact in ECM and idle air control solenoid valve connectors.</p>	Is there poor contact in ECM and idle air control solenoid valve connectors?	Repair poor contact in ECM and idle air control solenoid valve connectors.	Replace the idle air control solenoid valve. <Ref. to FU(DOHC TURBO)-36, Idle Air Control Solenoid Valve.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## BK:DTC P0509 — IDLE CONTROL SYSTEM CIRCUIT HIGH INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Engine breathing

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN1160

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<b>CHECK THROTTLE CABLE.</b>	Does the throttle cable have play for adjustment?	Go to step 2.	Adjust throttle cable. <Ref. to SP-7, INSTALLATION, Accelerator Control Cable.>
2	<b>CHECK OUTPUT SIGNAL FROM ECM.</b> 1)Turn the ignition switch to ON. 2)Measure the voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 10 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V?	Go to step 3.	Go to step 4.
3	<b>CHECK OUTPUT SIGNAL FROM ECM.</b> 1)Turn the ignition switch to OFF. 2)Disconnect the connector from idle air control solenoid valve. 3)Turn the ignition switch to ON. 4)Measure the voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 10 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V?	Repair battery short circuit in harness between ECM and idle air control solenoid valve connector. After repair, replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>	Replace the idle air control solenoid valve <Ref. to FU(DOHC TURBO)-36, Idle Air Control Solenoid Valve.> and ECM <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>
4	<b>CHECK OUTPUT SIGNAL FROM ECM.</b> Measure the voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 10 (+) — Chassis ground (-):</b>	Does the voltage change more than 10 V by shaking harness and connector of ECM while monitoring the value with voltage meter?	Repair battery short circuit in harness between ECM and idle air control solenoid valve connector. After repair, replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>	Contact with SOA (distributor) service.  NOTE: Insepection by DTM is required, because probable cause is deterioration of multiple parts.

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**BL:DTC P0512 — STARTER SWITCH CIRCUIT HIGH INPUT —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Failure of engine to start

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1	<b>CHECK OPERATION OF STARTER MOTOR.</b> NOTE: Place the inhibitor switch in each position.	Does the starter motor operate when ignition switch to "ON"?	Repair battery short circuit in starter motor circuit. After repair, replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.> Check starter motor circuit. <Ref. to EN(DOHC TURBO)-64, STARTER MOTOR CIRCUIT, Diagnostics for Engine Starting Failure.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## BM:DTC P0545 — EXHAUST GAS TEMPERATURE SENSOR CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Hard to start
  - Erroneous idling
  - Poor driving performance

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



EN1161

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK CURRENT DATA.</b>                      1)Start the engine.                      2)Read the data of exhaust gas temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:                      •Subaru Select Monitor                      For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;                      •OBD-II general scan tool                      For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value greater than 1200°C (2192°F)?</p>	<p>Go to step 2.</p>	<p>Repair poor contact.</p> <p>NOTE:                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Poor contact in exhaust gas temperature sensor</li> <li>• Poor contact in ECM</li> <li>• Poor contact in joint connector</li> </ul>
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN EXHAUST GAS TEMPERATURE SENSOR AND ECM CONNECTOR.</b>                      1)Turn the ignition switch to OFF.                      2)Disconnect the connector from exhaust gas temperature sensor.                      3)Turn the ignition switch to ON.                      4)Read the data of exhaust gas temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:                      •Subaru Select Monitor                      For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;                      •OBD-II general scan tool                      For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value less than 372°C (702°F)?</p>	<p>Replace the exhaust gas temperature sensor.                      &lt;Ref. to FU(DOHC TURBO)-46, Exhaust Temperature Sensor.&gt;</p>	<p>Repair ground short circuit in harness between exhaust gas temperature sensor and ECM connector.</p>


**BN:DTC P0546 — EXHAUST GAS TEMPERATURE SENSOR CIRCUIT HIGH INPUT —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Hard to start
  - Erroneous idling
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN1161

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>CHECK CURRENT DATA.</b></p> <p>1) Start the engine.</p> <p>2) Read the data of exhaust gas temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>• Subaru Select Monitor</li> </ul> <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>• OBD-II general scan tool</li> </ul> <p>For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value less than 372°C (702°F)?</p>	<p>Go to step 2.</p>	<p>Repair poor contact.</p> <p>NOTE:</p> <p>In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Poor contact in exhaust gas temperature sensor</li> <li>• Poor contact in ECM</li> <li>• Poor contact in joint connector</li> </ul>
<p><b>CHECK HARNESS BETWEEN EXHAUST GAS TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from exhaust gas temperature sensor.</p> <p>3) Measure the voltage between exhaust gas temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(B279) No. 1 (+) — Engine ground (-):</b></p>	<p>Is the voltage more than 10 V?</p>	<p>Repair battery short circuit in harness between ECM and exhaust gas temperature sensor connector.</p>	<p>Go to step 3.</p>
<p><b>CHECK HARNESS BETWEEN EXHAUST GAS TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn the ignition switch to ON.</p> <p>2) Measure the voltage between exhaust gas temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(B279) No. 1 (+) — Engine ground (-):</b></p>	<p>Is the voltage more than 10 V?</p>	<p>Repair battery short circuit in harness between ECM and exhaust gas temperature sensor connector.</p>	<p>Go to step 4.</p>
<p><b>CHECK HARNESS BETWEEN EXHAUST GAS TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>Measure the voltage between exhaust gas temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(B279) No. 1 (+) — Engine ground (-):</b></p>	<p>Is the voltage more than 4 V?</p>	<p>Go to step 5.</p>	<p>Repair harness and connector.</p> <p>NOTE:</p> <p>In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and exhaust gas temperature sensor connector</li> <li>• Poor contact in exhaust gas temperature sensor connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in joint connector</li> </ul>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>5</b></p> <p><b>CHECK HARNESS BETWEEN EXHAUST GAS TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Measure the resistance of harness between exhaust gas temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b> <b>(B279) No. 2 — Engine ground:</b></p>	<p>Is the resistance less than 5 <math>\Omega</math>?</p>	<p>Replace the exhaust gas temperature sensor. &lt;Ref. to FU(DOHC TURBO)-46, Exhaust Temperature Sensor.&gt;</p>	<p>Repair harness and connector.</p> <p><b>NOTE:</b> In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and exhaust gas temperature sensor connector</li> <li>• Poor contact in exhaust gas temperature sensor connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in joint connector</li> </ul>



**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**BO:DTC P0604 — INTERNAL CONTROL MODULE MEMORY CHECK SUM ERROR —**


- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Engine does not start.
  - Engine stalls.

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)

• WIRING DIAGRAM:



EN1171

Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b> Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0604?	Replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>	It is not necessary to inspect DTC P0604.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)



### BP:DTC P0703 — BRAKE SWITCH INPUT MALFUNCTION —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



B2M4366

Step	Check	Yes	No
1	<b>CHECK OPERATION OF BRAKE LIGHT.</b> Does the brake light come on when depressing the brake pedal?	Go to step 2.	Repair or replace the brake light circuit.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN TCM AND BRAKE LIGHT SWITCH CONNECTOR.</b>                      1) Disconnect the connectors from TCM and brake light switch.                      2) Measure the resistance of harness between TCM and brake light switch connector.  <b>Connector &amp; terminal</b>  <b>(B55) No. 12 — (B65) No. 3:</b></p>	<p>Is the resistance less than 1 <math>\Omega</math>?</p>	<p>Go to step 3.</p>	<p>Repair or replace the harness and connector.</p> <p><b>NOTE:</b>                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between TCM and brake light switch connector</li> <li>• Poor contact in TCM connector</li> <li>• Poor contact in brake light switch connector</li> </ul>
<p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN TCM AND BRAKE LIGHT SWITCH CONNECTOR.</b>                      Measure the resistance of harness between TCM and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B55) No. 12 — Chassis ground:</b></p>	<p>Is the resistance more than 1 <math>M\Omega</math>?</p>	<p>Go to step 4.</p>	<p>Repair ground short circuit in harness between TCM and brake light switch connector.</p>
<p><b>4</b></p> <p><b>CHECK INPUT SIGNAL FOR TCM.</b>                      1) Connect the connectors to TCM and brake light switch.                      2) Measure the voltage between TCM and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B55) No. 12 (+) — Chassis ground (-):</b></p>	<p>Is the voltage less than 1 V when releasing the brake pedal?</p>	<p>Go to step 5.</p>	<p>Adjust or replace the brake light switch. &lt;Ref. to LI-7, STOP LIGHT SWITCH, INSPECTION, Stop Light System.&gt;</p>
<p><b>5</b></p> <p><b>CHECK INPUT SIGNAL FOR TCM.</b>                      Measure the voltage between TCM and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B55) No. 12 (+) — Chassis ground (-):</b></p>	<p>Is the voltage more than 10 V when depressing the brake pedal?</p>	<p>Go to step 6.</p>	<p>Adjust or replace the brake light switch. &lt;Ref. to LI-7, STOP LIGHT SWITCH, INSPECTION, Stop Light System.&gt;</p>
<p><b>6</b></p> <p><b>CHECK POOR CONTACT.</b>                      Check poor contact in TCM connector.</p>	<p>Is there poor contact in TCM connector?</p>	<p>Repair poor contact in TCM connector.</p>	<p>Replace the TCM. &lt;Ref. to AT-45, Transmission Control Module (TCM).&gt;</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### **BQ:DTC P0731 — GEAR 1 INCORRECT RATIO —**

**NOTE:**

For the diagnostic procedure, refer to DTC P0734. <Ref. to EN(DOHC TURBO)-270, DTC P0734 — GEAR 4 INCORRECT RATIO —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

### **BR:DTC P0732 — GEAR 2 INCORRECT RATIO —**

**NOTE:**

For the diagnostic procedure, refer to DTC P0734. <Ref. to EN(DOHC TURBO)-270, DTC P0734 — GEAR 4 INCORRECT RATIO —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

### **BS:DTC P0733 — GEAR 3 INCORRECT RATIO —**

**NOTE:**

For the diagnostic procedure, refer to DTC P0734. <Ref. to EN(DOHC TURBO)-270, DTC P0734 — GEAR 4 INCORRECT RATIO —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

### **BT:DTC P0734 — GEAR 4 INCORRECT RATIO —**

• **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

• **TROUBLE SYMPTOM:**

- Shift point too high or too low; engine brake not effective in “3” range; excessive shift shock; excessive tight corner “braking”

**CAUTION:**

**After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.**

• **WIRING DIAGRAM:**

Step	Check	Yes	No	
<b>1</b>	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Is there any other DTC on display?	Inspect relevant DTC using “List of Diagnostic Trouble Code (DTC)”. <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
<b>2</b>	<b>CHECK THROTTLE POSITION SENSOR CIRCUIT.</b> Check throttle position sensor circuit. <Ref. to AT-52, DTC 31 THROTTLE POSITION SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Is there any trouble in throttle position sensor circuit?	Repair or replace the throttle position sensor circuit.	Go to step 3.
<b>3</b>	<b>CHECK FRONT VEHICLE SPEED SENSOR CIRCUIT.</b> Check front vehicle speed sensor circuit. <Ref. to AT-57, DTC 33 FRONT VEHICLE SPEED SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Is there any trouble in vehicle speed sensor 2 circuit?	Repair or replace the vehicle speed sensor 2 circuit.	Go to step 4.
<b>4</b>	<b>CHECK TORQUE CONVERTER TURBINE SPEED SENSOR CIRCUIT.</b> Check torque converter turbine speed sensor circuit. <Ref. to AT-62, DTC 36 TORQUE CONVERTER TURBINE SPEED SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Is there any trouble in torque converter turbine speed sensor circuit?	Repair or replace the torque converter turbine speed sensor circuit.	Go to step 5.

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

	<b>Step</b>	<b>Check</b>	<b>Yes</b>	<b>No</b>
<b>5</b>	<b>CHECK POOR CONTACT.</b> Check poor contact in TCM connector.	Is there poor contact in TCM connector?	Repair poor contact in TCM connector.	Go to step 6.
<b>6</b>	<b>CHECK MECHANICAL TROUBLE.</b> Check mechanical trouble in automatic transmission.	Is there any mechanical trouble in automatic transmission?	Repair or replace the automatic transmission. <Ref. to AT-12, INSPECTION, Road Test.>	Replace the TCM. <Ref. to AT-45, Transmission Control Module (TCM).>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## BU:DTC P0741 — TORQUE CONVERTER CLUTCH SYSTEM MALFUNCTION —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - No lock-up (after engine warm-up)
  - No shift or excessive tight corner “braking”

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

Step	Check	Yes	No	
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Inspect the relevant DTC using “List of Diagnostic Trouble Code (DTC)”. <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>	Go to step 2.	
2	<b>CHECK LOCK-UP DUTY SOLENOID CIRCUIT.</b> Check lock-up duty solenoid circuit. <Ref. to AT-94, DTC 77 LOCK-UP DUTY SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Is there any trouble in lock-up duty solenoid circuit?	Repair or replace the lock-up duty solenoid circuit.	Go to step 3.
3	<b>CHECK THROTTLE POSITION SENSOR CIRCUIT.</b> Check throttle position sensor circuit. <Ref. to AT-52, DTC 31 THROTTLE POSITION SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Is there any trouble in throttle position sensor circuit?	Repair or replace the throttle position sensor circuit.	Go to step 4.
4	<b>CHECK TORQUE CONVERTER TURBINE SPEED SENSOR CIRCUIT.</b> Check torque converter turbine speed sensor circuit. <Ref. to AT-62, DTC 36 TORQUE CONVERTER TURBINE SPEED SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Is there any trouble in torque converter turbine speed sensor circuit?	Repair or replace the torque converter turbine speed sensor circuit.	Go to step 5.
5	<b>CHECK ENGINE SPEED INPUT CIRCUIT.</b> Check engine speed input circuit. <Ref. to AT-44, DTC 11 ENGINE SPEED SIGNAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Is there any trouble in engine speed input circuit?	Repair or replace the engine speed input circuit.	Go to step 6.
6	<b>CHECK INHIBITOR SWITCH CIRCUIT.</b> Check inhibitor switch circuit. <Ref. to AT-115, CHECK INHIBITOR SWITCH., Diagnostic Procedure for No-Diagnostic Trouble Code (DTC).>	Is there any trouble in inhibitor switch circuit?	Repair or replace the inhibitor switch circuit.	Go to step 7.
7	<b>CHECK BRAKE LIGHT SWITCH CIRCUIT.</b> Check brake light switch circuit. <Ref. to AT-112, CHECK BRAKE SWITCH., Diagnostic Procedure for No-Diagnostic Trouble Code (DTC).>	Is there any trouble in brake light switch circuit?	Repair or replace the brake light switch circuit.	Go to step 8.

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
8	<b>CHECK ATF TEMPERATURE SENSOR CIRCUIT.</b> Check ATF temperature sensor circuit. <Ref. to AT-48, DTC 27 ATF TEMPERATURE SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Is there any trouble in ATF temperature sensor circuit?	Repair or replace the ATF temperature sensor circuit.	Go to step 9.
9	<b>CHECK POOR CONTACT.</b> Check poor contact in TCM connector.	Is there poor contact in TCM connector?	Repair poor contact in TCM connector.	Go to step 10.
10	<b>CHECK MECHANICAL TROUBLE.</b> Check mechanical trouble in automatic transmission.	Is there any mechanical trouble in automatic transmission?	Repair or replace the automatic transmission. <Ref. to AT-12, INSPECTION, Road Test.>	Replace the TCM. <Ref. to AT-45, Transmission Control Module (TCM).>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## BV: DTC P1086 — TUMBLE GENERATOR VALVE #2 (LH) POSITION SENSOR CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN1162

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>CHECK CURRENT DATA.</b>            1) Start the engine.            2) Read the data of tumble generator valve position sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:            • Subaru Select Monitor            For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;            • OBD-II general scan tool            For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	Is the value less than 0.1 V?	Go to step 2.	Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause. NOTE: In this case, repair the following: • Poor contact in throttle position sensor connector • Poor contact in ECM connector • Poor contact in coupling connector
<p><b>CHECK INPUT SIGNAL FOR ECM.</b>            Measure the voltage between ECM connector and chassis ground while tumble generator valve is fully closed.  <b>Connector &amp; terminal</b>  <b>(B135) No. 9 (+) — Chassis ground (-):</b></p>	Is the voltage more than 4.5 V?	Go to step 4.	Go to step 3.
<p><b>CHECK INPUT SIGNAL FOR ECM.</b>            Measure the voltage between ECM connector and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B135) No. 9 (+) — Chassis ground (-):</b></p>	Does the voltage change more than 4.5 V by shaking harness and connector of ECM while monitoring the value with voltage meter?	Repair poor contact in ECM connector.	Contact with SOA (distributor) service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.
<p><b>CHECK INPUT SIGNAL FOR ECM.</b>            Measure the voltage between ECM connector and chassis ground.  <b>Connector &amp; terminal</b>  <b>(B135) No. 13 (+) — Chassis ground (-):</b></p>	Is the voltage less than 0.1 V?	Go to step 6.	Go to step 5.
<p><b>CHECK INPUT SIGNAL FOR ECM. (USING SUBARU SELECT MONITOR.)</b>            Measure the voltage between ECM connector and chassis ground.</p>	Does the voltage change more than 0.1 V by shaking harness and connector of ECM while monitoring the value with Subaru Select Monitor?	Repair poor contact in ECM connector.	Go to step 6.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>6</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE POSITION SENSOR CONNECTOR.</b>                      1) Turn the ignition switch to OFF.                      2) Disconnect the connectors from tumble generator valve position sensor.                      3) Turn the ignition switch to ON.                      4) Measure voltage between tumble generator valve position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E50) No. 1 (+) — Engine ground (-):</b></p>	<p>Is the voltage more than 4.5 V?</p>	<p>Go to step 7.</p>	<p>Repair harness and connector.</p> <p><b>NOTE:</b>                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between tumble generator valve position sensor and ECM connector</li> <li>• Poor contact in tumble generator valve position sensor connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> <li>• Poor contact in joint connector</li> </ul>
<p><b>7</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE POSITION SENSOR CONNECTOR.</b>                      1) Turn the ignition switch to OFF.                      2) Measure the resistance of harness between ECM connector and tumble generator valve position sensor connector.</p> <p><b>Connector &amp; terminal</b>  <b>(B135) No. 13 — (E50) No. 3:</b></p>	<p>Is the resistance less than 1 Ω?</p>	<p>Go to step 8.</p>	<p>Repair harness and connector.</p> <p><b>NOTE:</b>                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between tumble generator valve position sensor and ECM connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in tumble generator valve position sensor connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>8</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE POSITION SENSOR CONNECTOR.</b>                      Measure the resistance of harness between tumble generator valve position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E50) No. 3 — Engine ground:</b></p>	<p>Is the resistance less than 10 Ω?</p>	<p>Repair ground short circuit in harness between tumble generator valve position sensor and ECM connector.</p>	<p>Go to step 9.</p>
<p><b>9</b></p> <p><b>CHECK POOR CONTACT.</b>                      Check poor contact in tumble generator valve position sensor connector.</p>	<p>Is there poor contact in tumble generator valve position sensor connector?</p>	<p>Repair poor contact in tumble generator valve position sensor connector.</p>	<p>Replace the tumble generator valve assembly. &lt;Ref. to FU(DOHC TURBO)-40, Tumble Generator Valve Assembly.&gt;</p>




**BW:DTC P1087 — TUMBLE GENERATOR VALVE #2 (LH) POSITION SENSOR  
CIRCUIT HIGH INPUT —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

**After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.**

• **WIRING DIAGRAM:**



EN1162

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<p><b>CHECK CURRENT DATA.</b>                      1)Start the engine.                      2)Read the data of tumble generator valve position sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:                      •Subaru Select Monitor                      For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;                      •OBD-II general scan tool                      For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	Is the value more than 4.9 V?	Go to step 2.	<p>Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause.</p> <p>NOTE:                      In this case, repair the following:                      • Poor contact in tumble generator valve position sensor connector                      • Poor contact in ECM connector                      • Poor contact in coupling connector</p>
2	<p><b>CHECK HARNESS BETWEEN TUMBLE GENERATOR VALVE POSITION SENSOR AND ECM CONNECTOR.</b>                      1)Turn the ignition switch to OFF.                      2)Disconnect the connector from tumble generator valve position sensor.                      3)Measure the resistance of harness between throttle position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E50) No. 2 — Engine ground:</b></p>	Is the resistance less than 5 $\Omega$ ?	Go to step 3.	<p>Repair harness and connector.</p> <p>NOTE:                      In this case, repair the following:                      • Open circuit in harness between tumble generator valve position sensor and ECM connector                      • Poor contact in coupling connector                      • Poor contact in joint connector</p>
3	<p><b>CHECK HARNESS BETWEEN TUMBLE GENERATOR VALVE POSITION SENSOR AND ECM CONNECTOR.</b>                      1)Turn the ignition switch to ON.                      2)Measure the voltage between throttle position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E50) No. 3 (+) — Engine ground (-):</b></p>	Is the voltage more than 4.9 V?	Repair battery short circuit in harness between tumble generator valve position sensor and ECM connector. After repair, replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>	Replace the tumble generator valve assembly. <Ref. to FU(DOHC TURBO)-40, Tumble Generator Valve Assembly.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)

## BX: DTC P1088 — TUMBLE GENERATOR VALVE #1 (RH) POSITION SENSOR CIRCUIT LOW INPUT —





- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**

TUMBLE GENERATOR VALVE  
POSITION SENSOR



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1 CHECK CURRENT DATA.</b>                      1) Start the engine.                      2) Read the data of tumble generator valve position sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:                      • Subaru Select Monitor                      For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;                      • OBD-II general scan tool                      For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	Is the value less than 0.1 V?	Go to step 2.	Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Poor contact in tumble generator valve position sensor connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>2 CHECK INPUT SIGNAL FOR ECM.</b>                      Measure the voltage between ECM connector and chassis ground while throttle valve is fully closed.</p> <p><b>Connector &amp; terminal</b>  <b>(B135) No. 9 (+) — Chassis ground (-):</b></p>	Is the voltage more than 4.5 V?	Go to step 4.	Go to step 3.
<p><b>3 CHECK INPUT SIGNAL FOR ECM.</b>                      Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B135) No. 9 (+) — Chassis ground (-):</b></p>	Does the voltage change more than 4.5 V by shaking harness and connector of ECM while monitoring the value with voltage meter?	Repair poor contact in ECM connector.	Contact with SOA (distributor) service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.
<p><b>4 CHECK INPUT SIGNAL FOR ECM.</b>                      Measure the voltage between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B135) No. 23 (+) — Chassis ground (-):</b></p>	Is the voltage less than 0.1 V?	Go to step 6.	Go to step 5.
<p><b>5 CHECK INPUT SIGNAL FOR ECM. (USING SUBARU SELECT MONITOR.)</b>                      Measure the voltage between ECM connector and chassis ground.</p>	Does the voltage change more than 0.1 V by shaking harness and connector of ECM while monitoring the value with Subaru Select Monitor?	Repair poor contact in ECM connector.	Go to step 6.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>6</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE POSITION SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.                  2) Disconnect the connectors from tumble generator valve position sensor.                  3) Turn the ignition switch to ON.                  4) Measure the voltage between throttle position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E54) No. 1 (+) — Engine ground (-):</b></p>	<p>Is the voltage more than 4.5 V?</p>	<p>Go to step 7.</p>	<p>Repair harness and connector.</p> <p><b>NOTE:</b>                  In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between tumble generator valve position sensor and ECM connector</li> <li>• Poor contact in tumble generator valve position sensor connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> <li>• Poor contact in joint connector</li> </ul>
<p><b>7</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE POSITION SENSOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.                  2) Measure the resistance of harness between ECM connector and tumble generator valve position sensor connector.</p> <p><b>Connector &amp; terminal</b>  <b>(B135) No. 23 — (E54) No. 3:</b></p>	<p>Is the resistance less than 1 <math>\Omega</math>?</p>	<p>Go to step 8.</p>	<p>Repair harness and connector.</p> <p><b>NOTE:</b>                  In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between tumble generator valve position sensor and ECM connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in tumble generator valve position sensor connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>8</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND THROTTLE POSITION SENSOR CONNECTOR.</b></p> <p>Measure the resistance of harness between tumble generator valve position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E54) No. 3 — Engine ground:</b></p>	<p>Is the resistance less than 10 <math>\Omega</math>?</p>	<p>Repair ground short circuit in harness between tumble generator valve position sensor and ECM connector.</p>	<p>Go to step 9.</p>
<p><b>9</b></p> <p><b>CHECK POOR CONTACT.</b></p> <p>Check poor contact in tumble generator valve position sensor connector.</p>	<p>Is there poor contact in tumble generator valve position sensor connector?</p>	<p>Repair poor contact in tumble generator valve position sensor connector.</p>	<p>Replace the tumble generator valve assembly. &lt;Ref. to FU(DOHC TURBO)-40, Tumble Generator Valve Assembly.&gt;</p>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## BY:DTC P1089 — TUMBLE GENERATOR VALVE #1 (RH) POSITION SENSOR CIRCUIT HIGH INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN1163

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1 CHECK CURRENT DATA.</b>                      1) Start the engine.                      2) Read the data of tumble generator valve position sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p><b>NOTE:</b>                      • Subaru Select Monitor                      For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt;                      • OBD-II general scan tool                      For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value more than 4.9 V?</p>	<p>Go to step 2.</p>	<p>Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause.</p> <p><b>NOTE:</b>                      In this case, repair the following:                      • Poor contact in tumble generator valve position sensor connector                      • Poor contact in ECM connector                      • Poor contact in coupling connector</p>
<p><b>2 CHECK HARNESS BETWEEN TUMBLE GENERATOR VALVE POSITION SENSOR AND ECM CONNECTOR.</b>                      1) Turn the ignition switch to OFF.                      2) Disconnect the connector from tumble generator valve position sensor.                      3) Measure the resistance of harness between tumble generator valve position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E54) No. 2 — Engine ground:</b></p>	<p>Is the resistance less than 5 Ω?</p>	<p>Go to step 3.</p>	<p>Repair harness and connector.</p> <p><b>NOTE:</b>                      In this case, repair the following:                      • Open circuit in harness between tumble generator valve position sensor and ECM connector                      • Poor contact in coupling connector                      • Poor contact in joint connector</p>
<p><b>3 CHECK HARNESS BETWEEN TUMBLE GENERATOR VALVE POSITION SENSOR AND ECM CONNECTOR.</b>                      1) Turn the ignition switch to ON.                      2) Measure the voltage between tumble generator valve position sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E54) No. 3 (+) — Engine ground (-):</b></p>	<p>Is the voltage more than 4.9 V?</p>	<p>Repair battery short circuit in harness between tumble generator valve position sensor and ECM connector. After repair, replace the ECM. &lt;Ref. to FU(DOHC TURBO)-47, Engine Control Module.&gt;</p>	<p>Replace the tumble generator valve assembly. &lt;Ref. to FU(DOHC TURBO)-40, Tumble Generator Valve Assembly.&gt;</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## BZ:DTC P1090 — TUMBLE GENERATOR VALVE SYSTEM #1 (RH) MALFUNCTION (STUCK OPEN) —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

Step	Check	Yes	No
<b>1</b> <b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate P1088, P1089, P1094 or P1095?	Inspect DTC P1088, P1089, P1094 or P1095 using List of Diagnostic Trouble Code (DTC) <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
<b>2</b> <b>CHECK TUMBLE GENERATOR VALVE RH</b> 1)Remove the tumble generator valve assembly. 2)Check tumble generator valve body.	Does the tumble generator valve move smoothly? (No dirt or foreign materials clogged)	Replace the tumble generator valve assembly. <Ref. to FU(DOHC TURBO)-40, Tumble Generator Valve Assembly.>	Clean tumble generator valve.

**CA:DTC P1091 — TUMBLE GENERATOR VALVE SYSTEM #1 (RH) MALFUNCTION (STUCK CLOSE) —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

Step	Check	Yes	No
<b>1</b> <b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate P1088, P1089, P1094 or P1095?	Inspect DTC P1088, P1089, P1094 or P1095 using List of Diagnostic Trouble Code (DTC) <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
<b>2</b> <b>CHECK TUMBLE GENERATOR VALVE RH</b> 1) Remove the tumble generator valve assembly. 2) Check tumble generator valve body.	Does the tumble generator valve move smoothly? (No dirt or foreign materials clogged)	Replace the tumble generator valve assembly. <Ref. to FU(DOHC TURBO)-40, Tumble Generator Valve Assembly.>	Clean tumble generator valve.

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

**CB:DTC P1092 — TUMBLE GENERATOR VALVE SYSTEM #2 (LH) MALFUNCTION (STUCK OPEN) —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Inspect DTC P1086, P1087, P1096 or P1097 using List of Diagnostic Trouble Code (DTC) <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
2	<b>CHECK TUMBLE GENERATOR VALVE RH</b> 1)Remove the tumble generator valve assembly. 2)Check tumble generator valve body.	Does the tumble generator valve move smoothly? (No dirt or foreign materials clogged)  Replace the tumble generator valve assembly. <Ref. to FU(DOHC TURBO)-40, Tumble Generator Valve Assembly.>	Clean tumble generator valve.

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

**CC:DTC P1093 — TUMBLE GENERATOR VALVE SYSTEM #2 (LH) MALFUNCTION (STUCK CLOSE) —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

Step	Check	Yes	No
<b>1</b> <b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate P1086, P1087, P1096 or P1097?	Inspect DTC P1086, P1087, P1096 or P1097 using List of Diagnostic Trouble Code (DTC) <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
<b>2</b> <b>CHECK TUMBLE GENERATOR VALVE RH</b> 1)Remove the tumble generator valve assembly. 2)Check tumble generator valve body.	Does the tumble generator valve move smoothly? (No dirt or foreign materials clogged)	Replace the tumble generator valve assembly. <Ref. to FU(DOHC TURBO)-40, Tumble Generator Valve Assembly.>	Clean tumble generator valve.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## CD:DTC P1094 — TUMBLE GENERATOR VALVE CIRCUIT #1 (OPEN CIRCUIT)

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1</b> <b>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE ACTUATOR CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from tumble generator valve and ECM connector. 3) Measure the resistance between tumble generator valve actuator and ECM connector. <b>Connector &amp; terminal</b> <b>(E55) No. 1 — (B84) No.4:</b> <b>(E55) No. 2 — (B84) No.5:</b>	Is the resistance less than 1Ω?	Go to step 2.	Repair open circuit between ECM and tumble generator valve connector.  <b>NOTE:</b> In this case, repair the following: • Open circuit in harness between ECM and tumble generator valve actuator connector. • Poor contact in coupling connector.
<b>2</b> <b>CHECK POOR CONTACT.</b> Check poor contact in tumble generator valve actuator connector.	Is there poor contact in tumble generator valve actuator connector.	Repair poor contact in tumble generator valve actuator connector.	Replace the tumble generator valve assembly. <Ref. to FU(DOHC TURBO)-40, Tumble Generator Valve Assembly.>


**CE:DTC P1095 — TUMBLE GENERATOR VALVE CIRCUIT #1 (OVERCURRENT)**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<p><b>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE ACTUATOR CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.            2) Disconnect the connector from tumble generator valve connector.            3) Measure the voltage between tumble generator valve actuator and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E55) No. 1 (+) — Chassis ground (-):</b>  <b>(E55) No. 2 (+) — Chassis ground (-):</b></p>	Is the voltage less than 5V?	Replace the tumble generator valve assembly. <Ref. to FU(DOHC TURBO)-40, Tumble Generator Valve Assembly.>	Repair battery short circuit between ECM and tumble generator valve actuator.


**CF:DTC P1096 — TUMBLE GENERATOR VALVE CIRCUIT #2 (OPEN CIRCUIT)**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b>     <b>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE ACTUATOR CONNECTOR.</b>                      1) Turn the ignition switch to OFF.                      2) Disconnect the connector from tumble generator valve and ECM connector.                      3) Measure the resistance between tumble generator valve actuator and ECM connector.</p> <p><b>Connector &amp; terminal</b>  <b>(E51) No. 1 — (B84) No. 10:</b>  <b>(E51) No. 2 — (B84) No. 11:</b></p>	<p>Is the resistance less than 1Ω?</p>	<p>Go to step 2.</p>	<p>Repair open circuit between ECM and tumble generator valve connector.</p> <p><b>NOTE:</b>                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and tumble generator valve actuator connector.</li> <li>• Poor contact in coupling connector.</li> </ul>
<p><b>2</b>     <b>CHECK POOR CONTACT.</b>                      Check poor contact in tumble generator valve actuator connector.</p>	<p>Is there poor contact in tumble generator valve actuator connector.</p>	<p>Repair poor contact in tumble generator valve actuator connector.</p>	<p>Replace the tumble generator valve assembly. &lt;Ref. to FU(DOHC TURBO)-40, Tumble Generator Valve Assembly.&gt;</p>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
 ENGINE (DIAGNOSTICS)


**CG:DTC P1097 — TUMBLE GENERATOR VALVE CIRCUIT #2 (OVERCURRENT)**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



EN1165

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)

Step	Check	Yes	No	
1	<b>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE ACTUATOR CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from tumble generator valve connector. 3) Measure the voltage between tumble generator valve actuator and chassis ground. <b>Connector &amp; terminal</b> <i>(E51) No. 1 (+) — Chassis ground (-):</i> <i>(E51) No. 2 (+) — Chassis ground (-):</i>	Is the voltage less than 5V?	Replace the tumble generator valve assembly. <Ref. to FU(DOHC TURBO)-40, Tumble Generator Valve Assembly.>	Repair battery short circuit between ECM and tumble generator valve actuator.

## CH: DTC P1110 — ATMOSPHERIC PRESSURE SENSOR CIRCUIT LOW INPUT

• **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

Step	Check	Yes	No	
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P1110?	Replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>  NOTE: Atmospheric pressure sensor is built into ECM.	It is not necessary to inspect DTC P1110.

## CI: DTC P1111 — ATMOSPHERIC PRESSURE SENSOR CIRCUIT HIGH INPUT

• **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

Step	Check	Yes	No	
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P1111?	Replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>  NOTE: Atmospheric pressure sensor is built into ECM.	It is not necessary to inspect DTC P1111.

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

**CJ:DTC P1112 — ATMOSPHERIC PRESSURE SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

Step	Check	Yes	No	
1	CHECK ANY OTHER DTC ON DISPLAY.	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0106, P0107, P0108, P1110 or P1111?	Inspect DTC P0106, P0107, P0108, P1110 or P1111 using "List of Diagnostic Trouble Code (DTC)".<Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>	Replace the ECM.<Ref. to FU(DOHC TURBO)-47, Engine Control Module.> NOTE: Atmospheric pressure sensor is built into ECM.



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## CK: DTC P1130 — FRONT OXYGEN (A/F) SENSOR CIRCUIT MALFUNCTION (OPEN CIRCUIT) —

- DTC DETECTING CONDITION:
  - Immediately at fault recognition

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>

- WIRING DIAGRAM:



FN1143

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1</b> <b>CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM and front oxygen (A/F) sensor connector. 3) Measure the resistance of harness between ECM and front oxygen (A/F) sensor connector. <b>Connector &amp; terminal</b> <b>(B137) No. 29 — (B18) No. 3:</b> <b>(B137) No. 19 — (B18) No. 4:</b>	Is the resistance less than 1 $\Omega$ ?	Go to step 2.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and front oxygen (A/F) sensor connector</li> <li>• Poor contact in front oxygen (A/F) sensor connector</li> <li>• Poor contact in ECM connector</li> </ul>
<b>2</b> <b>CHECK POOR CONTACT.</b> Check poor contact in front oxygen (A/F) sensor connector.	Is there poor contact in front oxygen (A/F) sensor connector?	Repair poor contact in front oxygen (A/F) sensor connector.	Replace the front oxygen (A/F) sensor. <Ref. to FU(DOHC TURBO)-42, Front Oxygen (A/F) Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## CL: DTC P1131 — FRONT OXYGEN (A/F) SENSOR CIRCUIT MALFUNCTION (SHORT CIRCUIT) —

- DTC DETECTING CONDITION:
  - Immediately at fault recognition

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- WIRING DIAGRAM:



EN1143

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1</b> <b>CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between ECM connector and chassis ground. <i>Connector &amp; terminal</i> <i>(B137) No. 19 — Chassis ground:</i>	Is the resistance more than 10 $\Omega$ ?	Go to step 2.	Repair ground short circuit in harness between ECM and front oxygen (A/F) sensor connector.
<b>2</b> <b>CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b> Measure the resistance of harness between ECM connector and chassis ground. <i>Connector &amp; terminal</i> <i>(B137) No. 29 — Chassis ground:</i>	Is the resistance more than 10 $\Omega$ ?	Go to step 3.	Repair ground short circuit in harness between ECM and front oxygen (A/F) sensor connector.
<b>3</b> <b>CHECK OUTPUT SIGNAL FOR ECM.</b> 1) Connect the connector to ECM. 2) Turn the ignition switch to ON. 3) Measure the voltage between ECM connector and chassis ground. <i>Connector &amp; terminal</i> <i>(B137) No. 19 (+) — Chassis ground (-):</i>	Is the voltage more than 4.5 V?	Go to step 4.	Go to step 5.
<b>4</b> <b>CHECK OUTPUT SIGNAL FOR ECM.</b> Measure the voltage between ECM connector and chassis ground. <i>Connector &amp; terminal</i> <i>(B137) No. 19 (+) — Chassis ground (-):</i>	Is the voltage more than 10 V?	Repair battery short circuit in harness between ECM and front oxygen (A/F) sensor connector.	Repair poor contact in ECM connector.
<b>5</b> <b>CHECK OUTPUT SIGNAL FOR ECM.</b> Measure the voltage between ECM connector and chassis ground. <i>Connector &amp; terminal</i> <i>(B137) No. 29 (+) — Chassis ground (-):</i>	Is the voltage more than 4.95 V?	Go to step 6.	Replace the front oxygen (A/F) sensor. <Ref. to FU(DOHC TURBO)-42, Front Oxygen (A/F) Sensor.>
<b>6</b> <b>CHECK OUTPUT SIGNAL FOR ECM.</b> Measure the voltage between ECM connector and chassis ground. <i>Connector &amp; terminal</i> <i>(B137) No. 29 (+) — Chassis ground (-):</i>	Is the voltage more than 10 V?	Repair battery short circuit in harness between ECM and front oxygen (A/F) sensor connector.	Repair poor contact in ECM connector.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## CM:DTC P1134 — FRONT OXYGEN (A/F) SENSOR MICRO-COMPUTER PROBLEM —

- DTC DETECTING CONDITION:
  - Immediately at fault recognition

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- WIRING DIAGRAM:



EN1143

Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b> Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P1134?	Replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>	It is not necessary to inspect DTC P1134.



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## CN: DTC P1139 — FRONT OXYGEN (A/F) SENSOR #1 HEATER CIRCUIT RANGE/PERFORMANCE PROBLEM —

- DTC DETECTING CONDITION:
  - Two consecutive driving cycles with fault

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

### • WIRING DIAGRAM:



EN1143

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1 CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b>                      1)Start the engine, and warm-up the engine.                      2)Turn the ignition switch to OFF.                      3)Disconnect the connectors from ECM and front oxygen (A/F) sensor.                      4)Measure the resistance of harness between ECM and front oxygen (A/F) sensor connector.  <b>Connector &amp; terminal</b>  <b>(B137) No. 5 — (B18) No. 1:</b>  <b>(B137) No. 4 — (B18) No. 1:</b></p>	Is the resistance less than 1 $\Omega$ ?	Go to step 2.	Repair open circuit in harness between ECM and front oxygen (A/F) sensor connector.
<p><b>2 CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b>                      Measure the resistance of harness between ECM and front oxygen (A/F) sensor connector.  <b>Connector &amp; terminal</b>  <b>(B137) No. 19 — (B18) No. 4:</b>  <b>(B137) No. 29 — (B18) No. 3:</b></p>	Is the resistance less than 1 $\Omega$ ?	Go to step 3.	Repair open circuit in harness between ECM and front oxygen (A/F) sensor connector.
<p><b>3 CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</b>                      Measure the resistance of harness between main relay and front oxygen (A/F) sensor connector.  <b>Connector &amp; terminal</b>  <b>(B47) No. 4 — (B18) No. 2:</b></p>	Is the resistance less than 1 $\Omega$ ?	Go to step 4.	Repair open circuit in harness between ECM and front oxygen (A/F) sensor connector.
<p><b>4 CHECK FRONT OXYGEN (A/F) SENSOR.</b>                      Measure the resistance between front oxygen (A/F) sensor connector terminals.  <b>Terminals</b>  <b>No. 2 — No. 1:</b></p>	Is the resistance less than 5 $\Omega$ ?	Go to step 5.	Replace the front oxygen (A/F) sensor. <Ref. to FU(DOHC TURBO)-42, Front Oxygen (A/F) Sensor.>
<p><b>5 CHECK POOR CONTACT.</b>                      Check poor contact in ECM and front oxygen (A/F) sensor connector.</p>	Is there poor contact in ECM or front oxygen (A/F) sensor connector?	Repair poor contact in ECM or front oxygen (A/F) sensor connector.	Replace the front oxygen (A/F) sensor. <Ref. to FU(DOHC TURBO)-42, Front Oxygen (A/F) Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## CO:DTC P1141 — MASS AIR FLOW SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (LOW INPUT) —

### • DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault


### • TROUBLE SYMPTOM:

- Erroneous idling
- Engine stalls.
- Poor driving performance

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

### • WIRING DIAGRAM:



EN1145

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 <b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does Subaru select monitor or OBD-II general scan tool indicate DTC P0102 or P0103?	Inspect DTC P0102 or P0103 using "Diagnostics Chart with Trouble Code" <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).> <b>NOTE:</b> In this case, it is not necessary to inspect DTC P1141.	Replace the mass air flow and intake air temperature sensor.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)





## CP:DTC P1142 — THROTTLE POSITION SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (LOW INPUT) —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN1166

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Inspect DTC P0122 or P0123 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).> <b>NOTE:</b> In this case, it is not necessary to inspect DTC P1142.	Replace the throttle position sensor. <Ref. to FU(DOHC TURBO)-33, Throttle Position Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## CQ:DTC P1146 — PRESSURE SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (HIGH INPUT) —





**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

**WIRING DIAGRAM:**



EN1146

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<p><b>CHECK ANY OTHER DTC ON DISPLAY.</b></p> <p>NOTE: In this case, it is not necessary to inspect DTC P0106.</p>	<p>Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0107, P0108 or P1112?</p>	<p>Inspect DTC P0107, P0108 or P1112 using "List of Diagnostic Trouble Code (DTC)". &lt;Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).&gt;</p>	<p>Go to step 2.</p>
2	<p><b>CHECK AIR INTAKE SYSTEM.</b></p>	<p>Are there holes, loose bolts or disconnection of hose on air intake system?</p>	<p>Repair air intake system.</p>	<p>Go to step 3.</p>
3	<p><b>CHECK PRESSURE SENSOR.</b></p> <p>1)Start the engine and warm-up engine until coolant temperature is greater than 60°C (140°F).</p> <p>2)Place the shift lever in the selector lever in "N" or "P" position.</p> <p>3)Turn the A/C switch to OFF.</p> <p>4)Turn all accessory switches to OFF.</p> <p>5)Read the data of pressure sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt; •OBD-II general scan tool For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual. Specification: •Intake manifold absolute pressure</p> <p><b>Ignition ON</b> <b>73.3 — 106.6 kPa (550 — 800 mmHg,</b> <b>21.65 — 31.50 inHg)</b></p> <p><b>Idling</b> <b>20.0 — 46.7 kPa (150 — 350 mmHg,</b> <b>5.91 — 13.78 inHg)</b></p>	<p>Is the value within the specifications?</p>	<p>Go to step 4.</p>	<p>Replace the pressure sensor. &lt;Ref. to FU(DOHC TURBO)-35, Pressure Sensor.&gt;</p>
4	<p><b>CHECK THROTTLE POSITION.</b></p> <p>Read the data of throttle position signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-38, Subaru Select Monitor.&gt; •OBD-II general scan tool For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the throttle positioning ratio equal to or less than 5% when throttle is fully closed?</p>	<p>Go to step 5.</p>	<p>Adjust or replace the throttle position sensor. &lt;Ref. to FU(DOHC TURBO)-33, Throttle Position Sensor.&gt;</p>
5	<p><b>CHECK THROTTLE POSITION.</b></p>	<p>Is the throttle positioning ratio equal to or more than 85% when throttle is fully open?</p>	<p>Replace the pressure sensor. &lt;Ref. to FU(DOHC TURBO)-35, Pressure Sensor.&gt;</p>	<p>Replace the throttle position sensor. &lt;Ref. to FU(DOHC TURBO)-33, Throttle Position Sensor.&gt;</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### CR:DTC P1230 — FUEL PUMP CONTROLLER MALFUNCTION —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN1141

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>CHECK POWER SUPPLY CIRCUIT TO FUEL PUMP CONTROLLER.</b></p> <p>1) Turn the ignition switch to OFF.                  2) Disconnect the connector from fuel pump controller.                  3) Turn the ignition switch to ON.                  4) Measure the voltage between fuel pump controller and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(R122) No. 10 (+) — Chassis ground (-):</b></p>	the voltage more than 10V?	Go to step 2.	Repair power supply circuit. NOTE: In this case repair the following: <ul style="list-style-type: none"> <li>• Open or ground short circuit in harness between fuel pump relay and fuel pump controller.</li> <li>• Poor contact in fuel pump controller connector.</li> <li>• Poor contact in fuel pump relay connector.</li> </ul>
<p><b>CHECK GROUND CIRCUIT OF FUEL PUMP CONTROLLER.</b></p> <p>1) Turn the ignition switch to OFF.                  2) Measure the resistance of harness between fuel pump controller and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(R122) No. 5 — Chassis ground:</b></p>	the resistance less than 5 ?	Go to step 3.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit between fuel pump controller and chassis ground.</li> <li>• Poor contact in fuel pump controller connector.</li> </ul>
<p><b>CHECK HARNESS BETWEEN FUEL PUMP CONTROLLER AND FUEL PUMP CONNECTOR.</b></p> <p>1) Disconnect the connector from fuel pump.                  2) Measure the resistance of harness between fuel pump controller and fuel pump connector.</p> <p><b>Connector &amp; terminal</b>  <b>(R122) No. 7 — (R58) No. 2:</b>  <b>(R122) No. 6 — (R58) No. 1:</b></p>	the resistance less than 1 ?	Go to step 4.	Repair open circuit between fuel pump controller and fuel pump.
<p><b>CHECK HARNESS BETWEEN FUEL PUMP CONTROLLER AND FUEL PUMP CONNECTOR.</b></p> <p>Measure the resistance of harness between fuel pump controller and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(R122) No. 7 — Chassis ground:</b>  <b>(R122) No. 6 — Chassis ground:</b></p>	the resistance more than 1M ?	Go to step 5.	Repair ground short circuit between fuel pump controller and fuel pump.
<p><b>CHECK HARNESS BETWEEN FUEL PUMP CONTROLLER AND ECM CONNECTOR.</b></p> <p>1) Turn the ignition switch to OFF.                  2) Disconnect the connector from ECM.                  3) Measure the resistance of harness between fuel pump controller and ECM connector.</p> <p><b>Connector &amp; terminal</b>  <b>(R122) No. 9 — (B134) No. 13:</b>  <b>(R122) No. 8 — (B136) No. 16:</b></p>	the resistance less than 1 ?	Go to step 6.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit between fuel pump controller and ECM.</li> <li>• Poor contact in fuel pump controller and ECM connector.</li> </ul>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
6	<b>CHECK HARNESS BETWEEN FUEL PUMP CONTROLLER AND ECM CONNECTOR.</b> Measure the resistance of harness between fuel pump controller and chassis ground. <b>Connector &amp; terminal</b> <b>(R122) No. 9 — Chassis ground:</b> <b>(R122) No. 8 — Chassis ground:</b>	Is the resistance more than 1M $\Omega$ ?	Go to step 7.	Repair ground short circuit between fuel pump controller and ECM.
7	<b>CHECK POOR CONTACT.</b> Check poor contact in ECM and fuel pump controller connector.	Is there poor contact in ECM and fuel pump controller connector.	Repair poor contact in ECM and fuel pump controller.	Replace the fuel pump controller. <Ref. to FU(DOHC TURBO)-50, Fuel Pump Controller.>



**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
**ENGINE (DIAGNOSTICS)**


**CS:DTC P1244 — WASTEGATE CONTROL SOLENOID VALVE RANGE/PERFORMANCE PROBLEM (LOW INPUT) —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK ANY OTHER DTC ON DISPLAY.	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0245 or P0246?	Inspect DTC P0245 or P0246 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>  NOTE: In this case, it is not necessary to inspect DTC P1244.	Replace the wastegate control solenoid valve. <Ref. to FU(DOHC TURBO)-41, Wastegate Control Solenoid Valve.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## CT:DTC P1245 — WASTEGATE CONTROL SOLENOID VALVE MALFUNCTION (FAIL-SAFE) —

- DTC DETECTING CONDITION:
  - Immediately at fault recognition

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, Operation.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>

- WIRING DIAGRAM:



EN1150

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No	
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0244, P0245, P0246 or P1244?	Inspect DTC P0244, P0245, P0246 or P1244 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>  NOTE: In this case, it is not necessary to inspect DTC P1245.	Replace the wastegate control solenoid valve. <Ref. to FU(DOHC TURBO)-41, Wastegate Control Solenoid Valve.>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC.</b> Conduct the troubleshooting for all DTC P0301, P0302, P0303 and P0304. <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>	Does failure for repair or replacement exist?	Repair or replace failure, then replace the precat-alytic converter.	Contact with SOA (distributor) ser-vice. <b>NOTE:</b> Inspection by DTM is required, be-cause probable cause is deteriora-tion of multiple parts.


**CV:DTC P1312 — EXHAUST GAS TEMPERATURE CIRCUIT MALFUNCTION —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



EN1161

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK ANY OTHER DTC ON DISPLAY.	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0545, P0546 or P1544?	Inspect DTC P0545, P0546 or P1544 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P1312.	Replace the exhaust gas temperature sensor. <Ref. to FU(DOHC TURBO)-46, Exhaust Temperature Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## CW:DTC P1400 — FUEL TANK PRESSURE CONTROL SOLENOID VALVE CIRCUIT LOW INPUT —


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

**WIRING DIAGRAM:**



EN1167

Step	Check	Yes	No
<b>1</b> <b>CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B137) No. 22 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V?	Go to step 2.	Go to step 3.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>CHECK POOR CONTACT.</b> Check poor contact in ECM connector.</p>	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Contact with SOA (distributor) service. <b>NOTE:</b> Inspection by DTM is required, because probable cause is deterioration of multiple parts.
<p><b>CHECK HARNESS BETWEEN FUEL TANK PRESSURE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from fuel tank pressure control solenoid valve and ECM. 3) Measure the resistance of harness between fuel tank pressure control solenoid valve connector and chassis ground. <b>Connector &amp; terminal</b> <b>(R68) No. 2 — Chassis ground:</b></p>	Is the resistance less than 10 $\Omega$ ?	Repair ground short circuit in harness between ECM and fuel tank pressure control solenoid valve connector.	Go to step 4.
<p><b>CHECK HARNESS BETWEEN FUEL TANK PRESSURE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b> Measure the resistance of harness between ECM and fuel tank pressure control solenoid valve connector. <b>Connector &amp; terminal</b> <b>(B137) No. 22 — (R68) No. 2:</b></p>	Is the voltage less than 1 $\Omega$ ?	Go to step 5.	Repair harness and connector. <b>NOTE:</b> In this case, repair the following: • Open circuit in harness between ECM and fuel tank pressure control solenoid valve connector • Poor contact in coupling connectors
<p><b>CHECK FUEL TANK PRESSURE CONTROL SOLENOID VALVE.</b> Measure the resistance between fuel tank pressure control solenoid valve terminals. <b>Terminals</b> <b>No. 1 — No. 2:</b></p>	Is the resistance between 10 and 100 $\Omega$ ?	Go to step 6.	Replace the fuel tank pressure control solenoid valve. <Ref. to EC(DOHC TURBO)-12, Pressure Control Solenoid Valve.>
<p><b>CHECK POWER SUPPLY TO FUEL TANK PRESSURE CONTROL SOLENOID VALVE.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between fuel tank pressure control solenoid valve and chassis ground. <b>Connector &amp; terminal</b> <b>(R68) No. 1 (+) — Chassis ground (-):</b></p>	Is the voltage more than 10 V?	Go to step 7.	Repair harness and connector. <b>NOTE:</b> In this case, repair the following: • Open circuit in harness between main relay and fuel tank pressure control solenoid valve connector • Poor contact in coupling connectors • Poor contact in main relay connector

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
7	<b>CHECK POOR CONTACT.</b> Check poor contact in fuel tank pressure control solenoid valve connector.	Is there poor contact in fuel tank pressure control solenoid valve connector?	Repair poor contact in fuel tank pressure control solenoid valve connector.	Contact with SOA (distributor) service. <b>NOTE:</b> Inspection by DTM is required, because probable cause is deterioration of multiple parts.



**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
**ENGINE (DIAGNOSTICS)**


**CX:DTC P1420 — FUEL TANK PRESSURE CONTROL SOLENOID VALVE CIRCUIT HIGH INPUT —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



EN1167

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Turn the ignition switch to OFF. 2) Connect the test mode connector at the lower portion of instrument panel (on the driver's side), to the side of the center console box. 3) Turn the ignition switch to ON. 4) While operating the fuel tank pressure control solenoid valve, measure voltage between ECM and chassis ground.  <b>NOTE:</b> Fuel tank pressure control solenoid valve operation can be executed using Subaru Select Monitor. For procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(DOHC TURBO)-50, Compulsory Valve Operation Check Mode.>  <b>Connector &amp; terminal</b> <b>(B137) No. 22 (+) — Chassis ground (-):</b>	Does voltage change between 0 and 10 V?	Go to step 2.	Even if MIL lights up, the circuit has returned to a normal condition at this time. In this case, repair poor contact in ECM connector.
<b>2 CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground.  <b>Connector &amp; terminal</b> <b>(B137) No. 22 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V?	Go to step 4.	Go to step 3.
<b>3 CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>
<b>4 CHECK HARNESS BETWEEN FUEL TANK PRESSURE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from fuel tank pressure control solenoid valve. 3) Turn the ignition switch to ON. 4) Measure the voltage between ECM and chassis ground.  <b>Connector &amp; terminal</b> <b>(B137) No. 22 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V?	Repair battery short circuit in harness between ECM and fuel tank pressure control solenoid valve connector. After repair, replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>	Go to step 5.
<b>5 CHECK FUEL TANK PRESSURE CONTROL SOLENOID VALVE.</b> 1) Turn the ignition switch to OFF. 2) Measure the resistance between fuel tank pressure control solenoid valve terminals.  <b>Terminals</b> <b>No. 1 — No. 2:</b>	Is the resistance less than 1 $\Omega$ ?	Replace the fuel tank pressure control solenoid valve <Ref. to EC(DOHC TURBO)-12, Pressure Control Solenoid Valve.> and ECM <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>	Go to step 6.
<b>6 CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
**ENGINE (DIAGNOSTICS)**


**CY:DTC P1443 — EVAPORATIVE EMISSION CONTROL SYSTEM VENT CONTROL FUNCTION PROBLEM —**

- **DTC DETECTING CONDITION:**
  - Immediately after fault occurrence
- **TROUBLE SYMPTOM:**
  - Improper fuel supply

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN1168

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Is there any other DTC on display?	Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
2	<b>CHECK VENT LINE HOSES.</b> Check the following items. •Clogging of vent hoses between canister and drain valve •Clogging of vent hose between drain valve and air filter •Clogging of drain filter	Is there a fault in vent line?	Repair or replace the faulty part.	Go to step 3.
3	<b>CHECK DRAIN VALVE OPERATION.</b> 1)Turn the ignition switch to OFF. 2)Connect the test mode connector at the lower portion of instrument panel (on the driver's side), to the side of the center console box. 3)Turn the ignition switch to ON. 4)Operate the drain valve.  NOTE: Drain valve operation can also be executed using Subaru Select Monitor. For the procedure, refer to the "Compulsory Valve Operation Check Mode". <Ref. to EN(DOHC TURBO)-50, Compulsory Valve Operation Check Mode.>	Does the drain valve produce operating sound?	Contact with SOA (distributor) service.  NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.	Replace the drain valve. <Ref. to EC(DOHC TURBO)-17, Drain Valve.>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**CZ:DTC P1480 — COOLING FAN RELAY 1 CIRCUIT HIGH INPUT —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Radiator fan does not operate properly.
  - Overheating



**CAUTION:**

**After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, Operation.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.**

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### • WIRING DIAGRAM:



EN1157

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Turn the ignition switch to OFF. 2) Connect the test mode connector at the lower portion of instrument panel (on the driver's side), to the side of the center console box. 3) Turn the ignition switch to ON. 4) While operating the radiator fan relay, measure voltage between ECM and chassis ground.  <b>NOTE:</b> Radiator fan relay operation can be executed using Subaru Select Monitor. For procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(DOHC TURBO)-50, Compulsory Valve Operation Check Mode.>  <b>Connector &amp; terminal</b> (B137) No. 17 (+) — Chassis ground (-): (B137) No. 28 (+) — Chassis ground (-):	Does the voltage change between 0 and 10 V?	Even if MIL lights up, the circuit has returned to a normal condition at this time. In this case, repair poor contact in ECM connector.	Go to step 2.
<b>2 CHECK SHORT CIRCUIT IN RADIATOR FAN RELAY CONTROL CIRCUIT.</b> 1) Turn the ignition switch to OFF. 2) Remove the main fan relay and sub fan relay. (with A/C models) 3) Disconnect the test mode connector. 4) Turn the ignition switch to ON. 5) Measure the voltage between ECM and chassis ground.  <b>Connector &amp; terminal</b> (B137) No. 17 (+) — Chassis ground (-): (B137) No. 28 (+) — Chassis ground (-):	Is the voltage more than 10 V?	Repair battery short circuit in radiator fan relay control circuit. After repair, replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>	Go to step 3.
<b>3 CHECK MAIN FAN RELAY.</b> 1) Turn the ignition switch to OFF. 2) Remove the main fan relay 1 and 2. 3) Measure the resistance between main fan relay terminals.  <b>Terminal</b> No. 25 — No. 26 (Main fan relay 1) No. 23 — No. 24 (Main fan relay 2)	Is the resistance less than 1 $\Omega$ ?	Replace the main fan relay and ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>	Go to step 4.
<b>4 CHECK SUB FAN RELAY.</b> 1) Remove the sub fan relay. 2) Measure the resistance between sub fan relay terminals.  <b>Terminal</b> No. 7 — No. 8 (Sub fan relay 1) No. 17 — No. 18 (Sub fan relay 2)	Is the resistance less than 1 $\Omega$ ?	Replace the sub fan relay and ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>	Go to step 5.
<b>5 CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)

## DA:DTC P1507 — IDLE CONTROL SYSTEM MALFUNCTION (FAIL-SAFE) —

### • DTC DETECTING CONDITION:

- Immediately at fault recognition


### • TROUBLE SYMPTOM:

- Engine keeps running at higher revolution than specified idling revolution.
- Fuel is cut according to fail-safe function.

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

### • WIRING DIAGRAM:



EN1160

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0506, P0507, P0508, P0509 or P1142?	Inspect DTC P0506, P0507, P0508, P0509 or P1142 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>  NOTE: In this case, it is not necessary to inspect DTC P1507.	Go to step 2.
<b>CHECK AIR INTAKE SYSTEM.</b> 1) Turn the ignition switch to ON. 2) Start the engine, and idle it. 3) Check the following items. • Loose installation of intake manifold, idle air control solenoid valve and throttle body • Cracks of intake manifold gasket, idle air control solenoid valve gasket and throttle body gasket • Disconnections of vacuum hoses	Is there a fault in air intake system?	Repair air suction and leaks.	Go to step 3.
<b>CHECK THROTTLE CABLE.</b>	Does the throttle cable have play for adjustment?	Go to step 4.	Adjust throttle cable. <Ref. to SP-7, INSTALLATION, Accelerator Control Cable.>
<b>CHECK AIR BY-PASS LINE.</b> 1) Turn the ignition switch to OFF. 2) Remove the idle air control solenoid valve from throttle body. <Ref. to FU(DOHC TURBO)-36, Idle Air Control Solenoid Valve.> 3) Confirm that there are no foreign particles in by-pass air line.	Are foreign particles in by-pass air line?	Remove foreign particles from by-pass air line.	Replace the idle air control solenoid valve. <Ref. to FU(DOHC TURBO)-36, Idle Air Control Solenoid Valve.>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**DB:DTC P1518 — STARTER SWITCH CIRCUIT LOW INPUT —**


- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Failure of engine to start

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)

## • WIRING DIAGRAM:



EN1139

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 <b>CHECK OPERATION OF STARTER MOTOR.</b>	Does the starter motor operate when ignition switch to "ST"?	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"><li>• Open or ground short circuit in harness between ECM and starter motor connector.</li><li>• Poor contact in ECM connector.</li></ul>	Check starter motor circuit. <Ref. to EN(DOHC TURBO)-64, STARTER MOTOR CIRCUIT, Diagnostics for Engine Starting Failure.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## DC:DTC P1544 — HIGH EXHAUST TEMPERATURE DETECTED —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Poor driving performance

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



EN1161

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b>      <b>CHECK ANY OTHER DTC ON DISPLAY.</b></p>	<p>Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0335, P0336, P0340, P0341, P0545, P0546, P1312, P0102, P0103, P0101, P1141, P0301, P0302, P0303, P0304, P1301, P0171, P0133, P1134, P0131, P0132, P1130, P1131, P1139, P0031, P0032, P0139, P0136, P0039 or P0037?</p>	<p>Inspect DTC P0335, P0336, P0340, P0341, P0545, P0546, P1312, P0102, P0103, P0101, P1141, P0301, P0302, P0303, P0304, P1301, P0171, P0133, P1134, P0131, P0132, P1130, P1131, P1139, P0031, P0032, P0139, P0136, P0039 or P0037 using List of Diagnostic Trouble Code (DTC). &lt;Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).&gt; NOTE: In this case, it is not necessary to inspect DTC P1544.</p>	<p>Go to step 2.</p>
<p><b>2</b>      <b>CHECK EXHAUST SYSTEM.</b> Check exhaust system parts. NOTE: Check the following items. •Loose installation of exhaust manifold •Cracks or hole of exhaust manifold •Loose installation of front oxygen (A/F) sensor</p>	<p>Is there a fault in exhaust system?</p>	<p>Repair or replace failure, then replace the pre-catalytic converter.</p>	<p>Contact with SOA (distributor) service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

---

**DD:DTC P1560 — BACK-UP VOLTAGE CIRCUIT MALFUNCTION —**

**• DTC DETECTING CONDITION:**

- Immediately at fault recognition



**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### • WIRING DIAGRAM:



EN1171

Step	Check	Yes	No
<b>1</b> <b>CHECK INPUT SIGNAL FOR ECM.</b> 1) Turn the ignition switch to OFF. 2) Measure the voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B137) No. 10 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V?	Repair poor contact in ECM connector.	Go to step 2.

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>2 CHECK HARNESS BETWEEN ECM AND MAIN FUSE BOX CONNECTOR.</b> 1) Disconnect the connector from ECM. 2) Measure the resistance of harness between ECM and chassis ground. <i>Connector &amp; terminal                      (B137) No. 10 — Chassis ground:</i>	Is the resistance less than 10 $\Omega$ ?	Repair ground short circuit in harness between ECM connector and battery terminal.	Go to step 3.
<b>3 CHECK FUSE SBF-5.</b>	Is fuse blown?	Replace the fuse.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and battery</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in battery terminal</li> </ul>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## DE:DTC P1590 — NEUTRAL POSITION SWITCH CIRCUIT HIGH INPUT —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



B2M4370

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1</b> <b>CHECK DTC P0705 ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0705?	Inspect DTC P0705 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
<b>2</b> <b>CHECK INPUT SIGNAL FOR ECM.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground in selector lever "N" and "P" positions. <i>Connector &amp; terminal</i> <i>(B134) No. 8 (+) — Chassis ground (-):</i>	Is the voltage less than 1 V?	Go to step 3.	Go to step 5.
<b>3</b> <b>CHECK INPUT SIGNAL FOR ECM.</b> Measure the voltage between ECM and chassis ground in selector lever except for "N" and "P" positions. <i>Connector &amp; terminal</i> <i>(B134) No. 8 (+) — Chassis ground (-):</i>	Is the voltage between 4.5 and 5.5 V?	Go to step 4.	Go to step 5.
<b>4</b> <b>CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Contact with SOA (distributor) service.  NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.
<b>5</b> <b>CHECK INPUT SIGNAL FOR ECM.</b> Measure the voltage between ECM and chassis ground. <i>Connector &amp; terminal</i> <i>(B134) No. 8 (+) — Chassis ground (-):</i>	Is the voltage more than 10 V?	Repair battery short circuit in harness between ECM and inhibitor switch connector.	Go to step 6.
<b>6</b> <b>CHECK HARNESS BETWEEN ECM AND INHIBITOR SWITCH CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM and inhibitor switch. 3) Measure the resistance of harness between ECM and inhibitor switch connector. <i>Connector &amp; terminal</i> <i>(B134) No. 8 — (T7) No. 12:</i>	Is the resistance less than 1 $\Omega$ ?	Go to step 7.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and inhibitor switch connector</li> <li>• Poor contact in coupling connector</li> <li>• Poor contact in inhibitor switch connector</li> <li>• Poor contact in ECM connector</li> </ul>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>7</b> <b>CHECK INHIBITOR SWITCH GROUND LINE.</b> Measure the resistance of harness between inhibitor switch connector and engine ground. <i>Connector &amp; terminal</i> <i>(T7) No. 7 — Engine ground:</i>	Is the resistance less than 5 $\Omega$ ?	Go to step <b>8</b> .	Repair open circuit in harness between inhibitor switch connector and starter motor ground line.  NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between inhibitor switch connector and starter motor ground line</li> <li>• Poor contact in starter motor connector</li> <li>• Poor contact in starter motor ground</li> <li>• Starter motor</li> </ul>
<b>8</b> <b>CHECK INHIBITOR SWITCH.</b> Measure the resistance between inhibitor switch connector receptacle's terminals in selector lever "N" and "P" positions. <i>Terminals</i> <i>No. 7 — No. 12:</i>	Is the resistance less than 1 $\Omega$ ?	Go to step <b>9</b> .	Replace the inhibitor switch. <Ref. to AT-28, Inhibitor Switch.>
<b>9</b> <b>CHECK SELECTOR CABLE CONNECTION.</b>	Is there any fault in selector cable connection to inhibitor switch?	Repair selector cable connection. <Ref. to CS-27, INSPECTION, Select Cable.>	Contact with SOA (distributor) service.  NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### DF:DTC P1591 — NEUTRAL POSITION SWITCH CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

• **WIRING DIAGRAM:**



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>CHECK DTC P0705 ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0705?	Inspect DTC P0705 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-80, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
<b>CHECK INPUT SIGNAL FOR ECM.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B134) No. 8 (+) — Chassis ground (-):</b>	Is the voltage between 4.5 and 5.5 V at except "N" and "P" positions?	Even if MIL lights up, the circuit has returned to a normal condition at this time.	Go to step 3.
<b>CHECK HARNESS BETWEEN ECM AND TRANSMISSION HARNESS CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM and transmission harness connector (T3). 3) Measure the resistance of harness between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B134) No. 8 — Chassis ground:</b>	Is the resistance less than 10 $\Omega$ ?	Repair ground short circuit in harness between ECM and transmission harness connector.	Go to step 4.
<b>CHECK TRANSMISSION HARNESS CONNECTOR.</b> 1) Disconnect the connector from inhibitor switch. 2) Measure the resistance of harness between transmission harness connector and engine ground. <b>Connector &amp; terminal</b> <b>(T3) No. 12 — Engine ground:</b>	Is the resistance less than 10 $\Omega$ ?	Repair ground short circuit in harness between transmission harness and inhibitor switch connector.	Go to step 5.
<b>CHECK INHIBITOR SWITCH.</b> Measure the resistance between inhibitor switch connector receptacle's terminals in selector lever except for "N" position. <b>Terminals</b> <b>No. 7 — No. 12:</b>	Is the resistance more than 1 M $\Omega$ at except "N" and "P" positions?	Go to step 6.	Replace the inhibitor switch. <Ref. to T-28, Inhibitor switch.>
<b>CHECK SELECTOR CABLE CONNECTION.</b>	Is there any fault in selector cable connection to inhibitor switch?	Repair selector cable connection. <Ref. to CS-27, INSPECTION, Select Cable.>	Contact with SOA (distributor) service. <b>NOTE:</b> Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)


**DG:DTC P1594 — AUTOMATIC TRANSMISSION DIAGNOSIS INPUT SIGNAL CIRCUIT MALFUNCTION —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



B2M4371

Step	Check	Yes	No
<b>1</b> <b>CHECK DRIVING CONDITION.</b> 1) Start and warm-up the engine until the radiator fan makes one complete rotation. 2) Drive the vehicle.	Is the AT shift control functioning properly?	Go to step 2.	Replace the TCM. <Ref. to AT-45, Transmission Control Module (TCM).>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
2 CHECK ACCESSORY.	Are car phone and/or CB installed on vehicle?	Repair grounding line of car phone or CB system.	Replace the TCM. <Ref. to AT-45, Transmission Control Module (TCM).>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## DH:DTC P1595 — AUTOMATIC TRANSMISSION DIAGNOSIS INPUT SIGNAL CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1</b> <b>CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. <i><b>Connector &amp; terminal</b></i> <i><b>(B135) No. 20 (+) — Chassis ground (-):</b></i>	Is the voltage less than 1 V?	Go to step 2.	Even if MIL lights up, the circuit has returned to a normal condition at this time.  NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Poor contact in ECM connector</li> <li>• Poor contact in TCM connector</li> </ul>
<b>2</b> <b>CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM and TCM. 3) Measure the resistance of harness between ECM and chassis ground. <i><b>Connector &amp; terminal</b></i> <i><b>(B135) No. 20 — Chassis ground:</b></i>	Is the resistance less than 10 $\Omega$ ?	Repair ground short circuit in harness between ECM and TCM connector.	Go to step 3.
<b>3</b> <b>CHECK OUTPUT SIGNAL FOR ECM.</b> 1) Connect the connector to ECM. 2) Turn the ignition switch to ON. 3) Measure the voltage between ECM and chassis ground. <i><b>Connector &amp; terminal</b></i> <i><b>(B135) No. 20 (+) — Chassis ground (-):</b></i>	Is the voltage more than 5 V?	Go to step 4.	Repair poor contact in ECM connector.
<b>4</b> <b>CHECK TROUBLE CODE FOR AUTOMATIC TRANSMISSION.</b> Read the trouble code for automatic transmission. <Ref. to AT-24, Read Diagnostic Trouble Code (DTC).>	Does the trouble code appear for automatic transmission?	Inspect trouble code for automatic transmission. <Ref. to AT-44, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Replace the TCM. <Ref. to AT-45, Transmission Control Module (TCM).>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## DI: DTC P1596 — AUTOMATIC TRANSMISSION DIAGNOSIS INPUT SIGNAL CIRCUIT HIGH INPUT —

- DTC DETECTING CONDITION:
  - Two consecutive driving cycles with fault

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- WIRING DIAGRAM:



B2M4371

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1</b> <b>CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. <i>Connector &amp; terminal</i> <i>(B135) No. 20 (+) — Chassis ground (-):</i>	Is the voltage more than 10 V?	Repair battery short circuit in harness between ECM and TCM connector. After repair, replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>	Go to step 2.
<b>2</b> <b>CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.</b> Measure the voltage between ECM connector and chassis ground. <i>Connector &amp; terminal</i> <i>(B135) No. 20 (+) — Chassis ground (-):</i>	Is the voltage more than 4 V?	Go to step 5.	Go to step 3.
<b>3</b> <b>CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.</b> Measure the voltage between ECM connector and chassis ground. <i>Connector &amp; terminal</i> <i>(B135) No. 20 (+) — Chassis ground (-):</i>	Is the voltage less than 1 V?	Repair poor contact in ECM connector.	Go to step 4.
<b>4</b> <b>CHECK OUTPUT SIGNAL FROM ECM.</b> Measure the voltage between ECM and chassis ground. <i>Connector &amp; terminal</i> <i>(B135) No. 20 (+) — Chassis ground (-):</i>	Does the voltage change from 1 V to 4 V while monitoring the value with voltage meter?	Even if MIL lights up, the circuit has returned to a normal condition at this time.  NOTE: In this case, repair the following: • Poor contact in ECM connector • Poor contact in TCM connector	Contact with SOA (distributor) service.  NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.
<b>5</b> <b>CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.</b> Measure the voltage between TCM and chassis ground. <i>Connector &amp; terminal</i> <i>(B54) No. 20 (+) — Chassis ground (-):</i>	Is the voltage more than 4 V?	Go to step 6.	Repair open circuit in harness between ECM and TCM connector.
<b>6</b> <b>CHECK POOR CONTACT.</b> Check poor contact in TCM connector.	Is there poor contact in TCM connector?	Repair poor contact in TCM connector.	Check TCM power supply line and grounding line.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)




## DJ:DTC P1698 — ENGINE TORQUE CONTROL CUT SIGNAL CIRCUIT LOW INPUT —

- DTC DETECTING CONDITION:
  - Two consecutive driving cycles with fault

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- WIRING DIAGRAM:



EN1169

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<b>CHECK OUTPUT SIGNAL FROM ECM.</b> 1)Start the engine, and warm-up the engine. 2)Turn the ignition switch to OFF. 3)Turn the ignition switch to ON. 4)Measure the voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 14 (+) — Chassis ground (-):</b>	Is the voltage more than 3 V?	Repair poor contact in ECM connector.	Go to step 2.
2	<b>CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.</b> 1)Turn the ignition switch to OFF. 2)Disconnect the connectors from ECM and TCM. 3)Measure the resistance of harness between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 14 — Chassis ground:</b>	Is the resistance less than 10 $\Omega$ ?	Repair ground short circuit in harness between ECM and TCM connector.	Go to step 3.
3	<b>CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.</b> Measure the resistance of harness between ECM and TCM connector. <b>Connector &amp; terminal</b> <b>(B136) No. 14 — (B55) No. 20:</b>	Is the resistance less than 1 $\Omega$ ?	Repair poor contact in ECM or TCM connector.	Repair open circuit in harness between ECM and TCM connector.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)


### DK:DTC P1699 — ENGINE TORQUE CONTROL CUT SIGNAL CIRCUIT HIGH INPUT —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

#### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



EN1169

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>I</b> <b>CHECK OUTPUT SIGNAL FROM ECM.</b> 1)Start the engine, and warm-up the engine. 2)Turn the ignition switch to OFF. 3)Disconnect the connector from TCM. 4)Turn the ignition switch to ON. 5)Measure the voltage between ECM and chassis ground. <i><b>Connector &amp; terminal</b></i> <i><b>(B136) No. 14 (+) — Chassis ground (-):</b></i>	Is the voltage less than 3 V?	Go to step 2.	Repair battery short circuit in harness between ECM and TCM connector. After repair, replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>
<b>2</b> <b>CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.</b> 1)Turn the ignition switch to OFF. 2)Measure the voltage between ECM and chassis ground. <i><b>Connector &amp; terminal</b></i> <i><b>(B136) No. 14 (+) — Chassis ground (-):</b></i>	Does the voltage change more than 10 V by shaking harness and connector of ECM while monitoring the value with voltage meter?	Repair battery short circuit in harness between ECM and TCM connector. After repair, replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>	Contact with SOA (distributor) service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## DL:DTC P1701 — CRUISE CONTROL SET SIGNAL CIRCUIT MALFUNCTION FOR AUTOMATIC TRANSMISSION —

- DTC DETECTING CONDITION:
  - Two consecutive driving cycles with fault

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- WIRING DIAGRAM:



EN1170

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK HARNESS BETWEEN TCM AND CCM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from TCM and CCM. 3) Measure the resistance of harness between TCM and CCM connector. <b>Connector &amp; terminal</b> <b>(B55) No. 22 — (B94) No. 3:</b>	Is the resistance less than 1 $\Omega$ ?	Go to step 2.	Repair open circuit in harness between TCM and CCM connector.
<b>2 CHECK HARNESS BETWEEN TCM AND CCM CONNECTOR.</b> Measure the resistance of harness between TCM and chassis ground. <b>Connector &amp; terminal</b> <b>(B55) No. 22 — Chassis ground:</b>	Is the resistance less than 10 $\Omega$ ?	Repair short circuit in harness between TCM and CCM connector.	Go to step 3.
<b>3 CHECK INPUT SIGNAL FOR TCM.</b> 1) Connect the connector to TCM and CCM. 2) Lift-up the vehicle or set the vehicle on free rollers. <b>CAUTION:</b> <b>On AWD models, raise all wheels off ground.</b> 3) Start the engine. 4) Turn the cruise control main switch to ON. 5) Move selector lever to "D" and slowly increase vehicle speed to 50 km/h (31 MPH). 6) Turn the cruise control command switch to ON. 7) Measure the voltage between TCM and chassis ground. <b>Connector &amp; terminal</b> <b>(B55) No. 11 (+) — Chassis ground (-):</b>	Is the resistance less than 1 V?	Go to step 4.	Check cruise control command switch circuit. <Ref. to CC-7, INSPECTION, Cruise Control Command Switch.>
<b>4 CHECK POOR CONTACT.</b> Check poor contact in TCM connector.	Is there poor contact in TCM connector?	Repair poor contact in TCM connector.	Replace the TCM. <Ref. to AT-45, Transmission Control Module (TCM).>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


## DM:DTC P1711 — ENGINE TORQUE CONTROL SIGNAL 1 CIRCUIT MALFUNCTION —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Excessive shift shock

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



B2M4374

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1</b> <b>CHECK INPUT SIGNAL FOR ECM.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. <i>Connector &amp; terminal</i> <i>(B135) No. 19 (+) — Chassis ground (-):</i>	Is the voltage more than 4.5 V?	Go to step 2.	Go to step 4.
<b>2</b> <b>CHECK INPUT SIGNAL FOR ECM.</b> Measure the voltage between ECM and chassis ground. <i>Connector &amp; terminal</i> <i>(B135) No. 19 (+) — Chassis ground (-):</i>	Is the voltage more than 10 V?	Repair battery short circuit in harness between ECM and TCM connector.	Go to step 3.
<b>3</b> <b>CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>
<b>4</b> <b>CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM and TCM. 3) Measure the resistance of harness between ECM and TCM connector. <i>Connector &amp; terminal</i> <i>(B135) No. 19 — (B54) No. 13:</i>	Is the resistance less than 1 $\Omega$ ?	Go to step 5.	Repair open circuit in harness between ECM and TCM connector.
<b>5</b> <b>CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.</b> Measure the resistance of harness between ECM and chassis ground. <i>Connector &amp; terminal</i> <i>(B135) No. 19 — Chassis ground:</i>	Is the resistance less than 10 $\Omega$ ?	Repair ground short circuit in harness between ECM and TCM connector.	Go to step 6.
<b>6</b> <b>CHECK POOR CONTACT.</b> Check poor contact in TCM connector.	Is there poor contact in TCM connector?	Repair poor contact in TCM connector.	Replace the TCM. <Ref. to AT-45, Transmission Control Module (TCM).>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)




**DN:DTC P1712 — ENGINE TORQUE CONTROL SIGNAL 2 CIRCUIT MALFUNCTION —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Excessive shift shock

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-49, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-46, Inspection Mode.>.

- **WIRING DIAGRAM:**



B2M4375

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK INPUT SIGNAL FOR ECM.</b> 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. <i>Connector &amp; terminal</i> <i>(B134) No. 18 (+) — Chassis ground (-):</i>	Is the voltage more than 4.5 V?	Go to step 2.	Go to step 4.
<b>2 CHECK INPUT SIGNAL FOR ECM.</b> Measure the voltage between ECM and chassis ground. <i>Connector &amp; terminal</i> <i>(B134) No. 18 (+) — Chassis ground (-):</i>	Is the voltage more than 10 V?	Repair battery short circuit in harness between ECM and TCM connector.	Go to step 3.
<b>3 CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Replace the ECM. <Ref. to FU(DOHC TURBO)-47, Engine Control Module.>
<b>4 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.</b> 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM and TCM. 3) Measure the resistance of harness between ECM and TCM connector. <i>Connector &amp; terminal</i> <i>(B134) No. 18 — (B56) No. 4:</i>	Is the resistance less than 1 $\Omega$ ?	Go to step 5.	Repair open circuit in harness between ECM and TCM connector.
<b>5 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.</b> Measure the resistance of harness between ECM and chassis ground. <i>Connector &amp; terminal</i> <i>(B134) No. 18 — Chassis ground:</i>	Is the resistance less than 10 $\Omega$ ?	Repair ground short circuit in harness between ECM and TCM connector.	Go to step 6.
<b>6 CHECK POOR CONTACT.</b> Check poor contact in TCM connector.	Is there poor contact in TCM connector?	Repair poor contact in TCM connector.	Replace the TCM. <Ref. to AT-45, Transmission Control Module (TCM).>

# GENERAL DIAGNOSTIC TABLE

ENGINE (DIAGNOSTICS)

## 19. General Diagnostic Table

### A: INSPECTION

#### 1. ENGINE

NOTE:

Malfunction of parts other than those listed is also possible. <Ref. to ME(DOHC TURBO)-91, Engine Trouble in General.>

Symptom	Problem parts
1. Engine stalls during idling.	1) Idle air control solenoid valve 2) Pressure sensor 3) Mass air flow and intake temperature sensor 4) Ignition parts (*1) 5) Engine coolant temperature sensor (*2) 6) Crankshaft position sensor (*3) 7) Camshaft position sensor (*3) 8) Fuel injection parts (*4)
2. Rough idling	1) Idle air control solenoid valve 2) Pressure sensor 3) Mass air flow and intake temperature sensor 4) Engine coolant temperature sensor (*2) 5) Ignition parts (*1) 6) Air intake system (*5) 7) Fuel injection parts (*4) 8) Throttle position sensor 9) Crankshaft position sensor (*3) 10) Camshaft position sensor (*3) 11) Oxygen sensor 12) Fuel pump and fuel pump relay
3. Engine does not return to idle.	1) Idle air control solenoid valve 2) Engine coolant temperature sensor 3) Accelerator cable (*6) 4) Throttle position sensor 5) Pressure sensor 6) Mass air flow sensor
4. Poor acceleration	1) Pressure sensor 2) Mass air flow and intake temperature sensor 3) Throttle position sensor 4) Fuel injection parts (*4) 5) Fuel pump and fuel pump relay 6) Engine coolant temperature sensor (*2) 7) Crankshaft position sensor (*3) 8) Camshaft position sensor (*3) 9) A/C switch and A/C cut relay 10) Engine torque control signal circuit 11) Ignition parts (*1)
5. Engine stalls or engine sags or hesitates at acceleration.	1) Pressure sensor 2) Mass air flow and intake temperature sensor 3) Engine coolant temperature sensor (*2) 4) Crankshaft position sensor (*3) 5) Camshaft position sensor (*3) 6) Purge control solenoid valve 7) Fuel injection parts (*4) 8) Throttle position sensor 9) Fuel pump and fuel pump relay

# GENERAL DIAGNOSTIC TABLE

ENGINE (DIAGNOSTICS)

Symptom	Problem parts
6. Surge	1) Pressure sensor 2) Mass air flow and intake temperature sensor 3) Engine coolant temperature sensor (*2) 4) Crankshaft position sensor (*3) 5) Camshaft position sensor (*3) 6) Fuel injection parts (*4) 7) Throttle position sensor 8) Fuel pump and fuel pump relay
7. Spark knock	1) Pressure sensor 2) Mass air flow and intake temperature sensor 3) Engine coolant temperature sensor 4) Knock sensor 5) Fuel injection parts (*4) 6) Fuel pump and fuel pump relay
8. After burning in exhaust system	1) Pressure sensor 2) Mass air flow and intake temperature sensor 3) Engine coolant temperature sensor (*2) 4) Fuel injection parts (*4) 5) Fuel pump and fuel pump relay

\*1: Check ignition coil & ignitor assembly and spark plug.

\*2: Indicate the symptom occurring only in cold temperatures.

\*3: Ensure the secure installation.

\*4: Check fuel injector, fuel pressure regulator and fuel filter.

\*5: Inspect air leak in air intake system.

\*6: Adjust accelerator cable.

# GENERAL DIAGNOSTIC TABLE

ENGINE (DIAGNOSTICS)

---